

Service Bulletin

PRELIMINARY INFORMATION

Subject: Diagnostic Aid - Surrogate MOST Master Node Upstream Position Changing

Models: 2014 Chevrolet Corvette

The following diagnosis might be helpful if the vehicle exhibits the symptom(s) described in this PI.

Condition/Concern

When diagnosing a MOST buss concern you may notice the GDS data parameter "Surrogate MOST Master Upstream Position" changing.

Recommendation/Instructions

Engineering is aware of the concern and looking into possible solutions. Currently it is recommended to diagnose the highest number first. Example: Surrogate reading 0-1 changing. Diagnose the surrogate of 1.

Please follow this diagnostic or repair process thoroughly and complete each step. If the condition exhibited is resolved without completing every step, the remaining steps do not need to be performed.