

Wayne Hutchinson / TMS Toyota Customer Services
Product Quality and Service Support, Quality Compliance

May 19, 2014
Approved By: Bob Waltz

To: All Toyota Dealers Participating in the Corrosion-Resistant Compound Frame Campaign Located in the 20 Cold Climate States
From: Product Quality and Service Support

Update to the Packaging Instructions:

"Make a copy of the bill of lading for the dealership to keep on file and provide the original bill of lading to the carrier."

Excessively Separated (Unusable) 712AM Dealer Stock Return
*******URGENT*******

Last fall TMS received information that some 712AM Corrosion Resistant Compound (CRC) used for frame application may have excessively separated. The separation condition renders that material unusable and is caused by aged inventory. We have obtained new 712AM CRC material and prepared new kits for use with Limited Service Campaigns C0D and D0D.

The unusable 712AM product in your dealership inventory should be returned following the procedure below.

Return Process:

1. Locate all 712AM in your dealer's inventory with the following lot numbers:

- 110101 • 111201 • 120301 • 120401
- 111101 • 120201 • 120302 • 120402

Note:

- Due to an inventory error, some kits supplied during 2014 may also contain the unusable 712AM. Please check **all** of the following kits in your inventory for the above lot numbers: **00289-T00KT-DS** and **00289-S00KT-DS**.

Lot No. : XXXXXX



2. **By May 21, 2014**, each Dealer will be sent (by UPS) return-kits (**Part Number TMS-COR-A**) for packaging the unusable 712AM material. **Kits sent to your dealer will be addressed to the Parts Manager and marked with a fluorescent label containing the wording "712AM Return-Kits".**

- a. Each return-kit will contain: 1 fiberboard box, 2 clear tape strips, 1 plastic bag, 2 grey absorbent sheets, 6 red sealing tape, 1 zip tie, shipping labels, and Bill of Lading.
- b. Return-kits will be distributed based on the number of liters Toyota shows to be in your dealer's inventory. Based upon our records, a dealership which does not have affected liters in stock will not receive a return-kit. If you determine your dealership needs a return-kit, please reference the note under 5a.

3. Follow the attached Standard Operating Procedure (SOP).

- a) Only return full, one liter bottles of 712AM (identified in step 1).
- b) Record the total bottle count for your reference.

Note:

- **Do not return complete CRC kits or bottles of Noxudol 300S.**
- Returned bottles of Noxudol 300S will not be reimbursed.
- Dealers may be debited for the transportation and disposal fees incurred for returned Noxudol 300S.



4. Once the return packaging process is complete, ship the return-kit via FedEx.

5. Replacement 712AM will be shipped directly to you within 2 weeks.

- a) The quantity of replacement bottles provided back to your dealership will be based on the count returned.

Note:

- If additional return-kits (Part Number TMS-COR-A) are needed or if you have any further questions regarding the 712AM return date, contact PQ&SS at 1-800-233-3718, option 4 or at quality_compliance@toyota.com

We apologize for any inconvenience the excessively separated 712AM may have caused you.
Thank you for your cooperation.
TOYOTA MOTOR SALES, U.S.A., INC.

CORROSION RESISTANT COMPOUND (712AM) PACKING INSTRUCTION – Kit TMS-COR-A

1. Using the clear tape strip (**provided**), assemble the fiberboard box (**provided**). Damaged or used packaging may not be used.
2. Place the plastic bag (**provided**) in the bottom of the box. Place one of the Grey Absorbent Sheets (**provided**) at the bottom of the plastic bag. If necessary fold the sheet to fit the box.
3. Ensure that the cap on every bottle is closed firmly. Hand-tight is sufficient. Do not use a wrench to tighten. Apply the red sealing tape (**provided**) around the circumference of the cap on each bottle.
4. Place the bottles inside the plastic bag, inside the box. Add additional cushioning if need. Place one of the Grey Absorbent pads (**provided**) on top of the bottles. Seal bag using the zip tie (**provided**). (Do NOT put more than six (6) bottles in each box.)
5. Close and secure the box with the clear tape strips (**provided**). Making sure the tape does not obstruct the Orientation arrow labels.
6. Place the FedEx Ground Shipping Label (**provided**) with the Ship To/Ship From information on the top of the box. Make sure it does not overlap any of the sides.



- In the fourth box on the left side of the documentation, write in the number of bottles being shipped. Do NOT put more than six (6) bottles per box.

- ## See Below

Bill of Lading

Questions? Please contact ShipMate at +1 (310)-370-3600

