



File in Section: -

Bulletin No.: PI1195

Date: March, 2014

Service Bulletin

PRELIMINARY INFORMATION

Subject: Information for Programming Extra Keys

Models: 2014 Chevrolet Caprice PPV
Equipped with RPO AMF

The 2014 Caprice PPV with RPO AMF comes with six extra cut keys with integrated Remote Keyless Entry. These extra keys and transmitters do not come pre-programmed to the vehicle. To program these, you must follow the steps below:

Important: Make sure the vehicle is out of transport mode and the ignition has been turned off for at least 15 seconds before trying to program any keys.



3762272



3762274

1. Remove the additional keys from the tie strap and/or bag and lay them out on the center console.
2. Enter the learn mode by first using a key that is already programmed to the vehicle. Insert this key into the ignition and turn it to the "Run" position.
3. Remove that key and place it on the passenger seat. Within 10 seconds (of ignition being off) insert the first key to be learned into the ignition and rotate it to the "Run" position.
Leave the key in the "Run" position for 3–5 seconds. Then rotate it back to the "Off" position and remove it from the ignition. Place this newly learned key back on the console.
4. Within 10 seconds, take the next key to be programmed and insert it into the ignition and turn the ignition to the "Run" position and leave it for 3–5 seconds. Then rotate the ignition back to the "Off" position and remove the key. Place it back on the console and repeat until all keys are programmed.

When all of the RKE transmitters have been learned, and ignition is off, wait 15 seconds and operate all of the FOB functions on all 8 keys to verify learning was complete.

Note: Failure to follow the above procedure can result in RKE transmitter (FOB) being inoperable.

If any of the RKE transmitters do not work, contact Technical Assistance Center (TAC) at 1-877-446-8227.