

Eldorado National - Kansas



Chrysler “Ignition–off Draw” or IOD Fuse User Guide

This procedure must be followed by the Eldorado National Amerivan dealer

When Eldorado National is completed with an Amerivan conversion on a Chrysler / Dodge 2008 to 2014 chassis we pull the OEM “Ignition-Off Draw” fuse or IOD fuse. The purpose of pulling this fuse is to limit the amount of parasitic draw on the battery. The IOD fuse is located under the hood within the “Totally Integrated Power Module” or TIPM. The Eldorado National / Amerivan dealer should always reconnect the IOD fuse in the TIPM before using the vehicle; this will insure that all OEM electrical accessories work properly.

When installing or removing the IOD fuse:

- 1: The ignition switch must be in the **off** position.
- 2: Press and completely seat the IOD fuse into its location.
- 3: Install the Totally Integrated Power Module cover.



