

SB-10057778-9971



Installing the back Two Screws of the C-85 and C-86 A/C's to the Roof.

MATERIALS NEEDED: 1- Battery Powered Gun

1- 5/16 inch Hex Head Bit

1- 12 inch extension

1- Philips Head Bit

1- Tube of Self Leveling Sealant

2- 12-14X3IN. HWD TEK SCREW

2- #12 NEO Bond Washer (5/8 O/D)

1. Remove the black shroud from the A/C by unscrewing the 4 screws on top of the shroud. Then pull the shroud straight up to remove. See photo below.



2. With the shroud removed the two tek screws with the neo bond washers ran through them can now be installed to secure the A/C to the roof. The location where the screws are run through the A/C's pan is on the right and left side of the motor. There is a screw that holds the metal shroud to the pan in front of this screw is where the tek screws will be placed. After securing the screws cover the heads with self leveling sealant then replace the A/C's shroud. See photo below.

