

SB-10058462-1927
ONLINE AUTOMOTIVE SERVICE INFORMATION
FOR MAY 2015

45108 2015 Transit - Adding And Programming Keys - PATS And Non-PATS Procedures

2015 Transit vehicles that require adding or programming keys must know whether the vehicle is equipped with Passive Anti-Theft System (PATS). To verify PATS capability, enter VIN into Professional Technician Society (PTS). In the OASIS tab click on Additional Information. Use the Search function (Ctrl + F) to search for ENG IMMOBILIZER THEFT SY-INTEG or LESS ENG IMMOBILIZER THEFT SYS. For programming Non-PATS (LESS ENG IMMOBILIZER THEFT SYS) vehicles refer to Work Shop Manual (WSM), Section 501-14. For programming PATS equipped (ENG IMMOBILIZER THEFT SY-INTEG) vehicles refer to WSM, Section 419-01B. There is no visual difference between the key fobs for PATS and non-PATS vehicles.