



PC-07.20.2016

Off Road Driven!

www.procompusa.com

2360 Boswell Road, Chula Vista, CA 91914

Phone: (619) 216-1444

Fax: (619) 216-1474

TECHNICAL BULLETIN

BULLETIN #: 7216 brake line installation

DATE: 7/20/2016

RE: 7216 brake line installation for K5150B / K5151B

PART #: 57086B / 57087 / 57088

Technical Overview:

We have received reports questioning the correct installation of the 7216 front brake lines in the 57086B Tundra LT suspension kits.

Step 78 on page 14 of the 57086B instructions states; locate and remove the rubber brake hose that runs from the *knuckle* to the *frame*.

Solution:

DO NOT REMOVE the hard line from the caliper to the knuckle.

The hard lines that run from the sides of the frame rails to the top will need to be removed.

The curved ends of the 7216 brake lines will attach to the 90 degree elbows above the frame rails



