

## Installation and Conversion Instructions

911 (991) 41/15 ENU 9615

9

#### **Rear Footwell Lighting**

- Vehicle Type: 911 (991) Gen. II
- Model Year: As of 2017
- Information: Retrofitting

Note: Rear footwell lighting comprises two LED footwell lights. The LED footwell lights are installed in the footwell of the left and right rear seat.

We recommend that you use rear footwell lighting in conjunction with the light design package (I-no. 630).



Parts Info:	991.044.900.25		$\Rightarrow$ Rear footwell lighting, set			
Parts List:		1 x	Wire harness $\Rightarrow$ <i>Figure 2</i> -1-			
	991.632.133.00	2 x	LED footwell light $\Rightarrow$ <i>Figure 2</i> -2-			




Figure 2

Materials:	_		— — Insulating tape (commercially available)								
Tools:	98	9818 - PIWIS Tester II									
Work Procedure: 1		Preparatory work									
		1.1	Connect a battery charger. $\Rightarrow$ Workshop Manual '2X00IN Battery trickle charging'								
		1.2	Remove right footwell light. $\Rightarrow$ Workshop Manual '961519 Removing and installing footwell light'								
1.3 1.4 1.5		1.3	Remove lower part of center console cover. $\Rightarrow$ Workshop Manual '681919 Removing and installing cover for centre console'								
		1.4	Remove shift-lever knob. $\Rightarrow$ Workshop Manual '340419 Removing and installing shift-lever knob'								
		1.5	Only for vehicles with PDK.								
			1.5.1 Remove selector knob. $\Rightarrow$ Workshop Manual '370419 Removing and installing selector knob'								
			1.5.2 Remove upper part of cover for PDK. $\Rightarrow$ Workshop Manual '681919 Removing and installing cover for centre console'								
		1.6	Remove switch console. $\Rightarrow$ Workshop Manual '962719 Removing and installing switch console'								
		1.7	Remove air conditioning control. $\Rightarrow$ Workshop Manual '870219 Removing and installing front air conditioning control - section on "Removing"'								
		1.8	Remove ashtray. $\Rightarrow$ Workshop Manual '682019 Removing and installing front ashtray - section on "Removing"'								
		1.9	Remove seat cushion. $\Rightarrow$ Workshop Manual '745719 Removing and installing rear seat cushion'								
	2	Make	e cut-out for LED footwell light.								

911 (991)

enu **41/15** 

9

9615

- 2.1 Make a template out of cardboard or stiff paper. Dimensions are given in millimeters.
  - 1 Lower edge of template
  - 2 Axis of symmetry





Figure 3



2.3 Mark cut-out for LED footwell light.




Figure 4

- 2.3.1 Place measuring tape at the edge of the carpet  $\Rightarrow$  *Figure 5*-arrow-.
  - 1 Fixing clip for carpet




Figure 5

2.5

- 2.3.2 Draw base line  $\Rightarrow$  Figure 6-1-.
  - **x** 21 cm

Draw center line  $\Rightarrow$  *Figure 6* **-2**- at a right angle to the base line.




Figure 6

2.4 Position lower edge of the template at the base line  $\Rightarrow$  *Figure* 7-1- and align it.

The axis of symmetry of the template  $\Rightarrow$ *Figure* 7-3- is in line with the center line  $\Rightarrow$ *Figure* 7-2-.

Copy the contour of the cut-out for the LED footwell light  $\Rightarrow$  *Figure 8*-1- onto the

adhesive tape.

3 2 1

Figure 7




Figure 8

Tequipment

 $2016 ^{\odot}$  Porsche Cars North America, Inc.



### Information

To avoid damaging the wire harness (Fig. 9 -1-), pull the carpet forward (Fig. 9 -arrow-).

2.6 Cut out cut-out for LED footwell light using a carpet knife.




Figure 9



Risk of short circuit and fire

- due to work on the vehicle electrical system.
- $\Rightarrow$  When working on the electrical system, the battery must always be disconnected and covered.
- ⇒ Always route the electrical wires without tension and so that no chafing occurs and secure to existing wires/components with tie-wraps/electrical tape.
  - 3 Install electric wire harness.
    - 3.1 Disconnect negative cable from the battery.  $\Rightarrow$  Workshop Manual '270619 Removing and installing battery'

 Route electric wire harness ⇒ Figure 10-1as follows: Rear seat cushion position → under rear oddments tray → center console → front footwell light at passenger's side




Figure 10

3.2.1 Secure wire harness to an auxiliary line  $\Rightarrow$  *Figure 11-***1**- and guide it under the oddments tray  $\Rightarrow$  *Figure 11*-**arrow**-.




Figure 11

3.2.2 Route wire harness  $\Rightarrow$  Figure 12-1along the standard wire harness for the center console.





Figure 12

Tequipment

- 3.2.3 Route wire harness to front footwell light on passenger's side.
  - 1 Wire harness
  - 2 Front footwell light on passenger's side




9615

911 (991)

41/15 ENU

Figure 13



Using a tie-wrap, fasten the wire harness to the shift cable boot  $\Rightarrow$  *Figure 14*-2-.

- 3.3 Connect wire harness.
  - 3.3.1 Pull wire harness back from front footwell light on passenger's side  $\Rightarrow$  Figure 15 arrow-.




Figure 14



Figure 15

# Installation and Conversion Instructions

911 (991) 9615 enu 41/15

> 3.3.2 Crimp RD/BK line from front footwell light on passenger's side and RD/BK line from the retrofit kit together using an insulated cable connection  $\Rightarrow$  Figure 16-arrow-.

> > Wrap insulating tape around the lines.

3.3.3 Crimp BN line from front footwell light on passenger's side and BN line from the retrofit kit together using an insulated cable connection.

Wrap insulating tape around the lines.

- 3.3.4 Pull wire harness from front footwell light on passenger's side back again  $\Rightarrow$  Figure 17-arrow-.
- 3.4 Fit LED footwell light.
  - 3.4.1 Plug in connectors on the LED footwell light until the connectors engage securely.
  - 3.4.2 Carefully press LED footwell light into the carpet.




Figure 16



4 Concluding work

Figure 17

- 4.1 Install seat cushion.  $\Rightarrow$  Workshop Manual '745719 Removing and installing rear seat cushion'
- 4.2 Install ashtray. ⇒ Workshop Manual '682019 Removing and installing front ashtray section on "Removing"
- 4.3 Install air conditioning control.  $\Rightarrow$  Workshop Manual '870219 Removing and installing front air conditioning control section on "Removing"
- 4.4 Install switch console.  $\Rightarrow$  Workshop Manual '962719 Removing and installing switch console'
- 4.5 **Only** for vehicles with PDK.
  - 4.5.1 Install selector knob.  $\Rightarrow$  Workshop Manual '370419 Removing and installing selector knob'
  - 4.5.2 Install upper part of cover for PDK.  $\Rightarrow$  Workshop Manual '681919 Removing and installing cover for centre console'

Labor time: 170 TU

- 4.6 Install shift-lever knob.  $\Rightarrow$  Workshop Manual '340419 Removing and installing shift-lever knob'
- 4.7 Install lower part of center console cover. ⇒ Workshop Manual '681919 Removing and installing cover for centre console'
- 4.8 Connect negative cable from the battery.  $\Rightarrow$  Workshop Manual '270619 Removing and installing battery'
- 4.9 Read out the fault memory of all systems, work through any existing faults, and erase the fault memory.  $\Rightarrow$  Workshop Manual '033500 Fault memory for on-board diagnosis'
- 4.10 Disconnect battery charger.  $\Rightarrow$  Workshop Manual '2X00IN Battery trickle charging'

Working Time: 96153100 Installing rear footwell lighting. Includes:

Important Notice: Technical Bulletins issued by Porsche Cars North America, Inc. are intended only for use by professional automotive technicians who have attended Porsche service training courses. They are written to inform those technicians of conditions that may occur on some Porsche vehicles, or to provide information that could assist in the proper servicing of a vehicle. Porsche special tools may be necessary in order to perform certain operations identified in these bulletins. Use of tools and procedures other than those Porsche recommends in these bulletins may be detrimental to the safe operation of your vehicle, and may endanger the people working on it. Properly trained Porsche technicians have the equipment, tools, safety instructions, and know-how to do the job properly and safely. If a particular condition is described, do not assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your authorized Porsche Dealer for the lates information about whether a particular technical bulletin applies to your vehicle. Part numbers listed in these bulletins are for reference only. Always check with your authorized Porsche dealer to verify the current and correct part numbers. The work procedures updated electronically in the Porsche PIWIS diagnostic and testing device take precedence and, in the event of a discrepancy, the work procedures in the PIWIS Tester are the ones that must be followed.

Dealership	Service Manager	Shop Foreman	 Service Technician	 	 
Distribution Routing	Asst. Manager	Warranty Admin.	 Service Technician	 	 

Dr. Ing. h.c. F. Porsche AG is the owner of numerous trademarks, both registered and unregistered, including without limitation the Porsche Crest®, Porsche®, Boxster®, Carrera®, Cayenne®, Cayenne®, Macan®, Panamera®, Speedster®, Spyder®, 918 Spyder®, Tiptronic®, VarioCam®, PCM®, PDL®, 911®, RS®, 4S®, FOUR, UNCOMPROMISED®, and the model numbers and the distinctive shapes of the Porsche automobiles such as, the federally registered 911 and Boxster automobiles. The third party trademarks contained herein are the properties of their respective owners. Porsche Cars North America, Inc. believes the specifications to be correct at the time of printing. Specifications, performance standards, standard equipment, options, and other elements shown are subject to change without notice. Some options may be unavailable when a car is built. Some vehicles may be shown with non-U.S. equipment. The information contained herein is for internal authorized Porsche dealer use only and cannot be copied or distributed. Porsche recommends seat belt usage and observance of traffic laws at all times.

#### 2016© Porsche Cars North America, Inc.

Mar 2, 2016 Page 9 of 9

## Tequipment