



Please use a flat screw driver to pry off the aluminum rail of the MCD shade housing. There will be another bracket on the other side as well.

Once removed, you lift the other side to unhook from the u-shape metal that holds the aluminum rail in place.