

Subject: ALL MODELS - USE GR8 BATTERY CHARGER WHEN REPROGRAMMING MODULES	M-Tips No.: MT-014/17
	Last Issued: 07/06/2017

DESCRIPTION

Whenever you are reprogramming a PCM or any other module, always use the GR8 Battery Charger in the Power Supply mode to prevent the battery from discharging.

Examples of modules that can be reprogrammed:

- TPMS unit (SSP85)
- MAZDA CONNECT (SSP98)
- ABS control unit
- TCM
- RCM