



They need to cut both lines and install a diverter line that will go to the side. They will have to drill a hole on the floor so that they can install 2 low point drain valves under the coach. They need to make sure to seal the holes so that insects and gas will not enter the coach.