

## Pursuit Vertical Storage Door TSB # 10-09-14

- 1) Open the rear vertical storage door on the driver rear corner of the vehicle.
- 2) Lift the pinch molding and rubber bulb seal from the lower lip of the door opening. (This should be the seal joint).



- 3) Trim the bulb seal back 1/8" leaving the pinch molding intact.



- 4) Apply a bead of 3M weather strip adhesive to the metal door frame lip and to the end of the pinch molding still attached to the door frame lip. Apply a small amount of 3M weather strip adhesive to the channel of the pinch molding that you removed from the door frame lip. Once the pinch molding is back on the lip apply 3M weather strip adhesive to the joint.



- 5) Attach the pinch molding to the door frame lip. You will notice there is a gap in the bulb seal allow this gap to remain as a drain.

Additional seal may be required:

The additional seals will be located on the back side of the door. Use 1/8" thick X 5/8" wide black neoprene seal tape. Tape is applied on the black metal frame of the door next to the outer ridge.

- 1) Apply the neoprene tape from the bottom of the ridge on the bottom of the slam latch to the bottom of the door.



- 2) Apply the neoprene tape from the top curve on the hinge side of the door to the bottom curve on the hinge side of the door.

