



Service Bulletin

File in Section: -

Bulletin No.: 17-NA-220

Date: July, 2017

TECHNICAL

Subject: Accessory Cargo Net T Bolts Loose

Brand:	Model:	Model Year:		VIN:		Engine:	Transmission:
		from	to	from	to		
Chevrolet	Bolt EV	2017	2017			All	All

Involved Region or Country	North America, Europe, South Korea
Additional Options (RPOs)	Equipped with Accessory Cargo Net (RPO W2D)
Condition	Some customers or technicians, upon installation of the accessory cargo net, may find the T bolts that are secured to the side panels will not tighten securely or pull out of the metal hole.
Cause	This may be due to the holes stamped in the metal on the side panels may have been stamped too large for the coarse threaded T bolts.
Correction	Insert Riv-Nuts and fine tread T bolts to install cargo net.

Parts Information

Description	Part Number	Qty
Riv-Nut	11518908	2
T-Bolt	92224547	2

Warranty Information

Labor Operation	Description	Labor Time
0580268*	Installation of Accessory Cargo Net T Bolts	0.6 hr
*This is a unique Labor Operation for Bulletin use only.		

Service Procedure

If you encounter a vehicle with the above concern, complete the following steps:



4828889

1. Unclip the rear of the quarter lower rear trim panel to gain access to the T bolt hole.

Note: Use a standard 2 x 4 block as a wedge support as illustrated above.

2. Using a 23/64 drill bit, drill out existing hole for the installation of Riv-Nut.



4828891



4828897



4828895

3. Using the Kent Moore Riv-Nut installer (B0-42151-8MM-KIT) or equivalent, insert and expand the Riv-Nut into the newly drilled hole.

4. Reinstall the quarter lower rear trim panel.



4828899

5. Install fine threaded T bolt into new Riv-Nut and tighten.

Version	1
Modified	