

Limit Opening on CRL Windows

STEP 1. MARK IT



STEP 2. MOVE ROLLER AWAY FROM DRILL POINT & DRILL HOLE



STEP 3. INSTALL RIVET



STEP 4. RIVET INSTALLED

