

Remove all the silicone on the edges first an inch before the bubble starts and an inch after the bubble ends. Cut 1/16 of an inch on the edge of the lino, pull lino out and spray adhesive underneath then push lino towards wall and apply silicone on edges again.

