Please use a flat screw driver
to pry off the aluminum rail of the MCD
shade housing. There will be another
bracket on the other side as well.
Once removed, you lift the other side to
unhook from the u-shape metal that holds
the aluminum rail in place.