

Inside the front cab compartment, just right at the center end of front curved wall, you need to cut half inch above to gain access to the antenna and cover it with this part (attached picture) after. This part is about 10 inches wide by 3 $\frac{3}{4}$ inches height. The hole that you need to make MUST NOT go over 3 $\frac{3}{4}$ inches in height so it will be covered by this part when you install it.

