

De-Winterizing 2017 Ascent TS

Note: Please check if you have a TRUMA or a GIRARD Water Heater. If you have a TRUMA follow steps 1 to 7. If you have a Girard, follow steps 1, 2 & 7 only.

1. Drain all the anti-freeze in the lines **by hooking to city water OR by filling the fresh tank with water** and open kitchen cold/hot faucet and let it run until all antifreeze is gone and water is running clear then close the kitchen faucet. Do the same procedure with the bathroom lavatory faucet, bathroom shower, outdoor shower, and flush the toilet so fresh water will rinse the antifreeze in the toilet.
2. Make sure the drain valve for fresh water tank is closed. Fill fresh water tank with water through passenger side valve. (Picture below.)



3. For TRUMA water heater, open the door of the water heater outside the van. Pull down the yellow lever and insert the filter then push back up the yellow lever and close the heater door. (Picture below.)



4. If you have a TRUMA water heater, Unscrew the wood panel below the refrigerator to access the water heater bypass valves. (Picture below.)



5. If you have a TRUMA water heater, open the valves on the white, red, and blue lines. This means the valve should be pointed in the same direction as the lines. SUMMER MODE.



6. If you have a TRUMA water heater, **close the valve where the blue and red line meets**. This means the valve should be turned 90 degrees to the line. Screw back in the wooden panel near the fridge. SUMMER MODE.
7. Drain the black tank but leave it open. Flush the black tank by draining the grey tank then close both drains. (Picture below.)

