

WANDERING ISSUE

Below are things that you can do to lessen the wandering problem:

1. Adding rear wheel spacers at the back rear tires to widened the stands. What we are using are 2 inches wide wheel spacers on each side for a total of 4 inches expansion for the back wheels. This is the website to get the wheel spacers from: www.wheeladapter.com .
2. You would like to check www.roadmasterinc.com for the rear sway/stabilizer bar and the part # is 1139-178.
3. Tire pressures. Making sure you are following what the chassis manufacturer recommended which is written on the driver side door pillar.
4. Alignment. Attached is a guide for the alignment spec for the Dodge.
5. Rear air bags. Set it at 50-60psi.
6. Steering box torque spec. You have to bring it to Dodge and have them check and adjust it if it requires adjustment.

Dodge B3500 - All Years

	Driver Side	Passenger Side	Cross Total
Steering	+3 - +4	+3 - +4	
Stabilizer	0 - +1/4	0 - +1/8	
Toe	+1/16	+1/16	1/8 - 3/16

Caster
Camber