

Note: if you have a rear view mirror on the windshield, the shade will have a slit on top, and the base of the mirror will fit perfectly on the slit.

1. Stretch out the shade.
2. Make sure the black part of the shade is facing inside the coach.
3. Make sure the shade is not upside down as it will only fit one way according to the shape of the windshield.
4. Place the lower part of the shade first on top of the dash touching the bottom of the windshield.
5. Place the top part of the shade against the top of the windshield.
6. Continue pressing the top part of the shade against the top part of the windshield until it is snug fit.
7. Secure the shade by lowering down the two visors.

