



Area1 Insert first the bottom left corner of the screen frame to the bottom left corner of the window and push in towards window to make the clips latch.

Area2 Then insert the bottom right corner of the screen frame to the bottom right corner of the window and push in towards window to make the clips latch.

Area3&4 Push the screen frame down while pushing-in towards direction of window at the same time until you hear the clips click on each side of 3 & 4

Area5 Push the screen frame to the right while pushing-in towards window at the same time until you hear the clips click.

Area6 Push the screen frame to the left while pushing-in toward window at the same time until you hear the clips click.

Hope this helps. If not please give us a call so we can assist you.