

1) Drain your fresh water tank. The fresh water tank is located behind the passenger cab entrance door. Open the drain spigot by turning the top lever and let the water drain (there may be a small amount of water left in the tank after it is drained.).



2) Turn off the hot water tank. (See picture (2) above)

3) Remove the water line from the inlet side of the water pump (this is the clear plastic line going into the water pump filter.) Connect a siphon hose to the inlet side of the water pump place the other end in a container RV non-toxic antifreeze. Turn on you're the pump. This will pump non-toxic RV antifreeze through all of your fresh water lines.

NOTE: Siphon hose consists of 40" of 1/2" clear tubing with a fitting to attach to the water pump. The fitting can be purchased through an RV dealer.



4) Open the kitchen and bathroom faucets one at a time allowing the antifreeze to flow through both the hot and the cold sides. Be sure to also open the toilet valve and exterior shower faucet. Turn off the water pump and disconnect the siphon hose, reattach the original fresh water supply fitting.

5) Pour 1/4 cup of RV antifreeze down each drain (kitchen sink, bathroom sink and shower drain).

6) Disconnect the engine starting battery (Mercedes next to the gas pedal).



7) Fully charge your auxiliary coach battery and turn off and remove the red disconnect. The red disconnect is located in the driver ottoman compartment. See battery care for more information.



9) Turn your propane tank off. (See picture (10) above)

10) Place your fridge door in a slightly open position for air to circulate through the fridge.

Note: It is recommended that you start and run your vehicle and generator once a month during the winter season.

Winter Use

We recommend that the water system not be used when the outside temperature drops below the freezing point. You should ensure that your unit is completely winterized by that time. If it is necessary to use water, we suggest that you bring containers of fresh water with you and add non-toxic RV antifreeze to the gray and black water holding tanks. Do not use your fresh water system.

- Keep in mind that as you add more water to the holding tanks the antifreeze will dilute more than the recommended amount and may start to freeze earlier at cold temperature.

Quick Drain of the Water system

- 1) Open the fresh water tank drain.
- 2) Open the low point drain valves located under the passenger side running board in front of the fresh water drain.
- 3) Open all hot and cold taps on the vehicle.
- 4) Drain the black and grey holding tanks.

