

## **Certain Stamped Spider Drum Brakes Replaced by Cast Spider Drum Brakes on Steer Axles (WST 165)**

May 14, 2018

In order to provide improved brake performance, certain stamped spider drum brakes will be replaced as tabulated below.

Western Star models will change to cast spider brakes with orders received on and after May 14, 2018.

SpecPro pricing will apply.

| DISCONTINUED STEER AXLE BRAKES |                                                                                         | REPLACED BY STEER AXLE BRAKES |                                                                                                 |
|--------------------------------|-----------------------------------------------------------------------------------------|-------------------------------|-------------------------------------------------------------------------------------------------|
| 402-084                        | MERITOR 16.5X5 Q+ STAMPED SPIDER CAM FRONT BRAKES, DOUBLE ANCHOR, FABRICATED SHOES      | 402-049                       | MERITOR 16.5X5 Q+ CAST SPIDER CAM FRONT BRAKES, DOUBLE ANCHOR, FABRICATED SHOES                 |
| 402-094                        | MERITOR 16.5X5 Q+ STAMPED SPIDER CAM FRONT BRAKES, DOUBLE ANCHOR, PLATINUM SHIELD SHOES | 402-1AT                       | MERITOR 16.5X5 Q+ CAST SPIDER CAM FRONT BRAKES, DOUBLE ANCHOR, PLATINUM SHIELD FABRICATED SHOES |

Ben Smith

Customer Application Engineering Manager

Western Star Trucks

[benjamin.smith@daimler.com](mailto:benjamin.smith@daimler.com)

**Daimler Trucks North America**

D0286 / P53346 / F 13066