

Repair Tofino Headliner

- 1) Remove the ceiling T Edge strips from the track on the ceiling panel.



- 2) Place $\frac{3}{4}$ " #5 Flat head screws - $\frac{1}{4}$ " from the plastic T edge track on the roof, screwing the head liner up to the roof blocking. Place the screws 7" - 8" apart. (Indicated in picture as staples) Place screws on both sides of the plastic track. Before installing the screws predrill through the head liner and plastic track with a $\frac{3}{32}$ " drill bit.



There is $\frac{3}{4}$ " blocking between the fiber glass roof and the head liner panel.

- 3) Once the headliner is screwed in place reinsert the ceiling T edge strips back into the track. Ensure there is no duct tape preventing the harpoon on the T edge from engaging in the track .