

91-20-03TT - Car Net®: No Green Light at PDI

04/10/20209

Condition

ATTENTION:

THIS IS A TECH TIP, NOT A TECHNICAL BULLETIN. TECH TIPS ARE NOT ASSOCIATED WITH WARRANTY CLAIMING.

Applicable Vehicles						
Model(s)	Year	Eng. Code	Trans. Code	VIN Range From	VIN Range To	
Tiguan LWB,Cross Sport,Atlas,Jetta,Golf,GTI,Arteon	2020,2021	All	All	All	All	

Revision Table						
Instance Number	Instance Number Published Date		Reason For Update			
2059226/1	4/10/20	91-20-03TT	Original publication.			

Technical Background

Car Net®: No Green Light at PDI.

Service

On 2020/2021 vehicles equipped with Car-Net® 2.0 while performing the PDI:

Once you take the vehicle out of transport mode, it may take up to 30 minutes for the system to come on line. The green light is an indicator that the vehicle has made a good connection.

No green light ON indicates that no connection was established. All vehicles equipped with Car-Net® 2.0 will need the green light ON, prior to being delivered to the customer.

Additional Information

© 2020 Volkswagen Group of America, Inc. All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.