

GPOP - Issue Review System

Part Number: 68251580A\$

Part Description: DAMPER, Steering

Issue Description: Additional service procedure steps before replacing the steering damper:

Before installing the steering damper to the vehicle, it is important to prime the new damper by 5 continuous compression – extension stroke cycles by hand, each cycle consists of a full compression and a full extension stroke, without stops as fast as possible. Use large screwdrivers inserted in the bushings to aid in purging. This will allow you to stand on the lower screwdriver to hold the damper stationary and pump the rod end easier. Perform purge before installing

NOTE: Hand purge to be completed in a vertical position with the base cup sticker end down toward the ground and the rod side facing up. See CSN V41 for detail procedure.

~
Contact us at CAGRIS@Chrysler.com for feedback related ONLY to this GPOP Tech Tip. Please include the Part Number(s) and Tech Tip Part Description of the Tech Tip you are referencing for our tracking system.
