

Subject Multimedia Recorder (MMR) Download Instructions		Market USA
Service Category Audio/Visual/Telematics	Section Navigation/Multi Info Display	
Applicability All Applicable Models		

APPLICABLE VEHICLES

2020-2021	C-HR	2018-2020	Sienna
2018-2021	Camry	2020-2021	Prius
2019-2021	Avalon	2019-2021	Avalon HV
2020-2021	Highlander	2020-2021	Highlander HV
2020-2021	Tacoma	2020-2021	Tundra
2020-2021	4Runner	2020-2021	Corolla HV
2019-2021	RAV4	2019-2021	Corolla Hatchback
2020-2021	Prius Prime	2020-2021	Corolla
2020-2021	Sequoia	2018-2021	Camry HV


CONDITION

To assist with the early detection and early resolution of audio related concerns, it may be requested as part of the remanufactured head unit return to recover MMR data from the head unit. The following steps are instructions on how to retrieve the data from the system and are only to be used when requested by audio suppliers, FTS, and/or FPEs.

RECOMMENDATIONS

Press and hold the “Audio” button on the faceplate while cycling the headlight switch from off to on three times.

2. Select “Failure Diagnosis”.



Subject

Multimedia Recorder (MMR) Download Instructions


Market

USA


Applicability

RECOMMENDATIONS


3. Select "Diagnosis Recorder".



4. Deselect "Recording ON/OFF" (it should be green and it needs to be white/grey to continue this process).



5. Press and hold the hidden button for 30 seconds.



6. Insert a blank USB drive into the vehicle's USB port (4GB capacity is needed).

Subject

Multimedia Recorder (MMR) Download Instructions


Market

USA


Applicability

RECOMMENDATIONS


7. Press and hold the “output” button for five (5) seconds.



8. Select the “Yes” button on the pop-up screen.



9. Select the “OK” button on the next pop-up screen.



Subject

Multimedia Recorder (MMR) Download Instructions


Market

USA


Applicability

RECOMMENDATIONS


10. Wait for the files to copy to the USB drive.



11. Once the files have transferred, select the "OK" button.



12. Select the "BACK" button in the upper right hand corner, then turn "Recording ON/OFF" back to the ON position (should be green to enable the MMR to record).



13. Turn the ignition off, then once the light on the USB turns off, the USB can be removed.

LINK REFERENCES

This Tech Tip does not contain any link references