

Regarding the shower pan, this will be a big job. Below in yellow is the procedure that will have to be done. OR second option, is just to seal the crack by applying white sealant used for plastic plumbing. Remember not to step on the drain because there is no foam support there because there is a hole in the foam support under the shower pan to make room for the drain connecting to the pipe going down to the tank under the vehicle.

As for the laminate that can just be re-secured using silicone.

Please advise.

1. Remove/install the toilet.
2. Remove/install metal frame around the wall.
3. Cut and apply new silicone around top of shower pan.
4. Cut and install new coupling to the vent stack behind toilet.
5. Remove/install bathroom door
6. Remove/install the step going inside the bathroom
7. Remove/replace shower pan.