

Please take this to an RV dealer and have them follow the procedure below by adding 4 rivets on the bracket that holds the strut. We will approved 0.5 hour for the work.

**PLXL Challenger Door Re-enforce Bracket-Strut Using Rivets**  
**See pictures below for reference:**

1. Remove old Robertson screws.
2. Drill 2 extra holes on bracket; drill 2 extra holes into the frame.
3. Clean surface underside of bracket, then apply epoxy (SIKA Fast 3131) or any epoxy for metal
4. Use 4 pcs. 3/16 inch PEEL DOME RIVET to secure bracket on to frame.

Note: epoxy cures in 30 mins.

