



Install, but do not fully tighten the 2 bolts (D) to the 2 rivet type nuts (E) that are part of the raised air intake.

1. Install the bolts (D) from the inside of the vehicle side panel.