

Paint Protection Film Decal Removal

Service Category Vehicle Exterior

Section Exterior Panels/Trim

Market USA

Toyota Supports
 ASE Certification 

Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2021	4Runner, Avalon, Avalon HV, C-HR, Camry, Camry HV, Corolla, Corolla Hatchback, Corolla HV, Highlander, Highlander HV, Land Cruiser, Mirai, Prius, Prius Prime, RAV4, RAV4 HV, RAV4 Prime, Sequoia, Supra, Tacoma, Tundra, Venza HV	

REVISION NOTICE

July 31, 2020 Rev1:

- **Applicability has been updated to include 2021 model year RAV4 Prime and Venza Hybrid vehicles.**

Any previous printed versions of this bulletin should be discarded.

Introduction

TMNA Accessory Sales and Marketing has developed a Toyota paint protection film (PPF) decal (treated with a specially developed light adhesive) for 2021 model year Toyota vehicles. The decal comes in two sizes (2.8 in. x 8 in. and 4 in. x 8 in.) for small and large hoods and will be applied to the top of PPF for all series at TLS accessory installation facilities. **The decal is intended to stay affixed to the film until delivery detail/wash.**

Just before customer delivery, follow the Removal Procedure in this bulletin to remove the decal and any residue left by the adhesive.

Figure 1.



Paint Protection Film Decal Removal

Warranty Information

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

Required Tools & Equipment

REQUIRED TOOLS & MATERIAL	QTY
70% Isopropyl Alcohol, Goo Gone®, or Equivalent	As Needed
Spray Wax (Meguiar's® Ultimate Quik Detailer™ or Equivalent)	As Needed

Removal Procedure

Decal Removal

1. With a fingernail, pick up one of the corners of the hood decal.

NOTICE
Do NOT push down on the decal while picking up the corner.

Figure 2.



2. Lift the loose corner of the decal until there is enough loose material to grab.
3. Slowly pull the decal up and away from the sticking surface, being careful not to force it.

Figure 3.



Paint Protection Film Decal Removal

Removal Procedure (continued)

Residue Cleaning

1. Apply a small amount of 70% isopropyl alcohol, Goo Gone®, or equivalent to a clean cloth and wipe down the adhesive area using a circular motion.

NOTE

- If using a spray cleaner, apply a light mist and allow the liquid to settle.
- Make sure to clean the surrounding area.

Figure 4.



2. Once ALL adhesive is removed from the vehicle panel, perform a final inspection. If necessary, perform a final wipedown with spray wax.

NOTE

- Make sure to clean the surrounding area.

Figure 5.

