

Tofino rear upper strut block. Disconnect the strut from the loose block.

Clean loose and flaky material on all surfaces. Prep all surfaces with sika activator 100, once dry you can secure the block back into place with (black) sika drive calking. Tape or prop the block into place so it doesn't dry out of position. After about 24 hours the strut can be reinstalled. Protect the canvas at all times.

https://ses.sika.com/dms/getdocument.get/f0922ace-7fdb-383f-951f-b72832f8a235/pds_Sika_Aktivator-100_e.pdf

https://can.sika.com/dms/getdocument.get/e30f734a-fc3a-3dc3-8961-75f0e29263d3/SikaTack-Drive-60%20min-EN_PDS.pdf