

Here is the procedure for the fiberglass panel separation:

1. Masked all painted areas before the cap and the cap itself because you do not have to paint the body for this procedure.
2. Wedge both ends of the affected area and try and remove as much old Sikaflex with a Olfa blade as you will need room for the new sikaflex to stick on.
3. Once some of the old Sikaflex is removed, you will need to clean both sides of the panel thats going to be bonded together (clean as much as you can and you may need a stick and rag wrapped around it).
4. Use Sikaflex 205 cleaner to wipe on and wipe off. Wait 20 minutes then use Sikaflex Aktivator 100. Wipe on the area as much as you can on both panels to be bonded then wait 10 minutes.
5. Clean up any spills if it runs down the side of the van as it will discolour the painted surfaces.
6. Use sikaflex 252 and starting from the top going as far as you can go in and work your way down but leaving enough room as it may squish out. If that happens it will have to be tooled back and cleaned up with sika remover.
7. You need to cover the fiberglass panel with a rag so that it will not make any marks before you place a horizontal wood block on top of the panel to spread the force. You will want to brace a stick against a wall to keep pressure against the panel. To do that, Put the wood brace on top of the horizontal wood creating a T-shape and rest on the wall for pressure.
8. Please make sure that the coach will be inside the shop at room temperature to have the sika adhesive to cure properly. The coach cannot be wet at all for 48 hours.