

PROCEDURE:

1. Lift roof stabilizer back and add wood blocks at the back (see picture 1 below in yellow)
2. Using ratchet strap, hook strap on top and bottom brackets that holds front strut (see picture 1 below in green) this is to keep front big strut from extending fully. Also if ratcheting down front struts keep them equal as possible and never release the ratchet till hinges are bolted and secure.

Note: Do NOT undo front shock ever. Do NOT undo bottom and top long brackets for "X" scissor. Tech has to be aware of the unforeseen instance that may come up. It wouldn't hurt to have some cardboard between scissor and the canvas.
3. With everything in place, work on replacing the scissor or X by using an Allen wrench.

