

PROCEDURE: See picture below for reference.

1. Look at one of the existing top strut mount bracket that are still screwed to the fiberglass. You are then going to draw a line (see sample red line below) at the front of the existing strut mount bracket for guidance. Also, you will need to make sure that the ball of the new bracket will line up on the same spot as the existing bracket so that the strut will mount properly. Put another vertical line if needed for guidance for the ball.
2. Remove screws that holds existing bracket.
3. Using the red line guide, install the NEW short bracket using the same screws but this time the screw position will be different.
4. Seal old holes with silicone first before installing new short top bracket.
5. Follow same procedure to use for the other top rear bracket.

