

2020 Plateau

I showed the pictures you sent to our department that does the install of those side moldings/panels. They said factory clips sprung loose or sometimes clips may pop if not pushed all the way in. They said, the only notable loose bowed molding/panels are:

1. The molding on driver side at rear and above of dually wheels
2. The molding below lower fridge vent on driver side

PROCEDURE:

First, push these panels so clips at the back of it will clamp in place to secure the panel. If this doesn't work, you can pull out by hand the panel or using a plastic prying tool, pry out panel and replace the clips (plastic mounting clamps) at back of it, You may need to put tape on surrounding area of molding before prying panel out so you don't scrape the paint on surround body panels. We will send you 25 pcs clips (plastic mounting clamps) for this. There should be extra clips after you've used them for the two panels/moldings.

The time approved is 0.6 hour (0.3 for each panel) and the Authorization# **25022101 J** for the work.