

2021 Tofino

Looks like plastic bottom piece is a bit long. Have someone hold roof down a few inches so someone else can release Velcro and slide the bottom plastic out. Once in hand cut 1/2" off of it. File the cut area nicely so there is no sharp edges. Then reverse the process sliding plastic piece back into its pocket. Look at pictures attached. It doesn't always lay flat and needs that little curve so it starts pulling inward as roof comes down.

