

SportDesign Package for Taycan

Vehicle Type: **Taycan**

Model Year: **As of 2020**

Information: **Retrofitting**



Figure 1

Scope 1 – SportDesign front apron

Scope 2 – SportDesign package, complete with side skirts

Scope 3 – SportDesign Carbon with side skirts



Information

Parts Info: **Important:** Also order number plate carrier for the relevant country version in the same way as in PET.

Important: Only the order sets are listed; current exploded drawings or a detailed list of the parts are visible in the PET (Porsche Electronic Parts Catalogue).

Package Order No.		Scope 1: SportDesign package, front apron 2D4
9J1.044.800.56	1 x	Front apron with ParkAssist
9J1.044.800.57	1 x	Front apron with Intelligent ParkAssist (IPA)

Package Order No.

9J1.044.800.50 1 x

9J1.044.800.51 1 x

Scope 2: SportDesign package consisting of front apron, rear apron and side skirts 2D1**SportDesign package, complete with ParkAssist****SportDesign package, complete with Intelligent ParkAssist (IPA)****Package Order No.**

9J1.044.800.60 1 x

9J1.044.800.61 1 x

For Scope 3: SportDesign package in Carbon, consisting of front apron, rear apron and side skirts 2D3**SportDesign package in Carbon with ParkAssist****SportDesign package in Carbon, complete with Intelligent ParkAssist (IPA)****Important:** The following carbon sets are for the Taycan Turbo S**Package Order No.**

9J1.044.800.64 1 x

9J1.044.800.65 1 x

For Scope 3: SportDesign package in Carbon, consisting of front apron, rear apron and side skirts 2D3**SportDesign package in Carbon with ParkAssist****SportDesign package in Carbon, complete with Intelligent ParkAssist (IPA)**Work
Procedure:**Information**

Some of the repair illustrations show only one side of the vehicle. Naturally, some steps also have to be performed on the opposite side of the vehicle as well. These must be carried out as a mirror image of the steps shown.

**Information**

The number of electric plug connections and clips will vary depending on equipment.

Important: Only paint prime-coated parts! Remove parts before painting. This note affects all work steps (Scope 1 – 3).

**CAUTION****Painting components**

- Risk of warping of components
 - Risk of damage to components
- ⇒ Observe the guidelines and instructions for painting components in the "Paint" Workshop Manual.
- ⇒ Always place parts without tension on the painting devices provided during painting and drying processes.

⇒ Workshop Manual 'Instructions for painting front apron (vehicles with Intersection Assist)'

- 1 The following work steps affect Scope 1, 2 and 3.
 - 1.1 Connect a battery charger. ⇒ *Workshop Manual 'Charging vehicle electrical system battery'*
 - 1.2 Raise the vehicle. ⇒ *Workshop Manual 'Lifting the vehicle'*
 - 1.3 Remove front apron. ⇒ *Workshop Manual 'Removing and installing front apron'*
 - 1.4 Disassemble and assemble front apron. ⇒ *Workshop Manual 'Replacing front apron'*
 - 1.5 Removing and installing front air grille at the left. ⇒ *Workshop Manual 'Removing and installing front air grille (at the left)'*
 - 1.6 Removing and installing front air grille at the right. ⇒ *Workshop Manual 'Removing and installing front air grille (at the right)'*
 - 1.7 Install front apron. ⇒ *Workshop Manual 'Removing and installing front apron'*

- 2 The following work steps affect Scope 2 and 3.

Important: Note the following when painting. ⇒ *Workshop Manual 'Instructions for painting rear apron (vehicles with Lane Change Assist)'*

 - 2.1 Remove rear apron. ⇒ *Workshop Manual 'Removing and installing rear apron'*
 - 2.2 Disassemble and assemble rear apron. ⇒ *Workshop Manual 'Replacing rear apron'*

- 3 The following work steps affect Scope 2 and 3.
 - 3.1 Removing and installing side skirts. ⇒ *Workshop Manual 'Removing and installing sill cover'*

- 4 Code vehicle.

NOTICE**Voltage drop**

- **Risk of irreparable damage to control unit**
 - **Risk of damage to control unit**
 - **Fault entries in the control unit**
 - **Coding in the control unit is aborted**
 - **Malfunctions in control unit, even during programming**
- ⇒ **Before disconnecting the control unit, switch off ignition and remove ignition key.**
- ⇒ **Make sure that the power supply is not interrupted during programming.**
- ⇒ **Connect battery charger/power supply - Suitable for AGM Type batteries, recommended current rating of 90A fixed voltage 13.5V to 14.5V.**

- 4.1 **9900 - PIWIS Tester 3** must be connected and ignition switched on.

- 4.2 Select "Diagnostics". **9900 - PIWIS Tester 3** detects the model line.
Press Next. PIWIS Tester III Diagnostics starts.
- 4.3 Update vehicle data.
- 4.3.1 **Additional menu** must be selected by pressing •F7" . Press •F11" to confirm the question "Create vehicle analysis log (VAL)?".
- 4.3.2 Select the **Maintenance of vehicle data** function. Press •F12" until PR numbers appears in the Value group column.
- 4.3.3 Select **Trim CD value** in the Family column. When you touch the cell behind Trim CD value, the drop-down menu opens.

Select the value **between the installed scope**.
Press •F12" to change values.
- 4.3.4 The selected values appear. Press •F8" to write values. Wait until the following message appears: **Generation of vehicle data is complete. Press**

Press •F11" to switch to the control unit overview.
- 4.4 Adapt coding.
- 4.4.1 Select all control units by pressing •Ctrl A" . Press •F12" to continue.
- 4.4.2 Switch to the **Coding/programming** menu. Press •F12" to continue.

Select **Automatic coding** mode. Press •F12" to continue.
- 4.4.3 Wait until the following message appears: **Coding was completed successfully**. Press •F12" to continue.

Press •F12" to return to the **Overview** menu.
- 4.5 Switch off ignition and disconnect **9900 - PIWIS Tester 3**.
- 4.6 Disconnect the battery charger.

Scope 1, SportDesign package, front apron

66992340: SportDesign package, rear apron Labor time: **290 TU**
Includes: Replace rear apron.

63156191 + SportDesign package, rear apron Labor time: **110 TU**
510117101: Includes: Paint rear apron.

Scope 2 SportDesign package, complete with side skirts

66992340: Complete SportDesign package Labor time: **760 TU**
Includes: Replace front apron, rear apron and side skirts.

510117101: Sport Design package for front apron, rear apron and side skirts
Includes: Paint front apron, rear apron and side skirts
Labor time: **220 TU**

Scope 3 SportDesign package in Carbon

66992340: Complete SportDesign package
Includes: Replace front apron, side skirts and rear apron.
Labor time: **760 TU**

510117101: Sport Design package for front apron, rear apron and side skirts
Includes: Paint front apron, rear apron and side skirts
Labor time: **220 TU**

Important Notice: Technical Bulletins issued by Porsche Cars North America, Inc. are intended only for use by professional automotive technicians who have attended Porsche service training courses. They are written to inform those technicians of conditions that may occur on some Porsche vehicles, or to provide information that could assist in the proper servicing of a vehicle. Porsche special tools may be necessary in order to perform certain operations identified in these bulletins. Use of tools and procedures other than those Porsche recommends in these bulletins may be detrimental to the safe operation of your vehicle, and may endanger the people working on it. Properly trained Porsche technicians have the equipment, tools, safety instructions, and know-how to do the job properly and safely. Part numbers listed in these bulletins are for reference only. The work procedures updated electronically in the Porsche PIWIS diagnostic and testing device take precedence and, in the event of a discrepancy, the work procedures in the PIWIS Tester are the ones that must be followed.

© 2021 Porsche Cars North America, Inc.