



V-MAC - Install Under Windows 2000/XP



> Internal Content

When running Windows 2000/XP, our V-MAC software and the related Noregon RP1210A drivers will install and function correctly if installed and run under the profile of Administrator with Administrator privileges.

If User Profiles are used, however, the following procedure must be followed.

1. Log onto the computer as User ID of Administrator with Administrator privileges.
2. Install all the software and drivers.
3. Restart the computer and log on as User ID of Administrator with Administrator privileges again (to be sure all Registry keys are properly set).
4. Reset the privileges of the target User Profile to that of Administrator.
5. Shut down the computer and restart Windows and log on as that User.
6. Install all the software and drivers.
7. Restart the computer and log on as that User again (to be sure all Registry keys are properly set).
8. Shut down the computer and restart Windows and log onto the computer as User ID of Administrator with Administrator privileges.
9. Reset the privileges of the User Profile to that User's normal privileges.

Note: The only software that we have been unable to get to function under User Profiles is the Meritor WABCO ABS Software. We recommend that this software be run only as Administrator.



Tags

k10128733 ch rb dm chn cl ct
cv cx cxm le Mr. rd mack

Related links and attachments

No links or attachments available



Feedback

[Give feedback](#)

to help improve the content of this article



Live UI