

36FL/378FL MID-DECK REPAIR

REMOVE TRIM, SOFA'S, AND DISCONNECT SLIDE OUTS. REMOVE LINO TO USE AS PATTERN. MEASURE AND CUT TOUNGE AND GROOVE

- **THIS SHOULD BE CUT OUT OF SMOOTH CDX PLYWOOD 5/8" THICK**
- **MAKE SURE TO MEASURE FROM BOTTOM OF PASSTHROUGH TO FIND LOCATION OF STRINGERS**

STARTING FROM THE BACK OF MID-DECK, 48" STAND-UP SLIDE IN UNDER SLIDE-OUT, 2ND PC. STAND-UP SLIDE IN UNDER SLIDE-OUT, AND 3RD PC. (AROUND 28") STAND-UP SLIDE IN UNDER SLIDE-OUT, FROM BACK OF DECK FORWARD. USE A PRY BAR TO PUT TOUNGE AND GROOVE TOGETHER. USE A PRY BAR TO PRY ON CARPET STEP IN FRONT OF TV CABINET.

*****NOTE: MAKE SURE TO SECAFLEX PLYWOOD DOWN AND LIGHTLY SAND SCREWS AND SEAMS**

****WIDTH OF DECKING CUT 1/2" SHORT****

