

INSTRUCTIONS TO APPLY VEHICLE EMISSION CONTROL INFORMATION (“VECI”) LABEL TO HOOD OF VEHICLE

1. Raise the hood.
2. Locate the original VECI label under the hood.



3. Clean the surface of the original VECI label with alcohol /glass cleaner or equivalent and a soft cloth.
4. Remove the new VECI label from its paper backing.
5. Apply the new VECI label directly over the existing VECI label.
6. Firmly press and smooth the label to ensure good adhesion.
7. Close the hood.