

Work Instructions to correct the fuel venting issue on the units in the field:

Step 1: Use a floor jack with a 2x4 long enough to span the width of all fuel tank brackets. Do this to evenly lift the fuel tank up enough to take the pressure off of the fuel tank bracket bolts.

Step 2: When the pressure is off the bolts, loosen only the three bolts that are on the passenger side of the unit. Leave the bolts on the driver's side intact. Loosen the passenger side bolts enough to reach the venting tube.

Step 3: When the bolts are loose, lower the tank using the floor jack until the venting hose is visible.

Step 4: Once visible, pull the hose toward the center of the Van and zip tie the hose to the center fuel tank bracket.

Step 5: Use the floor jack to lift the tank back up and secure the fuel tank bolts.