ADDING BOTTOM FASTENERS TO 8800 SERIES RV ENTRY DOORS

TI-557

DOORS

Purpose

This document outlines the procedure for measuring and driling holes then adding fasteners to RV entry doors in the field that are missing holes at the bottom of the doors (Fig. 1A and 1B).

Fig. 1



Resource Required

- Cordless or electric drill or screw gun
- #8 or 3⁄16" drill bit
- Marking pencil
- #8 Screws (quantity 2) - length must be long enough to penetrate sidewall framing.

Procedure

⚠ CAUTION

Moving parts can pinch, crush or cut. Keep clear and use caution.

1. Open door.
2. Measure from the threshold 1 ½" (38 mm) up the door and mark where the hole needs to be drilled. Repeat for the other side (Fig 1A and 1B).
3. Drill the holes using a #8 or 3⁄16" drill bit.
4. Install #8 screws in the new holes. The screws must be long enough to penetrate the sidewall framing.

NOTE: For wood frame construction, do not use self-tapping screws.