



Leading Edge Fabrication LLC

LEADING THE FABRICATED SURFACE INDUSTRY WITH QUALITY AND INNOVATION

If the chip is light enough to sand only, the instructions are as follows:

Use 220 grit sandpaper, lightly sand the chipped area, and approximately 2-3 inches on either side of the chip the blend it in. Repeat these steps with 400, 600, and 800 grit sandpaper. Use any polish suitable for countertops, to blend in to match the surrounding finish (a buffer is preferred, but usually not necessary)

If the chip is too big to sand, you will need to apply the appropriately colored methylacrylate glue. This requires a tube of glue, a glue dispenser and tip.

You will want to wipe the area to be glued with alcohol. Apply masking tape under the chip, insert a small amount of glue, just enough to fill the chip, and fold the tape over to hold the glue in place.

Depending on the temperature, it usually takes 5-10 minutes for the glue to dry. Once it's dry, remove the tape, and follow the same sanding and polishing instructions noted earlier.

501 W. Railroad Ave. Ste. A Syracuse, IN 46567

P: 574-658-3292 F: 574-658-3296

www.leadingedgefabrication.net