

Ember 'Congoleum' Patch Repair Instructions

Purpose

This document outlines the procedure for patching and repairing the linoleum floor according to Ember quality standards.

Parts/Tools Needed

- Linoleum (Item# 10000417)

- ½" Batten (Item# 15000091) (replacement only)
- Air Step Adhesive (Item# 95000970) (replacement only)
- Congoleum Quik Stik Tape (Item# 95000945) (patch only)
- Congoleum SU-80 Seam Sealer (patch only)
- 2" Masking Tape (patch only)
- Utility Knife
- Heavy Duty Scissors
- Straight Edge (patch only)
- Small Hand Roller

Procedure: Patch

Note: These instructions apply to model year(s) 2024 to current only.

Notes: Videos are available for this procedure. Select the following links to view:

- [Traditional Repair Method](#)
 - [Bond & Seal Repair Method](#)
1. Identify the best match replacement linoleum section and cut the section with a minimum of 1/4" wider than the grout lines.



2. Secure the replacement linoleum with tape over the damaged area. Using a straight edge and utility knife, cut through both layers around all four sides; be sure to have the blade perpendicular to the floor's surface.



Remove repair and damage section; discard damaged section. Then apply Congoleum Quik Stick Tape QS120 about ½" under the main linoleum floor. Secure tape in place using the small hand roller.



3. Remove the release liner from the tape. Lay the repair section into place, ensuring all the seams are nice and tight. Use a small hand roller to embed the repair section into the adhesive.



4. Apply Congoleum SU-80 Seam Sealer to all seams of the repaired area. Ensure the seam applicator tip is inserted between the two sections.



5. Let the seam sealer set for a couple of hours; the repair is complete.

Safety, education, and customer satisfaction are our primary concerns. Should you have any questions, please contact us at 844-732-4204 or by email at warranty@emberrv.com.