


To replace the luggage cover, adjust the cover so that "TOP" is facing upwards.



Use a floor mat of the correct size. If the vehicle carpet and floor mat have 2 holes, then they are designed for use with locking clips. Attach the floor mat to the vehicle carpet using the clips. Lock the clips into the holes in the vehicle carpet.



/ CAUTION Make sure the floor mat is properly placed on the vehicle carpet. If the floor mat slips and interferes with the movement of the pedals during driv ing, it may cause an accident.

Use the same as hexus manual on warming card on stacker

316

1X5 Clips/hours?

Stickers 100,000 Stickers for letter.

** Cost for Company hetter will be sent to Japan warranty to fix tiese. Need to work with Frank-san

__ Defect Information Request