

**EA02-025**

**FORD 10/27/03**

**APPENDIX N**

**BOOK 6 OF 61**

**PART 5 OF 6**

# TECH COMMENTS

REPLACED DEACTIVATION SWITCH  
 DIAGNOSED AS LEAKING FROM NEW SWITCH THAT WAS INSTALLED FROM RECALL 98S15, REMOVE AND REPLACE WITH ANOTHER ONE AND CLEAN UP FLU  
 118483 DEACTIVATION SWITCH LEAKING PULL ALL WHEELS OK BRAKES AND LINES REPLACE BRAKE SWITCH DEACTIVATION SWITCH  
 REPALCE DEACTIVATION SWITHC SPEED CONTROL ODDME VEHICLE NEVER LEFT BUILDING  
 R AND R FAULTY DEACTIVATION SWITCH PER SERVICE PARTS  
 90646 HAD TO REPLACED DEACTIVATION SWITCH PER NEW ONE LEAKING  
 INSPECTED, REPLACED DEFECTIVE CRUISE SWITCH  
 DIAGNOSIS ELECTRONIC TRANS TEST REMOVED TRANS AND REPLACED DEFECTIVE TORQUE CONVERTER, RETEST  
 SWITCH VERIFIED CONCERN AND REPLACED REPLACED SWITCH # 0838  
 SPW SPEED CONTROL DEACTIVATION SWITCH LINE 9  
 A26 42 SPW RO 68804 DT 7-3-99 MI 58188 REPLACE BRAKE DEACTIVATION SWITCH  
 54583 SERVICE PARTS REPLACEMENT W REPLACE CRUISE CONTROL DEACTIVATION SWITCH, WAS LEAKING BRAKE FLUID  
 60752 LACK OF TECH TIME DUE TO DISPATCH ERROR\*\*\* SPW\*\*\*R-O 107504\*\*\*ACCRUED 25 MILES\*\*7-15-99\*\*\* LABOR 2284A 3\*\*\*BASIC 9G852\*\*\*CC-01\*\*\*VEI  
 PRESSURE SWITCH LEAKING REPLACE PRESSURE SWITCH, LEAKING AROUND CRIMP  
 ORING NOT SEATING R&R DEACTIVATION SWITCH  
 OPEN CIRCUIT IN BREAK PRESURE SWITCH WHICH CHANGED IN RECALL REPLACE SWITCH & HARDSHELL CONNECTOR  
 REPLACE SWITCH AND BLEED SYSTEM  
 OASIS PERFORM RECALL 98S15 INSTALL SWITCH PART WAS BROKEN IN THE BOX  
 SWITCH FAILURE REPLACE SPEED CONTROL ACTIVATION SWITCH  
 9G852-42, BRAKE PEDEL SPONGY AFTER RECALL BRAKE SWITCH LEAKING BUT TIGHT REPL SWITCH BLEED BRA KES ROAD TEST OK  
 VERIFY CONCERN AND FOUND THAT THE SPEED CONTROL SWITCH IS CAUSING THE CONCERN-REPLACE AS NEEDED.  
 REPLACE SPED CONTROL DEACTIVATIONBAD SWITCH  
 52541 SPEED CONTROL DIAGNOSIS 9818A 0.7 REPLACE SPEED CONTROL SWITCH 9818A2 0.2 CC 42  
 CLIPS BROKEN REPLACE CRUISE CONNECTOR  
 1 REPLACED LEAKING SPEED CONTROL DEACTIVATION SWITCH SERVICE REPLACED TO RO 98987, DATE 6-18-99, MILES 93049  
 RPL DEACTIVATION SWITCH KIT  
 THREADS DAMAGED REPLACED CRUISE CONTROLL SWITCH, BLEED FRONT BRAKES  
 TEST CRUISE, PINPOINT TEST A1-A5, SERVICE INSTALL DEFECTIVE SWITCH FROM RECALL 98S15 SWITCH OPEN. PART#F2VY-9F924-A IS IN KIT PART#XW7  
 REPLACED DEACTIVATION SWITCH  
 REPLACE LEAKING BRAKE SWITCH  
 RR ALL WHEELS TO INSPECT BRAKES, FOUND FLUID LOW, CHECKED FOR LEAK AT PRESSURE SWITCH, REPLACE SWITCH, BLEED BRAKES AND CLEAN A/  
 INOP REPLACE SPEED CONTROL DEACTIVATOR SWITCH-DEFECTIVE  
 BRAKE PEDAL GOES TO FLOOR REPLACE DEFECTIVE SPEED CONTROL DISENGAGEMENT SWITCH  
 INOP SWITCH SPEED CONTROL - TEST  
 PERFORMED 98S15 8-8-99 RO68071 70489 MILES. CRUISE DEACTIVATION SWITCH REPLACED AT THAT TIME. SERVICE INSTALLED PART WARRANTY. REMK  
 RECHECK - RED BRAKE LITE ON REPL SWITCH - AFTER RECALL  
 INSTALL CRUISE CONTROL SWITCHED PER RECALL RECALL CLOSED DURING PROCESSING GOODWILL RECOVERY TO DEALER  
 51742 RECALL R AND R DEACTIVATOR SWITCH AND CONNECTOR PER RECALL, BLEED REAR BRAKES.

B REPLACE SWITCH-  
 58310 INSTALLED NEW CRUIS CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 024 INSTALLED CRUISE CONTROL DEACTIVATION SWITC  
 PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 RECALL PERFORMED RECALL 98S15  
 RECALL PERFORMED RECALL # 0836

PERFORMED RECALL 99S15

1 PERFORMED RECALL

REPLACE SWITCH AND CONNECTOR

REPLACED DEACTIVATION SWITCH

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

94412 RECALL WP40 REPLACE SPEED CONTROL PRESSURE SWITCH

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

REPLACE BRAKE PRESSURE DEACTIVATION SWITCH AND HARDSHELL

SPEED CONTROL STICKING PERFORMED 99S15B RECALL

134451 REPLACED THE DEACTIVATION SWITCH AND WIRING CONNECTOR. OK. RECALL 99S15

63301 99S15

E METERING BLOCK STRIPPED WHILE PERFORMING RECALL. INSTALLED NEW METERING BLOCK AND PERFORMED RECALL 99S15B .5 ADMIN .1 MTIME

REPLACE CRUISE CONTROL CUT OFF SWITCH

1 REPLACE BRAKE SWITCH PER RECALL

RECALL PERFORM 99S15 RECALL

REPLACED SC DEACTIVATION SWITCH 99S15

86285 PERFORMED 99S15 RECALL

COMPLETED RECALL

1 PERFORMED RECALL 99S15

PERFORM RECALL

PERFORMED RECALL 99S15 AND CHECKS OK

REPLACE CRUISE CONTROL SWITCH

81883 RECALL 99S15 INSPECT AND PERFORM RECALL

SPEED CONTROL RECALL

PERFORMED RECALL

109115 RECALL 99S15

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

VERIFIED CONCERN REPLACED CRUISE CONTROL SWITCH

PERFORMED RECALL

PERFORMED RECALL REPLACED SWITCH GKS OK

122101 RECALL 99S15B 0.5 0.5 RECALL

99S15 RECALL 99S15 RECALL, REPLACED SPEED CONTROL DEACTIVATION SWITCH

47150 RECALL 99S15 RECALL 99S15

REPLACE PRESSURE SWITCH AND CONNECTOR

PERFORMED RECALL 99S15

RECALL 99S15

REPLACE CABLE 99S15

109554 R&R SWITCH ASSY.

INSTALL HARDSHELL CONNECTOR AND PRESSURE SWITCH

CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPLACED SPEED CONTROL DEACTIVATION SWITCH, INSP CONNECTOR.

PERFORMED RECALL

REPLACE SWITCH

110082 BRAKE KIT RECALL  
RECALL 99S15 RECALL  
RECALL 99S15  
. PERFORM RECALL  
RECALL SWITCH

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E  
RECALL PERFORMED SPEED CONTROL DEACTIVATION SWIT

114714 PERFORMED RECALL  
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
151741 RECALL WPG40 REPLACE NEW WIRE CONNENCTOR & GINGER PER RECALL 99S15 FINISHED  
PERFORMED RECALL 99S15.TEC 120 WARR  
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
FORD RECALL PERFORMED CRUISE DEACTIVATION SWITCH RECALL  
PERFORMED SAFETY RECALL 99S15  
PERFORMED RECALL PERFORMED RECALL INSTALLED NEW SWITCH  
PERFORMED RECALL 99S15, REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTION.  
PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

RECALL 99S15  
110098 RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL  
R & R SWITCH & CONNECTOR  
RECALL 99S15 99S15 COMPLETED RECALL  
REPLACED DEACTIVATION SWITCH  
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
78448 REPLACED DEACTIVATION SWITCH,REPLACED HARNESS CONNECTER, TOPPED OFF BRAKE FLUID AND TEST DROVE OK  
PERFORM RECALL  
1 PERFORMED RECALL  
REPLACE BRAKE KIT PER RECALL

58483 RECALL 99S15 W PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATI ON SWITCH.

91829 WARR DONE RECALL 99S15 INSTALL BRAKE REPAIR KIT  
99S15 RECALL REPL CRUISE DEACTIVATION SWITCH

99S15 CRUISE  
RECALL REPLACE SPEED CONTROL SWITCH  
120802 99S15 WARR REPLACED SWITCH AND CONN  
INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99S15B .30

RECALL COMPLETED  
RECALL PERFORMED  
PERFORM RECALL 99S15  
70832 PERFORM RECALL 99S15  
PERFORMED RECALL  
REPL BRK PRSS SWITCH

PERFORMED RECALL 99S15  
99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION :  
DONE RECALL 99S15

INSTALL KIT PER RECALL  
PERFORMED RECALL

1 PERFORM RECALL

98S15

98S15

RECALL 98S15

RECALL PERFORME

AS PER RECALL

98S15 RECALL TO INSTALL SWITCH AND HARDSHELL CONNECTOR

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

RECALL

98S15

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

COMPLETED RECALL

REPLACED CRUISE CONTROL SWITCH

98S15 PERFORMED RECALL

PER RECALL

PERF RECALL

82252 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW AND CONN PER RECALL

PERFORMED RECALL

PERFORMED RECALL 98S15. 98S15B .5HRS

INSTALLED SWITCH

PERFORM RECALL

101213 RECALL 98S15, R&R DEACTIVATION SWITCH, AND CONNECTOR, RETURNED PARTS

RECALL PERFORMED

98S15 REPLACED DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED DEACTIVATION SWITCH PER RECALL 98S15

48828 98S15B .6 98S15B.6 .6 REPLACE SPEED CONTROL SWITCH

PERFORM RECALL

INSTALL SWITCH PER RECALL 98S15 A99

98S15B 0.5

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION

RECALL COMPLETED

PERFORMED 98S15B

20141 RECALL 98S15B 0.5, ADMIN 0.1 R&R DEACTIVATION SWITCH & CONNECTOR PER RECALL

REPLACED CRUISE DEACTIVATION SWITCH AND HARDSHELL FOR CONNECTOR

INSTALLED SWITCH AS PER RECALL

98S15

98S15 REPLACE SWITCHED CONNECTOR

INSTALLED NEW DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 98S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

REPLACE SWITCH AND HARD SHELL CONNECTOR LABOR OF 98S15B, BILLING TIME .8, TECH TIME .6 PROGRAM CODE 98S15

1 PERFORMED RECALL

DONE RECALL COMPLETED

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS

PERFORMED RECALL 98S15

RECALL 98S15. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15.

81648 98S15 SPEED CONTROL RECALL PERFORMED

PERFORM RECALL 98S15

.

PERFORM RECALL

REPLACED PARTS PER RECALL

RECALL 98S15; PERFORM RECALL 98S15; REPL BRK-PRESS. SWITCH;

INSTALL SWITCH PER RECALL  
RECALL REPLACED BRAKE PRESSURE SWITCH AND BLEED BRAKE SYSTEM.  
RECALL 98S15  
PERFORMED RECALL  
REPLACED DEACTIVATION SWITCH AND CONNECTOR, BLEED  
INSP AND REPL SWTH AND CONN PER RECALL  
PERFORM RECALL 98S15 REPLACED PRESSURE SWITCH PER RECALL 98S15  
PERFORMED RECALL

PERFORM RECALL 98S15-INSTALL SWITCH AND CONNECT OR  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

42 98S15  
98S15 98S15  
1 PERFORM 98S15 AS PER LETTER  
RECALL 98S15 98S15 COMPLETED RECALL  
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
RECALL 98S15  
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
PERFORMED RECALL  
REPLACED CRUISE CONTROL CUT OFF SWITCH.....  
REPLACE SW.  
REPLACED BRAKE SWITCH M TIME REPLACED BRAKE SWITCH  
RECALL 98S15 CRUISE CONTROL  
93484 98S15B .5 INSTALL KIT

REPLACED SPEED CONTROL SWITCH  
REPLACE SWITCH  
RECALL 98S15  
AS PER RECALL 98S15 REPLACE SWITCH AND HARDSHELL CONNECTOR  
INSPECTED SPEED CONTROL AND INSTALLED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIRS  
COMPLETE RECALL 98S15

RECALL 98S15 RECALL, REPLACED DEACTIVATION SWITCH  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S  
RECALL COMPLETE.  
PERFORMED RECALL 98S15  
PERFORMED RECALL 98S15

PERFORMED RECALL REPLACED SWITCH CKS OK  
RECALL COMPLETED  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S  
REPLACED SC DEACTIVATION SWITCH 98S15  
PERFORM RECALL  
112583 PERFORMED RECALL 98S15  
REPLACED DEACTIVATION SWITCH.

PERFORMED RECALL 98S15  
 RECALLED 98S15 PERFORMED  
 COMPLETED RECALL 98S15  
 98S15 RECALL  
 REPLACE DEACTIVATION SWITCH AND CONNECTOR  
 SPEED DEACTIVATION SWITCH RECALL L.O.C. 98S15B  
 REPLACED DEACTIVATION SWITCH PER RECALL 98S15  
 PERFORMED RECALL 98S15  
 INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S15B .50  
 38500 RECALL W/F PERFORM RECALL AS INSTRUCTED  
 1 COMPLETED REACTIVATION OF CRUISE CONTROL SYST  
 1 PERFORMED REPAIR PER RECALL  
 REPLACED CRUISE CONTROL DEACTIVATION  
 INSPECT AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 INSTALLED SWITCH KIT  
 RECALL 98S15 RECALL PERFORME  
 REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL  
 PERFORM RECALL  
 83580 PERFORMED RECALL  
 81180 RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS PER RECAL  
 98S15 98S15  
 PERFORM RECALL ON CRUISE CONTROL SWITCH  
 84210 RECALL 98S15  
 RECALL PERFORMED RECAL  
 98S15 RECALL 98S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNE  
 RECALL 98S15B \_ REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 98S15  
 PER FCSD PERFORMED RECALL 98S15 PERFORM REPAIR W-KIT.  
 MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETE.  
 RECALL 98S15 COMPLETED  
 PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION  
 COMPLETED AS PER RECALL  
 PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK  
 RECALL 98S15 - SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
 RECALL NOTIFICATION  
 PERFORMED RECALL  
 PERFORMED RECALL 98S15  
 PERFORM 98S15 RECALL  
 RECALL PERFORMED  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 82171 0.50 PERFORMED RECALL 98S15 DEACTIVATION SWITCH  
 73683 RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 98807 RECALL 98S15 INSTALLED NEW HARDSHELL CONNECTOR AND SWITCH. TEST DROVE TO VERIFY REPAIR.  
  
 81180 RECALL 98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 88853 98S15B WARR .5 REPLACED SWITCH AND WIRE CONNECTOR.  
 108308 REPL DEACTIVATION  
 PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION

1 PERFORMED RECALL AND REPLACED CRUISE CABLE  
REPLACE SWITCH AND CONNECTOR  
RECALL 99S15 99S15 COMPLETED RECALL  
PERFORMED RECALL 99S15 DEACTIVATION SWITCH

PERFORM RECALL 99S15-INSTALL SPEED CONTROL SWITCH AND CONNECTOR  
99S15 RECALL INSTALL SWITCH AS PER RECALL

82123 PERFORM RECALL 99S15  
99S15, REPLACE SWITCH AND WIRE COND  
REPLACE SWITCH  
SWITCH 99S15  
PERFORMED RECALL  
83538 PERFORMED RECALL 99S15  
REPAIR PER 99S16 RECALL  
99S15 RECALL INSTALL BRAKE SWITCH AND HARD SHELL CONECTOR  
40848 PERFORM RECALL  
RECALL 99S15 RECALL  
REPLACED CRUISE CONTROL SWITCH FOR RECALL  
1 COMPLETED RECALL  
COMPLETED SPEED CONTROL RECALL  
1 PERFORM RECALL 99S15  
PERFORM RECALL PER INST  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION  
RECALL PERFORMED RECALL  
1 PERFORMED RECALL 99S15  
REPLACED SWITCH  
PERF. RECALL  
MODIFIED SPEED CONTROL PER RECALL  
77957 RECALL 99S15 REMOVE OLD DEACTIVATION SWITCH AND INSTALL NEW BLEED REAR BRAKES  
RECALL CRUISE CONTROL  
PERFORM RECALL  
99S15 99S15  
74808 RECALL WA PERFORM RECALL, REPLACE DEACTIVATOR SWITCH AND CONNECTOR  
PERFORMED RECALL 99S15  
REPLACE CRUISE DEACTIVATION SWITCH  
TECH REPLACED CRUISE CONTROL SWITCH AS PER RECAL  
RECALL 99S15 RECALL  
77548 RECALL W PERFORMED RECALL 99S15 REPLACED BRAKE DEACTIVATION SWITCH  
DO RECALL 99S15

COMPLETED RECALL  
REPLACE SPEED CONTROL DEACTIVATION AND HARD SHEEL CONNECTOR

PERFORM 99S15  
114080 RECALL 99S15 PERFORMED RECALL  
RECALL 9915



90000 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
99S15 RECALL 99S15 REPLACE SPEED CONTROL SWITCH AS PER RECALL  
PERFORMED RECALL  
C REPLACED BROKEN DEACTIVATOR SWITCH

1 COMPLETED RECALL  
REPLACED DEACTIVATION SWITCH  
138810 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PREFRD RECALL 99S15

1 PERFORMED RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORMED RECALL 99S15  
REPAIR AS PER RECALL  
REPLACED SWITCH AND CONNECTOR PER RECALL  
28841 99S15B 0.5 HRS. SPEED CONTROL RECALL  
PERFORMED RECALL 99S15

===== PERFORM RECALL 99S16- INSTALL CRUISE CONTROL PARTS

90200 RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION  
118040 PERFORM RECALL FOR SPEED CONTROL DEACTIVATION SWITCH. WHEN INSTALLING SWITCH, THREADS STRIPPED IN BRAKE LINE BLOCK. INSTAL  
PERFORMED RECALL 99S15  
PERFORM RECALL  
REPAIR PER 99S15 RECALL  
99S15 99S16-REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH  
RECALL 99S15  
PERFORMED RECALL 99S16B

104270 WPR40 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH POST TEST, POST ROAD TEST

COMPLETED RECALL 99S15

RECALL 99S15 RECALL REPLACE SWITCH  
RECALL 99S15 RECALL 99S15B

PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15 PERFORMED 99S15 RECALL  
PERFORM RECALL 99S15 INSTALL BRAKE KIT PER RECALL 99S15  
ORDERED DEACTIVATION SWITCH 99S15 99S15  
99S15 RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15  
REPLACED SWITCH CODE 42  
SPEED CONT REPL SWITCH

PERFORMED RECALL 99S16 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

101313 RECALL WARRANT AND R SPEED CONTROL DEACTIVATOR SWITCH PER RECALL INSTRUCTIONS.  
INSTALL DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL

1 PERFORMED RECALL 99S15

1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH  
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL R-R DEAC SW, R-R HARDSHELL CONNL INSTALLED NEW, RECKD OK

52086 PERFORM RECALL 99S15, INSTALL SOP S.C. DEACTIVATION SWITCH.

78314 INSTALL NEW SWITCH AND HARNESS END PER RECALL 99S15

REPLACE CRUISE CONTROL SWITCH PER RECALL

SPEED CONTROL RECALL

RECALL 99S15 RECALL

130279 PERFORMED RECALL 0.5

RECALL 99S15

RECALL 99S15 COMPLETED

1 REPLACE BRAKE SWITCH AND CONNL PER RECALL

CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

COMPLETED RECALL

1 COMPLETED RECALL

INSTALL SWITCH AS PER RECALL

1 REMOVE AND REPLACE DEACTIVATION SWITCH AND CONNECTOR

RECALL 99S15 99S15 COMPLETED RECALL

RECALLED 99S15 PERFORMED

1 PERFORMED RECALL

PERFORMED RECALL 99S09

RECALL COMPLETE

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

99S15 99S15 PERFORM RECALL

COMPLETED RECALL

COMPLETED RECALL

REPLACED SWITCH PER RECALL

RECALL 99S15

63: PERFORM 99S15 RECALL

COMPLETED AS PER RECALL

PERFORM RECALL 99S15

RECALL 99S15

99S15 RECALL DEACTIVATION SWITCH

PERFORMED RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

64857 RECALL WARRANTY REMOVED DEACTIVATION SWITCH AND REPLACED THEN INSTALLED NEW PLUG PER RECALL

PERFORM RECALL 99S15 INSTALLED BRAKE SWITCH PER RECALL 99S15

RECALL 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

99S15 RECALL 99S15 RECALL

RECALL 99S15  
R&R CRUISE CONTROL DEACTIVATION SWITCH  
91120 RECALL 99S15 WARR. REPLACED DEACT SW. & HARDSHELL CONN. PER RECALL 99S15.  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
1 REPLACED CRUISE SWITCH AND CONNECTOR. BLEAD BRAKES AND TEST DROVE.  
PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
90237 PERFORMED RECALL TEST DROVE OK  
COMPLETED RECALL 99S15

99S15 RECALL  
PERFORM RECALL  
1 CAMPAIGN COMPLETED.  
94650 99S15 .5L RR CRUISE DEACTIVATOR SWITCH AND CONECTOR  
PERF. RECALL  
PERFORMED RECALL 99S15  
RECALL 99-S-15 - REPLACED CRUISE DEACTIVATION SW PER RECALL 99S15B .5 ADMIN .1  
REPLACE SPEED CONTROL SWITCH  
PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION  
PERFORMED RECALL AS REQUIRED 99S15  
94688 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 9937  
49409 REPLACE SWITCH PER LETTER.

PERFORM SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
REPLACED DEACTIVATION SWITCH PER SAFTEY RECALL 99S15.  
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
RECALL SWITCH  
110189 DEACTIVATION SWITCH RECALL PERFORMED RECALL  
35827 99S15B 0.5 HRS. SPEED CONTROL RECALL  
RECALL 99S15 PERFORMED RECALL 99S15, INSTALLED KIT 9G832, BLEED BRAKE SYS VERIFY.

1 INSTALL SWITCH  
24067 INSPECT AND REPLACE SWITCH AND CONNECTOR AS PER RECALL 99S15, ALSO HAD TO RESOLDER NEW ENDS ON WIRES DUE TO END BEING BAL  
VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT  
REPLACE CRUISE SWT PER RECALL  
RECALL REPLACED DEACTIVATION SWITCH  
REPLACED CRUISE DEACTIVATION SWITCH PER 99S15 RECALL RECALL STILL SHOWING OPEN ON OASIS. PREVIOUS REPAIR WAS AN INSPECTIC

PERFORM RECALL 99S15  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
99S15 REPLACE SWITCH  
OPEN RECALL PERFORM RECALL  
TECH REPLACED CRUISE CONTROL CABLE AS PER RECALL  
REPLACED NEW SPEED CONTROL KIT, INOP. PARTS WARR  
REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL  
REPLACE CRUISE DEACTIVATION SWITCH  
REPLACED THE SWITCH PER RECALL INSTRUCTIONS

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15  
 99S34 99 S 15 RECALL REPLACED CRUISE DEACTIVATION SWITCH & CONNECTOR  
 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
 42389 RECALL WARR COMPLETE. REPLACED SWITCH AS PER RECALL  
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA  
 99788 REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL 99S15  
 PERFORMED RECALL 99S15  
 PERFORMED RECALL  
 RECALL 99S15 99S15 COMPLETED RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH RECALL 99S15  
 RECALL REQUIRED RECALL PERFORMED REPLACED CRUISE SWITCH AND CONNECTOR  
 52221 RECALL 99S15 DID RECALL  
 CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPL SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR.  
 RECALL RECALL  
 REPL SPD CNTRL DEACTIVATION SW  
 99739 RECALL PERFORMED RECALL 99S16  
 PERFORMED RECALL

47233 RECALL DEACT SWITCH AS PER RECALL R&R SWITCH  
 RECALL 99S15  
 PERFORMED OPEN RECALL  
 INSTALL SWITCH AND CONNECTOR  
 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 28738 PERFORM RECALL  
 025 PERFORMED RECALL REPLACED SWITCH AND WIRE CONNECTOR  
 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECAL  
 RECALL REPLACED DEACTIVATION SWITCH PER RECALL

99S15 99S15

SPEED CONTROL RECALL

99S15 RECALL 99S15 REPAIRED AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL S15 0.8  
 PERFORM RECALL  
 REPLACED SPEED CONTROL SWITCH PER RECALL 99S15  
 119403 RECALL 99S15 .8  
 83224 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY  
 SEE ADVISOR FOR INFORMATION.  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 111988 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 57525 RECALL 99S15 REPL SWITCH AND CONECTOR ROAD TEST OK CRUISE OK  
 70750 RECALL .5 99S15B INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 INSTALL CRUISE DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS  
 RECALL REPLACE SWITCH AS PER RECALL 99S15

PERFORM RECALL  
INSTALLED KIT TO COMPLETE

PERF RECALL 99S15  
RECALL 99S15      REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
97220 RECALL REMOVED AND REPLACED DEACTIVATOR SWITCH, BLEED SYS, AND REPLACED CONN. COURTESY WASH  
REPLACED CRUISE SWITCH  
FACTORY RECALL. REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
148148 99S15  
RECALL. REPLACE SWITCH AS PER RECALL

PERFORM RECALL 99S15 DEACTIVATION SWITCH RECHECK OK 1  
1 COMPLETED RECALL PER INSTRUCTIONS  
PERFORM RECALL  
RECALL      INSTALL SWITCH  
INSTALLED NEW CRUISE DEACTIVATION SWITCH AND CONN., BLEED REAR BRAKES, TEST DRIVE OK  
PERFORMED 99S15 RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

FORD SAFETY RECALL      REPLACED SPEED DEACTIVATION SWITCH  
INSTALLED CONNECTOR  
RECALL 99S15      COMPLETED RECALL  
FACTORY RECALL. COMPLETED RECALL  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
COMPLETE RECALL 99S15  
PERFORMED SPEED CONTROL RECALL  
RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT  
25390 99S15B 0.5 0.5 PERFORM 99S15

RECALL R-R DEAC SW, AND CONNECTOR, RECKD OK.  
99S15      REPLACE SWITCH & CONN  
RPLCD SWITCH AND CONNECTOR  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
RECALL      PERFORMED RECALL 99S15  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
79101 PERFORM RECALL 99S15  
RECALL      99S15 REPLACE SWITCH CONNECTOR  
PERFORM RECALL      INSTALL SWITCH  
REPLACE SPEED CONTROL DISABLE SWITCH AND HARDSHELL PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND PLUG  
PERFORMED RECALL 99S15 DEACTIVATION SWITCH  
PERFORM RECALL 99S15  
REPL CRUISE CONTROL SWITCH  
DID RECALL  
PERFORM RECALL 8777  
95174 99S15B .5 PERFORM RECALL 99S15  
REPLACE DEACTIVATION SWITCH  
RECALL 99S15      COMPLETED RECALL 99S15

RECALL COMPLETE

COMPLETE SPEED CONTROL RECALL

COMPLETE RECALL

1 REPLACE SWITCH AND SHELL

86005 NOTE: BEFORE ATTEMPTING TO WORK ON CAR AFTER BATTERY INSTALLED, CHECK ENGINE LITE WAS ON TECH 879 INSTALLED BATTERY MOVED TO

PERFORMED 98S15 INSTALLED UPDATED SPEED CONTROL DEACTIVATION SWITCH

88707 RECALL WARRANTY INSTALL SPEED CONTROL DEACTIVATION SWITCH

98S15

REPLACE SWITCH & CONN

PERFORM RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

74285 INSTALLED A 98S15 CONNECTOR 4617

88388 REPLACE SWITCH PER RECALL 98S15

1 PERFORMED RECALL 98S15

SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL REPLACE CRUISE DEACTIVATION SWITCH

86040 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH

124883 RECALL 98S15 REPLACE SPD CONTROL ACTVATION SWITCH AS PER 98S15

173180 PERFORMED RECALL REPLACED SWITCH & CONNECTOR

1 PERFORM RECALL 98S15

A

RECALL COMPLETE

RECALL 98S15

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

98S15 RECALL

PERFORM SPEED CONTROL DEACT SW RECALL 98S15

78233 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY JH

1 REPAIRED AS PER RECALL 98S15

CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPL SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR.

INSPECT & REPLACED SPEED CONTROL DEACTIVATION SWITCH

D

INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S15B .50

RECALL R

RECALL

PERFORM RECALL 98S15 TECH 8788

RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH

98181 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15

PERFORM RECALL 98S15

REPLACED SWITCH PER RECALL

98S15 - PERFORMED RECALL, REPLACED SWITCH & CONNECTOR & RD. TEST.

RECALL REPLACED DEACTIVATION SWITCH PER RECALL

PERFORM RECALL PER ALL DEALER LETTER

RECALL

REPAIR PER RECALL 98S15

A

RECALL COMPLETE

RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

88388 REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

RECALL 99S15                      PERFORMED RECALL  
AS PER RECALL                      99S15 RECALL TO INSTALL SWITCH AND HARDSHELL CONNECTOR  
INSTALL SWITCH  
COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.  
. -DONE 99S15  
PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION  
REPLACE ACTIVATION SWITCH PER RECALL  
PERFORMED SAFETY RECALL 99S15  
PERFORM RECALL 99S15 SPEED CONTROL  
COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER 99S15 RECALL

REPLACE DEACTIVATION SWITCH AND BLEED BRAKES  
RECALL 99S16                      99S15B  
INSTALL UPDATE  
RECALL 99S16                      COMPLETED RECALL  
PERFORM RECALL 99S15

PERFORM SPEED CONTROL DEACT SW RECALL

REPLACED BRAKE DEACTIVATION SWITCH  
RECALL                      99S15 INSTALLED CRUISE DEACTIVATION SWITCH  
RECALL 99S15                      PERFORM RECALL 99S15  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
109033 PERFORM 99S15  
46459 99S15 WF REPLACE SWITCH AND CONNECTOR PER RECALL  
RECALL                      99S15  
PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
PER RECALL                      REPLACED SPEED CONTROL DEACTIVATION SWITCH  
INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL                      99S15  
130155 RECALL 99S15 PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR  
PERFORM RECALL PER ALL DEALER LETTER  
1 INSTALL SWITCH FOR CRUISE CONTROL  
REPLACE DEACTIVATION SWITCH  
99S15                      99S15

54612 RECALL 99S15 R&R SWITCH BLEED SYSTEM 2028  
PERFORM RECALL DEACTIVATION SWITCH  
PERFORMED AS PER RECALL  
1 RECALL COMPLETED 1  
REPLACED PRESSURE SWITCH AND CONNECTOR HARDSHELL PER RECALL  
REPLACED CONNECTOR AND SWITCH FOR CC CRTL

80125 INSTALLED SPEED CONTROL SWITCH

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15  
PERFORM RECALL 99S15  
25992 RECALL REPLACED CRUISE SWITCH 99S15B—.5 HR.

1 PERFORM RECALL REPLACE DEACTIVATOR SWITCH

PERF RECALL 99S15  
1 INSTALLED SWITCH  
1 COMPLETED RECALL 99S15  
73953 .50 DID PER RECALL  
RECALL 99S15

INSPECT AND PERFORM RECALL  
RECALL REPLACE SPEED CONTROL SWITCH  
RECALL REPLACED CRUISE SW  
RECALL RECALL  
OPEN RECALL 99S15 RECALL  
99S15 99S15 CRUISE CONTROL RECALL  
PERFORM RECALL PER PROGRAM  
RECALL 99S15 REPLACED SPEED CONTROL SWITCH PER RECALL  
REPL SWITCH PER RECALL  
PERFORM RECALL  
REPLACE SWITCH 99S15  
INSTALL SWITCH AND CONNECTOR  
INSTALLED CRUISE SWITCH  
1 PER RECALL REPLACE CRUISE DEACTIVATION SWITCH AND WIRING. OK  
COMPLETE RECALL  
99280 RECALL 99S15 RECALL 99S15  
123975 SERVICE WRITE UP INCORRECT, THIS RECALL IS FOR CRUISE SWITCH. INSTALLED CRUISE SWITCH AND CONNECTOR AS PER RECALL

RECALL RECALL  
PERFORMED RECALL  
96805 DID RECALL 99S15 TECH 3213  
PERFORMED RECALL 99S15  
REPL SWITCH PER RECALL  
38952 INSTALLED SWITCH LABOR OF 99S15B .5 HR

RECALL 99S15B RECALL 99S15B C-C ASS CORR 42  
99S15 REPLACED SWITCH AND CONNECTOR  
DEACTIVATION SWITCH 99S15  
RECALL PERFORM RECALL 99S15  
1 PERFORM RECALL  
PERFORM RECALL  
REPLACED RECALL PART  
REPLACED CRUISE CUT OFF SWITCH PERFORMED RECALL 99S15  
PER RECALL REPLACE THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
28370 PERFORM RECALL 99S15, REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR.



03000 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY

1 REPLACED SWITCH BLEED BRAKES

00000 PERF 00S15, INST KIT.

REPLACED CRUISE CABLE AS PER RECALL 00S15

COMPLETED RECALL

PERFORMED RECALL

117141 PERFORMED RECALL 00S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

00S15 00S15 RECALL

PERFORMED RECALL 00S15

REPLACED CRUISE CONTROL SWITCH

1 INSTALL NEW SWITCH AND CONNECTOR

07102 RECALL WARR INSTALLED SO PARTS AS PER RECALL

76172 REPLACED BRAKE SWITCH AS PER RECALL

RECALL ~~RECALL~~ BLEED BRAKES RECALL ~~RECALL~~

SPEED CONTROL RECALL?

D

30078 RECALL W PERFORM 00S15 RECALL

107052 COMPLETED RECALL AS PER 00S15 INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

100031 INSTALLED SW. AND SHELL AS PER RECALL

RECALL RECALL

PERFORM RECALL

REPL DEACTIVATION SWITCH PER RECALL

11304 REPLACE BRAKE DEACTIVATION SWITCH

PERFORM RECALL

RECALL 00S15 RECALL 00S15

FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

00S15 RECALL

INSTALL DEACTIVATION SWITCH PER RECALL

01712 00S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH TEST DRIVE CRUISE RESTORED

00730 00S15 RECALL INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SW AND HARNESS PLUG AS PER RECALL 00S15

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

REPLACED SWITCH AS PER RECALL

REPLACED SPEED CONTROL SWITCH AS PER CAMPAIGN

OTHER 00S15 PERFORM RECALL

00301 LABOR 00S15B\*\*\*.5\*\*\*ADMIN\*\*\*.1\*\*\* COMPLETED RECALL 00S15\*\*\*\*\*

00007 RECALL W PERFORMED RECALL 00S15 JH

PERFORM 00S15

RECALL 00S15

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

DID RECALL, REPLACED THE SWITCH AND THE CONNECTO

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE

PERFORMED RECALL

REPLACE SPEED CONTROL PER RECALL 00S15

SPEED CONTROL RECALL

PERFORM RECALL

PERFORM RECALL CLOSED BY WPI.  
RECALL COMPLETE RECALL  
REPLACE SWITCH AND CONNECTOR  
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS  
SWITCH 99S15  
PERFORMED RECALL

PERFORMED RECALL FOR CRUISE CONTROL MODIFICATION  
PERFORMED RECALL 99S15  
104484 RECALL REPL CRUISE SWITCH PER RECALL 87  
38212 COMPLETED RECALL AS PER 99S15 INSTRUCTIONS  
SWITCH REPL SPEED CONTROL DEACTIVATION SWITCH  
PERFORM RECALL 99S15 R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR & BLEED BRAKE SYSTEM  
PERFORM RECALL PER FORD NOTICE  
OPEN RECALL 99S15B

PERFORM RECALL  
1 PERFORM RECALL 99S15  
RECALL 99S15 REPLACED SWITCH  
SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
RECALL PERFORM RECALL 99S15  
PERFORM RECALL 99S15  
RECALL 99S15 PERFORMED RECALL 99S15  
118194 RR RECALL 99S15  
PERFORMED RECALL  
164710 99S15 INSTALL BRAKE SWITCH.  
REPLACE SWITCH PER RECALL 99S15  
RECALL 99S15 R&R SWITCH & CONNECTOR  
SPEED CNTRL DEACTVTN SWITCH REPLCMTPERF SAFETY RECALL 99S15  
97410 RECALL WARR. REPLACE SWITCH AND CONNECTOR SHELL PER 99S15.  
99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL  
99S15 REPLACE CRUISE SWITCH PER RECALL  
PERFORMED 99S15 RECALL  
00 99S15

PERFORMED RECALL  
158225 REPLACED SWITCH PER RECALL TECH 800  
RECALL 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL  
RECALL 99S15 RECALL 99S15  
PERFORM RECALL  
74718 REPLACED SPEED CONTROL SWITCH AND CON, 8-2 8274  
99S15 RECALL PERFORMED 99S15  
NOT OPERATING PROPERLY SPEED CONTROL - TEST  
61890 PERFORMED 99S15, INSTALLED NEW SWITCH AND CONNECTOR, RETEST OK.  
RECALL INSTALL SWITCH

PERFORMED RECALL

RECALL                      DID RECALL

RECALL                      98S15

REPLACE SWITCH PER RECALL ADMIN.1

RECALL 98S15                      RECALL PERFORME

REPLACE SWITCH AND HARDSHELL

RECALL                      98S15 RECALL

ROAD TEST, PIN POINT TEST AS PER SHOP MANUAL, REPLACE DEACTIVATOR SWITCH TO CORRECT CONCERN, ROAD TEST OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH

77616 PERFORMED RECALL 98S15

A99                      98S15

64811 RECALL RECALL REPLACED SPEED CONTROL DISENGAGE PRESSURE SWITCH AND CONNECTOR PER 98S15 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH & CONNECTOR PER RECALL

REPLACED SWITCH AND CONNECTORS PER RECALL

RECALL NOTICE

DIAG AND PERFORMED 98S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW

RECALL 98S15                      98S15

PERF. RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH AS PER RECALL

PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION

COMPLETE RECALL

INSTALL DEACTIVATION SWITCH AS PER RECALL

INSTALL SPEED CONTROL DEACTIVATION SWITCH & CONNECTORS PER 98S15 RECALL SPECS.

71495 TECH 679 PERFORMED RECALL 98S15 CRUISE SWITCH

113858 REPLACE SWITCH AND CONNECTOR PER RECALL

PERFORMED RECALL 98S15

98S15                      98S15

REPLACE SWITCH

RECALL COMPLETE

X                      RECALL

PERFORM RECALL 98S15

RECALL                      98S15 REPLACED SWITCH

PERFORMED RECALL 98S15

RECALL                      98S15 DONE REPLACED SWITCH

FACTORY RECALL COMPLETED RECALL

INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15

X                      98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS

REPLACED DEACTIVATION SWITCH AND CONNECTOR

REPLACED PARTS PER RECALL

PERFORMED 98S15B

INSTALLED SWITCH AND CONNECTOR.  
 PERFORM RECALL 99S15.  
 99S15, PERFORMED RECALL  
 99S15 RECALL PERFORMED  
 RECALL 99S15 REPLACED SWITCH  
 99S15 INSTALL SPEED CONTROL SWITCH  
 CAMPAIGN COMPLETED  
 RECALL 99S15 REPLACED SWITCH  
 104930 RECALL 99S15 0.5  
 REPLACE SPEED CONTROL SWITCH PER RECALL  
 88909 RECALL 0.5 INSTALLED NEW BRAKE SWITCH AND CONNECTOR 99S15B  
 RECALL 99S15 RECALL 99S15  
 PREFORM RECALL 99S15  
 PREFORM RECALL PER BULLETIN  
 RECALL 99S15  
 188867 REPLACED BRAKE SWITCH.  
 REPLACED DEACTIVATION SWITCH  
 C 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 PERFORM RECALL 99S15 INSTALL BRAKE PRESSURE SWITCH PER RECALL 99S15  
 1 PERFORM RECALL 99S15  
 DO RECALL 99S15  
 1 PERFORM RECALL  
 1 PERFORM RECALL  
 RECALL 99S15B  
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 REPLACED DEACTIVATION SWITCH  
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 PERFORMED CRUISE CONTROL RECALL PER FORD  
 REPLACED CONNECTOR AND SWITCH PER RECALL.  
 RECALL REPAIR  
 A99 99S15  
 PER RECALL  
 PERFORM RECALL AS PER NOTICE  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 PERFORM RECALL  
 77794 INSTALL NEW SWT.  
 RECALL COMPLETED  
 RECALL NOTICE  
 28902 PREFORM RECALL PER LETTER

57547 PERFORMED RECALL 99S15 BRAKE SWITCH OK FW. SEE P-A FOR MAIN. SER. P-A 26.  
 REPLACE SWITCH AS PER RECALL  
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 DEACTIVATION SWITCH AND CONNECTOR. REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 PERFORM RECALL  
 R AND R SWITCH PER RECALL.  
 RECALL 99S15 COMPLETE RECALL 99S15

INSTALLED DEACTIVATION SWITCH  
80889 RECALL 98S15 INSTALL CRUISE DEACT SWITCH  
RECALL 98S15 REPLACED SWITCH

PERFORMED RECALL  
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL T  
RECALL PERFORMED  
RECALL 98S15 REPLACED SWITCH  
REPLACE SWITCH AND HARD SHELL  
PERFORM RECALL RECALL PERFORME  
1 PERFORMED RECALL 98S15 DEACTIVATION SWITCH CONNECTOR AND SWITCH  
.....INSTALL SWITCH AND CONNECTOR AS PER RECALL  
RECALL 98S15 RECALL 98S15  
34194 DUE 98S15 RECALL NOTE TRANS FLUID SHOULD HAVE BEEN CHANGED AT 30000 AND FLUID TURNING BROWN NEEDS TRANS SERVICE 8002N THF  
1 RECALL COMPLETED

98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
98S15 PERFORMED RECAL  
PERFORM 98S15 AS INSTRUCTED  
REPL CRUISE CONTROL SWITCH  
48177 WF RENEW HARD SHELL CONNECTOR AND SWITCH  
RECALLED 98S15 PERFORMED  
RECALL PERFORM RECALL 98S15  
98143 RECALL COMPLETE. REPLACED SWITCH AND CONNECTOR  
REPLACE SWITCH

REPLACED DEACTIVATION SWITCH  
RECALL 98S15 RECALL, REPLACED SWITCH  
OK AND REPAIR PER RECALL INFO

RECALL 98S15 REPLACED SWITCH  
REPLACE SWITCH AND HARD SHELL  
PERFORMED CAMPAIGN 98S15B DONE.  
PERFORMED 98S15B  
INSTALL SWITCH AND HARD SHELL

COMPLETE RECALL  
85780 PERFORMED RECALL 98S15 - REPLACED SWITCH  
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
PERFORMED RECALL  
104044 REPLACED CRUISE SWITCH  
PERFORMED RECALL 98S15 PERFORM PERMANENT REPAIR ON CRUISE CONTROL--AS PER RECALL REPLACED BRAKE PRESSURE SWITCH  
RECALL 98S15 REPLACED SWITCH  
OPEN RECALL 98S15 PERFORMED RECALL 98S15  
RECALL R-R DEAC SW, R-R CONNECTOR, INSTALLED NEW, RECKD OK.  
PERFORMED RECALL

40903 99S15B 0.5 HRS. SPEED CONTROL RECALL

COMPLETE RECALL

PERFORMED RECALL 99S15 AND CHECKS OK

SPEED CONTROL SWITCH 99S15 RECALL

REPLACED BRAKE DEACTIVATION SWITCH

RECALL REPLACE DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED SWITCH PER RECALL

REPLACE SWITCH PER RECALL

PERFORM RECALL 99S15 CRUISE CONTROL DEACTIVATION SWITCH

RECALL 99S15

RECALL 99S15

99S15B

REPLACE DEACTIVATION SWITCH

99S15

99S15 RECALL, INSTALL NEW SWITCH & CONNECTOR

COMPLETE RECALL

77732 RECALL 99S15. REPLACE CRUISE SWITCH AND CONNECTOR.

RECALL PERFORMED RECALL-CRUISE INOP. NOT CONNECTED WITH RECALL. NO REPAIRS MADE AT THIS TIME

PERFORMED 99S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH 1

PERFORM RECALL AS PER NOTICE

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 99S15

PERFORM RECALL ON CRUISE DEACT SWITCH

COMPLETED RECALL, REPLACED DEACTIVATION SWITCH

CHECKED OASIS. REPLACE SPEED CONTROL DEACTIVATION SWITCH ROADTEST

BOXB REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

75427 REPLACE SWITCH AND CONNECTOR PER RECALL

REPLACED SPEED CONTROL SWITCH FOR RECALL

REPAIR AS PER RECALL

58980 99S15 RECALL WARRANTY REMOVED SPEED CONTROL SWITCH AND CONNECTOR AND REPLACED THEM WITH NEW 3314

MODIFIED PER RECALL

PERFORMED RECALL

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

PERFORMED RECALL 99S15

113723 INSTALLED CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

RECALL 99S15 DONE

99S15 CRUISE CONTROL 99S15

COMPLETE RECALL

PERFORM RECALL

PERFORMED RECALL 99S15

RECALL 99S15 - REPLACE DEACTIVATION SWITCH COMPLETE

82497 REPLACE SWITCH AND CONNECTOR PER 99S15

NO PARTS IN STOCK COMPLETED RECALL AS OUTLINED REMOVED DEACTIVATION SWITCH AND INSTALLED NEW SWITCH AND CONN. THANK YOU

99S15 PERFORMED RECALL

98S15 98S15 REPLACED CRUISE DEACTIVATION SWITCH  
RECALL RPEIAR  
PERFORM RECALL PER INSTRUCTIONS  
RECALL REPLACE CRUISE DEACT SWITCH  
98S15 98S15  
REPLACED DEACTIVATION SWITCH  
138381 R-R SW PER RECALL  
RPL SWITCH PER 98S15  
SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 98S15

RECALL 98S15  
RECALL DONE  
98S15 REPLACE SWITCH  
RECALL 98S15 REPLACED SWITCH AND CONNECTOR PER RECALL  
PERFORMED RECALL 98S15 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK  
COMPLETED RECALL  
PERFORM RECALL KIT B  
PERFORM RECALL 98S15B  
PERFORMED RECALL  
98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR

COMPLETE RECALL  
RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
98S15 98S15  
PERFORM RECALL  
RECALL CRUISE CONTROL RECALL 98S15  
SPD CTRL DEACTIVATION SW REPLCMTPERFORMED RECALL 98S15  
COMPLETE RECALL  
INSTALLED SPEED DEACTIVATION SESOR  
RECALL 98S15 COMPLETED  
48820 98S15 PERFORMED RECALL  
R&R CRUISE SWITCH  
RECALL 98S15  
PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH.  
REPLACE DEACTIVATION SWITCH  
90090 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR  
98S15 98S15  
PBARS-AUTH# PER FORD RECALL HOTLINE CHECKED UNIT AND FOUND UNIT HAD FIRE DAMAGE-ADVISED FORD TECH INSPECTED UNIT AND REPLACED I  
REPLACED SPEED CONTROL ACT SWITCH AND HARD SHELL CONN. PER RECALL 7548  
REPAIR AS PER RECALL 98S15.  
INSTALLED DEACTIVATION SWITCH AS PER RECALL  
PERFORMED RECALL  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
98S15B RECALL 3 PERFORM RECALL

RECALL 98S15

PERFORMED 99S15B

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

024 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL AS PER FORD SPECIFICATIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH SWITCH WITH UPDATED KIT

PERFORMED RECALL AS PER INSTRUCTIONS 99S15

PERFORMED 99S15 RECALL

PERFORMED RECALL 99S15

86018 PERFORM RECALL 99S15 REPLACE DEACTIVATION SWIC

PERFORM RECALL

99S15

99S15 RECALL R&R CRUISE CONTROL BRAKE CANCEL SWITCH

99S15 RECALL

RECALL 99S15

PERFORM RECALL

INSTALL SWITCH

RECALL

99S15

CRUISE SWITCH RECALL

PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.

RECALL COMPLETED

31874 INSTALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORMED RECALL

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

VEHICLE WAS TOWED IN SWITCH BURNT UP AND MELTED ALL THREE HARNESS WIRES ABOVE IT PERFORMED RECALL AND ALSO CHANGE ALL THREE MU

99S15

REPAIRED AS PER RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

REPLACE SWITCH AND HARD SHELL

PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL CABEL AND RECHECK OK

PERFORM RECALL 99S15 REPL SWT AND CONNECTOR.

REPLACE BRAKE PRESSURE SWITCH PER RECALL

RECALL COMPLETE

REPLACED DEACTIVATION SWITCH AS PER RECALL

RECALL

99S15 REPLACED SWITCH

INSTALL BRAKE KIT

#N006#

99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS PER FORD

PERFORMED RECALL

COMPLETED 99S15

INSTALL DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS

99S15

99S15

PERFORM RECALL. REPLACE CRUISE CONTROL DEACTIVATION SWITCH.



COMPLETED RECALL, INSTALLED DEACTIVATION SWITCH AND CONN ASSY  
99: PERFORMED 99S15 RECALL, REPLACE BRAKE SENSO  
REPL CRUISE CONTROL SWITCH  
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
78783 99S15B 0.5 HRS. SPEED CONTROL RECALL  
RECALL REPLACE SWITCH AND CONNECTOR PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
RECALL RECALL  
PERFORMED RECALL 99S15  
99S15 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
REPLACE SWITCH AND CONECTOR  
COMPLETE RECALL 99S15  
44742 PARTS REPL SPEED CONTROL DEACTIVATION SWITCH 9G852 THREADS STRIPPED

RECALL CRUISE SWITCH  
REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL  
51078 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL  
COMPLETED RECALL  
99S15 REPLACED DEACTIVATION SWITCH  
1 PERFORM RECALL

PERFORM RECALL 99S15  
122230 INSTALLED BRAKE KIT PER RECALL  
REPLACE FAILED SWITCH  
RECALL SPEED CONT REPLACE DEACTIVATION SWITCH  
INSTALLED NEW SWITCH PER RECALL  
PERFORMED RECALL  
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
1 REPLACED SPEED CONTROL SWITCH PER RECALL  
INSTALLED SWITCH PER RECALL  
RECALL COMPLETED  
PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL CABLE

REPLACED DEACTIVATION SWITCH PRIE RECALL 99S15  
99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT  
FORD RECALL REPLACED DEACTIVATION SWITCH.  
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
PERFORMED RECALL 99S15 INSTALLED BRAKE PRESSURE SWITCH. ROAD TEST AFTER RECALL  
REPLACED SWITCH  
RECALL COMPLETED

52870 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATI SWITCH  
REPLACED SPEED CONTROL DEACTIVATE SWITCH PER RECALL 99S15B  
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
99S15 99S15  
PERFORMED RECALL  
PERFORM RECALL. REPLACE SPEED CONTROL DEACTIVATION SWITCH 99S15

REPAIR AS PER RECALL 99S15.  
 PERFORMED RECALL 99S15  
 REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 1 REPLACED SPEED CONTROL SWITCH PER RECALL  
 128110 RECALL DONE  
 99S15 PERFORMED RECALL  
 81519 WARR INSTALLED SPEED CONTROL DEACT SWITCH AS PER RECALL 99S15  
 RECALL CRUISE CUT OFF SWITCH  
 1 PERFORM RECALL AS PER INSTRUCTIONS  
 RECALL 99S15 REPLACED CRUISE DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15  
 83404 99S15 .8

43341 REPLACE DEACTIVATION SWITCH 99S15B 0.5 ADMIN 0.1  
 1 REPLACE BRAKE SWITCH AND CONN PER RECALL  
 1 PERFORMED RECALL  
 SERVICE INSTALLED SWITCH PER RECALL

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH KI  
 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 99S15 RECALL PERFORM RECALL

PERFORMED RECALL  
 OPEN RECALL PERFORMED RECALL 99S15  
 PER NOTIFICATION RECALL 99S15 RENEW CRUISE CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15 INSTRUCTIONS  
 REPLACE DEACTIVATION SWITCH  
 CRUISE RECALL DONE PER FACTORY  
 COMPLETE RECALL  
 120035 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0937  
 1 PERFORM RECALL  
 1 PERFORM RECALL  
 PERFORM RECALL  
 130072 REPAIR PER 99S15B 0.5  
 ...REPLACE SWITCH AND CONNECTOR AS PER RECALL # 99S15  
 1 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH-99 99S15B  
 99S15 99S15  
 99S88 DID RECALL 99S15 LABOR OP.- 99S15B- 0.5 HRS. 8-27-99  
 INSTALL SWITCH PER RECALL 99S15  
 COMPLETE RECALL 99S15, SWITCH AND CONNECTOR  
 1 COMPLETED RECALL 99S15  
 112287 INSTALL RECALL PIECES  
 C INSTALL SWITCH AS PER RECALL  
 RECALL PERFORMED  
 RECALL COMPLETE

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

1 PERFORM RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACED BRAKE DEACTIVATION SWITCH

RECALL 99S15 PERFORMED RECAL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 99S15 REPLACED SPEED CONTROL SWITCH

51251 WARR RECALL; REPLACE DEACTIVATOR SWITCH AND CONNECTOR

PERFORM RECALL 99S15

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.

93219 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 TEST OK

50048 RECALL W/ INSPECT REPLACE DEACTIVATION SWITCH AND CONNECT OR PER 99S15 S4 9830

REPLACED SWITCH

99S15 PERFORMED RECALL

1 RECALL COMPLETED

RECALL COMPLETED

37577 REPLACE THE CRUISE DEACTIVATOR SWITCH 99S15B 0.5 HRS. TECH 2112

REPLACE DEACTIVATION SWITCH AS PER RECALL

99S15 99S15

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

REPLACED DEACTIVATION SWITCH

1 REPLACED SWITCH PER RECALL

CAMPAIGN COMPLETED

1 PERFORMED 99S15 RECALL 794 WARRANTY

1 REPLACE DEACTIVATION SWITCH

RECALL COMPLETED CRUISE SWITCH RECALL

COMPLETE INSTALLED SWITCH AS PER RECALL

82874 WT RECALL 99S15

CHECKED OASIS. INSTALLED SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

91442 99S15 INSTALLED A BRAKE KIT PER THE RECALL, RETESTED OK

R AND R SPEED CONTROL SWT PER RECALL

104353 RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL

84734 RECALL 99S15 RECALL 99S15

. REMOVE TAPE AND SECURE DEACTIVATION SWITCH 99S15E.3

PERFORMED RECALL

REPLACE SWITCH PER RECALL

REPLACE DEACTIVATION SWITCH PER 99S15

PERFORMED RECALL 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

INSTALLED BRACKET.

RECALL SW REPL

COMPLETE RECALL 99S15

INSTALL DEACTIVATION SWITCH

RECALL 99S15B DONE REPLACED CABLE

PERFORM RECALL

RECALL SW REPL

REPLACED DEACTIVATION SWITCH PER RECALL  
38092 RECALL W PERFORMED RECALL 98S15  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

122921 RECALL 98S15 PERFORMED 98S15 PER INSTRUCTIONS  
1 REPLACED SPEED CONTROL SWITCH  
92812 R-R SW  
RECALL 98S15 PERFORMED 1  
RECALL COMPLETE  
98S15 98S15  
108832 RECALL WPR40 INSTALL CRUISE CONTROL DISCONNECT SWITCH.  
PERFORM RECALL  
RECALL 98S15  
RECALL REPLACE BRAKE SWITCH AND PLUG HARNESS PER RECALL  
REPLACE BRAKE PART PER 98S15

89084 98S15B 0.5 ADMIN 0.1  
98S15B .5 ADMIN .1 REPLACE SPEED CONTROL SWITCH  
RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15

1 REPLACE SWITCH AND SHELL.

32873 RECALL 98S15 RECALL 98S15 DEACTIVATION SWITCH  
PERFORMED RECALL  
RECALL REPLACE SWITCH; BLEED BRAKES  
X 98S14 REPLACE WIRE CONNECTOR AND INSPECT FOR HEAT DAMAGE  
PERFORMED RECALL 98S15  
RECALL SW REPL  
80083 WT REPLACED BRAKE SWITCH  
PERFORMED OPEN RECALL  
49880 RECALL 98S15 0.5 HRS DID RECALL 98S15B  
PERFORM RECALL  
1 PERFORM RECALL  
REPAIR AS PER RECALL  
PERFORM RECALL  
PERFORM RECALL 98S15  
1 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL CRUISE CUT OFF SWITCH  
COMPLETE RECALL 98S15  
INSTALLED KIT TO COMPLETE  
80258 REPL CRUISE DEACTIVATION SWITCH PER RECAL

RECALL 98S15 REPLACED SPEED CONTROL SWITCH PER RECALL  
27114 INSTALL SPEED CONTROL SWITCH PER RECALL

INSTALL WS KIT 98S15 RECALL PERFORMED

99S15B  
 RECALL CRUISE SW  
 SPEED CNTRL DEACTVTN SWITCH REPLCMTPERF SAFETY RECALL 99S15  
 RECALL REPAIR  
 REPLACE SPEED CONTROL SWITCH, BRAKE ADAPTOR CRACKED AND HAD TO BE REPLACED.  
 REPLACE SPEED CONTROL SWITCH, BRAKE ADAPTOR CRACKED AND HAD TO BE REPLACED.  
 1 REPLACE DEACTIVATION SWITCH  
 RECALL INSTALL DEACTIVATION SWITCH AS DIRECTED  
 UNK PERFORMED RECAL  
 1 INSTALLED KIT RECALL COMPLETED  
 COMPLETE RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 99S15 CRUISE  
 PERFORM RECALL 99S15  
 RECALL 99S15  
 1 REPLACED SPEED CONTROL SWITCH 99S15 RECALL  
 REPLACED SWITCH AND CONNECTORS  
 99S15 PERFORM RECALL 99S15  
 60079 WARR DONE RECALL 99S15 REPLACE BRAKE REPAIR KIT  
 REPLACE SWITCH  
 99S15 99S15  
 REPL SWITCH 99S15  
 PERFORMED RECALL  
 RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 NAC REWORK AS PER RECALL  
 0 RECALL 99S15  
 PERFORM RECALL 99S15-REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 60585 0.50 PERFORM RECALL 99S15 AND REPLACE HARD SHELL CONNECTOR  
 RECALL CRUISE SW SW REPL  
 RECALL PERFORM RECALL 99S15 SPEED CONTROL  
 REPLACED DEACTIVATION SWITCH AND REPAIRED CONNE CTOR  
 167262 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL  
 1 PER RECALL REPLACE SWITCH  
 99S15 COMPLETE  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.  
 RECALL PERFORM RECALL # 0836  
 67335 INSTALLED NEW CRUISE DEACT. SWITCH AND CONNEC.  
 RECALL COMPLETE  
  
 1 PERFORMED RECALL 99S15. REPLACE DEACTIVATION SWITCH.  
 PERFORMED OPEN RECALL  
 UNK PERFORMED RECAL  
 RECALL REPAIR  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 COMPLETE RECALL 99S15  
 44583 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 95017 99S15 S-W RECALL WT REPLACED SPEED CONTROL DEACTIVATION S-W AND CONNECTOR PER RECALL

RECALL 99S15 REPLACE C-C SW  
 PERFORMED RECALL  
 COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15 REPLACE SPEED CONTROL SWITCH  
 1 PERFORMED RECALL 99S15.TEC 126 WARR  
 REPLACED SWITCH AS PER RECALL 99S15  
 FORD CAMPAIGN MI OUT 87,417 REPLACE SPEED CONTROL BRAKE SWITCH PER RECALL 99S15.  
 RECALL 99S15  
 48055 RECALL W-F REPLACE SWITCH.  
 RECALL 99S15  
 RECALL REPIAR  
 REPLACE DEACTIVATION SWITCH  
 RECALL 99S15 RECALL 99S16  
 58804 99S16 B 0.5 REPL SW  
 70882 W. REPLACE CRUISE SWITCH PER RECALL

PERFORMED RECALL  
 RECALL 99S15  
 PERFORMED RECALL 99S15  
 RECALL 99S15 INSTALLED BRAKE KIT AS PER RECALL  
 PERFORM RECALL  
 58849 PERFORM RECALL 99S15, REPLACE CRUISE CONTROL SWITCH WITH NEW CONNECTOR.  
 REPLACED DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH AND REPAIRED WIRE  
 PERFORMED RECALL  
 INSTALL SWITCH PER RECALL  
 PERFORM 99S15 RECALL REPLACED SWITCH AND CONNECT  
 PERFORMED RECALL 99S15  
 RECALL COMPLETED  
 99S15 99S15  
 REPLACED SWITCH

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION  
 28338 99S15 W REPLACE SPEED CONT. SWITCH  
 1 RECALL PERFORMED  
 RECALL CRUISE REPL SW  
 REPLACED DEACTIVATION SWITCH PER RECALL  
 PERFORMED RECALL AS PER 99S15  
 41005 99S15 PERFORMED RECALL 99S15  
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 PERMF RECALL 99S15  
 PERFORMED RECALL  
 30531 RECALL 99S15 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL  
 REPLACE DEACTIVATION SWITCH PER RECALL 99S15  
 PERFORMED RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 R AND R SPEC CONTROL CABLE AS PER RECALL

CAMPAIGN COMPLETED

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL.

99S15

99S18

RECALL

99S15 REPLACED SPEED CONTROL SWITCH

RECALL

REPLACE SWITCH PER RECALL

INSTALLED DEACTIVATION SWITCH AND HARDSHELL PER 99 S 15 RE- CALL

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

INSTALL DEACTIVATION SWITCH PER 99S15

92911 99S15B 0.5 - ADMIN 0.1 RECALL

150188 99S15 RECALL WARRANTY REMOVED SPEED CONTROL DEACTIVATION SWITCH AND REPLACED IT AND THE CONNECTOR WITH NEW 3814

INSTALL CRUISE DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK TO RELEASE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15.

08

COMPLETE RECALL

113631 RECALL 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

1 REPLACED SWITCH AND CONNECTOR AS PER 99S15 RECALL

RECALL 99S15

RECALL DONE

REPLACE SWITCH

PERFORMED RECALL

V

99S15 PERFORMED RECALL

PERFORM RECALL

REPLACED SPEED CONTROL SWITCH AND CONNECTOR, PER RECALL. 4827

PERFORM RECALL

SPEED CONTROL STICKING

PERFORMED 99S15 RECALL

RECALL

DONE

38831 NOT APPLICABLE

99S15

SPEED CONTROL RECALL

14001 W.. REPLACE CRUISE SWITCH PER RECALL(CC82)

138772 RECALL 99S15B 0.5 REPLACE DEACTIVATION SPEED CONTROL SWITCH

PERFORM RECALL

99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION

64045 W PERFORM RECALL

69727 REPLACED CRUISE SWITCH PER RECALL

SERVICE PUBLICATION

99S15 REPLACED SWITCH

PERFORMED RECALL

99S15

REPLACE CONNECTOR AND SWITCH

RECALL COMPLETED

PERFORMED RECALL 99S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

90486 RECALL W-F REPLACE SPEED CONTROL SWITCH

REPLACED SWITCH AND CONNECTOR AS PER RECALL

SPEED CONTROL DEACTIVATION SWITCH REPLACE 99S15B PERFORMED RECALL 99S15B

PERFORM RECALL 99S15

RECALL 99S15 PERFORMED RECAL  
99S15 RECALL  
PERFORMED RECALL 99S15 1  
RECALL CRUISE SW REPL  
40473 INSTALL SOP RECALL 99S15, DEACTIVATION KI  
REPLACE SPEED CONTROL CABLE AS PER RECALL 99S15  
49284 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH  
1 PERFORM RECALL 99S15  
REPLACE DEACTIVATION SWITCH PER RECALL 99S15  
RECALL 99S15

RECALL 99S15 PERFORMED  
115108 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACT SWITCH AND CONNECT OR PER RECALL 99S15.  
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORM RECALL PER INSTRUCTION RECALL PERFORMED PER INSTRUCTION .3 99S15E .3  
RECALL RECALL  
99S15  
58738 RECALL 99S15B 0.5 REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15.

REPLACE CRUISE CONTACT SWITCH  
REPLACED SWITCH  
78791 RECALL INSTALLED CRUISE DEACTIVATION SWITCH AND CONNECTOR  
130795 RECALL WPB40 INSTALL CRUISE CONTROL DISCONNECT SWITCH.  
X 99S15  
REPLACED DEACTIVATION SWITCH.  
REPLACE DEACTIVATION SWITCH AS PER RECALL  
RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 99S15B .5 - ADMIN .1  
RECALL

REPLACE CRUISE CONTROL SWITCH  
RECALL COMPLETED  
RECALL 99S15 COMPLETED RECALL 99S15 (CRUISE CONTROL SWITCH) HAS BEEN COMPLETED  
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN.  
INSTALLED PARTS AS PER RECALL  
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORM RECALL  
99S15 99S15 RECALL

133233 R-R SW  
RECALL CAMPAIGN PERFORMED RECALL CAMPAIGN, REPLACED DEACTIVATION SWITCH  
REPLACE DEACTIVATION SWITCH

D  
77818 WF REPLACED RECALL  
RECALL REPAIR

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL  
114187 PERFORMED RECALL 99S15.



REPLACE SWITCH AND HARD SHELL  
REPL SPD CNTRL DEACTIVATION SW  
SPEED CONTROL DEACTIVATION SWITCH 98S15  
APPLIED RECALL 98S15  
RECALL 98S15  
COMPLETE RECALL 98S15  
PERFORMED RECALL 98S15. 98S15B .5HRS LABOR  
RECALL RECALL

29867 RECALL 98S15B 0.5HRS INSTALL NEW SWITCH AND CONNECTOR TIG72  
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15.  
REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR, BLEED BRAKES.  
PERFORM RECALL 98S15

130847 RECALL 98S15B 0.5 REPLACED CRUISE CONTROL DEACTIVATION SWITCH.

R & R CRUISE CONTROL DEACTIVATION SWITCH  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
REPLACE SWITCH AND HARNESS PER RECALL  
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
PERFORMED RECALL AS PER INSTRUCTIONS  
RECALL COMPLETED -DID 98S15B.

98S15-SPEED CONTROL 98S15-SPEED CONTROL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 98S15 - B - RECALL

81671 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATOR SWITCH & HARSHIELD CONNECTOR 5 WP

SUPPLEMENT #1 5-98 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

RECALL 98S15

RECALL 98S15 REPLACED DEACTIVATION SWITCH AS PER RECALL 98S15

PERFORM RECALL 98S15 98S15 00

RECALL 98S15 PERFORM RECALL 98S15

D

53024 PERFORMED RECALL 98S15 INSTALLED CRUISE K

REPLACED SPEED CONTROL SWITCH

RECALL 98S15 R&R SPEED CONTROL SWITCH

PERFORMED RECALL 98S15

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL RECALL COMPLETE

COMPLETE RECALL 98S15

92925 COMPLETED RECALL 98S15

REPLACE CRUISE DEACTIVATION SWITCH PER 98 S 15

98S15 RECALL RECALL

RECALL 98S15

PERFORM RECALL 98S15

OPEN RECALL PERFORM RECALL

95480 REPLACED DEACTIVATION SWITCH & CONNECTOR

RPLC DEACTIVATION SWITCH PER 99S15  
REPLACE DEACTIVATION SWITCH  
RECALL 99S15 PERFORMED 1  
INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL REPAIR  
110020 RECALL 99S15 REPLACE THE SPEED DEACTIVATION SWIT REPLACED THE SPEED DEACTIVATION SWITCH  
38867 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPLACE DEACTIVATION SWITCH PER RECALL  
66183 AS PER RECALL  
83532 RECALL W REPLACE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.  
CHECK AND PERFORM 99S15 DEACTIVATION  
PERFORMED RECALL 99S15  
RECALL 99S15 COMPLETED

1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH AND CONNECTOR  
77799 PERFORM RECALL 99S15

94783 99S15 RECALL 99S15 REPLACE DEACTIVATION SWITCH  
1 COMPLETED RECALL PER INSTRUCTIONS  
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE  
99S15 99S15  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRING HARD SHELL CONNECTOR. BLEED BRAKES.  
RECALL PERFORM RECALL 99S15  
28785 REPLACE CRUISE-BRAKE SWITCH  
REPL DEACTIVATION SWITCH PER RECALL  
RPLC CRUISE CTRL DEACTIVATION SWITCH PER 99S15  
62840 PERFORMED 99S15 RECALL  
RECALL 99S15 CRUISE CONTROL  
REPLACE CRUISE CONTROL SWITCH  
SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15  
RECALL RECALL  
PERFORMED RECALL  
REPLACE SWITCH CONNECTION PER 99S15.

85834 99S15 WARR REPLACED PARTS PER 99S15 RECAL  
REPLACE SPEED SWITCH  
INSTALL SWITCHG AND CONNECTOR PER RECALL

86216 99S15 R&R CRUISE CONTROL SWITCH  
PERFORM RECALL

REPLACED DEACTIVATION SWITCH PER SAFTEY RECALL 99S15.  
REPLACE CRUISE SWITCH PER RECALL  
78410 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
PROG 99S15 BRAKE REPAIR KIT  
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

LINK PERFORMED RECALL  
REPLACE CRUISE SWITCHES PER RECALL 99S15  
RECALL 99S15 RECALL  
RECALL PERFORMED  
INSTALLED DEACTIVATION SWITCH AS PER RECALL  
RECALL RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
39911 WARR PERFORM RECALL 99S15 SPEED CONTROL SWITCH AND CONNECTOR  
RECALL 99S15 - B - RECALL

PERFORM RECALL REPLACE SWITCH  
1 INSTALLED SWITCH  
REPLACE CRUISE CONTROL SWITCH  
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
99S15 RECALL 99S15 REPAIRED AS PER RECALL  
REPLACED SWITCH  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
COMPLETED RECALL  
NAC 99S15  
INSTALL SPEED CONTROL SWITCH AND SWITCH CONTROLLER, AS PER 99S15 CAMP.

R&R DEACTIVATION SWITCH  
COMPLETE RECALL. 99S15  
79941 REPLACE SWITCH AND HARD SHELL CONNECTOR AS OUTLINED IN RECALL  
PERFORMED RECALL  
99S15 REPL DEACTIVATION SWITCH  
99S15 RECALL  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
REPLACE SWITCH PER FORD RECALL  
PERFORMED RECALL 99S15  
RECALL 99S15B  
FACTORY RRECALL COMPLETED RECALL  
1 COMPLETED RECALL PER FORD INSTRUCTIONS. REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
RECALL PERFORMED RECALL 99S15.  
141117 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 6115  
RECALL PERFORMED  
INSTAL SWITCH  
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
1 PERFORMED RECALL 99S15, INSTALLED NEW DEACTIVATION SWITCH  
99S15 99S15  
RECALL PERFORM RECALL 99S15  
REPLACED DEACTIVATION SWITCH PER INSTRUCTIONS.  
REPLACE SPEED CONTROL SWITCH PER RECALL  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15 PER INSTRUCTIONS  
PERFORM RECALL  
RECALL 99S15 RECALL 99S15

REPLACE CRUISE SWITCH PER RECALL  
RECALL 99S15 REPLACE C-C SW  
INSTALLED DEACTIVATION KIT

1 INSTALL SPEED CONTROL SWITCH  
INSPECT AND REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
REPLACED CRUISE SWITCH PER RECALL

REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15  
RECALL PERFORMED RECALL 99S15.  
75488 99S15 W REPLACED SPEED CONTROL 0937  
COMPLETED FACTORY RECALL  
99S15B PERFORMED RECALL - REPLACED SWITCH  
PERFORM RECALL 99S15. INSTALL DEACTIVATION SWITC  
PERFORM RECALL-REPLACE SWITCH  
FACTORY RECALL COMPLETED RECALL  
1 REMOVE AND REPLACE CRUISE CONTROL SWITCH PER RECALL  
RENEW SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
INSPECT AND REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
PERFORM RECALL 99S15  
PREFORM RECALL  
RECALL REPLACED CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL

24741 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
REPLACE DEACTIVATION SWITCH PER RECALL  
39480 RECALL 99S15 6310 REPLACE SWITCH & PLUG G  
PERFORM RECALL 99S15  
58731 R-R SW PER RECALL  
49299 I DID THE RECALL 99S15.  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
PERFORM RECALL 99S15 REPLACE CONNECTOR AND SWIT

RECALL 99S15 PERFORM RECALL 99S15  
REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
REPLACED CRUISE DEACTIVATION SWITCH  
PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH PER 99S15  
106901 PERFORM RECALL 99S15. REMOVED SPEED CONTROL CUT OFF SWITCH AS PER RECALL. THREADS INSIDE CONNECTING BLOCK CAME OUT WITH:  
OPEN RECALL PERFORM RECALL  
131078 RECALL 0.5 REPLACED SPEED CONTROL SWITCH  
99S15 REPLACED DEACTIVATION SWITCH  
PERFORM RECALL  
62780 W REPLACE SWITCH 99S15 ME  
TECH REPLACED DEACTIVATION SWITCH AS REQUIRED  
117188 RECALL 99S15 PERFORMED RECALL  
PERF RECALL 99S15  
RECALL PERFORMED

SPEED CONTROL DEACT. SWITCH R&R DEACTIVATION SWITCH AS DIRECTED  
REMOVE AND REPLACE CRUISE CONTROL DEACTIVATION K

98S15 RECALL

RECALL 98S15 COMPLETED

PERFORMED RECALL

PERFORM RECALL 98S15 RECHECK OPERATION SYSTEM OK

PERFORM RECALL

1 PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR OPER 98S15B

REPL SPEED CONTROL DEACTIVATION 98S15

PERFORM SPEED CONTROL DEACT SW RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

REPLACE SWITCH

PERFORM 98S15 CRUISE CONTROL RECALL

PER RECALL

PERF RECALL

AS PER RECALL

98S15 RECALL TO INSTALL DEACTIVATION SWITCH & HARDSHELL CONNECTOR

RECALL

REPLACED DEACTIVATION SWITCH AS PER RECALL

REPLACE DEACTIVATION SWITCH

RECALL PERFORMED RECALL # 0836

RECALL

98S15 REPLACED SWITCH.

PERFORMED RECALL AS PER 98S15

83674 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15

73409 PERFORMED RECALL 98S15

REPLACE SPD. CONTROL DEACTIVATION SWITCH

RECALL COMPLETE

PERFORMED RECALL

PERFORM RECALL 98S15

33385 RECALL - CRUISE CONTROL SWITCH REPLACE SWITCH & CONNECTOR AS PER RECALL

98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN.

REPLACED SWITCH

REPLACE SWITCH AND HARNESS PER RECALL

PERFORM RECALL INSTALL REPAIR KIT

122548 98S15 W SCD SWITCH GA

63592 RECALL 98S15 INSTALL SWITCH AND CONNECTOR

1 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL

REPLACE SWITCH AND HARD SHELL

98S15 RECALL

98S15 REPAIRED AS PER RECALL

REPLACE BRAKE SWITCH & BLEED BRAKES

APPLIED RECALL 98S15

PERFORMED RECALL

PERFORM RECALL, REPLACE PRESSURE SWITCH AND CONECTOR.

REPLACE DEACTIVATION SWITCH PER RECALL

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR PER RECALL

REPLACE DEACTIVATION SWITCH

RECALL 98S15

PERFORM RECALL 98S15

52805 REPLACED THE SWITCH AND THE CONNECTOR FOR RECALL 99S15  
99S15 RECALL 99S15 REPAIRED AS PER RECALL  
1 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL RPEIAR  
88022 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

REPLACE PER RECALL

PERFORMED RECALL  
REPLACE SWITCH AND CONNECTOR  
42 REPLACED DEACTIVATION SWITCH AND RETESTED  
PERFORM 99S15 RECALL  
PERFORM RECALL  
58918 SWITCH RECALL RECALL COMPLETED  
REPLACED SPEED CONTROL SWITCH  
PERFORM RECALL 99S15  
99S15 99S15 REPLACED DEACTIVATION SWITCH  
PERFORM RECALL 99S15-SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15  
RECALL 99S15 99S15 COMPLETED RECALL  
REPLACE SW.  
48550 PERFORMED RECALL AND INSTALLED NEW SWITCH AND CONNECTOR FOR SPEED CONTROL.  
99S15-1827 REPLACED SPEED CONTROL DEACTIVATION SWITCH

111030 PERFORM 99S15 RECALL

PERFORMED RECALL  
1 PERFORM RECALL 99S15  
PERFORM RECALL  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
INSTALL SPEED CONTROL SWITCH  
85258 REPLACED SWITCH PER RECALL  
REPLACED BRAKE PRESSURE-SPEED CONTROL DE-ACTIVATION SW. AND CONNECTOR PER RECALL 99S15.  
PERFORMED RECALL 99S15 REPLACED SWITCH PROPORTIONING VALVE WAS STRIPPED OUT HAD TO REPLACE DIFFERENTIAL VALVE ASSEMBLY BLEED

1 08 REPLACED DEACTIVATION SWITCH PER RECALL  
AS PER RECALL 99S15 RECALL TO REPLACED DEACTIVATION SWITCH & HARDSHELL CONNECTO  
OPEN RECALL PERFORMED RECALL 99S15  
RECALL 99S15 PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
RECALL REPLACED CONNECTOR  
PERFORM RECALL  
99S15 RECALL PERFORMED.  
INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATOR SWITCH PER CUSTOMER NOTIFICATION.

98S15

98S15

PERFORMED RECALL PER FORD NOTICE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL #98S15

RECALL #98S15

COMPLETED RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 98S15

RECALL 98S15

PERFORMED RECALL 98S15

PERFORMED RECALL

45223 WARR PERFORMED RECALL 98S15

115307 RECALL PERFORM RECALL 98S15 AS PER INSTRUCTIONS ROAD TEST AND CHECK SPEED CONTROL OPERATION FOUND OK

PERFORMED RECALL 98S15

117719 INSTALLED RECALL

REPLACE KIT PER RECALL

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE SWITCH

02951 RECALL 98S15 WR RECALL 98S15 SPEED CONTROL ACTIVATION REPLACE CONNECTOR AND PRESSURE SWITCH RECHECK, PASS OK

PREFROM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH 1

E PERFORM RECALL

1 REPLACED DEACTIVATION AND CONNECTOR AS PER RECALL 98-S-15

OPEN RECALL

COMPLETE RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

TECH 145 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL 98S1

98S15 98S15 PERFORM RECALL REPLACED SWITCH

118252 PERFORM RECALL REPLACE SWITCH AND CONNECTOR

RECALL

98S15 REPLACE BRACKET FOR INERTIA SWITCH

78815 RECALL DID RECALL 98S15

1 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL

REPLACED DEACTIVATION SWITCH 98S15 REPAIRED PER RECALL

REPAIR AS PER RECALL 98S15.

FACTORY RECALL COMPLETED RECALL

PERFORM RECALL R.J SWITCH FOR CRUISE SYSTEM INSTALL NEW CONNECTOR

98S15 RECALL

PERFORM RECALL

98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT

98S15 INSTALL DEACTIVATION SWITCH AS PER RECALL 98S15  
REPLACED DISENGAGE SWITCH PER RECALL 98S15.  
RECALL; REPAIR PER RECA  
COMPLETED RECALL 98S15

A RECALL COMPLETE  
COMPLETED RECALL 98S15  
RECALL; REPLACE SWITCH  
88098 RECALL 98S15 0.5 REPLACED CRUISE CONNECTOR

PERFORM SPEED CONTROL MODIFICATION  
78538 RECALL WA PERFORM RECALL, REPLACE SWITCH AND CONNECTOR  
INSTALLED DEACTIVATION SWITCH KIT PER INSTRUCTIONS ADMIN  
REPACKED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTORS AS PER RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
98S15 REPLACED SPEED DEACTIVATION SWITCH  
RECALL; PERFORM RECALL 98S15  
INSTALLED SWITCH AND CONNECTOR  
ADD 98S15  
REPLACED DEACTIVATION SWITCH  
COMPLETE RECALL 98S15  
RECALL 98S15. CARRY OUT FACTORY RECALL AS DESCRIBED BY BULLETIN

83049 RECALL WARR REPLACE SWITCH AND CONNECTOR SHELL PER 98S15.

COMPLETED RECALL PER NOTIFICATION.  
RECALL 98S15 RECALL COMPLETED  
140584 RECALL .5 REPLACED SPEED CONTROL SWITCH PER RECALL  
111257 RECALL PERFORMED RECALL 98S15  
PERFORM RECALL 98S15

ADD 98S15  
REPLACE SWITCH PER RECALL  
RECALL COMPLETED

COMPLETED RECALL 98S15  
PERFORMED RECALL

98S15 98S15  
PERFORM RECALL 98S15 --REPLACE SPEED CONTROL SWITCH  
PERFORM SPEED CONTROL RECALL  
INSTALLED SPEED CONTROL SWITCH

RECALL; REPLACE SWITCH  
53080 INSPECT & INSTALL CRUISE SWITCH & BLEED SYSTEM AS PER 98S15 RECALL.  
48805 PERFORMED RECALL RETESTED OK

98S15 98S15  
COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
COMPLETED RECALL  
VERIFY R&R SWITCH AND CONNECTOR PER RECALL  
PERFORM RECALL 98S15  
REPLACED SWITCH



PERFORMED RECALL 99S15

1 ACCESS & REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15

42368 W PERFORM RECALL REPLACE DEACT SWITCH

REPLACE KIT PER RECALL

PERFORMED RECALL

PERFORMED RECALL 99S15 FOR SPEED CONTROL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

1 INSTALL UPDATED SWITCH AND CONNECTOR

PERFORM RECALL

PERFORMED RECALL 99S15

SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15 TO SPECIFICATIONS PER FORD MOTOR CO. REPLACED DEACTIVATION SWITCH AND

INSTALL DEACTIVATION SWITCH

PERFORM RECALL PER FORD NOTICE

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REPLACED SPEED CONTR

PERFORM RECALL

INSTALL KIT PER RECALL

99S15 99S15 RECALL REPLACED CRUISE SWITCH

OWNER NOTIF

PERFORMED RECALL

PERFORM RECALL

PERFORMED 99S15 SPEED CONTROL DEACTIVATION SWITCH RECALL INSPECTED. REPLACED SWITCH AND CONNECTOR AS PER RECALL. PERFORMED S

REPL SWITCH PER RECALL

REPLACE HARDSHELL CONNECTOR & SWITCH PER RECALL

130312 PERFORMED RECALL 99S15 REPLACEMENT OF SPEED CONTROL DEACTIVATION SWITCH AND AND PLUG.

REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL

99S15 99S15

PERFORM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH

1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.

RECALL 99S15

REPLACE KIT PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH DUE TO RECALL

COMPLETED RECALL 99S15, CRUISE CONTROL SWITCH

PERFORMED RECALL 99S15 INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED DEACTIVATOR AND SWITCH 99S15 REPAIRED PER RECALL

72159 REPLACED DEACTIVATION SWITCH AS PER RECALL# 9915

COMPLETED RECALL

REPAIR AS PER RECALL

69666 SAFETY RECALL 99S15 LABOR OF 99S15B 0.5 HRS. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 98S15  
181214 PERFORM RECALL 98S15  
SPEED CONTROL SWITCH 98S15 RECALL  
RECALL PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATOR  
98S15 SPEED CONTROL SWITCH RECALL MIL30867 REPLACED SPEED CONTROL SWITCH AND CONNECTOR AS PER RECALL.

REPLACE KIT PER RECALL  
INSTALLED SWITCH PER RECALL

RECALL REPLACED BRAKE SWITCH AS PER RECALL 98S15  
40091 PARTS AND SERVICE FROM RO 300844 42 90652 FOUND DEACTIVATION SWITCH TO BE LEAKING R AND I NEW SWITCH  
PERFORMED RECALL 98S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
108327 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
PERFORM RECALL

RECALL 98S15 REPLACED SPEED CONTROL AS PER RECALL

90557 REPLACE SWITCH & CONNECTOR

98S15 RECALL 98S15 RECALL COMPLETE

REPLACED CRUISE DEACTIVATION SWITCH

COMPLETE RECALL 98S15 REPLACE SPEED CONTROL SWITCH.

PERFORMED RECALL

INSTALL SWITCH AND CONNECTOR

PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTION

REPLACE SWITCH PER RECALL

1 INSTALLED SWITCH RECALL COMPLETED

98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL PERFORMED RECALL

PERFORMED RECALL AS OUTLINED 1

CHECK FOR RECALLS 98S15 OPEN PERFORM RECALL F

REPLACE SPEED CONTROL SWITCH PER RECALL

INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S15B .50

R & R SPEED DEACTIVATION SW PER RECALL 0100 T

R&R SWITCH PER RECALL 98S15

REPLACE SWITCH AND CONNECTOR AS PER RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRING CONNECTOR HARD SHELL BLEED BRAKES.

REPLACE SWITCH AND HARDSHELL CONNECTOR

RECALL INSTALLED CRUISE DEACTIVATION SWITCH

CC42 RECALL 98S15 98S15B-0.5-0.5 TOTAL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER 98S15 RECALL

RECALL 98S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH 98S15 PER RECALL

REPLACE KIT PER RECALL

X COMPLETED

MISC PERFORMED RECALL

93970 RECALL DID RECALL 98S15

94955 .50 DID PER RECALL RIDE LIGHT ON DASH AND RUN VERY BAD

PERFORMED RECALL 99S15.TEC 126 WARR  
74781 99S16 PERFORM RECALL REPLACE SWITCH AND CONNECTOR  
15733 PERFORM RECALL - BRAKE DE-ACTIVATION SWIT  
1 PREFORMED RECALL 99S15  
118254 OPEN RECALL 99S15 REPLACE SWITCH DONE REINSPECT OK  
REPLACED CRUISE DEACTIVATION SWITCH.  
PERFORM SPEED CONTROL RECALL

75820 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
1 PERFORMED RECALL 99S15  
COMPLETED RECALL  
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
22820 DEACTIVATION SWITCH RECALL R/R DEACTIVATION SWITCH AND CONNECTOR PER RECALL L,BLED BRAKES, AND CHECKED;OK.  
48548 REPLACE DE ACTIVATION SWITCH

F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
1 COMPLETED RECALL  
REPLACED SPEED CONTROL SWITCH AS PER RECALL 99S  
RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AD HARD-SHELL CONNECTOR

108806 REPLACED CRUISE SWITCH PER RECALL  
RECALL 99S15 COMPLETED  
RECALLED 99S15 PERFORMED  
RECALL 99S15 DONE  
90285 REPLACE SPEEDCONTROL DEACTIVATION SWITCH AND CONECTOR  
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
OTHER 99S15 PERFORM RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
REPLACED SWITCH AND CONECTOR  
REPLACE SW AND PLUG  
RECALL REPLACE SPEED CONT DEACTIVATION SWITCH  
PERFORMED THE RECALL 99S15

CHECKED AND FOUND VEH NEEDED CRUISE DEACT SWITCH PER RECALL 99S15 REPLACED SWITCH PER RECALL 99S15 CHECKED SYSTEM OK AT THIS T T  
REPLACE CABLE PER RECALL  
INSTALLED SWITCH ANFD HARD SHELL CONNECTOR.  
121883 99S15B.5 ADMIN .1  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
PERFORM RECALL  
PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTION  
RECALL DONE  
99S15 VERIFIED 99S15 RECALL COMPLETED  
REPLACED DEACTIVATION SWITCH AS PER RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
REPLACED DISENGAGE SWITCH PER RECALL 99S15.  
64388 79 PERFROM 99S15 R R SPEED COTTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST

09819 PERFORMED RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
RECALL DONE  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL  
RECALL DONE  
REPLACE SWITCH AND CONNECTOR  
RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT  
INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR 99S15  
119184 RECALL WP40 PERFORMED RECALL, REPLACED BRAKE PRESSURE SWITCH ASSY.  
PERFORM RECALL  
REPLACE CRUISE SWITCH PER RECALL WARR

11804 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
INSTALL DEACTIVATION SWITCH PER 99S15  
RECALL PERFORMED RECALL  
99S15 99S15  
RECALL 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT  
REPLACE CRUISE CONTROL CANCEL SWITCH  
61149 RECALL J5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS REQUIRED.

62094 RECALL WARR R AND R SPEED CONTROL DEACTIVATOR SWITCH PER RECALL INSTRUCTIONS.  
RECALL RECALL

42718 RECALL INSTALL RECALL  
82532 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONECTOR TK372  
111475 RECALL W PERFORM RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SW AND HARD SHELL CONNECTOR LABOR OF 99S15B .5HRS ADM  
99S15 99S15 RECALL  
85058 RECALL 99S15 WARR INSTALL SWITCH PER RECA

1 PERFORMED PINPOINT TESTS FOUND DEFECTIVE DEACTIVATION SWITCH REMOVE AND REPLACE SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.

PERFORMED 99S15  
127720 99S15 INSTALL BRAKE SWITCH AND CONNECTOR  
RECALL 99S15 COMPLETED RECALL 99S15  
PERFORMED THE RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15  
TECH COMPLETED RECALL AS REQUIRED  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

55436 COMPLETED RECALL 99S15  
REPLACED CRUISE SWITCH AS PER RECALL 99S15  
1 REPLACE CRUISE CONTROL DEACTIVATOR SWITCH PER RECALL 99S15  
99S15 INSTALL KIT 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND BLEED SYSTEM  
COMPLETED RECALL PER INSTRUCTIONS  
RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

99S15                      99S15 RECALL  
1 INSTALLED CRUISE SWITCH  
PERFORMED RECALL AS NEEDED ALL OK  
REPLACE SWITCH PER RECALL  
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15  
PERFORMED RECALL  
99S15                      99S15 DONE  
INSTALL SWITCH AND CONNECTOR

REPLACED THE SWITCH AND BLED THE BRAKES  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL  
99S15                      99S15 RECALL DO

COMPLETED RECALL 99S15  
43942 COMPLETED RECALL 99S15. 245  
1 INSTALL SPEED CONTROL DEACTIVATION  
REPL SPEC ORDER PARTS FOR RECALL  
47979 RECALL 99S15 DONE DEACT SWITCH  
REPLACED DEACTIVATION SWITCH PER RECALL  
PERFORMED RECALL 99S15  
82D11 99S15B 0.5 ADMIN 0.1  
REPLACE PERBHER BRAKE VALVE  
84178 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15 LABOR OP- 99S15B 0.3 HRS  
COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1  
RECALL -99S15                      PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH  
46703 TECH 738 HAS FINISHED INSTALLING RECALL 99S15 ON SPEED CONTROL SWITCH.  
PERFORMED RECALL 99S15 SPEED CONTROL DEAC SW REPLASWITCH  
RECALL                      REPLACE DEACTIVATION SWITCH PER RECALL

52888 99S15 RECALL WARR 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S15  
PERFORM RECALL 99S15  
87321 RECALL REPLACED SWITCH AND CONECTOR PER RECALL  
REPLACED CRUISE CONTROL SWITCH  
PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH ANDCONNECTOR  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL  
PERFORMED RECALL  
PERFORM RECALL

PERFORM RECALL  
PREFORM RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
PERFORMED THE RECALL 99S15  
PERFORM RECALL 99S15  
1 INSTALL DEACTIVATION SWITCH PER RECALL  
99S15                      REPLACED SWITCH  
99S15-SPEED CONTROL                      99S15-SPEED CONTROL

SWITCH 99S15 RECALL PERFORMED  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH 1  
 RECALL 99S15 99S15 COMPLETED RECALL  
 RECALL 99S15 RECALL 99S15  
 58442 RECALL RECALL INSTALL DEACTIVATION SWITCH PER 99S15  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
 RECALL COMPLETED  
 RECALL 99S15  
 PERFORM RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH AS PER RECALL  
 RECALL 99S15  
 PERFORM RECALL 99S15 SPEED CONTROL  
 PERFORMED RECALL  
 COMPLETED FACTORY RECALL  
 RECALL 99S15 REPLACED SPEED CONTROL SWITCH  
 101685 WARR 99S15B 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 PERFORMED RECALL  
 RECALL PERFORMED  
 REPL CRUISE CONTROL SWITCH  
 RECALL PERFORM RECALL  
 1 PERFORMED 99S15 RECALL  
 PERFORM RECALL 99S15  
 RECALL REPLACE DEACTIVATION SWITCH  
 PERFORMED RECALL 99S15  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CO  
 RECALL PERFORMED RECAL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 1 REPLACED DEACTIVATOR SWITCH  
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 PERFORMED RECALL  
 1 PERFORM RECALL  
 REPLACE SWITCH PER RECALL LETTER  
 PERFORM RECALL  
 PERFORM 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL AS PER FORD SPECIFICATIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.  
 99S15 99S15 REPLACED SWITCH AND CONNECTOR  
 99S15B PERFORMED RECAL  
 99S15 PERFORM RECALL 99S15, REPLACE SWITCH AND CONNECTOR  
 INSTALL CRUISE SWITCH AND HARNESS PLUG AS PER 99S15 RECALL  
 1 COMPLETED RECALL PER INSTRUCTIONS  
 PERFORMED RECALL 99S15 AS PER FORD SPECIFICATION  
 PERFORM RECALL 99S15  
 99S15 RECALL PERFORMED 99S15 RECALL PERFORMED  
 RECALL 99S15 PERFORM RECALL 99S15  
 0 PERFORM RECALL 99S15  
 1 PERFORMED 99S15 RECALL 794 WARRANTY

REPLACED SPEED CONTROL-DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
INSTALLED NEW SPEED DEACTIVATION SWITCH PERFORM RECALL #99S15  
119540 PERFORM RECALL 99S15 REPL HARD SHELL CONNECTOR AND SWITCH CRUISE DEACTIVATION  
RECALL COMPLETED.

REPLACE SPEED SWITCH AND HARD COVER AS PER RECALL  
PERFORM RECALL  
RECALL 99S15 PERFORM RECALL 99S15 PER LETTER

80990 INSTALL SPEED CONTROL SWITCH PER RECALL  
PERFORM RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
RECALL 99S15 RECALL

CHECKED OASIS. REPLACED DEACTIVATION SWITCH  
INSTALL CRUISE SWITCH  
RECALL RECALL  
PERFORMED RECALL

1 PERFORM RECALL  
TEST CRUISE LOCATE AN OPEN CIRCUIT IN THE DEACTIVATION SWITCH REPLACED SWITCH REPAIR CONNECTION RETEST M1 TIME FOR NO LABOR OR AV.  
REPLACED CABLE  
SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CIRCUIT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVATION  
RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONTROLLER AS PER RECALL 99S15  
REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL  
PERFORMED RECALL  
1 PERFORMED RECALL 99S15

REPLACED SWITCH AND CONNECTOR  
RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
COMPLETED OP 99S15B CAMPAIGN COMPLETED 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15  
PERFORM RECALL 99S15

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
REPLACED SWITCH PER RECALL 99S15  
99S15 REPLACE SWITCH AND CONNECTOR PER RECALL  
99S15 REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL  
REPLACED DEACTIVATION SWITCH PER RECALL 99S15  
COMPLETED CAMPAIGN COMPLETED OP 99S15B

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
87408 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0837  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
RECALL COMPLETED

99S15B-0.5- RECALL 99-S-15 (CC42) REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR.  
SPEED CNTRL DEACTIVATION SWITCH REPLCMTPERF SAFETY RECALL 99S15  
RECALL 99S15  
RECALL REPLACE BRAKE SWITCH AND INSPECT HARNESS PER RECALL  
1 PERFORM RECALL

INSPECTED PER RECALL SWITCH AN HARNESS NOT REPLACED REPLACED SWITCH AN HARNESS ALL OK  
INSTALL SWITCH BRKT  
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORMED RECALL

RECALL PERFORMED RECAL

RECALL 98S15,CRUISE SWITCH

1 REPLACED CRUISE SWITCH AND BLEAD BRAKES. MILEAGE IS CORRECT

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER R ECALL

RECALL 98S15 COMPLETED RECALL 98S15

REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL

98S15 PERFORMED RECALL

115810 DONE WITH RECALL 98S15 SPEED CONTROL SWITCH HAD TOO REPLACE PORPORTIONING VALVE AND BLEED BRAKES TEST DROVE AND WORKS

RECALL PERFORM RECALL 98S15

INSTALLED SPEED OCNTORL SWITCH

INSPECT AND PERFORM RECALL

REPLACED CONNECTOR AND SWITCH. BLEED BRAKES. RETEST OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 98S15

98S70 RECALL 98S15 DONE SPEED CONTROL DEACT SWITCH

PERFORM RECALL

PERFORM RECALL

1 RPELACED THE SPEED CONTROL DEACTIVATION AS PER FORD RECALL INSTRUCTION

1 REPLACE C-C SWITCH

REPLACED DEACTIVATION SWITCH.

PERFORM RECALL 98S15 T121

98S15 SPEED CONTROL DEACTIVATION 98S15 SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 98S15B

R&R CRUISE DEACTIVATION SWITCH

RECALL DONE

98S10 RECALL INSTALL NEW SWITCH AND CONNECTOR AS REQ

PERFORMED RECAL

PERFORMED RECALL 98S15

RECALL 98S15

REPLACE PROPORTIONING VALVE,THREADS FOR DEACTIVATION SWITCH STRIPPED,PERFORM RECALL

DISCONNECTED SPEEDO CABLE AS PER RECALL INTERIM REPAIR

RECALL PERFORM RECALL 98S15

PERFORMED RECALL 98S15

98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED DEACTIVATION SWITCH AS PER RECALL

81874 98S15 OK OUT AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

INSTALL SWITCH & CONNECTOR, BLEED AS PER RECALL 98S15

82780 RECALL 98S15 INSPECT SPEED CONTROL SYSTEM. REMOVE AND REPA E THE DEACTVATING SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE SW.



RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH  
REPLACED SWITCH AND CONECTOR  
99S15 PERFORM 99S15 (99S15B 0.5) .

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

PERFORMED RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15

REPLACE CRUISE DEACTIVATION SWITCH CONNECTOR

99S15 RECALL 99S15 RECALL  
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
0000 99S15B 0.5 - ADMIN 0.1 RECALL  
REPLACE SPEED CONTROL SWITCH  
X COMPLETED COMPLETED  
RECALL PERFORM RECALL  
CRUISE CONTROL  
RECALL 99S15

REPLACE SPEED CONTROL CABLE AND REPLACE PER RECA  
RECALL. REPLACED DEACTIVATION SWITCH AS PER RECALL  
99S15 RECALL 99S15 RECALL

84285 REPLACE SWITCH PER LETTER.

RECALL CRUISE REPL SW.  
99S15 INSTALL SWITCH AND CONNECTOR AS PER RECALL

PRMFD RECALL 99S15

INSTALLED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

OPEN RECALL COMPLETED OPEN RECALL

OPEN RECALL PERFORMED RECALL 99S15

PERFORM RECALL PER BULLETIN

REPLACE SPEED CONTROL DEACTIVATOR SWITCH PER RECALL.

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SE  
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

RECALL 99S15 PERFORM AS INSTRUCTED

PERFORMED RECALL 99S15B.

99S15 RECALL 99S15 REPAIRED AS PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 99S15B .5

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

99S15 RECALL

REPL SPD CNTRL DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL                      RECALL COMPLETE  
98S15                      98S15 REPLACED SWITCH AND CONNECTOR  
PERFORMED RECALL 98S15  
COMPLETED RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR .... 98S15B .5 + .1  
PERFORM RECALL  
INSTALL DEACTIVATION SWITCH  
PERFORM RECALL 98S15 T121

REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
PERFORMED RECALL  
98S15                      98S15 REPLACED SWITCH AND CONNECTOR  
RECALL 98S15 PERFORM RECALL 98S15 REPLACE SWITCH AND CONNECTOR  
COMPLETED RECALL  
MODIFIED PER RECALL

RECALL                      RECALL COMPLETE  
PERFORM RECALL  
REPLACED SWITCH AND CONNECTOR  
RECALL COMPLETE

REPLACE SPEED CONTROL SWITCH PER RECALL  
REPLACED CONNECTOR PER RECALL  
98S57 PERFORMED RECALL 98S15  
1 REPLACED SWITCH BLEED BRAKES  
PERFORM RECALL 98S15  
                                INSTALL DEACTIVATION SWITCH AS PER 98S15  
98S15                      98S15  
1 PERFORMED RECALL 98S15  
RECALL 98S15 REPLACED DEACTIVATION SWITCH AS PER RECALL 98S15  
RECALL                      98S15 RECALL COMPLETED  
116746 PERFORM RECALL 98S15 REPLACED SPEED DEACT SWITCH M.S TECH 522  
73229 PERFORMED RECALL, INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
INSTALL NEW SWITCH AND CONNECTOR AS PER RECALL 98S15  
RECALL                      98S15

REPLACED SC DEACTIVATION SWITCH 98S15  
1 REPLACE SWITCH AND CONNECTOR AS PER RECALL  
PERFORMED SERVICE CAMPAIGN , 98S15 B .5 ADMIN .1  
98S15                      REPLACED BRAKE DEACTIVATION SWITCH AS PER RECALL  
SPEED CONTROL SWITCH RECALL  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
0                      RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
RECALL 98S15B                      98S15B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL  
RECALL 98S15                      98S15 COMPLETED RECALL  
REPLACED SWITCH PER RECALL  
COMPLETED RECALL 98S15  
RECALL                      98S15 REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

0 RECALL 99S15  
99S15 RECALL COMPLETE  
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE  
99S15B3 REPLACE SWITCH AND HARDSHELL CONNECTER  
COMPLETED RECALL  
PERFORM RECALL PER INSTRUCTION  
80483 REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
INSTALL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORMED RECALL, INSTALL SWITCH AND CONNECTOR  
COMPLETE RECALL  
97029 REPLACR SPEED CONTROL SWITCH AND HARD SHELL CONNECTOR  
95787 RECALL 99S15 INSTALLED RECALL  
REPLACED SWITCH AND CONNECTOR  
88083 R R DEACTIVATOR SWITCH PER RECALL  
99S15 RECALL 99S15 COMPLETED RECALL  
13477 PERFORM RECALL 99S15 REPLACE CUT OFF SWITCH AND PLUG FOR CRUZ  
RECALL SW REPL CRUISE SW  
REPLACED SPEED CONTROL SWITCH  
70840 RECALL RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
REPLACE SWITCH

47809 RECALL PERFORM RECALL AS OUTLINED NECESSARY TO REMOVE INNER L-F FENDER TO GAIN ACCESS TO FROZEN DEACTIVATION SWITCH  
PERFORMED RECALL  
89423 PERFORM RECALL, REPL SWITCH 99S15B .5  
REPLACE SWITCH CONNECTOR AND FUSE PER RECALL 99S  
INSTALLED NEW CONNECTOR PER 99S15 RECALL  
71880 PERFORMED RECALL 99S15.  
REPLACED CRUISE SWITCH  
1 PER RECALL R-R DEACTIVATION SWITCH AND CONNECTOR ON CRUISE CONTROL.  
PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTION  
1 INSTALL CONNECTER PER RECALL  
RECALL RECALL COMPLETE  
RECALL 99S15 COMPLETED RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
99S15B 99S15B  
MODIFIED PER RECALL  
70504 PERFORMED RECALL 0.5  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORMED RECALL #23 MM  
38309 R-R DEACTIVATION SWITCH & CONNECTOR FOR RECALL

PERFORMED RECALL  
COMPLETED RECALL

RECALL                      REPLACE CRUISE SWITCH AS PER RECALL  
SAFETY RECALL              99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
1 PERFORM RECALL-REPLACE DEACTIVATION SWITCH  
RECALL COMPLETE  
REPLACE SWITCH              RECALL 99S15  
PERFORM RECALL

CRUISE CONT              REPL SWITCH  
RECALL AS PER LETTER  
RECALL COMPLETED.  
70245 42W W REPLACE SWITCH AND CONNECTOR PER RECALL 3472  
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
PERFORMED RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
RECALL CRUISE              REPL SW  
PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK  
RECALL PERFORMED RECALL # 0030  
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
1 PERFORMED RECALL 99S15  
99-S-15                      99-S-15 COMPLET  
REPLACE SPEED CONTROL SWITCH  
59875 REPLACED SWITCH AND HARDSHELL CONNECTOR PER RECALL  
RECALL 99S15  
RECALL                      99S15 REPLACE C-C SW  
COMPLETE RECALL 99S15  
RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR  
46428 REPLACED SWITCH & CONNECTOR  
53747 RECALL 99S15 W PERFORMED RECALL 99S15 INSTALLED PRESSURE SWITCH  
REPLACED SWITCH PER RECALL  
RECALL                      99S15 RECALL COMPLETED  
REPLACE BROKE SWITCH AND CONNECTOR PER RECALL  
REPLACE SWITCH AND CONNECTOR  
PERFORM RECALL 99S15  
PERFORMED RECALL 99S15  
57852 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH  
REPLACED THE SWITCH PER RECALL 99S15  
PERFORMED RECALL  
RECALL AS PER LETTER  
99S15 R&R DEACTIVATION SWITCH & CONNECTOR  
99S15                      99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL  
INSTALLED SWITCH PER RECALL  
RECALL 99S15                      PERFORMED RECALL 99S15  
91230 REPLACE SWITCH AND HARD SHELL  
RECALL                      DEACTIVATE SPEED CONTROL  
COMPLETED RECALL  
93071 99S15 S 0.5 REPL DEV CRUISE SW  
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
  
POSSIBLE SHORT CIRCUIT IN SPEED CONTROL DEACTIVATION SWITCH REPLACE SWITCH PER BULLETIN 99S15

PERFORMED RECALL

PERFORM RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

122502 RECALL 98S15B 0.5HRS INSTALL NEW SWITCH AND CONNECTOR TK372

118168 RECALL INSTALL SWITCH PER RECALL

X 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

118804 DID RECALL

A DONE

REPLACE SWITCH AND HARNESS PER RECALL

REPLACE SPEED SWITCH AS PER RECALL

PERFORMED 98S15 RECALL

FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

RECALL REPLACE SWITCH & CONNECTOR

G RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SWITCH PER RECALL LETTER

INSTALL CRUISE CABLE PER RECALL 98S15

PERF RECALL AS PERSCRIBED

RECALL AS PER CUSTOMERS LETTER

REPLACED SWITCH PER RECALL

RECALL 98S15 REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 98S15 INSTRUCTION

47006 PERFORMED RECALL 98S15

82863 REPLACED SWITCH AND HARNESS END PER RECALL- TECH 842

REPLACE SWITCH

PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

REPLACED DEACTIVATION SWITCH

PERFORM SAFETY RECALL

REPLACED SWITCH AND CONNECTOR

REPLACE DEACTIVATION SWITCH

RPL SPEED CONTROL BRAKE SWITCH PER 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH TO PREVENT CRUISE FROM SHORTING OUT COMPLETE

43662 WARR INSTALL CRUISE CONTROL DEACTIVATION SWITCH

FORD FACTORY RECALL NOTICE. PERFORMED FACTORY RECALL AS PER RECALL NOTICE. DONE.

PERF RECALL 98S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

PERFORMED 98S15 RECALL

PERFORM RECALL 98S15

PERFORM 98S15

PERFORMED RECALL 98S15

84705 PERFORMED RECALL 98S15, R-R DEACTIVATION SWITCH AND CONNECTOR, BLEED RR BRAKE.

RECALL 98S15 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

78828 42 WP40 98S15 RECALL REPLACE SWITCH

OPEN RECALL PERFORMED RECALL 99S15  
48811 99S15 W REPLACED SPD CONTROL DEACTIVATE SW 0937  
PER NOTICE PERFORM RECALL  
PERFORMED RECALL 99S15  
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH INSPECTED VEHICLE - HAS ONLY VACUUM OPERATED SYSTEM  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE AFFECTED VECI LABELS REPLACE FAULTY DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
REPL SWITCH PER RECALL  
OWNER NOTIFICATION 99S15B  
PERFORM RECALL 99S15- REPLACE SPEED CONTROL SWITCH  
103806 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B

PERFORMED RECALL  
RECALL 99S15 RECALL, REPLACED DEACTIVATION SWITCH  
RECALL 99S15 OPEN PERFORM RECALL  
REPLACE SPEED CONTROL PER RECALL  
REPLACE SWITCH  
INSTALL SPEED CONTROL HARNESS  
99S15 REPLACE SWITCH  
128081 99S15 PERFORMED RECALL 99S15.  
PERFORMED RECALL  
REPLACED CRUISE DEACT SWITCH  
99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL  
RECALL 99S15 DONE  
PERFORMED RECALL  
77441 99S15 SPEED CONTROL SWITCH RENEW DEACTIVATION SWITCH FOR RECAL 23

PERFORMED RECALL  
INSTALL SWITCH PER RECALL  
FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL SWITCH WAS NOT DISCONNECTED  
REPLACE SPEED CONTROL CABLE  
SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
85408 PERFORM C-C RECALL  
PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH, PER 99S15  
RECALL PERFORM RECAL 99S15  
RECALL CK AND REPL FLUID CC SWITCH AND CONECTOR PER RECALL WF TEC300 ON DRIV

INSTALL SWITCH AND CONNECTOR  
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
RECALL RECALL REPLACE SPEED CONTROL SWITCH  
COMPLETE RECALL 99S15  
REPLACED DEACTIVATION SWITCH PER RECALL 99S15  
RECALL 99S15  
INSTALLED SPEED CONTROL SWITCH AS PER RECALL 99S  
1 COMPLETED RECALL 99S15 NOTE-SEE JOB#6 FOR RECALL RELATED REPAIRS...  
68488 TESTED SPEED CONTROL ELEC. SPEED CONTROL INOP. PINPOINT TEST, OPN IN BRAKE PRESSURE SWITCH. REPLACED SWITCH, BLEED BRAKES.

RECALL 98S15                      98S15  
 RECALL                      REPAIR PER RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 RECALL                      98S15 REPLACE C-C SW  
 - MODIFY PER RECALL 98S15  
 PERFORMED RECALL 98S15  
 COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 REPLACE SWITCH PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.  
  
 PERFORMED RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
  
 98S15                      98S15 INSPECT REPLACED SPEED CONTROL DEACTIVATED SWITCH AND CONN  
  
 COMPLETED RECALL 98S15B 1  
 RECALL 98S15                      PERFORMED RECALL 98S15  
 98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL  
 COMPLETED RECALL  
 RECALL COMPLETED  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 10825 REPLACED SW- AND CONNECTOR FOR CRUISE DEACTIVAT PER RECALL 98S15.  
 SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVAT  
 PERFORM RECALL 98S15  
 PERFORMED RECALL  
 REPAIRED PER 98S15  
  
 CONTROL DEACTIVATION SWITCH RECALL  
 SAFETY RECALL                      98S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 98S15 RECALL PERFORMED  
  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH.  
 90731 REPLACED CRUISE CUT OFF SWITCH AS PER RECALL  
 RECALL                      98S15 RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
  
 COMPLETED RECALL  
 RECALL                      REPAIR PER RECA  
  
 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 PERFORMED RECALL  
 RECALL 98S15B RECALL 98S15B C-C A99 CORR 42  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 COMPLETE RECALL 98S15  
 SPEED CONT                      REPL SWITCH  
 PERFORMED RECALL

REPLACE CONNECTOR AND SWITCH

85828 WARR PERFORM RECALL 98S15 B REPLACE SWITCH AND CON- NECTOR

0 DEFECTIVE SWITCH.X REF RD 54448 LINE 51

RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH AND HARD SHELL

98S15B PERFORMED RECAL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORM SPEED CONTROL DEACTIVATION RECALL

REPLACED CRUISE SWITCH PER RECALL

PERFORMED RECALL

87788 RECALL .5 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

PERFORMED RECALL

RECALL 98S15 PERFORMED RECALL 98S15B

98S16 98S16 PERFORM RECALL REPLACED SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 1

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

84744 RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL INST.

RECALL SW REPL

PERFORM RECALL AS PER INSTRUCTIONS

RECALL COMPLETE

80818 REPLACED SWITCH AND CONNECTOR

REPLACE SWITCH PER RECALL LETTER

RECALL 98S15 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO

B 98S15

PERFORM 98S15

1 PERFORMED RECALL

PERFORM RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

REPL DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH PER 98S15

C RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTORS. CHECK NORMAL OPERATION.

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR

INSTALL SWITCH PER RECALL

COMPLETE RECALL 98S15

1 REPLACED SPEED CONTROL SWITCH AS PER 98S15

REPLACED SPEED CONTROL SWITCH AND WIRE CONNECTIO

21942 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

REPAIR CRUISE CTL PER RECALL

PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION

REPL CRUISE CONTROL SWITCH



RECALL SPEED CONTROL DEACTIVATIONREPLACE CRUISE SWITCH AND CONECTOR  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH

COMPLETED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.  
PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS  
ADD ON AUTH 98 1 PERFORMED RECALL C

RECALL 98S15  
RECALL 98S16  
PERFORMED RECALL 98S15  
PERFORM RECALL  
RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
RECALL 98S15 98S15 REPAIR AS PER RECALL  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
REPLACE CRUISE SWITCH

RECALL #98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
REPLACE DEACTIVATOR PER INSTRUCTIONS

RECALL COMPLETED

RECALL COMPLETE

PERFORMED RECALL 98S15

RECALL 98S15 PERFORM RECALL 98S15

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL RECALL

PERFORMED RECALL

PERFORM RECALL 98S15 INSTALL BRAKE KIT PER RECALL 98S15

51889 PERFORMED RECALL 98S16

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

98S16, CRUISE SWITCH

REPLACE SW AND CONNECTOR

RECALL RECALL

RUN STAR TEST FOR CODES, PINPOINT TEST FOR RESEVOIR CODE. BRAKE LEAK AT DEACTIVATION SWITCH-DEFECTIVE DEACTIVATION SWITCH  
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORM RECALL.

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH 98S15B 0.5 ADMIN 0.1

PERFORM RECALL 98S15-REPLACE SPEED CONTROL SWIT

REPLACE SPEED CONTROL SWITCH PER RECALL 98S16

PERFORM RECALL 98S16

RECALL REPLACED SWITCH AS PER RECALL

98S15 REPLACED DEACTIVATION SWITCH

98S16 SWITCH AND CONNECTOR 98S16

REPL SWITCH PER RECALL

RECALL COMPLETED  
98S15 RECALL COMPLETED  
REPLACED BRAKE SWITCH PER RECALL  
INSTALLED SWITCH RECALL COMPLETED

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S  
1 CAMPAIGN COMPLETED.

40834 TRY TO REMOVE THE SW OUT IT WAS SEIZE IN THE MOUNTING. .2 HR M TIME TO REMOVE THE SW OUT . PER FORM THE RECALL  
PERFORMED RECALL

RECALL 98S15 REPLACE SPEED CTRL. DEACTIVATION SWITCH & HARDSHELL CONNECTO  
REPLACED SPEED CONTROL ACTUATOR PER RECALL RETE STED OK. NO OTHER CONCERN AREAS EVIDENT AT THIA TIME  
SWITCH 98S15  
RECALL 98S15 98X15  
COMPLETED RECALL 98S15 98S15B 1  
78067 746 PERFORM RECALL 98S15 BLEAD REAR BRAKES ROAD TEST TO RECHECK OK  
RECALL PERFORMED RECALL 98S15

FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH SWITCH WAS DEACTVATED

98822 REPLASD SPEED CONTROL DEACTIVATION SWITC  
PERFORM RECALL  
RECALL REPAIR AS PER RECALL 98S15

1 PERFORM 98S15 RECALL  
1 EPLACE BRAKE SWITCH AND CONNECTOR  
REPLACED SWITCH AND CONNECTOR AS PER RECALL  
REPLACED BRAKE PRESSURE-SPEED CONTROL DE-ACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15. THANK YOU. 1  
COMPLETE RECALL  
REPLACED SPEED CONTROL SWITCH  
98114 INSTALL SWITCH AND HARDSHELL CONNECTOR.  
REPLACE SWITCH PER RECALL CRUISE INOP PUT OLD SWITCH BACK INCRUISE STILL INOP PUT NEW SWITCH BACK IN CUST.DECLINE ANY REPAIRS AT 1  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
045 REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR  
RECALL COMPLETED  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

98S15 REPLACED DEACTIVATION SWITCH

68490 RECALL 98S15. PERFORM RECALL 98S15. REPLACE THE SWITCH AND THE CONNECTOR.  
PERFORMED RECALL 98S15 CRUISE SWITCH  
C INSTALL SWITCH AS PER RECALL  
79 RECALL

PERFORMED RECALL 98S15 REPLACED CRUISE SWITCH  
REPLACED THE SWITCH PER RECALL 98S15  
FORD SAFETY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

COMPLETED RECALL 99S15  
99S15 99S15  
PERFORMED RECALL 99S15  
PERFORMED RECALL  
RECALLED BY FORD MOTOR COMPANY COMPLETED RECALL PER LETTER REPLACED THE SWITCH.  
PERFORMED RECALL 99S15 REPL DEACT SWITCH  
88728 PERFORMED 99S15 RECALL  
118941 REPLACE SWITCH AND CONNECTOR PER 99S15 8728  
RECALL COMPLETED RECAL  
PERFORM RECALL  
RECALL 99S15 99S15 COMPLETED RECALL  
AS PER RECALL 99S15 RECALL TO INSTALL HARDSHELL CONNECTOR  
RECALL CK AND REPL FLUID CC SW PER RECALL AND RECK WF TEC300  
SUPPLEMENT #1 5-09 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
RECALL 99S15 SPEED CONT DEACT SWITCH  
REPAIR PER RECALL 1  
RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH CONNECTOR  
COMPLETE RECALL #99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

53985 PERFORM RECALL REPLACE CRUISE SWITCH  
PERFORM 99S15 R R SPEED CONTROL SWITCH AND CONNECTOR  
99S15B .5 PLUS .1 ADMIN REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED SERVICE AS REQUESTED  
PERFORMED RECALL  
CORRECTED RECALL  
82489 REPALCED CRUISE CONTROL SWITCH AND CONECT  
120871 RECALL 99S15 R&R BRAKE DEACTIVATION SWITCH AND HARNESS CONNECTOR AS PER RECALL 99S15  
INSTALLED SPEED CONTROL DEACTIVATION KIT  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
RECALL 99S15  
1 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTYOR

08 REPLACED SWITCH  
RECALL PERFORMED RECALL

99S15 REPL DEACTIVATION SWITCH  
PERFORMED RECALL  
PERFORMED RECALL 99S15  
RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL  
REPLACED DEACTIVATION SWITCH  
PERFORMED RECALL 99S15  
PERFORM RECALL 99S15  
D  
RECALL REPLACE DEAC SWITCH AND CONNECTOR  
REPLACE SPEED CONTROL SWITCH AND WIRE CONNECTOR AS PER RECAL L 99S15. 1  
99S15 REPLACE PRESSURE SWITCH AND CONNECTOR PER RECALL  
PERFORM RECALL  
PERFORMED RECALL 99S15

47700 98S15B 0.5 ADMIN 0.1  
PREFORM RECALL 98S15  
REPL SWITCH PER RECALL  
A DONE  
122202 I PERFORMED RECALL 98S15  
INSTALLED NEW SWITCH KIT

REPLACE SPEED CONTROL CABLE AS PER RECALL 98S15 2 OF 2 RO8  
93533 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
RECALL PERFORMED  
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
RECALL 98S15  
PERFORMED RECALL 98S15  
COMPLETED RECALL -DID 98S15B.  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
176245 PERFORMED SPEED CONTROL RECALL 98S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
INSTALL HARNESS & KIT PER RECALL  
PERFORMED RECALL  
98535 RECALL LABOR OP. 98S15B 0.5 HRS.  
98805 REPLACE CRUISE SWITCH BRAKE AS PER RECALL

PERFORM RECALL 98S15 RECHECK OPERATION OK  
98897 PERFORMED RECALL 98S15  
PERFORM RECALL  
REPL SWITCH PER RECALL  
RECALL REPLACED DEAC SWITCH AND CONNECTOR  
INSTALLED SPEED CONTROL DEACTIVATION KIT  
REPLACED SWITCH PER 98S15.  
DO RECALL 98S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
PERFORM 98S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 98S15, REFER TO 106478-02 FOR RELATED DAMAGE.  
98S15 RECALL NOTIFICATION 98S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL  
RECALL 98S15 COMPLETED  
G RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH 48

RECALL COMPLETED  
RECALL 98S15  
45977 RECALL W RECALL 98S15 BRAKE REPAIR KIT INSTALLED  
PERFORMED RECALL 98S15  
DID RECALL-DID 98S15B.  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.  
SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 98S15  
RECALL RECALL  
REPL SWITCH PER RECALL

1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS

REPLACE SWITCH PER RECALL.

PERFORMED RECALL

REMOVE & REPLACE SPEED CONTROL CABLE

99S15B .5 PLUS .1 ADMIN REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED SERVICE AS REQUESTED

147804 RECALL 99S15B .5 REPLACED DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACT SWITCH AND CONNECTOR  
COMPLETED RECALL, REPLACED SWITCH

D

PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK

40112 INSTALL RECALL PPS15 SPD CONTROL DEACTIVATION

RECALL 99S15

RPLC SPEED CTRL DEACTIVATION SWITCH & CONN PER 99S15

PERFORM RECALL

RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

INSPECTED DEACTIVATION SWITCH NEEDED RECALL-REPLACED WITH RECALL 99S15

COMPLETED RECALL

RECALL REPLACE DEAC SWITCH AND CONNECTOR

SPEED CONTROL SWITCH MOD 99S15 RECALL SPEED CONTROL SWITCH

1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.

1 PERFORMED 99S15 RECALL

75848 PERFORMED RECALL #99S15 REPLACED BRAKE SENSOR

SPEED CONTROL LEAKING PERFORMED 99S15 RECALL

RECALL 99S15 COMPLETED

RECALL 99S15

PERFORM RECALL 99S15 PER INSTRUCTIONS

RECALL 99X15

A DONE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15.

PERFORMED SAFETY RECALL 99S15

PERFORMED RECALL 99S15

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTOR. CHECK NORMAL OPERATION.

127801 PERFORM RECALL 99S15 SPEED CONTROL SWITCH. FOUND TO BE FINE AT THIS TIME

99S15. REPLACE CRUISE LOCK OUT SWITCH AND HARD SHELL.

1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL

PERFORM RECALL

75371 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR HARD SHELL CODE 42 TK574

REPLACED DEACTIVATION SWITCH.

INSTALL SWITCH PER RECALL

REPAIR AS PER RECALL 99S15.

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR.

REPLACED DEACTIVATION SWITCH

PERFORMED RECALL  
 PERFORMED RECALL 99S15 O.C. 99S15B 0.5 ADMIN 0.1  
 99S15 99S15 INSPECT AND REPLACE SPEED CONTROL DEACTION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACED SPEED CONTROL  
 REPLACED CRUISE DEACT SWITCH  
 REPLACED DEACTIVATION SWITCH PER RECALL  
 RECALL 99S15 CRUISE CONTROL DEACTIVATION PERFORM RECALL 99S15 INSTALL BRAKE SWITCH & HARD SHELL CONNECTOR  
 80930 99S15B 0.5 ADMIN 0.1  
 70294 RECALL REPLACE SWITCH AS PER RECALL 2000  
 REPLACED SWITCH AND CONNECTOR  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 88983 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONICTOR TK372  
 141741 REPLACE CRUISE DEACTIVATION SWITCH AND RELATED CONNECTOR PER RECALL 99S15  
 REPL SWITCH PER RECALL  
 REPL SWITCH PER RECALL 99S15  
 RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT  
 PERFORMED RECALL  
 RECALL REPLACE SPEED CONT DEACT SWITCH  
 REPLACE SPEED CONTROL CABLE  
 99S15 99S15 RECALL  
 RECALL REMOVED AND REWIRE CONNECTOR AND REPLACED SWITCH DONE 144. RECHECK OK  
 REPLACED SWITCH  
 51090 99S15B .5 .5 RECALL  
 RECALL PERFORM RECALL INSTALL DEACTIVATION SWIT  
 PERFORM SPEED CONTROL RECALL 99 S 15  
 PERFORMED RECALL  
 POERFORMED SAFETY RECALL 99S15  
 REPLACED SPEED CONTROL CABLE  
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
  
 REPLACE CRUISE CABLE CONTROL SWITCH AND WIRE CONN., BLEED BRAKE, RT OK  
 1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.  
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 RECALL REPLACE SPEED CONTROL DEACT SWITCH AND HARD SHELL CONNECTOR  
 1 PERFORM RECALL  
 REPLACED DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 02466 INSTALL RECALL  
 PERFORMED RECALL 99S15  
 PERFORM RECALL  
  
 1 REPLACED SWITCH AND CONNECTOR PER RECALL 99S1  
 PERFORM RECALL  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 DEACTIVATION SWITCH 99S15  
 INSTALL SWITCH PER RECALL 99S15 A99

99S15 RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.  
 REPL SWITCH PER RECALL  
 112033 TECH 181 99S15-0.5 REPLACE SWITCH  
 RECALL 99S15-INSPECT AND REPLACE BRAKE SWITCH AND CONNECTOR TECH 518  
 RPL CRUISE DEACTIVATION SWITCH  
 PERFORM RECALL 99S15B  
 99S15 RECALL C 9G262 AA  
 81084 TECH NO. 5932 REPLACE DE-ACTIVATION SWITCH AND HARDSHELL CONNECTOR PER 99S15.  
 RECALL 99S15  
 RECALL 99S15 REPL SPEED CONTROL SWITCH  
 PERFORMED 99S15 RECALL.  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15  
 28035 RECALL DEATERTATION SWITCH I WILL REPLACE SWITCH AND CONNECTOR  
 PERFORMED RECALL  
 83078 WARR DONE RECALL 99S15 REPLACE BRAKE KIT  
 PERFORMED RECALL  
 RECALL 99S15  
 99S15B COMPLETE RECALL 99S15  
 PERFORM RECALL  
 RECALL COMPLETED

99S15 RECALL  
 REPLACE SWITCH AND CONNECTOR PER RECALL  
 PERFORM RECALL 99S15  
 REPLACED SWITCH  
 99062 RECALL W REPLACE SWITCH GA  
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 71272 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR.  
 - MODIFY PER RECALL 99S15  
 RECALL RECALL  
 PRODUCT MODIFICATION REPLACE SPD CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 1 INSTALL SWITCH AS PER RECALL

PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.  
 RECALL REPLACE SPEED CONTROL DEACT SWITCH AND HARD SHELL CONNECTOR

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15  
 PERFORM RECALL  
 PERFORM RECALL  
 1 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 .... PERFORMED RECALL 99S15  
 82054 RECALL WARRANTY REPLACE SPEED CONTROL DEACTIVATION SWITCH

78599 TECH NO. 5932 REPLACE DE-ACTIVATION SWITCH PER 99S15  
INSTALLED DEACTIVATION KIT

INSTALL SPEED CONTROL SWITCH

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

REPLACE THE CONTROL

REPLACED SWITCH AND CONNECTOR

PERFORM RECALL 99S15

PERFORMED RECALL 99S215.

INSPECT AMBD INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK

PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

99S15 99S15 PRESSURE SWITCH

RECALL COMPLETE

REPLACE SPEED CONTROL SWITCH

REPLACED SPEED CONTROL SWITCH 7 CONNECTOR

73304 RECALL REPLACED SWITCH

RECALL COMPLETED

20482 RECALL REPLACED DEACTIVATOR SWITCH 160

RECALL 99S15 RECALL

103333 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH

58573 PERFORMED RECALL 99S15-REPLACED SPEED CONTROL

INSTALL SWITCH 99S15B 0.0

D

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL NOTICE

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

86254 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 99S15

RECALL RECALL

PERFORMED RECALL

PERFORM RECALL

99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

1 CAMPAIGN COMPLETED.

RECALL 99S15

1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-

PERFORMED RECALL PERFORMED RECAL

RECALL COMPLETED

REPLACE SWITCH

CAMPAIGN REPLACE SWITCH CONNECTOR PER RECALL

VEHICLE HAS AN OPEN RECALL PERFORM RECALL

107735 PERFORMED RECALL 99S15-REPLACED SPEED CONTROL

INSTALL SWITCH PER RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL



PERFORM RECALL REPL DEACTIVATION SWITCH  
RECALL                      REPLACE DEACTIVATION SWITCH  
INSTALL CRUISE DEACTIVATION SWITCH. 99S15  
COMPLETED RECALL  
VERIFY RECALL RREPLACE CRUISE SWITCH AS PER FMC CHECK OK

024 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND      REWIRED HARNESS  
99S15                      REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTO  
99S15                      99S15  
REPLACE SWITCH  
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
1 INSTALL SWITCH AND CONNECTOR.  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
-                      99S15 COMPLETED

RECALL PERFORMED  
99S15                      99S16  
R&R SPEED CONTROL SWITCH & HARD SHELL BLEED SYSTEM PER RECALL  
PERFORMED RECALL                      PERFORMED RECAL  
99S15  
119923 RECALL W 99S15 REPLACED NEEDED SWITCH AND CONNECTOR.  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.  
RECALL PERFORMED

RECALL R-R DEAC SW, INSTALLED NEW, AND CONN.  
REPL SWITCH PER RECALL 99S15

INSTALL CRUISE CONTROL SWITCH

PERFORMED RECALL 99S15  
RECALL COMPLETE  
TECH COMPLETED RECALL #99S15 AS REQUIRED  
1 INSTALLED NEW CRUISE DEACT SWITCH AND BLEED BRAKES PER RECALL AND TEST DROVE  
1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
115579 PERFORMED RECALL 99S15  
73508 PERFORM RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
77354 1 INSTALLED SWITCH AND CONNECTOR  
114448 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL  
TECH REPLACED SWITCH AS REQUIRED  
VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK  
1 INSTALLED CRUISE SWITCH AS PER RECALL 1  
PERFORM RECALL  
REPLACED THE SWITCH PER RECALL 99S15

REPLACED SWITCH  
 RECALL COMPLETED  
 REPLACE CRUISE SWITCH PER RECALL  
 RECALL 99S15 COMPLETED  
 99S15 RECALL 99S15 RECALL  
 FACTORY RECALL COMPLETED RECALL  
 05789 PERFORMED RECALL 99S15  
 99S15 99S15  
 PREFORM RECALL  
 REPLACED DEACTIVATION SWITCH  
 COMPLETE RECALL 99S15  
 REPLACED SWITCH AND CONNECTOR  
 - MODIFY PER RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH  
 COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH  
 PERFORMED RECALL  
 01384 RECALL 99S15B 0.5 ADMIN 0.1 REPLACE PLUG AND SWITCH  
 REPLACED SPEED CONTROL SWITCH.  
 83222 99S15  
 A99 99S15  
 INSTALLED SWITCH  
 REPLACED DEACTIVATION SWITCH  
 99S15 99S15

RECALL 99S15  
 REPL SWITCH PER RECALL  
 1 REPLACED SWITCH PER RECALL 99S15  
 REPLACE DEACTIVATION SWITCH PER RECALL  
 AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL CABLE  
 91535 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 PERFORMED 99S15  
 1 INSTALL PRESURE SWITCH KIT AS PER RECALL.  
 RECALL 99S15  
 REPLACED DEACTIVATION SWITCH.  
 PERFORMED RECALL 99S145 - CHECK AND REPLACE CRUISE CONTROL CABLE AND RECHECK OK  
 COMPLETED RECALL  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL.  
 SERVICED AS PER RECALL  
 PERFORM RECALL 99S15  
 PERFORM RECALL 99S15 PER FORD

99S15 ADM .1  
 82878 RECALL 0.5 INSTALLED NEW BRAKE PRESSURE SWITCH AND CONNECTOR 99S15B  
 REPLACED DEACTIVATION PER RECALL  
 REPL SWITCH PER RECALL  
 RECALL RECALL  
 77020 RECALL 99S15 WRT PERFORMED RECALL 99S15 PLACED NEW DEACTIVATION SWITCH ON AND PASSED.

COMPLETED OP 98S15B CAMPAIGN COMPLETED 98S15  
RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15  
98S15 SPEED CONTROL SWITCH RECALL 98S15  
53809 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR  
RECALL 98S15 98X15

PERFORM RECALL

INSTALL DEACTIVATION SWITCH & HARD SHELL CONNECTOR PER 98S15

98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 98S15.

138458 98S15 WARR REPLACED SWITCH AND CONN

58467 RECALL 98S15 INSTALL RECALL KIT- 98S15 CRUZ CONTROL SWITCH R REPL.

INSTALL PARTS PER RECALL

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

PERFORM RECALL 98S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

RECALL INSTALLED CONNECTOR AS PER RECALL

COMPLETED RECALL 98S15

PERFORM RECALL 98S15

49108 98S15 PERFORMED RECALL AS PER INSTRUCTIONS REPLACED DEACTIVATION SWITCH AND CONNECTOR SHEL

PERFORM RECALL 98S15 CRUISE SWITCH CONNECTOR

REPLACE DEACTIVATION SWITCH

84118 INSPECTED AND REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15.

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

84105 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH PER RECALL X98 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SWITCH

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

REPLACE CRUISE SWITCH

61067 INSTALLED NEW SPEED DEACTIVATION SWITCH AS PER RECALL 98S15.

VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT

1 PERFORMED 98S15 RECALL

REPLACE SWITCH AND CONNECTOR

REPLACED SWITCH

PERFORM RECALL TECH NOTES REAR SHOCKS LEAKING AND REAR AXLE SHAFT SEEPAGE.

RECALL R-R DEAC SW, R-R CONN, INSTALLED NEW, RECKD OK.

RECALL 98S15 REPLACE C-C SW

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTIONS

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTO

PERFORM RECALL

98S15 RECALL PERFORM RECALL 98S15

PERFORM RECALL 98S15

73210 RECALL INSPECT SPEED CONTROL SYSTEM. REPLACED DEACTIVATION SWITCH AND REWIRED HARDSHELL

98S15 RECALL 98S15 RECALL COMPLETED

INSTALL SWITCH AND CONNECTOR  
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH. REPLACED SWITCH AND THE CONNECTOR  
RECALL COMPLETE  
REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
53245 INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15.  
SAFETY RECALL NOTICE PERFORMED AS OUTLINED IN THE FOMOCO INSTRUCTIONS  
109033 RECALL 0.5 REFORM RECALL 98S15  
PERFORMED RECALL 98S15

1 REPLACE CRUISE CONTROL SWITCH PER RECALL  
COMPLETE RECALL

PERFORMED RECALL 98S15 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK  
RECALL PERFORMED RECALL  
53107 \*98S15B .5\* REPLACED DEACTIVATION SWITCH AND CONNECTOR  
REPLACED SWITCH AND CONNECTOR

REPLACED CRUISE CONTROL BRAKE SWITCH  
AS PER RECALL 98S15 RECALL TO INSTALL SPEED CONTROL CABLE  
PERFORM RECALL, REPLACE SWITCH.  
98S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
RECALL RECALL  
98S15 PERFORMED RECALL  
PERFORMED RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
INSTALL DEACTIVATION SWITCH

PERFORM RECALL 98S15  
RECALL 98S15 COMPLETED  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
98S15 REPLACED CONNECTOR AND SWITCH  
PERFORMED RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL  
98S15 98S15 PERFORM RECALL 98S15 REPLACE CRUISE CONTROL DEACTIVATION SW  
98S15 REPLACE DEACTIVATION SWITCH  
1 PERFORM RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRUCT  
REPLACED SWITCH AND CON  
RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
98S15 98S15  
70824 .3 + .1 ADMIN. 98S15B. REPLACED DE- ACTIVATION SWITCH.  
RECALL 98S15 PERFORM RECALL 98S15  
PERFORMED RECALL

75247 PERFORM RECALL ABS LIGHT ON BEFORE RECALL  
RECALL COMPLETED  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

RNR DEACTIVATION SWITCH      PERFORM RECALL 99S15  
PERFORM RECALL  
99S15      99S15 REPLACED SWITCH  
RECALL      99S15 - COMPLET

99S15      99S15  
REPLACED DEACTIVATION SWITCH,  
COMPLETED FACTORY RECALL  
53384 REPLACED CRUISE SWITCH  
1 COMPLETED RECALL 99S15  
PERFORMED RECALL  
RECALL      99S15 REPLACED SWITCH  
RECALL CRUISE COMPLETED AS PER RECALL 99S15  
70074 PERFORMED RECALL  
RECALL      RECALL  
33379 COMPLETED RECALL OPER#99S15B 0.5 HR  
REPLACED SWITCH PER RECALL 99S15 4.6L AUTO  
73567 PERFORMED RECALL 99S15 REPLACED DEACTIVA  
99S15 REPLACED SWITCH AND CONNECTOR  
INSTALLED CRUISE CONTROL SWITCH AND PLUD END AS PER RECALL MO-28833  
92180 COMPLETED RECALL OPER#99S15B 0.5 HR  
INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR. 99S15  
PER RECALL INSTALL SWITCH  
87307 RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
CRUISE DEACTIVATION SWITCH REPLACE AND REWIRE AS INSTRUCTED  
95440 PERFORMED RECALL AS PER LETTER, INSTALLED SWITCH AND CONNECTOR SHELL 99S15B 0.5 HR LABOR 0.1 ADMIN.  
38380 DID RECALL 99S15 TECH 3213  
REPLACE SPEED CONTROL PRESSURE SWITCH PER 99S15  
1 REPLACED DEACTIVATION SWITCH AS PER RECALL  
PERFORM RECALL 99S15.  
99S15      99S15-INSTALL SWITCH AND COONECTOR  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL  
RECALL 99S15  
PERFORMED RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUC  
COMPLETER RECALL  
INSTALL NEW VALVE AND CONNECTOR REPLACE WIRING HARNESS ALSO  
49007 99S15B 0.5 0.5 PERFROM 99S15  
110382 RECALL REPLACE SWITCH AND CONNECTOR AS PER RECALL  
PER RECALL REPLACE SPEED CONTROL REACTIVATION SWITCH AND CONNECTOR.

PERFORMED 99S15

PERFORMED RECALL 99S15  
1 REPLACED SPEED CONTROL SWITCH  
INSOECT FOR RECALL 99S15  
PERFORMED RECALL 99S15 PER INSTRUCTIONS  
21988 PERFORM 99S15 RECALL  
91166 REPLACE SW PER RECALL

REPLACE DEACTIVATION SWITCH  
RECALL PERFORM RECALL 99S15  
COMPLETED FACTORY RECALL  
RECALL 99S15  
SPEED CNTRL DEACTVTN SWITCH REPLMNTPERF SAFETY RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER PROGRAM  
99S15 REPLACE CRUISE BRAKE SWITCH  
SWITCH WOULD NOT DISCONNECT REPLACE SHUT OFF SWITCH  
DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW  
AE REPLACE SPEED CONTROL PRESSURE SITCH PER 99S15 NOTE ABS LIGHT ON  
PERFORM RECALL  
PERFORM RECALL AS PER NOTICE  
1 DO RECALL 99S15  
COMPLETED RECALL  
REPLACED CRUISE SWITCH  
99S15 SPEED CONTROL SYS 99S15  
INSTALL CRUISE CONTROL DEACTIVATION SWITCH AND REWIRE HARDSHELL CONNECTOR  
99S15 RECALL 99S15 REPLACE SWITCH AND CONNECTOR AS PER RECALL  
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
105079 RECALL #99S15 PERFORM RECALL #99S15 REPLACING CRUISE CONTROL BRAKE PRESSURE DEACTIVATION SWITCH \*% WP  
PERFORMED RECALL 99S15 B 1  
56856 99S15 RECALL REPLACE PRESSURE SWITCH AND CONNECTOR PER RECALL  
CORRECTED RECALL  
PERFORM RECALL PER 99S15 DONE

99S15 99S15 RECALL  
? INSTALLED CRUISE DEACTIVATION SWITCH PER RECALL 99S15  
SPD CTRL DEACTIVATION SW REPLMNTPERFORMED RECALL 99S15  
PERFROM RECALL 99S15  
RECALL 99S15 SPEED CONTROL DEACT SWITCH  
1 REPLACE SPEED CONTROL SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. RECALL 99S15  
71303 PERFORMED RECALL  
99S15 COMPLETE  
99S15 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS P ER RECALL 99S-15  
REPLACE SPD CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL AS NEEDED ALL OK  
RECALL PERFORMED RECALL 99S15  
PERFORM RECALL

PERFORM RECALL  
REPLACE SWITCH

RECALL COMPLETED  
R R SPEED CONTROL SWITCH AND CONNET  
PERFORMED RECALL 98S15  
RECALL 98S15 INSTALL INERTIA SWITCH  
COMPLETED RECALL 98S15B 1  
VEHICLE HAS AN OPEN RECALL PERFORM RECALL  
RECALL 98S15 INSTALL SWITCH  
PERFORMED RECALL  
RECALL 98S15 COMPLETED  
INSTALL DEACTIVATION SWICTH  
98S15 RECALL 98S15 REPAIR AS PER RECALL  
PERFORMED RECALL 98S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH  
RECALL RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
RECALL RECALL ACCOMPLISHED  
RECALL 98S15 RECALL 98S15  
F RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR, 98S15  
PERFORM RECALL  
INSTALL DEACTIVATION SWITCH  
PERFORMED AS PER FORD MOTOR CO.  
REPLACED DEACTIVATION SWITCH AND CONNECTOR

RECALL 98S15 REPLACED SWITCH  
74409 98S15 W REPLACED SWITCH  
RECALL WARR REPLACE SWITCH AND CONNECTOR  
1 CK REPLACED SWITCH AND HARNESS CONNECTOR  
98S15 RECALL  
PERFORM RECALL 98S15  
187517 REPAIR PER 98S15B 0.5  
RECALL RECALL  
PERFORMED RECALL  
COMPLETED AS PER RECALL  
RECALL 98S15 COMPLETED  
1 PERFORMED RECALL 98S15  
RECALL PERFORMED RECALL 98S15 INSTALLED NEW SWITCH AND CONNECTOR PER RECALL AND RETESTED OK  
PERFORM RECALL REPL DEACTIVATION SWITCH  
REPLATED DAMAGE TO CRUISE SWITCH RECALL-VEHICLE HARNESS CAUGHT FIRE DAMAGED 3 WIRING HARNESSES IN ENGINE COMPARTMENT-M TIME 71  
PERFORMED RECALL  
1 PERFORMED RECALL  
RECALL 98S15  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH DUE TO RECALL

REPLACED CRUISE SWITCH  
 RECALL RECALL  
 PERFORM RECALL 99S15  
 REPL SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED RECALL  
 99S15 PERFORM 99S15  
 PERFORMED RECALL 99S15  
 RECALL SPEED CONTROL DEACTIVATION SWITCH  
 COMPLETED 99S15  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 PERFORMED RECALL  
 128047 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 S #DC#99S15  
 REPL CRUISE CONTROL SWITCH  
 99S15 RECALL PERFORM RECALL  
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 RECALL 99S15 REPLACED SWITCH  
 1 PERFORMED RECALL 99S15  
 PERFORM RECALL REPLACE SWITCH  
 RECALL PERFORMED RECALL  
  
 DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH OK NOW  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 72838 RECALL 99S15B 0.5 + 0.1 REPLACE SPEED CONT. SWITCH & PLUG.  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR  
 PERFORM RECALL  
 34711 RECALL 99S15 INSTALLED NEW CONNECTOR  
 RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S15B .5) COMPLETED  
 RECALL 99S15 COMPLETED RECALL 99S15  
 PERFORM RECALL  
 PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15  
 PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH  
 99S15 99S15 REPLACED CRUISE DEACTIVATION SWITCH  
 99S15 RECALL PERFORMED

99S15 RECALL PERFORMED 99S15  
 1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUX  
 82704 RECALL REPLACED DEACTIVATOR SWITCH AND CONNECTOR PER RECALL LETTER  
 81400 RECALL 99S15 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR AS PER RECALL 99S15.  
  
 COMPLETED RECALL...



1 INSTALLED CONNECTOR AND CRUISE SWITCH

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR ON VEHICLE FOR RECALL 99S15

REPL SPD CNTRL DEACTIVATION SW

80009 RECALL 99S15B 0.5 TECH 151 PERFORM RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND HARDSHELL CONNECTOR-ROAD TI

RECALL COMPLETED. THREAD STIPPED OUT ON PROPORTIONING VALVE  
D

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

INSTALL DEACTIVATION SWITCH AS PER RECALL

RNR SWITCH PERFORM RECALL 99S15

CHECKED OASIS. INSTALLED SPEED CONTROL DEACTIVATION SWITCH

X RECALL 99S15

REPLACED CRUISE SWITCH

VEHICLE NOT ELIGIBLE FOR CAMPAIGN AT THIS TIME.

RECALL INSTALL DEACTIVATION SWITCH PER 99S15

COMPLETED RECALL AS REQUIRED

RECALL DONE

99S15 99S15 REPLACED SWITCH

INSTALL SWITCH AND CONNECTOR

REPLACE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15 2 OF 2 ROS

99S15 RECALL SPEED CONTROL DEACT SWITCH

99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S

RECALL 99S15 INSTALLED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL PER RECALL

RENEW SPEED DEACTIVATION SWITCH

REPLACED SWITCH.

80869 RECALL 99S15B 0.5 0.5 REPLACE SWITCH AND CONNECTOR

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

15892 CK FOR RECALL 99S15. REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15

PERFORM RECALL 99S15 SPEED CONTROL AS PER MENU ALL CHECKS OK

99S15 99S15 RECALL

AE REPL BKSW & CONN.

RECALL REPLACE CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW

REPL SWITCH

RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL

REPLACED SPEED CONTROL PER RECALL

80654 PERFORMED RECALL 99S15

PER RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

25200 REPLACED SWITCH AND CONECTOR  
 88761 REPLACE SWITCH AS PER RECALL  
 128354 REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR FOR RECALL  
 INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98A15A .20  
 INSTALLED SOP PERFORMED RECALL 98S15  
 RECALL REPLACE SWITCH  
 1 PERFORMED REPAIRS  
 PERFORMED RECALL  
 98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL  
 PERFORM RECALL-INSTALL SWITCH  
 PERFORM RECALL  
 RECALL 98S15 M-O 82460 REPLACE DEACTIVATION SWITCH PER RECALL  
 47371 RECALL 98S15B 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR  
 88883 REPLACE CRUISE DEACT SWITCH RECALL 98S15  
 132026 PERFORMED RECALL 0.5  
 98S15  
 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 98S15B .5 - ADMIN .1  
 RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL  
 REPLACED CRUISE CONTROL SWITCH  
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE  
 PERFORMED RECALL 98S15  
 1 COMPLETED RECALL PER INSTRUCTIONS 1  
 REPLACED BRAKE SWITCH, WIRE HARNESS BURNT, REPAIRED WIRE HARNESS, AND REPLACED CONN. RETEST OK  
 PERFORMED RECALL 98S15 T128  
 1 PERFORMED RECALL 98S15  
 INSTALL SPEED CONTROL SWITCH  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .8  
 PERFORMED RECALL AS PER INSTRUCTIONS  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
 1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 98S15 98S15 REPLACED DEACTIVATION SWITCH  
 1 PERFORM RECALL 98S15  
 PERFORM RECALL 98S15  
 1 REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND PIGTAIL CONN. PER RECALL  
 RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 48115 98S15 PERFORM RECALL  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .8

1 PERFORM RECALL 98S15  
 RECALL 98S15 RECALL 98S15 REPLACE SWITCH AND PLUG  
 PERFORM RECALL 98S15  
 RECALL PERFORMED RECALL 98S15  
 REPL SPEED CONTROL DEACTIVATION 98S15

PERFORM RECALL

RECALL

PERFORM RECALL 99S15

INSTALL SPEED CONTROL DEACTIVATION AS PER FMC TEST OK

07617 RECALL DID RECALL ON DEACTIVATION SWITCH REPLACED SWITCH

RECALL 99S15

99S15

99S15 INSPECT AND REPLACED SWITCH

38929 RECALL 99S15 INSTALL CRUISE CONTROL SWITCH

REPLACED DEACTIVATION SWITCH.

A89 99S15B 82 .1 ADMIN .5 LABOR 888 REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15

PERFORM RECALL 99S15 T125

99S15

99S15 RECALL

RECALL

CK AND INSTALL CRUISE CONTROL HARNESS

REPLACED DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL

COMPLETE INSTALLED SWITCH AS PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8

RECALL

REPLACED CRUISE CUT OFF SWITCH

CHECK AND INSTALLED CRUISE RECALL

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

OPEN RECALL

PERFORMED RECALL 99S15

RECALL PERFORM EXC

REPLACE SWITCH AND WIRE END

1 INSTALLED DEACTIVATION SWITCH PER RECALL

57938 DO RECALL 99S15

1 REPLACED SPEED CONTROL DEACTIVATION AND HARD SHELL CONNECTOR

INSTALLED DEACTIVATION SWITCH PER RECALL

REPLACED CRUISE SWITCH

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15

FORD RECALL

PERFORMED SPEED DEACTIVAT SWITCH RECALL

INSTALLED DEACTIVATION SWITCH

RECALL 99S15

71798 99S15B 0.5 ADMIN 0.1

40023 PERF. RECALL REPLACED SWITCH TAPE AND INSP. CONNECTOR

RECALL

99S15

111522 .8 DID RECALL REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH, CONNECTOR

PERFORMED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

REPLACE SWITCH

80354 W PERFORM RECALL 99S15

99S15 99S15 PERFORM RECALL

COMPLETE RECALL

COMPLETED RECALL 99S15

RECALL COMPLETE

88558 RECALL DID RECALL ON DEACTIVATION SWITCH

85219 REPLACE DEACTIVATION SWITCH PER RECALL 98S15.

PERFORMED RECALL

RECALL PERFORMED RECALL

1 PERFORM RECALL

120379 RECALL PERFORMED RECALL 98S15

REPLACE CRUISE CONTROL CABLE SWITCH AND WIRE CONN,BLEED BRAKE AND RT PER RECALL

PERFORMED RECALL E

REPLACD DEACTIVATION SWITCH

INSTALL DEACTIVATION SWITCH AS PER RECALL 98S15 2 OF 2 ROS

A89 98S15

REPLACED SWITCH AND CONNECTOR PER RECALL

98S15 RECALL 98S15 REPAIRED AS PER RECALL

RECALL 98S15 COMPLETED

PERFORM RECALL

PERFORMED RECALL 98S15

80418 PERFORM RECALL - DEACTIVATION SWITCH

RECALL 98S15

98S15 REPLACE DEACTIVATION SWITCH AS PER RECALL

REPL SWITCH PER RECALL 98S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S

RECALL 98S15 - B - RECALL

RECALL 98S15B PERFORM RECALL 98S15

PERFORMED 98S15 REPLACED PRESSURE SWITCH AND CONNECTOR

PERFORM RECALL

INSPECTED & REPLACED THE HARDSHELL CONNECTOR.

COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

1 INSTALL SWITCH AND CONNECTOR.....

REPAIR PER 98S15B

PERFORMED RECALL 98S15

1 PERFORMED RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH.

85549 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH RECALL 98S15

PERFORMED RECALL

PERFORMED RECALL

REPLACE AS PER RECALL 98S15

REPLACED THE SWITCH PER RECALL 98S15

PERFORMED RECALL

INSTALL SWITCH AND CONNECTOR

PERFORM 98S15 REPLACED SWITCH AND CONNECTOR

75521 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 98S15

REPLACE CRUISE DEACTIVATION SWITCH PER 99 S 15

REPLACE BRAKE KIT PER RECALL

RECALL 99S15

PERFORM RECALL

COMPLETE RECALL 99S15

REPLACED CRUISE DEACTIVATION SWITCH AS PER RECAL

113104 RECALL REPLACE DEACTIVATION SWITCH OER RECALL(WP) 23

REPLACED DEACTIVATION SWITCH AND BLEED BRAKES AS PERR RECALL

83210 R-R SWITCH CRUISE AND BLEED .

AS PER RECALL

99S15 RECALL TO REPLACED SPEED CONTROL CABLE

REPLACE SPEED CONTROL DEACTIVATION SWITCH

99S15

REPLACE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

99S15 RECALL PERFORMED 99S15

PERFORMED RECALL

72380 WPR30 REPLACE CRUISE CONTROL DEACTIVATION SWITCH

AS PER RECALL

99S15 RECALL TO INSTALL SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15

99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORM RECALL 99S15.

REPLACE SWITCH AND HARNES.

PREFORM 99 S 15 RECALL BY REPLACING SWITCH AND HARD SHELL CONECTER MO 84989

COMPLETE RECALL

PERFORMED RECALL

RECALL

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

1 PERFORM RECALL

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

PERFORM RECALL 99S15

RECALL

REPLACED CRUISE CONTROL CABLE

PERFORMED RECALL 99S15

REPAIR AS PER RECALL 99S15.

RECALL 99S15

99S15

37318 99S10B 0.5 ADMIN 0.1

REPLACE SWITCH PER RECALL

74187 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH

PERFORM RECALL

99S15

108315 RECALL CC42 INSPECT AND REPLACE DEACTIVATION SWITCH AND CON NECTOR

99S15 RECALL

99S15 REPLACED SWITCH AND CONNECTOR

PERFORMED RECALL 99S15

COMPLETED RECALL

RECALL 98S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
RPLC CRUISE DEACTIVATION SWITCH PER 98S15  
REPLACED CONNECTOR AND SWITCH PER RECALL  
RECALL DTD RECALL  
RECALL PERFORMED  
98S15 98S15  
PERFORM RECALL 98S15  
RECALL PERFORMED RECALL # 0836

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 98S15  
PERFORMED RECALL  
SPEED CONTROL DEACTIVATION SWITCH COMPLETE RECALL 98S15  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
R&R CONNECTOR AND SWITCH PER RECALL  
RECALL 98S15  
PERFORMED RECALL 98S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

98S15 98S15  
1 INSPECTED PER RECALL CRUISE CONNECTOR WAS NOT DONE REPLACED CONNECTOR AN SWITCH PER RECALL  
REPLACED DEACTIVATION SWITCH  
REPLACED SPEED CONTROL SWITCH FOR RECALL  
APPLIED RECALL 98S15

22085 98S15B 0.5 HRS SPEED CONTROL RECALL  
PERFORM RECALL  
98S15 RECALL  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15  
COMPLETED RECALL  
1 COMPLETE CAMPAIGN  
PERFORM RECALL 98S15  
RECALL COMPLETED  
DONE WITH RECALL  
PERFORM RECALL  
PERFORM RECALL  
98S15 98S15 INSPECT AND REPLACE CABLE

REPLACE BRAKE DEACTIVATION SWITCH RECALL 98S15

REPAIR AS PER RECALL 98S15  
REPLACE SWITCH PER RECALL  
REPLACED HARDSHELL CONNECTOR & DEACTIVATION SWITCH AS PER 98S15  
REPLACE SWITCH AND CONNECTOR  
1 PERFORMED RECALL  
PERFORMED RECALL 98S15B. PERMANENT REPAIR. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SWITCH  
47716 W REPLACED HARDSHELL CONNECTOR, SWITCH, & LOCKING PIN AS PER RECALL SPECS GA  
RECALL PERFORMED CRUISE DEACTIVATION RECALL  
PERFORMED 99S15 RECALL  
RECALL 99S15 RECALL COMPLETE  
PERFORM RECALL  
99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL  
RECALL 99S15 COMPLETED  
PER RECALL PERF RECALL  
PERFORMED RECALL  
72580 RECALL 99S15 WPC PERFORMED RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
REPL SWITCH PER RECALL 99S15  
SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15  
80080 99S15B 0.5 HRS SPEED CONTROL RECALL  
INSTALLED SPEED CONTROL SWITCH AS PER RECALL 99S  
RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

1 RECALL 99S15 SAFETY SWITCH  
PERFORM RECALL  
1 PERFORMED 99S15 RECALL  
REPLACED RECALLED SWITCH.  
INSTALLED KIT  
PERFORMED RECALL  
99S15 RECALL  
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
99S15 BRAKE KIT 99S15  
REPLACE SWITCH AS PER RECALL  
1 INSTALLED SPEED CONTOTOL DEACTIVATION SWITCH AS PER RECALL  
115244 RECALL 99S15 W PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPL  
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
99S15B RECALL PERFORMED RECAL  
RECALL 99S15  
PERFORM RECALL  
PERFORM RECALL  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
RECALL REPLACE CONNECTOR AND SWITCH  
PERFORM INSPECTION AND REPALCE CONNECTOR AND SWITCH ASSEMBLY  
  
REPLACED CONN AND SW1TCH PER RECALL  
PERFORM RECALL

57141 PERFORM RECALL AS DIRECTED BY TECH INFO REPLACE REDUNDENT CIR BK OVERRIDE SWITCH AND CONECTOR.  
95111 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
99S15B RECALL SPEED CONTROL  
REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15  
OPEN RECALL PERFORM RECALL  
REPL SPEED CONTROL SWITCH 99S15

PERFORM RECALL  
99S15 RECALL 99S15 REPAIRED AS PER RECALL

1 SPEED CONTROL DEACTIVATION SWITCH RECALL  
RECALL 99S15 RECALL 99S15  
RECALL COMPLETED  
RECALL 99S15  
83380 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS  
COMPLETED 99S15 99S15  
NA 99S15 REPLACE SWITCH AND CONNECTOR  
RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPLACEMENT  
PERFORMED RECALL  
RECALL COMPLETED  
99144 RECALL DID RECALL 99S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
SPEED CONTROL DEACTIVATION SWITCH NOT WORKING PROPERLY R AND R DEACTIVATION SWITCH  
RECALL COMPLETED  
RECALLED 99S15 PERFORMED  
RECALL PERFORM RECALL  
PERFORMED RECALL 99S15  
RECALL PERFORM RECALL  
RECALL CRUISE SWITCH RECALL  
99S15 99S15 RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
COMPLETED RECALL 99S15  
REPLACED C CONTROL DEACTIVATION SWITCH PER 99S15 RECALL  
99S15 RECALL PERFORM RECALL  
REPLACED SWITCH AND CONNECTOR  
FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
PERFORM SPEED CONTROL RECALL 99 S 15  
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
COMPLETED RECALL 99S158

PERFORMED RECALL  
PERFORMED RECALL  
REPLACED SWT PER RECALL

RECALL COMPLETED  
70501 PERFORM RECALL 99S15  
COMPLETE RECALL 99S15 T  
REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL INSTRUCTIONS



RECALL 99S15 RECALL  
 SPEED CONTROL SWITCH PERFORM 99S15  
 83679 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 INSTALLED SPEED CONTROL DEACTIVATION AS PER RECALL 99S15 . TECH 43-2418 E  
 INSTALL SWITCH PREVIOUSLY DISCONNECTED ON RO 158832  
 TECH PERFORMED RECALL AS PER OUTLINED-REPLACING DEACTIVATION SWITCH AND REPLACED FAULTY SWITCH-DURING REPAIR FOUND DAMAGE PR  
 REPLACED SWITCH PER RECALL  
 REPLACE CRUISE SWITCH  
 RECALL 99S15 RECALL PERFORME  
 PERFORM RECALL  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 1 REPLACED SPEED CONTROL SWITCH  
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
  
 PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH  
 SPEED CONTROL SWITCH 99S15 RECALL  
 116739 99S15B 0.5 HRS. SPEED CONTROL RECALL  
 REPLACE SPEED SWITCH AS PER RECALL  
 REMOVED SPEED DEACTIVATION SWITCH INSTALLED NEW SWITCH BLEED BRAKES TESTDROVE  
 PERFORMED 99S15 RECALL  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR  
 204702 DEACTIVATION SWITCH REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 PERFORMED RECALL 99S15  
 PERFORM RECALL  
 RECALL REPLACE SWITCH  
  
 99S15B 0.5  
  
 PERFORMED RECALL  
 1 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 99S15B .5 - ADMIN .1  
 76742 PERFORMED RECALL 99S15 AND ROADTESTED.  
 AS PER RECALL 99S15 RECALL TO INSTALL HARDSHELL CONNECTOR SWITCH  
 PERFORMED RECALL  
 RECALL PERFORM RECALL # 0636  
 106733 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
 RECALL 99S15  
 INSTALLED KIT 99S15 RECALL PERFORMED  
 COMPLETE RECALL  
 109144 REPLACED SWITCH  
 PERFORMED SPEED CONTROL RECALL 99S15  
 PERFORMED RECALL  
 INSP AND REPL SWTH AND CONN PER RECALL  
 PERFORM RECALL REPLACE SWITCH  
 PERFORM 99S15 RECALL, REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 99S15 99S15 COMPLETED  
  
 PERFORM RECALL

AS PER RECALL 99S15 RECALL TO INSTALL HARD SHELL CONNECTOR

1 INSTALL KIT

INSTALL BRAKE SWITCH PER RECALL

R&R DEACTIVATION SWITCH PERFORM RECALL 99S15

PERFORMED RECALL 99S15

REPLACE SWITCH TO CORRECT

PERFORMED RECALL

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

99S15B RECALL 99S15B RECALL

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

RECALLED BY FORD MOTOR COMPANY 99S15 COMPLETED RECALL PER LETTER

PERFORMED DEACTIVATION SWITCH RECALL

PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH

99S15 99S15 PERFORM RECALL INSTALLED NEW BRAKE SWITCH AND WIRE HARNESS

REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15

INSTALL SPEED CONTROL KIT

COMPLETE RECALL 99S15 PER FORD SPECIFICATIONS

PERFORMED RECALL 99S15

R&R SPEED CONTROL DEACTIVATION SWITCH PER 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

99013 RECALL INSTALLED CRUISE SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

99S77 42 WPM0 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR

REPLACE SWITCH PER RECALL

RECALL 99S15 COMPLETED

PERFORMED OPEN RECALL 99S15

RECALL REPAIR CRUISE

INSTALL NEW DEACTIVATION SWITCH PER RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH

REPL SWITCH PER RECALL 99S15

REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL

SPEED CONTROL DEACTIVATION SWITCH

CLOSED BY WPI

RECALL 99S15 RECALL 99S15

99S15 INSTALL RECALL PARTS AS PER INSTRUCTIONS.

RECALL REPLACE SWITCH AND CONNECTOR

PERFORM RECALL