

EA02-025

FORD 10/27/03

APPENDIX N

BOOK 6 OF 61

PART 6 OF 6

COMPLETED RECALL 99S15

1 REPLACE DEACTIVATION SWITCH 99S15B

1 PERFORM SPEED CONTROL SWITCH RECALL 1839 .5

CHECK OASIS TO SEE IF VEHICLE WAS COVERED. R AND R BRAKE PRESSURE SWITCH AND CONNECTOR. COMPLETED RECALL 99S15 . TECH 627-5405

154889 RECALL WARR COMPLETED

99S15

INSPECT AND PERFORM RECALL 99S15

TECH REPLACED SWITCH AS REQUIRED

99S15 RECALL

99S15 RECALL, REPLACED SPEED CONTROL CANCEL SWITCH AND HARDSHELL

99S15

99S15 RECALL

RECALL 99S15

RPL SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR

102194 INSTALLED BRAKE KIT.

RECALL COMPLETED

COMPLETE RECALL REPAIRS

44084 PERFORM RECALL 99S15.

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E

RECALL 99S15

APPLIED RECALL 99S15

140820 LABOR 99S15B .5***ADMIN .1***REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

VERIFY R&R CONNECTOR PER RECALL

99S15 WARR PREFORMED RECALL 99S15

COMPLETED SPEED CONTROL RECALL 99S15. THANK YOU FOR USING MONACO FORD.

99S15 RECALL

99S15 MO 93452 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

99S15

99S15

PERFORMED RECALL AS NEEDED 1

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

RECALL 99S15

99S15 RECALL PERFORMED

RECALL 99S15 REPLACED CRUISE DEACTIVATION SWITCH -WIRING CONNECTOR PER RECALL 99S15

REPLACED DEACTIVATION SWITCH

58652 RECALL 99S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL

1 PERFORM RECALL 99S15 REPLACE DEACTIVATION SWITCH. THANKS JEFF S.

REPLACE SPEED CONTROL SWITCH

REPLACE DEACTIVATION SWITCH

RECALL

REPLACE SWITCH

PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED 99S15 RECALL

85738 RECALL 99S15 PREFORMED RECALL INSTALLED NEW SWITCH AND CONNECTOR. ROAD TESTED CHECKED OPERATI OF SPEED CONTROL WORKED F

1008 REPLACE BRAKE SWITCH PER 99S15 RECALL TECH1140

1 PERFORMED RECALL 99S15

RECALL 99S15

INSTALLED SWIT

INSTALL SWITCH PER RECALL

REPLACE SWITCH AND HARNESS PER RECALL.
PERFORMED RECALL PERFORMED RECALL
PERFORMED RECALL 99S15
REPLACED DEACTIVATION SWITCH PER RECALL 99S15
PERFORM RECALL-REPLACE SWITCH AND CONNECTOR

99S15, REPLACED CRUISE CONTROL HARDSHELL CONN
RECALL REPLACE SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL

1 REPLACED CRUISE SWITCH PER RECALL
99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
70205 RECALL WP40 PERFORMED 99S15 RECALL. REPLACED CRUISE CONTROL SWITCH.
PER NOTICE PERFORM RECALL
PERFORM RECALL 99S15
98150 PERFORMED RECALL 99S15
PERFORM RECALL
RECALL COMPLETED

75081 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND SHELL. 99S15B 0.5 HR LABOR 0.1 ADMIN.
PERFORM RECALL 99S15, INSTALL CRUISE DEACTIVATION SWITCH. THANK YOU, JEFF S
INSTALL SWITCH ASSY
REPLACE SWITCH

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
PERFORM RECALL
1 PERFORMED RECALL
REPLACED DEACTIVATION SWITCH
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
REPLACED DEACT CRUISE SWITCH

COMPLETE RECALL 99S15
PER RECALL. COMPLETED RECALL
REPLACE SWITCH PER RECALL
83713 99S15 W REPLACED SWITCH
COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH T
PERFORMED RECALL 99S15: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR.
RECALL 99S15 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH

OPEN RECALL PERFORMED RECALL
INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
99S15B COMPLETED RECALL
REPAIR AS PER RECALL
PERFORMED RECALL
72831 PERFORMED RECALL 99S15
RECALL INSTALL CUTOFF SWITCH AS DIRECTED

41730 PERFORMED RECALL 98S15.

PERFORMED RECALL

G RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

1 PERFORM RECALL

PRFMD RECALL 98S15

98S15 REMOVE TAPE AND SECURE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL FOR INTERIM REPAIR

FACTORY RECALL. COMPLETED RECALL

98S15

1 PERFORM SPEED CONTROL RECALL 1830 .5

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15. BLEED BRAKE SYSTEM AND CHECKED OPERATIC

RECALL. PERFORMED RECALL 98S15

PERFORMED RECALL 98S15

PERFORM RECALL

REPLACED SWITCH

07290 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL.

98S15B COMPLETED

REPLACE AS PER RECALL 98S15

REPLACED CRUISE DEACT SWITCH

PERFORMED RECALL REPLACED THE SWITCH AND CONNEC TOR

RPL CRUISE SWITCH PER RECALL 98S15

INSTALLED KIT TO COMPLETE

PERFORM RECALL

AE REPLACE SWITCH AND CONNECTORE

98S15 RECALL

FORD SAFETY RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTO

05101 RECALL GA

REPLACED THE SWITCH PER SERVICE CAMPAIGN . 98S15 B .5 ADMIN .1

RECALL

RECALL

08232 REPLACE SPEED CONTROL SWITCH AND CONNECTOR PER RECALL 98S15.

RECALL

98S15 - COMPLET

REPLACED DEACTIVATION SWITCH AS PER RECALL.

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL

REPLACED SWITCH AND CONNECTOR PER RECALL

INSPECTED CRUISE SWITCH AND INSTALLED NEW SWITCH AS PER RECALL AS NEEDED FOR REPAIRS

REPLACED SW & CONECTOR

REPLACED SWITCH AND CONNECTOR

PERFORMED 98S15 AS PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 RECALL 98S15 REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR X 930 X

AS PER RECALL

98S15 RECALL TO INSTALL SWITCH KIT

114208 PERF RECALL-REPLACE CRUISE SWITCH

PERFORM RECALL 98S15.

RECALL 98S15

RECALL 98S15

RECALL COMPLETED

55954 98S15 WARRANTY INSTALL SWITCH AND WIRE PLUG .

RECALL DUE PERFORMED RECALL 98S15B

PERFORM RECALL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL T

128702 RECALL 98S15 98S15B .5 REPLACED SWITCH AND CONNECTOR PER RECALL

FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 98S15 RECALL

REPLACED DEACTIVATION SWITCH PER 98S15 RECALL

PERFORM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

024 REPLACED CRUISE DEACTIVATION SWITCH

78757 98S15 WARRANTY RECALL INSTALL SWITCH AND PLUG

REPLACE DEACTIVATION SWITCH

87487 RECALL 98S15 INSTALL DEACTIVATOR SWITCH AS PER RECALL

98S15 98S15 RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PE RECALL 98S15

REPLACED CRUISE DEACTIVATION SWITCH PER 98S15

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL COMPLETE

RECALL 98S15 REPLACED CRUISE DE-ACTIVATION SWITCH AS PER RECALL 98S15

PERFORMED PROGRAM 98S15

RECALL 98S15 COMPLETED

TECH RECOMMENDS-TRANSMISSION SERVICE-125.00 PLUS TAX

-TIRE ROTATION 15.50 PLUS TAX

-FRONT END AL

PERFORM RECALL

1 PERFORM RECALL 1638 .50

82865 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15

110493 RECALL 98S15 REPLACE DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL 98S15B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.

REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

RECALL COMPLETE RECALL

CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL

PERFORMED RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR

GOODWILL.....

1 CAMPAIGN COMPLETED.

REPLACED THE SWITCH PER RECALL 98S15

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL

101084 CHECK AND INSTALL NEW CRUISE DEACTIVATION SWITCH PER RECALL 2588

98S15 RECALL INSTALL DEACTIVATION SWITCH

98S15 98S15-REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH

REPLACED SWITCH & CONNECTOR PER RECALL

98S15 98S15

1 PERFORMED RECALL 98S15

98353 DID RECALL 98S15 REPLACED SWITCH AND CONNECTOR SHELL

51083 PERFORM 98S15 RECALL PER INSTRUCTIONS

PERFORM 98S15 RECALL

31818 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B .5
PERFORM RECALL

REPLACE SWITCH

RPL CRUISE SW PER RECALL 99S15

X 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
RECALL PERFORM RECALL 99S15 CRUISE CONTROL

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTIONS

1 PERFORM SPEED CONTROL RECALL 1839 .5

1 INSPECT AND PERFORM RECALL AND BLEED BRAKES .5 1839

85908 REMOVE AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.

PERFORMED RECALL REPLACED SWITCH AND CONECTOR

RECALL 99S15

115531 99S15B 0.5 HRS. SPEED CONTROL RECALL

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE

109837 RECALL REPLACED SWITCH

PERFORM RECALL 99S15

PERFORMED RECALL

PERFORMED RECALL 99S15

RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

99S15 PERFORM 99S15

99S15 51117 MILAGE REPLACE SPEED CONTROL PRESSURE SWITCH PER 99S15

1 PERFORM RECALL

1 PERFORMED RECALL

RAN DIAGNOSTIC TESTS. REPLACED DEFECTIVE SOLENOID FOR TORQUE CONVERTOR CONTROL. ROAD TESTED 99-06-06 CC-41 CP-7G138

INSTALLED RECALL 99S15 NOTE: RADIO DOES NOT WOR

85957 99S15B 0.5 ADMIN 0.1

PERFORMED RECALL 99S15

94989 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745

PERFORM RECALL 99S15

PERFORM RECALL

1 PERFORM CRUISE RECALL 1839 VEHICLE ALSO NEEDS TUNE, FUEL FILTER, PCV VALVE, INJECTOR CLEAN

00 99S15

52735 PERFORM RECALL, REPLACE DEACTIVATION SWITCH 99S15B .5

RECALL 99S15 RECALL COMPLETED

1 PROFORMED RECALL 99S15 DIACTIVATION SWITCH AND CONNECTOR 99S15B

REPLACE SPEED CONTROL CABLE PER RECALL 99S15

PER THE OASIS PERFORMED RECALL 99S14.

TECH COMPLETE RECALL AS REQUIRED

REPLACE SWITCH

99S15 99S15 RECALL

1 REPLACED SWITCH AND BLEED BRAKES AS PER RECAL

88303 1 PERFORMED RECALL 99S15

COMPLETED RECALL

REPLACED SC DEACTIVATION SWITCH 99S15

PERFORM RECALL

INSTALL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
RECALL DUE PERFORMED RECALL 98S15B

1 PERFORMED RECALL

98S15 RECALL

98S15 RPL SPEED CONTROL DEACTIVATION SWITCH & REWIRE CONNECTOR

98S15

98S15 RECALL

48001 SERVICE RECALL 98S15 REPLACE NEW BRAKE SWITCH

PERFORM RECALL

PERFORMED RECALL

98S15

98S15 RECALL

34211 INSTALL SWITCH PER RECALL

98S15

98S15 RECALL

REPAIR AS PER RECALL

RECALL PERFORMED

REPLACED SWITCH & CONNECTOR PER 98S15

98S15

CAMPAIGN COMPLETED

REPLACED SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL PER INSTRUCTION

PERFORMED RECALL 98S15

RECALL

CRUISE CONTROL RECALL 98S15

REPLACED SPEED CONTROL SWITCH AND CONNECTOR

A99

98S15

1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 98S15 PER RECALL INSTRUCTIONS

RECALL 98S15

RECALL PERFORME

PERFORM RECALL 98S15

PERFORM RECALL 98S15

85596 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 98S15

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORMED RECALL 98S15

98S15 RECALL

98S15 REPLACE SWITCH AND HARDSHELL CONNECTOR

D

98679 WAS FOR 98S15E.

58174 98S15 INSPECT AND INSTALL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

PERFORM RECALL 98S15

INSTALL BRAKE KIT PER RECALL 98S15

RECALL COMPLETED 98S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL 98S15B ... REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 98S15

98S15 BRAKE REPAIR

MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

RECALL 98S15 SPEED CONT DEACT SWITCH

RECALL 99S15 REPLACE C-C SW
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH
 SPEED CONTROL DEACTIVATION SWITCH REPLACE 99S15B PERFORMED RECALL 99S15B
 2009S RECALL W REPLACE SWITCH GA
 PERFORM 99S15 RECALL
 PERFORM RECALL 99S15
 COMPLETED RECALL 99S15
 RECALL 99S15 PERFORMED RECALL 99S15-REPLACED CRUISE CONTROL SWITCH
 1 REPLACE THE CRUISE CONTROL SWITCH AND PLUG 99S15
 COMPLETE RECALL 99S15
 OPEN RECALL PERFORMED 99S15
 REPLACE SWITCH PER RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION
 PERFORM RECALL
 REPLACED SPEED CONTROL SWITCH PER RECALL
 99S15 RECALL 99S15 REPAIRED AS PER RECALL

REPLACE SPEED CTRL CONNECTOR AND HARNESS
 60829 0.5 REPLACED DEACTIVATION SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 99S15 COMPLETED REPLACED SWITCH.
 COMPLETED RECALL PER INSTRUCTIONS
 126163 REPLACE SPEED CONTROL CABLE ROAD TEST TEST OK AT THIS TIME, COMPLETED
 RECALL 99S15 PERFORMED RECALL-REPLACED C-C DEACTIVATION SWITCH
 135814 TECH 679 PERFORMED RECALL 99S15 ON CRUISE CONTROL

65782 REPLACED DEACTIVATION SWITCH 6314
 INSTALL DEACTIVATION SWITCH

REPAIR REPLACE
 100677 RECALL REPLACED DEACTIVATOR SWITCH AND CONNECTOR RECALL 99S15

REPLACED SWITCH
 INSPECT AND PERF RECALL ACCORDING TO INSTRUCTIONS 1
 RECALL 99S15 RECALL
 REPLACE SWITCH PER RECALL
 83158 99S15B 0.5 HRS. SPEED CONTROL RECALL
 RECALL PERFORM RECALL 99S15
 RECALL 99S15 RECALL
 1 99S15EL5 ADMIN .1
 1 INSTALLED RECALL SWITCH 1

98S15 RECALL 98S15 RECALL COMPLETE
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 98S15
98233 RR SWITCH
38207 98S15 REPLACE DEACTIVATION SWITCH & CONNECTOR PER 98S15 TECH 5323 TECH 532
109712 RECALL DO RECALL

REPLACED DEACTIVATION SWITCH
1 REPLACE BRAKE SWITCH AND CONNECTOR
SAFETY RECALL 98S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
98S15 98S15 REPLACE DEACTIVATION SWITCH AS PER RECALL
98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED SWITCH

PERFORMED CRUISE CONTROL RECALL 98S15
COMPLETED AS PER RECALL

RPLC SPEED CONTROL DEACTIVATION SWITCH PER 98S15

REPLACE DEACTIVATION SWITCH AS PER RECALL
PERFORM RECALL
1 PERFORM RECALL 98S15 E
INSTALLED CRUISE RECALL 98S15.

PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR
RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 98S15B FOR .5 AND .1 FOR ADMIN. TIME
REPLACE SPEED CONTROL DEACTIVATION SWITCH 1
33801 INSTALL DEACTIVATION SWITCH PER RECALL
REPLACED SWITCH
104051 SHRS PERFORMED RECALL 98S15 REPLACED CRUISE CONTROL DEACT SWITCH.
81955 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH
1 PERFORM RECALL
REPLACED SPEED CONTROL SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL 98S15

COMPLETED AS PER RECALL
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .6
INSTALLED SWITCH
REPLACE SWITCH CONNECTOR ASSEMBLY
98S15 98S15
82297 PERFORMED RECALL # 98S15
REPLACED DEACTIVATION SWITCH
DIAGNOSE REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

99S15 SPEED CONTROL RECALL
PERFORM RECALL PER FORD
.5 LABOR AND .1 ADMIN PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS REPLACED DEACTIVATION SWITCH AND CONNECTOR
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
RECALL 99S15 COMPLETED
INSTALLED SWITCH ON CRUISE CONTROL AS PER RECALL 99S15.

103394 PERFORM RECALL 99S15 REPLACE CUT OFF SWITCH FOR CRUZ
99S15B RECALL 3 PERFORM RECALL
RECALL 99S15 PERFORMED RECALL 99135
REPLACE SPEED CONTROL DEACTIVATION SWITCH.
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS

RECALL SPEED CONTROL REPLACE SWITCH AND CONECTOR
99S15 RECALL 99S15 RECALL
99S15 REPLACED SWITCH & CONNECTOR PER RECALL
72936 WARR PAY TECH 4207 AS PER C. BEBER PERF 99S15
99S15 PERFORMED RECAL
REPLACE SWITCH AND CONNECTOR
RECALL 99S15 RECALL
SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
OPEN RECALL PERFORMED RECAL
RECALL REPLACESWITCHAND CONNECTOR
93337 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORMED RECALL
41693 REPLACED SPEED CONTROL DEACTIVATION SWITCH 99S15B 0.5 HRS. 0.1 ADMIN
REPLACE DEACTIVATION SWITCH TO CRUISE CONTROL 1
RECALL 99S15 RECALL-R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR

1 PERFORMED RECALL 99S15
PERFORMED RECALL 99S15
PERFORM RECALL 99S15 - -REPLACE SPEED CONTROL SWITCH
PERFORMED RECALL

99S15 INSTALL CRUISE DEACTIVATION SWITCH PER RECALL
A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE,ALSO A FIRE COULD DEVOPE. REPLACE
110947 REPLACED DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
93786 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONECTOR
RECALL 99S15 REQUIRED REPL BRAKE DEACTIVATOR SWITCH PER RECALL 99S15.
CAMPAIGN COMPLETED

64438 RECALL99S15 99S15B 0.5 0.5 RECALL
RECALL INSTALL DEACTIVATION SWITCH AS PER RECAL
RECALL 99S15
PERFORM RECALL99S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR

REPLACE SWITCH PER RECALL

125690 CRUISE DEACTIVATION SWITCH RECAL 98S15 INSTAL CRUISE DEACTIVATION SWITCH FOR RECAL 23

100488 PERFORM 98S15 RECALL

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

INSPECT AND REPLACE CRUISE CONTROL SWITCH

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

00

98S15

REPLACE SPEED CONTROL SWITCH PER RECALL 98S15

AS PER RECALL

98S15 RECALL TO INSTALL HARSHELL CONNECTOR KIT

COMPLETED AS PER RECALL

98S15

PERFORMED RECAL

RECALL 98S15

RECALL 98S15

INSTALLED KIT PER FACTORY RECALL

OWNER NOTIFICATION

CRUISE CONTROL RECALL 98S15

COMPLETED RECALL PER INSTRUCTIONS

RECALL

PERFORMED RECAL

RECALLED

98S15 PERFORMED

REPLACED SWITCH

98S15

98S15

PERFORM RECALL 98S15 BLEED BRAKE SYSTEM ROAD TEST OK AT THIS TIME..

D

98S1 WAS FOR 98S15E

177224 PERFORM RECALL AS PER INSTRUCTIONS

TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL

RECALL

REPLACE SWITCH PER RECALL

RECALL 98S15 PERFORMED

103279 INSTALLED RECALL 98S15

27255 08 REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

98S15B

98S15B

COMPLETED AS PER RECALL

PERFORM RECALL

SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL

98S15 REPLACED DEACTIVATION SWITCH PER RECALL

1 REPLACED SWITCH

COMPLETED RECALL PER INSTRUCTIONS

PERFORM RECALL AS REQUIRED

98S15

PERFORMED RECALL 98S15
REPAIR CRUISE CTL PER RECALL
RECALL 98S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
COMPLETED RECALL 98S15
CRUISE SWITCH 98S15 REPLACE CRUISE SWITCH AND CONNECTOR
INSTALL CRUISE CONTROL CANCEL SWITCH
REPLACED SWITCH PER FACTORY RECALL
SPEED CONTROL SWITCH 98S15 RECALL
PERFORM RECALL 98S15 INSTALL KIT
RECALL COMPLETE
PERFORMED RECALL 1

98S15 SPEED CONTROL RECALL
REPLACED SWITCH
84295 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
11380 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONICTOR TK372
PERFORMED RECALL
82 RECALL 98S15-R&R SPEED CONTROL DEACTIVATION SWITCH

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
98S15 INSTALL SWITCH CONNECTOR
PRFORMED RECALL TECH 1737
PERFORM RECALL
82686 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL
REPLACED DEACTIVATION SWITCH AND COVER
102999 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH
112885 PERFORM 98S15 SPEED CONTROL DEACT SWITCH
INSTALLED KIT 98S15 RECALL PERFORMED
RECALL SPEED CONTROL DEACTIVATION SWITCH

PERFORMED THE RECALL 98S15
REPLACED CRUISE CONTROL SWITCH PER RECALL
1 REPLACE CRUISE CONTROL SWITCH AS PER RECALL
PERFORMED THE RECALL 98S15
REPLACE SPED CONTROL DEACTIVATION SWITCH
91706 RECALL 98S15
PERFORM 98S15 RECALL
0894-REPLACE HARDSHELL CONNECTOR AND SWITCH
81985 PERFORM RECALL

42754 98S15 R&R CRUISE CONTROL SWITCH
REPLACE SWITCH AND CONNECTOR FOR RECALL RECALL _____
PERFORMED RECALL
TYPE 2 PROGRAM 98S15 PERFORM RECALL PER GUIDEL

RECALL 98S15 COMPLETED
REPLACED DEACTIVATION SWITCH.
COMPLETED RECALL

SHORT MAY DIASABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PERFORM RECALL

PERFORMED RECALL 98S15 CRUISE SWITCH REPLACEMENT

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN

82052 98S15 RECALL R&R SWITCH AND CONNECTOR PER RECALL

45342 42 WP40 COMPLETE RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTION

83332 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONECTOR TIG72

84448 RECALL TECH 9177 PERFORM RECALL 98S15 INSTALL SWITCH AND CONNECTOR

84284 98S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745

OK AND REPAIR AS PER RECALL

PERFORMED RECALL #98S15.. REPLACED THE SPEED CONTROL DEACTIVATION SWITCHES.. NOTE: SPEED CONTROL DID NOT OPERATE PRIOR TO RECA
INSTALL KIT

1 PERFORMED RECALL-REPLACE CRUISE CONTROL DEACTIVATION SWITCH

OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15

24508 INSTALLED NEW SPEED DEACTIVATION SWITCH AS PER RECALL 98S15.

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS

48551 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

3089 WLM 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

98S15 COMPLETED

REPLACED SWITCH PER RECALL

98S15 SPEED CONTROL RECALL

NA PERFORMED REPAIRS AS PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PERFORM RECALL

PERFORMED RECALL PERFORMED RECALL

INSPECT OR REPLACE CABLE PERFORMED RECALL 98S09

22458 CC 42 PERFROM RECALL 98S15

RECALL REPAIR AS PER RECALL 98S15 DEACTIVATION SWITCH REPLACEMENT

REPLACE CRUISE CONTROL SWITCH AS PER RECALL

PERFORMED RECALL 98S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

98S15 98S15 RECALL

PERFROMED RECALL

98S15 REPL SPEED CONTROL DEACTIVATION SWITCH

INSPECT AND REPALCE CRUISE CONTROL CONNECTOR

PERFORM RECALL

RECALL 98S15

RECALL 98S15 PERFORM RECALL 98S15 PER LETTER

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PERFORMED AS PER RECALL

PERFORMED REECALL 98S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORM RECALL

REPLACE SWITCH AND HARNESS PER RECALL

PERFORMED CRUISE RECALL

PERFORM RECALL 98S15

FACTORY RECALL COMPLETED RECALL

58516 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK

R REPLACE SWITCH PER RECALL INSTRUCTIONS

94883 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST

PERFORMED THE RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

38806 CC-42 RECALL TECH 8045 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15

PERFORM RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

REPLACE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

63824 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL # 98S15

REPLACE AS PER RECALL 98S15

PREFROEND RECALL

60821 RECALL#98S15 SPEED CONTROL DEACT SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL#98S15.

RECALL SPEED CONTROL DEACTIVATION SWITCH SELF APPROV FOR MISENTERED MILEAGE

PERFORM RECALL INSTALL SWITCH

COMPLETED RECALL

PERFORM RECALL -DONE

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL 98S15

COMPLETED RECALL

RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

48573 PERFORMED RECALL 98S15

128380 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH AND CONNECTOR AS PER RECALL

PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK

INSTALL UPDATED SPEED CONTROL DEACTIVATION SWITCH

31094 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL

1 REPLACED SPEED CONTROL SWITCH AND CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL PERFORMED RECALL

REPLACED DISENGAGE SWITCH PER RECALL 98S15

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

75885 REPLACE DEACT SWITCH AND CONN PER RECALL 98S15

REPAIR SPEED CTL PER RECALL

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL

RECALL 98S15 REPLACE C-C SW

RECALL 98S15 CONNECTOR MELTED WIRES MELTED AND FUSE BLOWN REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15 ALSO

CRUISE RECALL REPL SW.
RECALL 99S15
PERFORM RECALL 99S15
PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL 99S15

INSTALL DEACTIVATION SWITCH KIT
1 DO RECALL 99S15

COMPLETE RECALL
120138 RECALL PERFORM RECALL 99S15 REPLACE SWIT
COMPLETE RECALL
REPLACED SWITCH PER RECALL 99S15
84206 W.. REPLACE CRUISE SWITCH PER RECALL(CC82)
99S15 99S15 RECALL
99S15 REPAIR PER RECA
RECALL
99S15 RECALL PERFORMED
PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL,BLED BRAKES,CHECKS OK
48009 INSTALLED 99S15 SPEED CONTROL SWITCH
99S15 99S15

1 REPLACED DEACTIVATION SW AS PER RECALL 99-S-1
RECALL 99S15 RECALL 99S15
99S15 99S15
99S15 RECALL COMPLETE RECALL
INSTALL SWITCH KIT

COMPLETE RECALL 99S15
PERFORM RECALL 99S15
COMPLETE RECALL 99S15
PERFORM RECALL 99S15 REPLACE SWITCH.
PERFORM RECALL 99S15
99S15-4404 REPLACED SPEED CONTROL DEACTIVATION SWITCH

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15
99S15B
RECALL 99S15 RECALL
RECALL 99S15 RECALL 99S15

PERFORM RECALL SPEED CTRL DEACT SWITCH
REPLACED CRUISE SWITCH AND CONNECTOR PER RECALL
99S15 REPLACED CRUISE DEACTIVATION REPLACED DEACTIVATION SWITCH FOR CRUISE CONTROL
132500 R-R SW PER RECALL
INSPECT AND REPALCE CRUISE SWITCH AND CONNECTOR
45718 W PERFORM RECALL

99990 RECALL INSTALL RECALL SWITCH AND CONTACTOR AS INSTRUTED

1 PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S15B .5) COMPLETED

REPL SWITCH PER RECALL 99S15

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL PARTS

99S15

99S15 RECALL

78135 REPLACE SWITCH AS PER RECALL

RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.

PERFORMED RECALL 99S15B.

COMPLETE RECALL 99S15

5400 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPAIR AS PER RECALL 99S15.

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT

PERFORMED RECALL

COMPLETED RECALL

REPL SWITCH PER RECALL 99S15

99S15

99S15

PERFORMED RECALL 99S15

REPLACED SWITCH AS PER RECALL

PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

007 COMPLETED RECALL 99S15

PERFORMED RECALL

78914 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH AND CONNECTOR

PERFORMED OPEN RECALL

90087 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

99S15 REPLACED SPEED CONTROL DEACTIVATION SWITC

99S15

99S15 RECALL

PERFORMED 99S15 RECALL

PERFORM SAFETY RECALL

99S15 RECALL

PERFORMED 99S15 RECALL

UNKNOWN

INSTALL CRUISE DEACTIVATION SWITCH PER 99S15

30937 .3 + .1 ADMIN. 99S15B. REPLACED DE- ACTIVATION SWITCH.

REPL KIT PER RECALL 99S15

109391 REPLACED SPEED CONTROL SWITCH AS PER RECALL # 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED 99S15 RECALL

PERFORM 99S15 RECALL

PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

PERFORMED RECALL

81575 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

99S15

99S15-REPLACED THE CRUISE CONTROL SWITCH

RECALL

INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

115517 99S15

PERFORMED RECALL

AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL HARDSHELL SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

126003 99S15B 0.5 0.5 PERFORM 99S15
RECALL DONE AS PER RECALL

23448 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

REPLACE SWITCH AND HARD SHELL

OPEN RECALL PERFORM RECALL

REPLACE DEACTIVATION SWITCH.

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

99S15 99S15

COMPLETED RECALL 99S15

99S15 INSTALLED REPAIR KIT AS PER RECALL

COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH

18C733 42 ROAD TEST TO VERIFY, EVAC & RECHARGE TO REMOVE EXCESS OIL REPLACE ORFICE & PRESS SWITCH & BLEND DOOR ACT & PET.OMETER

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 99S15

101849 RECALL W INSPECT REPLACE DEACTIVATOR SWITCH AND CONNECTOR PER 99S15 911 1168

REPLACED CRUISE DEACTIVATION SWITCH

RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

08548 PERFORM RECALL 99S15

PERFORME 99S15

08532 WARRANTY, PERFORMED SPEED CONTROL SWITCH RECALL AS PER RECALL INSTR,

REPLACE SPEED CONTROL SWITCH

PERFORMED RECALL 99S15

99S15 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR

1 RECALL 99S15

118018 PERFORM 99S15 RECALL,REPLACE DEACTIVATION SWITC

38448 PERFORMED RECALL 99S15.

PERFORMED RECALL 99S15

REPLACE CRUISE DEACTIVATION SWITCH

RECALL 99S15 REPLACE DEACTIVATION SWITCH

PERFORM RECALL 99S15 --REPLACE CRUISE CONTROL SWITCH

RECALL 99S15 RECALL

SPEED CONTROL SWITCH 99S15 RECALL

INSTALL HARDSHELL CONNECTOR

45398 99S15B .5 REPLACE SWITCH AND HARDSHELL

99S15 99S15

RECALL 99S15

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8

REPL SWITCH PER RECALL 99S15

REPL SWITCH PER RECALL 99S15

99S15B 0.5

COMPLETED RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
REPLACED DEACTIVATION SWITCH PER 98S15 RECALL
84894 DID RECALL # 98S15

X PERFORMED RECALL

100221 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 98S15.

1 REPLACE CRUISE CONTROL SWITCH AS NEEDED

B 5 INSTALLED SWITCH AND WIRING 7548

SWITCH AND WIRING CONECTOR. 1

1 PREFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION

201433 RECALL 98S15 RPL BRAKE PRESSURE SW AND CNCTR PER 98S15

REPLACE SWITCH PER RECALL

REPLACE SPEED CONTROL SWITCH

98S15

SPEED CONTROL RECALL

RECALL

98S15 REPLACE C-C SW

98S15 RECALL

98S15 RECALL INSTALLED SPEED CONTROL CABLE PER RECALL

08828 WHILE REMOVING THE DEACTIVATOR SWITCH THE THREADS PULLED OUT OF THE METERING VALVE THE VEHICLE NEEDS A NEW VALVE INSTALLED

PERFORMED RECALL

82255 RECALL W REPLACE SWITCH AND PLUG GA

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

REPLACED HARD SHELL AND SWITCH AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

94163 INSTALLED THE BRAKE INPUT SWITCH FOR THE SPEED CONTROL SYSTEM PER RECALL NOTICE.

REPLACED SC DEACTIVATION SWITCH 98S15

REPLACED DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 98S15

REPL SWITCH PER RECALL 98S15

PERFORM RECALL 98S15

PERFORMED RECALL 98S15

RECALL

98S15 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL

RECALL COMPLETE

98S15

REPLACE DEACTIVATION SWITCH

RECALL 98S15

PERFORM RECALL 98S15

RECALL

RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

PERFORMED RECALL

PERFORMED RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH 98S15

RECALL INSTALL NEW DEACTIVATION SWITCH

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

98S15

98S15 RECALL

OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRU

98S15 COMPLETED

98S15 COMPLETED

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

REPLACED SPEED CONTROL

RECALL PERFORM RECALL .RENEW SWITCH AND CONNECTOR

98S15 PERFORM RECALL 98S15

1 1 REPL DEACTIVATION SWITCH AND CONNECTOR.

1 REPLACED DEACTIVATION SWITCH. AS PER RECALL 98S15

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL 98S15

9 PERFORM RECALL 98S15

14882 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST

PERFORMED RECALL 98S15

PERFORM RECALL

RECALL 98S15 RECALL 98S15 COMPLETED.

98S15 SPEED CONTROL RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRUCT

VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

RECALL 98S15 RECALL

REPL SWITCH AND CONNECTOR REPAIR AS PER RECALL #98S15

REPLACED KIT PER RECALL

PERFORMED RECALL

98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

98S15 REPLACE DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

98S15B PERFORMED RECALL

PERFORM RECALL 98S15

RECALL 98S15 PERFORM RECALL 98S15

RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE DEACTIVATION SWITCH PER RECALL 98S15

PERFORMED RECALL 98S15

PERFORM RECALL 98S15

42246 W 752 PERFORMED RECALL 98S15

PERFORM RECALL

INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 98S15E 0.3 HRS PERMANENT REPAIR REPLAC

REPLACE DEACTIVATION SWITCH FOR CRUISE CONTROL

REPLACE DEACTIVATION SWITCH. MILEAGE WAS VERIFIED

REPLACED SPEED CONTROL SWITCH AND CONNECTOR

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACE DEACTIVATION SWITCH

1 INSTALLED SWITCH AND CONNECTOR

REPL SWITCH PER RECALL 98S15

107338 RECALL 98S15 PERFORM RECALL 98S15 AS PER TSB TEST DRIVE 4 MILES O. K

REPLACED CRUISE DEACTIVATION SWITCH

PERFORM RECALL 98S15
98S15 98S15 COMPLETED

83854 RECALL WPG40 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15
OPEN RECALL PERFORM RECALL
CRUISE DEACTIVATION SWITCH, PERFORM RECALL AS PRESCRIBED ROAD TESTED OK

X RECALL

1 INSTALLED SWITCH AND WIRE CONNECTOR
PERFORMED AS PER RECALL
REPLACED SWITCH AND CONNECTOR AS PER RECALL
RECALL RECALL DONE
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. INTERIM REPAIR-REMOVE, TAPE AND SE
CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECALL
98S15 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 98S15
PERFORM RECALL INSTALL SWITCH
118884 RECALL 98S15B 0.5 0.5 RECALL
REPLACED SWITCH
PERFORM RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
98S15 COMPLETED 98S15 COMPLETED
PERFORMED THE RECALL 98S15
PERFORMED RECALL 98S15
98S15 PERFORMED RECALL
RECALL COMPLETED
COMPLETED RECALL 98S15

181438 RECALL W PERFORMED RECALL 98S15 REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR
PERFORM RECALL
1 REPLACED SPEED CONTROL DEACTIVATION SWITCH
1 PERFORMED RECALL
RECALL 98S15 RECALL, REPLACE SWITCH
78203 98S15 WARR REPLACED SWITCH AND CONN
PERFORMED RECALL
PERFORMED RECALL
SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACT. SWITCH AS DIRECTED
PERFORMED 98S15 RECALL

JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
REPLACED DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH. DIFFERENCE OF ONE MILE FOR ROAD TESTING.
SERVICE REPLACED SWITCH AND BLEED BRAKES PER RECALL
REPLACED DEACTIVATION SWITCH PER RECALL

RECALL 99S15 REPLACE C-C SW

PERFORMED THE RECALL 99S15

PERFORM SPEED CONTROL RECALL

PERFORM RECALL 99S15

PER RECALL RPLC SPEED CONTROL DEACTIVATR SW PER RECALL & HARD SHELL

1 RECALL 99S15 COMPLETED

MILEAGE ENTERED IS CORRECT. ON 6/2 VEHICLE HAD 69983 MILES, THEN ON 7/28 IT HAD 71004. DONT UNDERSTAND PROBLEM ?

88203 99S15 RECALL ADD ON OKD BY R.A.B. INSPECT AND INSTALL DEACTIVON SWITCH AND HARD SHELL AS PER 99S15 INSTRUCTIONS

RECALL 99S15 PERFORMED RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15

PERFORMED THE RECALL 99S15

CERTRAIN 1982 AND 83 CROWN VICTORIA, GRAND MARQ. AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL AC

PERFORM RECALL 99S15

42585 RECALL 99S15 W 99S15B 0.5 HRS ADMS 0.1 HRS REPLACE SPEED CONTROL DEACTIVATION SWITCH AND C ONNECTER PERRECALL 99S15-B

RECALL 99S15

OPEN RECALL PERFORMED RECALL 99S15

99S15 RECALL 99S15 RECALL

RECALL RECALL

INSTALLED NEW SPEED CONTROL SWITCH AS PER RECALL 99S15 ROAD TEST NORMAL . TECH 406-05845

RECALL INSTALL SPEED CONTROL DEACTIVATION SWITC

REPLACE DEACTIVATION SWITCH PER RECALL

110406 RECALL 99S15 INSTALL SPEED CONTROL SWITCH AND HARNESS

REPLACE DEACTIVATION SWITCH.

REPLACED DEACTIVATION SWITCH

99S15B 99S15B

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S15

RECALLED 99S15 PERFORMED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15 SERVICE WRITER FORGOT TO ADD MILEAGE FROM REPLACEMENT SPEEDOME

RECALL PERFORM RECALL

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

1 COMPLETED RECALL 99S15

93774 RECALL 99S15B-0.5 HRS PERFORMED RECALL 99-S-15 TK 8276

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

RECALL 99S15 - B -RECALL

PERFORM RECALL 99S15

RECALL 99S15 - B - RECALL

RECALL CRUISE CONTROL RECALL 99S15

98772 RECALL REPLACED SWITCH AND TEST DROVE WORKS NORMAL

PERFORMED THE RECALL 99S15

PERFORMED RECALL

REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 99S15

PERFORM SPEED CONTROL RECALL
REMOVED & REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 PERFORMED RECALL 99S15
SPD CTRL DEACTIVATION SW REPLCMTPERFORMED RECALL 99S15
REPLACED DEACTIVATION SWITCH PER RECALL
RECALL 99S15 99S15
DIAG REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15
1 PERFORMED RECALL 99S15
PERFORM RECALL 99S15 AS PER TECHNICAL INSTRUCTIO

PERFORM RECALL 99S15
RECALL 99S15 REPLACE C-C SW
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST E
99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
PER RECALL PERF RECALL
99S15 - SPEED CONTROL SWITCH 99S15 - REPLACE SWITCH AND CONNECTOR

REPLACED CABLE
RECALL 99S15 RECALL COMPLETE
RECALL 99S15 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 99S15
INSTALLED SPEED CONTROL DEACTIVATION SWITCH
RECALL REPLACE CRUISE SWITCH CONNECTO.,
99S15 99S15

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
RECALL 99S15 RECALL
REPL SWITCH PER RECALL 99S15
PERFORMED RECALL 99S15, REPL DEACTIVATION SWITCH
42089 PERFORM RECALL 99S15 INSTALL SWITCH
REPLACE SPEED CONTROL SWITCH PER RECALL
PERFORMED RECALL
MODIFIED PER RECALL
82263 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
INSTALL DEACTIVATION SWITCH
COMPLETED RECALL
PERFORMED RECALL 99S15 F
RECALL PERFORM RECALL, INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH
1 PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACE DEACTIVATION SWITCH AS PER 99S15
1 COMPLETED RECALL 99S15
INSTALL DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS
COMPLETED AS PER RECALL
1 PERFORMED RECALL, REPLACED SPEED CONTROL DE-ACTIVATION SWITCH
130588 RECALL 99S15 R&R CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
81057 REPLACED DEACTIVATION SWITCH 5314
115- CRUISE SWITCH RECALL - 99S15 - REPLACE CRUISE BRAKE SWITCH AND CONN PER 99S15

COMPLETED RECALL INSTALL SW
PERFORMED RECALL 99S15
INSTALLED SWITCH PLUG PER RECALL 99S15
RECALL 99S15 REPLACE C-C SW
RECALL 99S15 RECALL 99S15
30413 INSTALLED RECALL KIT 99S15 OPERATION OK
99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
REPLACED SPEED CONTROL SWITCH PER RECALL
RECALL COMPLETED

PERFORM RECALL
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 COMPLETED RECALL
FDF RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
RECAL PERFORMED SPEED CONTROL DEACTIVATION SWTIC
PERFORM RECALL 99S15

00886 RECALL WA PERFORM RECALL, REPLACE SWITCH
DOES NOT OPERATE PROPERLY ANTI-LOCK BRAKE SYSTEM - DIAGNOSIS
PERFORMED RECALL 99S15
REPL SWITCH PER RECALL 99S15
PERFORM RECALL 99S15
1 PERFORMED RECALL
PERFORMED THE RECALL 99S15

PERFORM RECALL 99S15
99S15 99S15 RECALL
REPLACE SWITCH FOR SPEED CONTROL PER RECALL 99S1
COMPLETE RECALL
PERFORM RECAL
REPLACED SPEED CONTROL SWITCH
SPEED CONTROL DEACTIVATION SWITCHREPLACED DEACT. SWITCH AS DIRECTED
RECALL PERFORMED RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR
RECALL REPLACE SWITCH M
RECALL 99S15 99S15
REPLACED SWITCH AND CONNECTER PER RECALL

RECALL COMPLETED
REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTION
RECALL COMPLETE
REPLACED SC DEACTIVATION SWITCH 99S15
PERFORMED RECALL 99S15
99S15 REPLACE SWITCH
90334 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15B
RD TEST, RUN ELEC TRAN DIAG,NO CODES,R&R TRAN PAN,REPLACED EPC SOLENOID AND BRACKET,R&R V-B & O-H,FLUSHED SYSTEM,RD TEST OK
REPLACED DEACTIVATION SWITCH AND HARD SHELL
CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL PART.
PERFORMED RECALL AS PER INSTRUCTIONS
RECALL 99S15 COMPLETED
PERFORM RECALL

REPLACE DEACTIVATION SWITCH AS PER 98S15
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
PERFORM RECALL 98S15

98S15E PERFORMED RECALL - SPEED CONTROL SWITCH

OPEN RECALL PERFORM RECALL

98S15 98S15

PERFORMED 98S15 RECALL, REPLACED DEACTIVATOR SWITCH & CONNECTOR

REPLACED SWITCH AND CONNECTOR

91683 CC 42 98S15B 0.5- ADMIN 0.1 REPLACED SWITCH AND CONNECTOR

SPEED CONTROL DEACTIVATION SWITCH-REPLACED SWITCH

PERFORMED RECALL PER FACTORY

1 PERFORM RECALL

REPLACE CRUISE CONTROL DEACTIVE SWITCH

REPLACE DEACTIVATION SWITCH

RECALL 98S15 INSTALLED SWITCH

PERFORM RECALL 98S15

98S15 98S15-REPLACE CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR ASSY

PERFORM SAFETY RECALL

118818 REPLACE SWITCH AND CONNECTOR

48800 INSPECTED AND INSTALLED DEACTIVATION SWITCH AND PARTS PER RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

- MODIFY PER RECALL 98S15

98S15 98S15 REPLACE THE CONN AND SWITCH

98S15, REPLACED HARD SHELL CONN PER RECALL

REPLACED DEACTIVATION SWITCH

98S15 SPEED CONTROL RECALL

REPLACE SW PER RECALL

RECALL 98S15 INSTALLED DEACTIVATION SWITCH PER RECALL

RECALL 98S15 REPLACED CABLE

RECALL RECALL

42200 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15

REPLACE DEACTIVATION SWITCH

78520 RECALL WARR TECH 495 PERFORMED RECALL 98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL, RECHECKED OK

1 CAMPAIGN COMPLETED.

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL 98S15 RECALL 98S15 REPLACE SWITCH AND PLUG

PERFORMED RECALL 98S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

COMPLETED RECALL 98S15B 1

PERFORMED RECALL

RECALL 98S15 REPLACE DEACTIVATOR SWITCH PER RECALL

PERFORMED THE RECALL 98S15

PERFORMED RECALL AS PER FORD SPECIFICATIONS

RECALL 98S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH IN AW RECALL 98S15.

PERFORMED RECALL 98S15 SPEED CONTROL

CABLE PERFORM RECALL 99S15
APPLIED RECALL 99S15
1 PER RECALL INSTALL CRUISE CANCEL SWITCH AND CONNECTOR RETEST OK
PERFORMED RECALL
SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99S15
RECALL PERFORMED RECALL
99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S
PERFORMED RECALL 99S15

.9 RECALL
71545 WARR REPLACE SWITCH AS PER RECALL 99S15

99S15 RECALL 99S15 REPAIR AS PER RECALL
49914 REPLACE SPEED CONTROL SWITCH
RECALL 99S15 REPLACE C-C SW
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
99S15 INSTALL SWITCH AND CONN
1 COMPLETED RECALL 99S15
RECALL 99S15 COMPLETED RECALL 99S15 (SPEED CONTROL SWITCH) HAS BEEN COMPLETED
RECALL 99S15 REPLACED PLUG AND SENSOR AS PER RECALL 99S15

DO THE RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL
OPEN RECALL PERFORM RECALL
RECALL 99S15 REPLACED CRUISE CONTROL SWITCH
RECALL PERFORMED RECALL
RECALL 99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
COMPLETED RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATION SWITCH.
99S15 REPLACE SPEED CONTROL DEACTIVATION AND HARD-SHELL CONNECTOR
REPLACED SPEED CONTROL SWITCH.
PERFORM RECALL 99S15
1 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
99S15-CRUISE RECALL 99S15-CRUISE RECALL

PERFORMED RECALL 99S15 CRUISE SWITCH
99S15B .5 ADMIN .1 INSTALL CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
99S15, REPLACED CRUISE DE-ACTIVATION SW
INSTALL SWITCH PER RECALL

PERFORMED RECALL

104035 PERFROM RECALL 99S 15
REPLACED SC DEACTIVATION SWITCH 99S15

REPLACE CRUISE CONTROL SWITCH

111358 PERFORM RECALL 98S15 INSTALL SWITCH-CONN KIT
RECALL 98S15; PERFORM RECALL 98S15;REPL BRK-PRESS. SWITCH;
REPLACE SPEED CONTROL SWITCH
COMPLETED RECALL
INSTALL SWITCH 98S15
PERFORMED RECALL 98S15

PERFORM RECALL PER FORD SPECS
REPLACE SWITCH AND CONNECTOR PER RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
RECALL 98S15 REPLACED SWITCH
RECALL 98S15 98S15 INSTALL CRUISE DEACTIVATION SWITCH PER RECALL=

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN
98S15 R&R SPEED CONTROL DEACTIVATION SWITCH
48966 COMPLETED 98S15 CRUISE SWITCH
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
COMPLETED RECALL 98S15
1 COMPLETE RECALL 98S15
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
RECALL 98S15 REPLACED SWITCH AND CONNECTOR FOR CRUISE CONTROL
112853 REPLACE SWITCH AND CONNECTOR AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
98038 98S15 98S15E 3 PERFORMED 98S15 REPLACED DEACTIVATION SWITCH
RECALL 98S15 RECALL COMPLETE
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
63677 RECALL WARR TECH 485 PERFORMED RECALL 98S15 REPLACED DEACTIVATION SWITCH PER RECALL , REPLACED CONNECTOR PER RECALL REC
98S15 RECALL 98S15 RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
REPLACE DEACTIVATION SWITCH PER 98S15
REPLACE SWITCH PER 98S15, BLEED BRAKE,
R&R BRAKE SWITCH & HARD SHELL BLEED SYSTEM PER RECALL
71887 INSTALLED CRUISE SWITCH
R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98-S-15
1 EWPLACE CRUISE CONTROL SWITCH 1
38870 REPLACE SWITCH AND CONNECTOR PER RECALL
COMPLETED RECALL AS PER LETTER
120243 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR
PERFORM RECALL
PERFORMED RECALL 98S15
RECALL 98S15 REPLACE SWITCH AND CONNECTOR
REPL SWITCH PER RECALL 98S15
COMPLETED RECALL 98S15
INSTALLED CRUISE DEACTIVATION SWITCH.
REPL SWITCH PER RECALL 98S15

SERVICED AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
PERFORMED RECALL
99S15 99S15 SPEED CONTROL SWITCH RECALL
RECALL 99S15 REPLACE SPEED CONTROL SWITCH
PERFORM RECALL AS PER NOTICE
F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
A DONE
PERFORMED RECALL 99S15
RECALL COMPLETE

REPLACED THE SWITCH PER RECALL 99S15
RECALL COMPLETE
DEACTIVATION SWITCH 99S15
RECALL COMPLETE
COMPLETED RECALL AS PER LETTER
PERFORMED RECALL REPAIR
PERFORMED RECALL 99S15
REPLACED CRUISE KIT
99S15 PERFORM RECALL 99S15
PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUC
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
OPEN RECALL PERFORM RECALL
99S15 99S15 RECALL
COMPLETED RECALL 99S15
WE PERFORMED RECALL 4237
INSTALL SWITCHBLEED AS PER RECALL 99S15

RECALL 99S15 - B - RECALL
1 INSTALL CRUISE CONTROL KIT, RECALL 99S15
REPLACED SWITCH CONNECTOR
RECALL COMPLETED
FD RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
PERFORM RECALL 99S15
1 REPLACED SWITCH

124802 99S15 PERFORMED RECALL AS PER INSTRUCTIONS REPLACED SWITCH
REPLACED SWITCH AND CONNECTOR
PERFORM RECALL

REPLACE SWITCH AND HARNESS PER RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
11583 RECALL 99S15 INSTALL NEW CONNECTOR AND SWITCH
PERFORMED RECALL

RECALL SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL 98S15
114175 REPLACE SWITCH PER RECALL
RECALL 98S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK
RECALL 98S15
51707 RECALL 98S15 DONE
REPLACE SPEED CONTROL CABLE
REPLACE SWITCH

PERFORM RECALL AS PER NOTICE
PERFORMED RECALL 98S15
1 INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL 98S15-INSTALL SWITCH
118963 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
PERFORMED 98S15 RECALL REPLACED SWITCH
REPLACED SWITCH ASSEMBLY PER RECALL
REPLACE SWITCH
RECALL SPEED CONTROL DEACC SWITCH REPLACE CRUISE SWITCH
COMPLETED RECALL 98S15-INSTALLED DEACTIVATION SWITCH.
INSTALL SWITCH PER RECALL

RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH INSTALL SWITCH AND CONNECTOR
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
ONP RECALL 98S15
RECALL 98S15 INSTALL CRUISE DEACTIVATION SWITCH PER 98S15
PERFORM RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITHC

RECALL 98S15 CRUISE CTONROL SWITCH
COMPLETED RECALL PER INSTRUCTIONS

RECALL 98S15 RECALL 98S15 REPL SWITCH AND CONNECTOR
98S15B REPLACE CRUISE DEACTIVATION SW
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.
RECALL 98S15 RECALL 98S15
48929 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
REPLACED SWITCH AND CONNECTOR
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
RECALL 98S15 98S15
98S15 RECALL 98S15 REPLACED SWITCH AND CONNECTOR
RECALL RECALL
RECALL RECALL
113567 RECALL WARR REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND CO NNECTOR PER RECALL
COMPLETE RECALL 98S15
98S15E PERFORMED RECALL AS PER RECALL
COMPLETED RECALL
REPLACED LEAKING THERMASTAT AND GASKET COOLING F
SOP HERE REPLACE BRAKE SWITCH AND CONN PER RECA

99S15 99S15
PERFORMED RECALL
RECALL 99S15 COMPLETED
99S15 99S15
OPEN RECALL PERFORM RECALL
REPL SWITCH PER RECALL 99S15
RECALL 99S15
INSTALL SWITCH
RECALL 99S15 PERFORMED RECALL 99S15

1 REPLACED CRUISE CONTROL SWITCH PER RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
PER RECALL REPL DEACTIVATOR SWITCH
PERFORM RECALL INSTALL SWITCH
116888 AS PER RECALL
1 REPLACED CRUISE SWITCH AND CONNECTOR.
87684 REPLACE SWITCH AND WIRES PER RECALL AND BLEED BRAKES
INSTALLED NEW SWITCH PER RECALL
COMPLETE RECALL 99S15
REPLACE SWITCH PER RECALL
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
PERFORM RECALL
RECALL PERFORM RECALL # 0836
PERFORM RECALL
PERFORMED RECALL 99S15,REPLACED SPEED CONTROL DEACTIVATION SWITCH.
PERFORMED RECALL 99S15-INSTALL SWITCH
REPLACE PARTS PER RECALL
REPLACE SWITCH PER RECALL
PERFORM RECALL 99S15 RECHECK OK 1
COMPLETED RECALL PER NOTIFICATION.

REMOVE AND INSTALL RECALL 99S15 CRUISE CONTROL TECH.23856
55802 REPLACED SPEED CONTROL SWITCH, S-2 8274
REPLACED DEACTIVATION SWITCH PER RECALL
99S15 99S15 PERFORM RECALL
INSTALLED NEW DEACTIVATION SWITCH AND CONNECER
PERFORMED RECALL HAD TO REPLACE PROPORTIONING VALVE REPLACED DUE TO BEING FROZEN IN SWITCH A TIME TOREPLACE VALVE
PERFORM RECALL INSTALL SWITCH
RECALL 99S15 RECALL 99S15
REPLACE DEACTIVATION SWITCH 1
REPLACE THE SPEED CONTROL SWITCH PER RECALL 99S1
108801 REPLACED SPEED CONTROL SWITCH AS PER RECALL
PERFORMED RECALL
REPLACE SWITCH PER RECALL
RECALL RECALL 99S15 REPLACE SPEED DEACTIVATION KIT
PERFORMED RECALL 99S15-INSTALL SWITCH
76747 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
REPLACE DEACTIVATION SWITCH AND CONNECTOR

12 REPLACE CRUISE SWITCH PER RECALL
73680 REPLACE DEACTAVATION SW AND CONNECTOR OK OP ALL OK
RECALL 98S15 REPLACE C-G SW

VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK
PERFORM RECALL
COMPLETED RECALL INSTALLED DEACTIVATION SWITCH.

REPL SWITCH PER RECALL 98S15
REPLACED CRUISE SWITCH
SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 98S15
PERFORMED RECALL 98S15
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACED CONTACT SWITCH AND SWITCH CONVERTER.
DEACTIVATION SWITCH 98S15
98S15 PERFORM 98S15
98S15 98S15

PERFORM RECALL 98S15
98S15 RECALL 98S15 REPAIR AS PER RECALL
PERFORM CAMPAIGN 98S15, SPEED CONTROL DEACTIVE SWITCH REPLACED SPEED CONTROL SWITCH
1 REPLACE SWITCH
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.
1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-
102228 REPLACED SWITCH
RECALL COMPLETE

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
41480 PERFORMED RECALL 98S15 9728
84784 PERFORMED SPEED CONTROL SWITCH RECALL
REPLACE DEACTIVATION SWITCH AS PER RECALL
98S15 RECALL 98S15 RECALL 98S15
RECALL

98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL
PERFORMED CRUISE CONTROL SWITCH RECALL 98S15 J. .1 ADMIN.
91842 PERFORM 98S15 RECALL
PERFORM RECALL

PERFORM RECALL 98S15
REPL CRUISE CONTROL SW AND WIRE CONNECTOR AND BLEED BRAKE FLUID. ROAD TEST OK PER RECALL
PERFORMED RECALL
REPLACE DEACTIVATION SWITCH PER RECALL 98S15
1 PERFORMED RECALL 98S15
98S15 RECALL 98S15 REPLACE CONNECTOR AND SWITCH AS PER RECALL
RECALL RELACED DEACTIVATION SWITCH PER RECALL
PERFORMED CRUISE CONTROL RECALL
REPLACE DEACTIVATION SWT. PER RECALL
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15.

99S15 RECALL

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

PERFORM RECALL INSTALL SWITCH

REPLACED DEACTIVATION SWITCH - PER RECALL

1 99S15B .5 ADMIN .1

RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

62033 PERFORM 99S15 RECALL REPLACE DEACTIVATION SWITCH.

DO RECALL 99S15 PUT IN NEW SW AND COND

VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT

PERFORM RECALL

RECALL COMPLETED

REPLACE CRUISE CONTROL SWITCHES PER RECALL 99S15

REPLACED DEACTIVATION SWITCH

1 TECH PERFORMED CRUISE DEACTIVATION SWITCH RECALL 99S15

1 REPLACED SPEED CONTROL SWITCH

34720 99S15 RECALL COMPLETED

PERFORM RECALL

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X3

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE

RECALL PERFORMED 1

REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORM 99S15 RECALL

99S15 RECALL

99S15 RR BRAKE SWITCH AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

COMPLETED REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

57191 99S15

NA

99S15 INSTALLED SWITCH

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X3

SAFETY RECALL 99S15 PERFORMED SAFETY RECALL 99S15 REPLACED CRUISE CONTROL

REPAIR PER RECALL

PERFORMED BY AND CLOSED BY ANOTHER DEALERSHIP BUT STILL OPEN WHEN WE HAD VEH

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SE

REPLACE SWITCH PER RECALL

RECALL

SPEED CONTROL DEACTIVATION SWITCH

65261 RECALL 0.5 REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR 99S15B

99S15 REPLACE DEACTIVATION SWITCH

PERFORM RECALL INSTALL SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

107083 RECALL 99S15B 0.5L PERFORMED RECALL REPLACED SWITCH AND CONNE CTOR.

INSTALLED SWITCH PER RECALL

1 REPLACED DEACTIVATION SWITCH AND CONECTOR AS PER RECALL 99S15B

COMPLETE RECALL THIS IS NOT A REPEAT REPAIR WITH 035003 BECAUSE THAT REPAIR WAS FOR INSPECTION ONLY

RECALL PERFORMED

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED SWITCH CAMPAIGN
98S15B PERFORMED RECALL
RECALL 98S15 COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

98S15
98S15 RECALL COMPLETE RECALL
93502 REPLACE SWITCH AS PER RECALL
128387 RECALL 98S15 PERFORM RECALL 98S15 REPLACE SWITCH AND HARDSHELL CONNECTOR
98S15 REPLACE DEACTIVATION SWITCH
OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15
RECALL REPAIR AS PER RECALL 98S15 DEACTIVATION SWITCH REPLACEMENT
TECH REPLACE SWITCH AS REQUIRED
98S78 RECALL 98S15
PERFORMED RECALL, SPEED CONTROL DEACTIVATION SWITCH
UNKNOWN RECALL COMPLETE
1 COMPLETED RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
INSTALLED DEACTIVATION SWITCH AS PER RECALL
PERFORM SPEED CONTROL RECALL 98S15
RECALL REPLACED DEACTIVATION SWITCH AND HARDSHELL PER RECALL.

108887 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS RECALL 98S15
RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 98S15
SERVICED AS PER RECALL E
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
CK BRAKE SYSTEM BRAKE SWITCH IS LEAKING AT THREADS REPLACE SWITCH AND BLEED SYSTEM
RECALL 98S15B RECALL 98S15B
1 INSTALLED RECALL SWITCH
RECALL PERFORM RECALL PER PROGRAM 98S15, DEACTIVATION SWITCH
RECALL 98S15 PERFORMED RECALL AS PER FORD
COMPLETED 98S15
RECALL DID RECALL
RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH REPLACEMENT
98S15 REPLACE SWITCH AND CONNECTOR PER RECALL
PERFORM RECALL
INSPECTED CRUISE CONTROL OPERATION AND REPLACED REAR BRAKE RELEASE KIT AS PER RECALL AS NEEDED FOR REPAIRS

1 PERFORMED RECALL
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
COMPLETE RECALL 98S15
NAC 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
98S15B RECALL 98S15B RECALL

REPLACE SPEED DEACTIVATION SWITCH
 PERFORMED RECALL AS BY FACTORY PERFORMED RECALL
 PERFORM RECALL 98S15
 PERFORM RECALL 98S15
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL AS PER 98S15
 RECALL 98S15 COMPLETED
 71276 REPLACED SPEED CONTROL DEACTIVATION AS TO RECALL 98S15
 1 RECALL COMPLETE
 RECALL COMPLETED.
 REPLACE CRUISE CONTROL SWITCH AND CONN, SHELL, BLEED REAR BRAKES
 COMPLETED 98S15
 COMPLETED RECALL
 RECALL COMPLETED
 81789 SPEED CONTROL DEACT SWITCH RECALL WARR COMPLETED
 PERFORMED RECALL
 98S15 REPL SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACE SWITCH PER RECALL
 INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S15B .50
 98S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 98S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.
 POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH INSPECTED VEHICLE - HAS ONLY VACUUM OPERATED SYSTEM
 REPLACED CRUISE DEACTIVATION SWITCH
 PERFORM RECALL 98S15.
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
 AS PER RECALL REPLACED SPEED CONTROL SWITCH
 AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
 98S15 98S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORM RECALL 98S15

 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 INSTALL SWITCH AND HARD SHELL
 RECALL 98S15
 PERFORM RECALL
 CHECKED OASIS INSTALLED HARDSHELL CONNECTOR AND SWITCH

 98S15 RECALL SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 INSTALLED SWITCH AND CONNECTOR
 POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED RECALL REPLACE CRUISE CABLE
 RECALL 98S15
 PERFORMED RECALL 98S15 B
 71704 RECALL PERFORM 98S15
 PERFORMED SPEED CONTROL RECALL
 1 REPLACED PART PER RECALL
 PERFORM RECALL
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE

117578 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.
RECALL COMPLETE
1 PERFORMED SAFETY RECALL 99S15.
PERFORMED THE RECALL 99S15
PERFORMED 99S15 RECALL

1257B4 99S15 INSTALL CRUISE SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL 99S15
RECALL 99S15 RENEW CRUISE DEACT SWITCH
1 99S15 RECALL, INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.
PERFORMED RECALL PER SPECS
COMPLETED RECALL
SPEED CONTROL SWITCH 99S15 RECALL
UNKNOWN RECALL COMPLETE

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
PREFORMED RECALL 99S15 SPEED CONTROL SWITCH
125045 99S15 W/ REPLACED DEACTIVATION SWITCH
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
REPLACE CRUISE DEACTIVATION SWITCH AS PER RECALL
PERFORM RECALL 99S15
REPLACE DEACTIVATION SWITCH
INSTALLED DEACTIVATION SWITCH
R/R CRUISE SWITCH PER RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL.
99S15
00 99S15
21185 PREFORMED RECALL
REPLACE SWITCH
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL.
REPLACED SWITCH AND CONNECTOR
PERFORM RECALL...CAMPAIGN...
RECALL 99S15 RECALL REPLACE SWITCH
COMPLETE RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL INSTALLED BRAKE REPAIR KIT AS PER RECALL
99S15 RECALL 99S15 REPAIR AS PER RECALL
RECALL 99S15-DEACTIVE SWITCH 99S15
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
COMPLETED RECALL PER INSTRUCTIONS
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
REPLACE SPEED CONTROL DEACTIVATION SWITCH 1

1 PERFORMED RECALL
REPAIRED AS PER RECALL
RECALL REPLACED SWITCH REPLACED SWITCH PER RECALL
99S15 COMPLETED RECALLS-CAMPAIGN 99S15

RECALL REPLACE SWITCH AND WIRE PLUG
COMPLETED RECALL
98S15 REPLACED SWITCH AND CONNECTOR
PERFORMED RECALL PERFORMED RECALL
R CRUISE CONTROL RECALL 98S15

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
FACTORY RECALL COMPLETED RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
84726 PERFORM RECALL 98S15
PERFORMED RECALL 98S15-INSTALL SWITCH
REPLACED BRAKE PRESSURE SWITCH & CONNECTOR PER RECALL 98S15
RECALL PERFORM RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH.

COMPLETE RECALL
RECALL----- RECALL----- PERMANENT REPAIR
RECALL RECALL
RECALL 98S15 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
CHECKED OASIS. REPLACED BRAKE PRESSURE SWITCH
PERFORMED RECALL 98S15-INSTALL SWITCH & PLUG CONNECTOR.
COMPLETE RECALL 98S15
. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S5
REPLACE SPEED CONTROL SWITCH
PERFORM RECALL 98S15
REPLACED SPEED CONTROL SWITCH
1 --REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL--
PERFORMED RECALL
PERFORMED RECALL
PERFORMED RECALL 98S15-REPLACED CRUISE CONTROL DEACTIVATION SWITCH
PERFORMED RECALL AS PER INSTRUCTIONS
COMPLETED . REPLACED SWITCH
78544 REPLACED SPEED CONTROL SWITCH, S-2 8274
COMPLETED RECALL 98S15B
REPLACE SWITCH AND CONNECTOR
88417 INSTALL DEACTIVATION SWITCH PER RECALL
42778 PERFORM RECALL 98S15 INSTALLED BRAKE REPAIR KIT JH
132885 PERFORMED RECALL.

PERFORM RECALL

DEACTIVATION SWITCH 98S15

REPLACE CRUISE CABLE
PERFORM RECALL
PERFORMED SPEED CTL DEACTIVATION SWITCH RECALL
1 PERFORMED RECALL
C RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

OTHER RECOMMEND SERVICES: SERP BELT, ENGINE COOLING SYSTEM HOSES, COOLANT FLUSH, ENGINE FLUSH, POWER STEERING FLUSH, BATTERY SER
COMPLETE RECALL 99S15

47767 REPLACED DEACTIVATION SWITCH.

48081 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SW PER RECALL 99S15, BLED BRAKES AND TESTED OPERATION. OK

72088 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL REPLACED THE SWITCH AND CONNec TOR BLEED THE SYSTEM

RECALL PERFORMED RECALL

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SE

106- SPD CONTROL SWITCH RECALL - 99S15 - REPLACE SPEED CONTROL ACTIVATION SWITCH PER RECALL

PERFORMED RECALL

REPLACE CRUISE CONTROL SWITCH

RECALL PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

75995 99S15B 0.5 ADMIN 0.1

99S15E REMOVE, TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED

RECALL REPAIR SPEED CONTROL

99S15 PERFORMED RECALL 99S15

REPLACED CONTROL DEACTIVATION SWITCH

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

REMOVED AND REPLACED SPEED CONTROL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15 - MILES OUT 99621

REPLACED BRAKE SWITCH PER RECALL

PERFORMED RECALL

PER RECALL REPL HEADLIGHT DEACTIVATOR SWITCH

RECALL 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTO

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 REPLACE C-C SW

PERFORMED RECALL

WARRANTY MILES OUT 90,110 PERFORMED RECALL #99S15 DEACTIVATION SWITCHH.

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

CHECK AND REPAIR AS REQUIRED

REPL SWITCH PER RECALL 99S15

PERFORMED RECALL REPLACED THE DEACTIVATION SWI TCH AND CONNECTOR BLEED THE SYSTEM

REPLACED SPEED DEACTIVATION SWITCH RECALL 99S15

59848 WARR PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

134488 RECALL 99S15 DND 99S15

INSTALLED SWITCH AND HARDSHELL PER RECALL 99S15

136327 RECALL 99S15B REPLACE SWITCH AND CONECTOR TK372

99S15E REMOVE, TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED

RECALL INSTALLED DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH AS PER RECALL 99S15

RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

REPL SWITCH PER RECALL 99S15

REPLACE DEACTIVATION SWITCH
RECALL RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
RECALL SPEED CONTROL DEACT SWITCH PERFORM RECALL 99S15 TECH 131 PERFORM WORK
RECALL PERFORMED RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH
92114 RECALL, REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 99S15
PROGRAM CODE 99S15.
PERFORMED RECALL
COMPLETED RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL 99S15
1 CAMPAIGN COMPLETED.

REPLACED SPEED CONTROL SWITCH AS PER RECALL
RECALL COMPLETE
101-CRUISE CONTROL SWITCH RECALL-99S15 - CHECK AND REPLACE CC BRAKE SWITCH

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH.
99S15 SPEED CONTROL DEACTIVATION REPLACED SWITCH AND CONNECTOR PER RECALL 99S15

REPLACE SWITCH
109S16 RECALL 99S15B 0.5 0.5 REPLACE DEACTIVATION SWITCH AND CONNECTOR
R&R SWITCH AND CONNECTOR
INSTALLED SWITCH KIT
RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
99S15B .5 HRS ADMIN .1 HRS R&R SWITCH AND CONNECTOR

RECALL 99S15 RECALL 99S16
REPL BRK PRESSURE SWITCH
91680 RECALL REPLACE DEACTIVATION SWITCH PER RECALL(WP) 23
99S15 99S15 REPLACE SWITCH

RECALL 99S16 RECALL 99S15
PERFORMED RECALL
REPLACE DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
RECALL 99S15
PERFORMED RECALL 99S15
PERFORMED RECALL 99S15
PERFORMED RECALL 99S15-INSTALL SWITCH
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

1 INSTALL SWITCH AND CONNECTOR

COMPLETE RECALL 99S15

PERFORMED RECALL PERFORMED RECAL

RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 REPLACED SPEED CONTROL PER RECALL

RECALL COMPLETED

PERFORM 99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

RECALL INSTALL SWITCH

PERFORM RECALL.....

REPLACED CRUISE DEACTIVATION SWITCH

REPL SWITCH PER RECALL 99S15

REPL HARDSHELL CONNECTOR PER RECALL

PERFORMED RECALL 99S15-INSTALL SWITCH

RECALL PERFORMED RECAL

PERFORM RECALL

RECALL COMPLETED

PERFORMED RECALL 99S15

COMPLETED RECALL

REPLACE BRAKE SWITCH AND HARD SHELL CONNECTOR

99S15 99S15 RECALL

PERFORMED RECALL 99S15-INSTALL SWITCH

RECALL RECALL

1 OK REPLACED SWITCH BLEED BRAKES

OPEN RECALL COMPLETE 99S15

PERFORMED CRUISE CONTROL RECALL 99S15

RECALL PERFORMED RECAL

99S15 REPLACED SWITCH AND CONNECTOR

RECALL 99S15

100043 REPAIR AS PER RECALL 99S15

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

PERFORM RECALL 99S15 INSTALL SWITCH PER RECALL 99S15

PERFORM RECALL 99S15

PERFORM RECALL 99S15 REPLACE BRAKE PRESSURE SWITCH PER RECALL 99S15

INSTALLED UPDATE SPEED CONTROL DEACTIVATION SWITCHTRS

120045 MOD. 99S15 COMPLETE

99S15 RECALL

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

COMPLETED RECALL 99S15 SPEED CONTROL

REPAIR AS PER RECALL 99S15

COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 REPLACED CABLE AND SWITCH ASSEMBLY.

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL 98S15. INSTALL SPEED CONTROL DEACTIVATION SWITCH, RE-CHECK-OK
COMPLETED 98S15 RECALL 1

PERFORM RECALL
REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER CAMPAIGN 98S15
RECALL 98S15 98S15 COMPLETED RECALL
98S15 SPEED CONTROL SWITCH 98S15
RECALL 98S15

PERFORMED RECALL 98S15
REPLACE CRUISE DEACTIVATION SWITCH AS PER 98S15 RECALL
92173 PERFORMED 98S15, REPLACED SWITCH & CONNECTOR
RECALL 98S15 RECALL COMPLETE
PERFORM RECALL
R AND R CRUISE CRT CONNECTOR AND SWITCH

RECALL 98S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK
RECALL 98S15 98S15 REPLACE SPEED CONTROL SWITCH
PERFORM RECALL RENEW SWITCH AND CONNECTOR
REPLACE CC SWITCH AND CONNECTOR
DIAG AND PERFORMED RECALL 98S15 INSTALL NEW DEACTIVATION SWITCH OK NOW

RECALL 98S15
RECALL COMPLETED 98S15 SPEED CONTROL DEACT SWITCH
RECALL PERFORM RECALL 98S15
INSP AND RR CONNECTOR AND SWITCH

98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
RECALL - 98S15B
OPEN RECALL PERFORMED RECALL
REPLACE CRUISE CONTROL SWITCH AS PER RECALL 98S1
REPLACE DEACTIVATION SWITCH PER RECALL
37765 PERFORMED RECALL 98S15.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR, CPN, 98S15, 98S15B, 0.5, ADMIN, 0.1, CC RECAL
COMPLETED RECALL AS REQUIRED
SPD CNTRL DEACTIVATION SWITCH BAD REPLACED SPEED CONTROL DEACTIVATION SWITCH HARDSHELL CONNECTOR
RECALL PERFORMED
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
71588 WF PERFORM RECALL AS INSTRUCTED
REPLACE SPEED CONTROL SWITCH
98S15 RECALL SPEED CONTROL PERFORMED RECALL OF SPEED CONTROL
RECALL COMPLETED
REPL SWITCH PER RECALL
50069 PERFORM RECALL
RENEW DEACTIVATION SWITCH
- 98S15 RECALL COMPLETED
98S15 SPEED CONTROL RECALL
PERFORMED RECALL 98S15

RECALL 98S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTION
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CHANGED HARD SHELL CONNECTOR.
RECALL 98S15
1 PERFORMED RECALL 98S15.

PERFORMED RECALL
72088 98S15B 0.5 HRS. SPEED CONTROL RECALL
PERFORM RECALL 98S15- REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL
98S15 RECALL 98S15 RECALL PERFORMED
REPLACED DEACTIVATION SWITCH
PERFORM RECALL
CC RECALL PERFORM RECALL 98S15 REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
COMPLETE RECALL #98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
98S15 COMPLETED
RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
INSTALL CRUISE CABLE PER RECALL 98S15
PERFORMED RECALL 98S15
REPLACED SWITCH PER RECALL
56893 RECALL 98S15 REPLACED SPEED CONTROL SWITCH AS PER RECALL 98S15.
98S15 CC DE ACTIVATION SW RECAL 98S15 CC DE ACTIVATION SW RECALL

REPLACED SWITCH CONNECTOR PER RECALL 98S15
DIAG AND PERFORMED RECALL 98S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW
REPLACE CONNECTOR AND SWITCH AS PER RECALL

43553 98S15 INSTALL BRAKE SW AND CONNECTOR
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.
COMPLETED RECALL 98S15
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
56899 RECALL 98S15 XX OPERATION 98S15B REPLACE SWITCH AND ELECTRICAL CONNECTOR XX BLEAD BRAKE
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
88894 REPLACED SPEED CONTROL SWITCH 98S15
PERFORM RECALL 98S15
98S15 RECALL 98S15 RECALL COMPLETE
RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
25587 DO RECALL 98S15
PER RECALL REPLACE SWITCH CONNECTORS
RECALL 98S15
PERFORM RECALL
PERFORM RECALL
THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WILL
98S15 MO B2966 REPLACED SPEED CONTROL DEACTIVATION SWITCH

76278 INSTALL DEACTIVATION SWITCH PER 99S15 7921 MILES AT 76278

70758 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL

REPLACED CONNECTOR AND SWITCH PER RECALL

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE

REPLACED SWITCH PER RECALL

PERFORM RECALL 99S15

RECALL 99S15

COMPLETED AS PER RECALL

RPL CRUISE DEACTIVATION SWITCH

PERFORM RECALL 99S15

PERFORM SAFETY RECALL

COMPLETED RECALL 99S15

99S15 RECALL 99S15 RECALL COMPLETE

RECALL COMPLETED

REPLACED SWITCH

REPLACE CC SWITCH AND CONNECTOR ASSEMBLY

107483 RECALL 99S15 WARR. PERFORMED DEACTIVATION SWITCH RECALL 99S15.

COMPLETED RECALL ON SPEED CONTROL SWITCH

99S15 99S15 REPLACE S-C DEACTIVATION SWITCH AND CONNECTOR

REPLACE CRUISE SWITCH AND HARNESS CONNECTOR AS PER 99S15 RECALL

1 REPLACE BRAKE SWITCH AND CONN PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL RECALL

99S15 RECALL 99S15 RECALL

1 99S15B .5 ADMIN .1

RECALL INSPECT SPEED CONTROL CABLE

1 INSTALLED DEACTIVATION SWITCH

93808 CK FOR RECALL 99S15. REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15

PERFORMED RECALL

PERFORM SPEED CONTROL DEACTIVATION PER RECALL

REPL SWITCH PER RECALL 99S15

PERFORMED RECALL RECALL COMPLETED

RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL

DID 99S15 RECALL

PERFORM RECALL

INSTALLED PINS IN NEW CONNECTER AND REMOVED OLSD SWITCH AND REPLACED WITH NEW BLEED SYSTEM OF AIR TEST DROVE GOOD

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL

PERFORMED RECALL

99S15 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

PERFORM RECALL 99S15

CAUSE=RECALL CORRECTION=PERFORM RECALL

80007 PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL ACTIVATION SWITCH
100038 98S15 PERFORM RECALL, REPLACE SWITCH AND CONNECTOR.
REPLACED SWITCH

REPLACE SWITCH PER RECALL 98S15
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORM RECALL 98S15 REPLACE SWITCH.
RECALL 98S15 RECALL COMPLETE
INSTALL SPEED CONTROL DEACTIVATION SWITCH PWR RECALL
98S15 RECALL 98S15 RECALL COMPLETE
RECALL 98S15 REPLACED DEACTIVATION SWITCH
RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
RECALL PERFORMED
98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
90448 COMPLETED RECALL 98S15, 245
REPL SWITCH PER RECALL 98S15
PERFORMED RECALL
INSTALLED SWITCH PER RECALL
83029 INSPECT AND REPLACE DEACTIVATOR SWITCH AND CONNECTOR.
REPLACE SWITCH
14547 RECALL W INSTALL CONNECTOR GA
RECALL 98S15
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL COMPLETED
PERFORM RECALL
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTED
PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR

RECALL COMPLETED
RECALL COMPLETE, REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL.
98S15 RECALL PERFORM RECALL
PERFORMED RECALL 98S15
INSTALL SWITCH & CONNECTOR RECALL COMPLETED PERFORM CAMPAIGN PER FORD'S SPECIFICATIONS AND INSTRUCTIONS 98S15B FOR .5 AND .1 FOR .1
98S15 REPLACED SPEED CONTROL SWITCH RECALL PERFORMED
1 1 PERFORMED RECALL 98S15
INSPECT AND REPAIR/REPLACE CONNECTOR AND SWITCH
REPLACE CONNECTOR AND SWITCH
70082 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
PERFORM RECALL 98S15 RECHECK OK 1
RECALL 98S15B PERFORM RECALL 98S15B
COMPLETE RECALL REPAIRS

RECALL 98S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
58888 INSTALL SWITCH PER RECALL
REPLACED SWITCH

98S15 SPEED CONTROL RECALL
REPLACED SPED CONTROL DEACTIVATION SWITCH..

98S15 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
1 PERFORM RECALL
REPLACE KIT PER RECALL
PERFORMED RECALL

RECALL PERFORMED RECALL 98S15
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
RECALL REPLACE SWITCH PER RECALL
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL
RECALL 98S15

88380 DID RECALL 98S15B 0.5 HRS
PERFORM RECALL 98S15
1 REMOVE AND REPLACE CRUISE CONTROL SWITCH PER RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORMED RECALL 98S15
REPLACE SWITCH

83061 PERFORMED RECALL 98S15 AND RR SWITCH
98S15 98S15
REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH
1 RECALL 98S15
1 PERFORM RECALL

79201 98S15B 0.5 HRS. SPEED CONTROL RECALL
REPLACED DE-ACTIVATION SWITCH PER 98S15 RECALL
REPLACE SWITCH AND CONNECTOR
85579 INSTALL RECALL SWITCH AND CONNECTOR
182402 28 98S15 REPLACED SWITCH PER RECALL 98S1
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B
COMPLETED RECALL

SPEED CONTROL DEACTIVATION SWITCH 98S15 REPAIR PER RECALL
RECALL COMPLETED

88820 PERFORMED SPEED CONTROL RECALL AND CONNECTOR Y
REPLACED SWITCH & CONNECTOR PER RECALL
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
REPLACE CRUISE CONTROL CONNECTOR AND SWITCH
RNAD R SPD CRTL CONN AND SWITCH
98S15 RECALL COMPLETE
88809 RECALL DO RECALL 98S15
REPLACE SWITCH PER RECALL
PERFORMED RECALL 98S15

RECALL INSTALL SWITCH
150421 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR PER RECALL
PERFORMED RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR RECALL 99S15 BOX B

PERFORMED RECALL 99S15

70149 R-T CK CRUISE OPERATION, PERF SPEED CONTROL TEST P-P TO RECALL NOT DONE HARNESS DISCONNECTED INST RECALL R-T OK
75080 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL

INSTALL SWITCH PER RECALL PER SPECS
RECALL REPLACE SWITCH AND CONNECTOR PER RECALL
RECALL RECALL
1 PERFORM THE 99S15 RECALL AND REPLACED THE SWITCH
REPLACE CRUISE DEACTIVATION SWITCH
RECALL COMPLETE
REPLACE DEACTIVATION SWITCH
RECALL RECALL
75800 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
RECALL 99S15 99S15
PERFORMED RECALL PER FACTORY SPEC
RECALL 99S15 - B - RECALL
REPLACE DEACTIVATION SWITCH PER RECALL 99S15 2 OF 2 ROS
INSTALL SWITCH AND HARD SHELL RD TEST
REPAIR AS PER 99S15 RECALL
PERFORMED RECALL
INSTALLED SWITCH PER RECALL

PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
90586 RECALL REPLACE SPEED CONTROL SWITCH AND CONNECTOR
58018 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
DIAG AND PERFORMED RECALL 99S15 INSTALLED A DEACTIVATION SWITCH OK NOW
REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15
INSPECT AND REPLACE SWITCH
PERFORMED RECALL
1 COMPLETED RECALL 99S15
REPLACE SWITCH AND HARD SHELL
PERF RECALL 99S15
REPLACED THE SPEED CONTROL DE-ACTIVATION SWITCH & HARD SHELL CONNECTOR
58189 RECALL COMPLETE
CHECK AND REPLACE CONNECTOR PER RECALL
F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
COMPLETE RECALL
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH.
87836 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH
TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDELI
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER SAFETY RECALL 99S15.
PERFORMED RECALL 99S15
RECALL REPLACE SPEED CONT DEACT SWITCH PER RECALL
ADD 99S15
PERFORMED RECALL 99S15
PERFORM RECALL 99S15
39124 DO RECALL 99S15
PER RECALL REPLACED SWITCH.
RECALL 99S15 DONE- REPL CRUISE SW
PERFORMED 99S15B
REPL SWITCH PER RECALL
PER OASIS PERFORMED RECALL 99S15 B

REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORM RECALL 99S15B

INSTALL SWITCH
RECALL PERFORM RECALL
89453 RECALL 99S15 W PERFORMED RECALL 99S15; REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTING HARNESS, 1
REMOVE AND REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
REPLACE SWITCH AND HARD SHELL
PER RECALL PERF RECALL
PERFORMED RECALL
97996 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP
1 REPLACED SWITCH
REPLACED SC DEACTIVATION SWITCH 99S15
117818 PERFORM SPEED CONTROL DEACTIVATION SWITCH AND CONNECTER REPLACEMENT RECALL
REPLACE SWITCH PER RECALL
48224 W REPLACE SWITCH GA
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
RECALL RECALL
RECALL 99S15 REPLACED SPEED CONTROL SWITCH
99S15 CRUISE DEACTIVATION SWITCH 99S15
1 TECH 247 COMPLETE RECALL
PER FCSD PERFORMED RECALL 99S15.
REPLACE DEACTIVATION SWITCH AS PER RECALL
RECALL 99S15

RECALL REPLACE DEACT SWITCH
REPLACED SPEED CONTROL CUT OFF SW FOR RECALL 99S15 BLEED BRAKES ROAD TEST OK..

PERFORMED RECALL 99S15

INSTALL NEW HARD SHELL AND SWITCH AS PER RECALL

116231 99S15 WARR REPLACED SWITCH AND CONN
99S15 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
79999 RECALL W 2071 CHANGED SPEED CONTROL DEACTIVATION SWITCH AND CONN.
RECALL 99S15 99S15
VERIFY CONCERN, INSTALL NEW SWITCH
RECALL 99S15 RECALL
REPLACE DEACTIVATION SWITCH AS PER RECALL
REPLACED THE SWITCH PER RECALL 99S15
91191 REPLACE DEACTIVATION SWITCH WITH IMPROVED TYPE
PERFORMED RECALL
PERFORMED RECALL
99S15 RECALL 99S15 COMPLETED RECALL
1 RECALL COMPLETED BY TECH 1
PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE CRUISE DEACTIVATION SWITCH
99S15 99S15
1 REPLACE SWITCH
TEST CRUISE, PINPOINT, REPL DEACTIVATION SWITCH, OPEN.
60214 99S15 0.5HR RECALL COMPLETE
024 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
RECALL 99S15 - B - RECALL
1 PERFORMED 99S15 RECALL
DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW
COMPLETED 99S15 RECALL
REPLACED BRAKE DEACTIVATION SWITCH PER RECALL
RECALLED BY FORD PERFORMED RECAL

SWITCH 99S15

PERFORM RECALL
PERFORM RECALL 99S15
REPLACED DE-ACTIVATION SWITCH PER 99S15 RECALL

70830 99S15 REPL SWITCH

PERFORM RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL
COMPLETED RECALL
73210 COMPLETE
REPLACE AS PER RECALL 99S15
PERFORMED 99S15 RECALL
1 INSTALLED SWITCH
VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
TESTED AND FOUND FUSE BLOWN TO BRAKE SWITCH, FOUND SPEED DEACTIVATION SWITCH BLOWING THE FUSE, PERFORMED RECALL 99S15
REPLACE DE-ACTIVATION SWITCH
F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
REPLACED SWITCH & HARD SHELL PER 99S15
PERFORMED RECALL 99S15

PERFORM SAFETY RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALL SPEED CONTROL SWITCH
REPLACE DEACTIVATION SWITCH
INSTALL CABLE PER RECALL 99S15
REPLACED DEACTIVATION SWITCH
PERFORM RECALL 99S15
RECALL 99S16

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL DEACTIVATION SWITCH
99S15 RECALL 99S15 COMPLETED RECALL
RECALL

REPLACED BRAKE SWITCH AND CONNECTOR PER 99S15..

RECALL 99S15

PERFORMED RECALL 99S15

INSTALLED SWITCH PER RECALL

99S15 99S15

PERFORMED RECALL

COMPLETED RECALL 99S15

99S15-RECALL 99S16-RECALL

99S15 PERFORM RECALL 99S15

1 REPLACED CRUISE CONTROL SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 99S16. ALSO SEE JOB 1.

INSPECT AND REPLACE SPEED DEACTIVATION SWITCH AND PLUG BLEED BRAKES.

RECALL COMPLETED

RECALL PERFORMED

48880 99S15B 0.5 HRS. SPEED CONTROL RECALL

INSTALL SENDER & CONNECTOR.

INSTALLED SWITCH AND HARD SHELL

RECALL PERFORM RECALL

99S15

99S15

99S15

99S16-REPLACE CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR ASSY

PERFORM RECALL 99S15

65834 PERFORM RECALL

RECALL COMPLETED

REPLACE DEACTIVATION SWITCH

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
PERF RECALL 99S15
PERFORMED RECALL
SPEED CONTROL SWITCH REPL. SPEED CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
REPLACED SC DEACTIVATION SWITCH 99S15
REPLACED CRUISE CONTROL CABLE
43397 RECALL WARR PERFORM 99S15, REPLACED DEACTIVATION SWITCH AND HARDSHELL TEST DROVE ALL OK.

RECALL 99S15
ASDFADSFADSFADSF
RECALL 99S15 RECALL
PERFORMED SPEED CONTROL RECALL
INSTALL SWITCH AND HARD SHELL
PERFORMED RECALL
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B
ASA PER RECALL AS PER RECALL
RECALL 99S15
RECALL 99S15 COMPLETED
99S15 REPL. DEACTIVATION SWITCH
99S15 99S15
X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
99S15 RECALL 99S15 RECALL
PERFORMED RECALL
X REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR
95858 99S15B 0.5 ADMIN 0.1
PERFORMED RECALL
99S15 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.
REPLACE SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
23605 RECALL 99S15 RECALL 99S15
INSTALLED SPEED CONTROL TIE DOWN PER RECALL RET ESTED OK. NO OTHER CONCERN AREAS EVIDENT AT THIS TIME.
RECALL REPAIR PER RECALL
REPLACE DEACTIVATION SWITCH AS PER RECALL
RECALL 99S15 PERFORM RECALL 99S15
COMPLETE RECALL
PERFORMED RECALL AS BY FACTORY PERFORMED RECALL
80111 PERFORM RECALL 99S15

PERFORMED 99S15 RECALL
REPLACED SPEED CONTROL CABLE AS PER RECALL

X REPLACED CLIP & SWITCH, RETEST, SYSTEM OK PER RECALL
PERFORMED 99S15 RECALL, REPLACED REDUNDANT DEACTIVATOR SWITCH
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

98S15 REPLACED CONNECTOR AND SWITCH
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 108151 98S15B 0.5 HRS. SPEED CONTROL RECALL
 RECALL 98S15 REPLACE C-C SW
 1 PERFORM RECALL
 107671 RECALL REPLACE DEACTIVATION SWITCH & CONN 94
 48857 98S15 98S15 0.8 REPLACE SWITCH & CONNECTOR
 48093 REPLACE SPEED DEACTIVATION SWITCH AND CONNECTOR AS PER 98S15B .5 +.1 ADMIN
 REPLACED SPEED CONTROL SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRUK
 RECALL RECALL
 PERFORMED RECALL 98S15
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 RECALL 98S15 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 58766 98S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745
 43477 COMPLETED 98S15
 82008 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 98S15
 REPLACE CRUISE CONTROL CUT OFF SWITCH AS PER RECALL
 REPL SWITCH PER RECALL 98S15
 PERF. RECALL
 PERFORMED RECALL
 42 98S15
 PERFORMED RECALL 98S15
 COMPLETE RECALL 98S15
 REPLACE SWITCH AND CONNECTOR
 98S15-RECALL 98S15-RECALL
 86848 98S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745
 RECALL PERFORM RECALL
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 . REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL AS PER INSTRUCTIONS
 REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACE SWITCH PER RECALL
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
 RECALL COMPLETE
 RECALL COMPLETED
 SPEED CONTROL DEACTIVATION SWITCH. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL
 REPLACED SWITCH AND CONNECTOR
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PERRECALL 98S15
 1 PERFORM RECALL 98S15 BRAKE SWITCH
 1 PERFORMED CRUISE CONTROL RECALL
 PERFORM BRAKE SWITCH RECALL WARR
 PERFORMED 98S15 RECALL

 REPLACED DEACTIVATION SWITCH AND HARD SHELL
 1 PERFORMED RECALL 98S15 REPLACED SPEED CONTROL SWITCH AND CONNECTOR
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HAROSHELL CONNECTO
 COMPLETE RECALL

RECALL 99S15 PERFORM RECALL 99S15
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 RECALLED BY FORD PERFORMED RECALL
 REPLACE SWITCH AS PER 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 99S15B .5
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME
 RECALL R-R DEAC SW, INSTALLED NEW CONNECTOR.... WHILE UNDER HOOD I RECCOMEND THAT THE BATTERY BE SERVICED
 REPAIR PER RECALL 1
 REPLACED DE-ACTIVATION SWITCH
 REPLACE CABLE PERFORM RECALL
 PERFORMED RECALL 99S15
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X5
 PERFORMED RECALL 99S15
 PERFORM RECALL 1
 REPLACED CRUISE CONTROL SWITCH PER RECALL 99S15
 RECALL 99S15 CRUISE CONTROL SWITCH
 1 PERFORM RECALL 99S15
 RECALL PERFORMED RECALL
 RECALL COMPLETE
 RECALL RECALL
 82138 RECALL INSTALL DEACTIVATION SWITCH
 AS PER RECALL 99S15 RECALL TO INSTALL HARDSHELL SWITCH CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 RECALL 99S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 48815 RECALL 99S15 RECALL 99S15 R-R DEACTIVATION SWITCH
 RECALL 99S15 RECALL
 99S15 99S15
 RECALL - PERFORMED RECALL # 8178

 REPAIR AS PER RECALL
 50374 INSTALL NEW DEACTIVATION SWITCH
 1 PERFORMED RECALL
 RECALL INSTALL CRUISE CONTROL DEACTIVATION SWIT
 RECALL COMPLETED ALL OK
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 REPLACE AND INSPECT CRUISE CRL CONNECTOR
 R AND R SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED RECALL 99S15
 COMPLETED RECALL
 . PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN BULLETIN REPL DEACTIVATION SWITCH,PER 99S15
 REPLACED DEACTIVATTOR SWITCH
 . REPLACED SWITCH AS PER RECALL 1
 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

 108426 PERFORM RECALL 99S15 INSTALL SWITCH
 PERFORM RECALL PER INST
 18109 RECALL WF PERFORMED RECALL AS INSTRUCTED
 43122 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15 RECALL I ALSO REPLACED CONNECTOR
 RECALL #99S15; PERFORM RECALL #99S15;REPL BRK-PRESS. SWITCH;

REPLACE SWITCH PER RECALL
REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARD-SHELL CONNECTOR AS PER RECALL 99S15. 99S15B 0
PERFORMED RECALL PERFORMED RECAL

PERFORM RECALL
MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEATIVATION SWITCH
PERFORMED 99S15B

99S15 INSTALL NEW SWITCH ASY.-NOTE-MASTER CLY WAS VERY LOW ON FLUID,HOIST VEHICLE AND CHECK ALL BRAKES AND FOUND ALL FOUR TO BE .
COMPLETE RECALL

1 INSTALLED SPEED CONTROL SWITCH
51468 99S15 PERFORM RECALL,REPLACE SWITCH AND CONNECTOR.
71048 DONE

RECALL COMPLETE

RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
44816 RECALL #99S15 PERFORM RECALL #99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND ITS CONNECTOR *5 WP
118930 99S15 PREFORMED 99S15 PER INSTRUCTIONS

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
COMPLETED CAMPAIGN COMPLETED OP 99S15B
INSOECT FOR RECALL 99S15

RECALL RECALL

PERFORM SAFETY RECALL

PERFORMED RECALL 99S15 REPLACED SPEED SWITCH AND TERMINAL BLEED BRAKES

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

PERFORM RECALL 99S15

64014 RECALL W/F PERFORMED RECALL AS PER INSTRUCTIONS

48123 REPLACE GUISE DEACTIVATE SWITCH AND CONNECTOR PER RECALL

99S15-1827 REPLACED SPEED COTNROL DEACTIVATION SWITCH

PERFORMED RECALL PERFORMED RECAL

PERFORM 99S15

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

77878 RECALL 99S15 5 W PERFORM RECALL 99S15

REPL BRAKE PRESSURE SWITCH

RECALL COMPLETED

COMPLETE RECALL 99S15

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

114628 REPLACED SPEED CONTROL SWITCH 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

188597 RECALL 99S15 PERFORM RECALL 99S15

REPLACE CRUISE SWITCH

44660 99S15 RECALL W RR DEACTIVATION SWITCH PER 99S15 RECALL

SWITCH 99S15

REPLACED DEACTIVATION SWITCH PER RECALL

PERFORM SUBFRAME SAFETY RECALL AS INSTRUCTED

99S15

99S15

REPLACE SWITCH AND HARNESS PER RECALL

PERFORM SAFETY RECALL

23108 99S15 C 0.5 HRS.

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

PERFORM RECALL

PERFORM RECALL

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

A DONE

SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH PER RECALL 99S15

1 1 COMPLETED RECALL

60080 RECALL W/ REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15 JH

REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15

55385 99S15 .5L RR CRUISE DEACTIVATION SWITCH

PERFORMED RECALL 99S15 B

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORMED RECALL 99S15

98358 RECALL RECALL COMPLETED

COMPLETED RECALL

REPLACE DEACTIVATION SWITCH AND HARSHELL CONNECTOR 99S15B-00

PERFORM SPEED CONTROL SWITCH RECALL

REPLACE SWITCH PER RECALL

PERFORMED RECALL

99S15 99S15

REPLACED THE SPEED CONTROL SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

PERFORMED RECALL 99S15

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

REPLACE BRAKE KIT PER RECALL

X REPLACE SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 REPLACE C-C SW

RECALL COMPLETED

PERFORM RECALL

REPLACED THE SPEED CONTROL SWITCH PER RECALL

128435 RECALL 99S15 WR RECALL 99S15 SPEED CONTR

18385 RECALL REPLACE DEACTIVATION SW AND CONNECTOR

REPLACE SWITCH

REPLACED DEACTIVATION SWITCH AS PER RECALL

REPLACE DEACTIVATION SWITCH FOR SPEED CONTROL 3

PREFORM 99S15 AS INSTRUCTED

REPLACE SWITCH AS DIRECTED BY RECALL

PERFORMED RECALL 99S15, CRUISE CONTROL

RECALL REPLACE SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATOR SWITCH

1 REPLACED SWITCH AND CONNECTOR

REPLACE SWITCH PER RECALL
 REPL SWITCH PER RECALL 98S15
 PERFORM RECALL
 105293 INSTALLED RECALL
 PERFORMED RECALL
 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 98 S 15 FOR CRUISE CONTROL
 98S15 PERFORMED RECALL
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORM RECALL

 DO RECALL 98S15
 . INSTALLED DEACTIVATION SWITCH AS PER RECALL 98S15
 REPLACED SWITCH AND CONNECTOR COMPLETED RECAL
 INSPECTED SPEED CONTROL OPERATION AND INSTALLED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIRS
 RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
 REPLACED THE SWITCH PER RECALL 98S15

 INSTALL SPEED SWITCH PER RECALL 98S15
 PERFORM SAFETY RECALL 98S15
 98S15 REPLACE DEACTIVATION SWITCH
 98S15 COMPLETE
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
 REPLACED SWITCH
 COMPLETED 98S15 RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 REPLACE SWITCH PER RECALL

 REPLACE CRUISE CNTRL SWITCH AND CONNECTOR ASSEMB

 98S15 RECALL
 PERFORMED RECALL 98S15
 RECALL 98S15 98S15 REPLACE SPEED CONTROL SENSOR AND CONNECTOR
 COMPLETE RECALL 98S15
 COMPLETED FACTORY RECALL
 28291 98S15 DONE *28
 122478 RECALL 98S15 W PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
 73493 RECALL WF PERFORM RECALL
 98S15 PERFORM RECALL 98S15
 54240 SWITCH RECALL REPLACE SWITCH AND CONNECTOR, RECALL JH
 REPLACE DEACTIVATION SWITCH PER RECALL
 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 RECALL COMPLETE
 78510 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONNECTOR TK372

COMPLETED RECALL

RECALL 99S15 99S15

DO RECALL 99S15

PER RECALL PERF RECALL

COMPLETE RECALL 99S15

PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTION

RECALL 99S15 99S15

REPL SWITCH PER RECALL 99S15

53681 RECALL PERFORM RECALL 99S15. REPLACE SWITCH AND HARD SHELL CONNECTOR

PER FORD INSTALLED SWITCH

PERFORM RECALL 99S15 PERFORM RECALL 99S15

REPL SWITCH PER RECALL 99S15

45064 RECALL INSTALL DEACTIVATION SWITCH

125787 RECALL REPLACE SWITCH AND CONNECTOR AS PER RECALL

88644 RECALL 99S15 PERFORMED RECALL 99S15.

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

149139 RECALL REPLACE CRUISE SWITCH AND CONNECTOR

PERFORM RECALL 99S15

RECALL 99S15 99S15 INSTALL CABLE PER RECALL

RPL SPEED CONTROL 99S15 RECALL

45788 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 8115

REPLACED SPEED CONTROL DEACTIVATION BRACKET.

RECALL COMPLETE

COMPLETE RECALL

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 99S15

PERFORMED RECALL 99S15

99S15 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

116820 RECALL REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH

REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORM SPEED CONTROL RECALL

204587 99S15C 0.5 HRS.

RECALL RECALL

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

RECALL 99S15 PERFORMED RECALL

INSTALLED DEACTIVATION SWITCH PER RECALL

CHECK AND INSTALLED PARTS PER RECALL

RECALL COMPLETED

PERFORMED OPEN RECALL 99S15B

37759 RECALL 99S15

PERFORM RECALL 99S15

PERFORM RECALL 99S15

RECALL 98S15 INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL
X 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
REPLACED DE-ACTIVATION SWITCH

PERFORM RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRUK
PERFORMED RECALL
INSTALL CRUISE CONTROL DEACTIVATION SWITCH & PLUG PER RECALL

VERIFY CRUISE CONTROL SWITCH
INSTALL SWITCH AND PLUG AS PER RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL PERFORM RECALL
PERFORM RECALL PER FORD NOTICE
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
98S15 98S15
PERFORMED RECALL #98S15 SPEED CONTROL DEACTIVATION SWITCH
23960 REPLACED CRUISE DEACT. SWITCH & CONECTER PER RECALL #98S15
PERFORM RECALL
PERFORM RECALL
PERFORM RECALL
PERFORM RECALL
1 1 REPL SWITCH AND CONNECTOR
PERFORM RECALL
RECALL 98S15
PERFORMED RECALL 98S15
1 PERFORMED RECALL
84381 PERFORM RECALL 98S15
SWITCH 98S15

98S15 RECALL ON OASIS 98S15 RECALL REPLACED SWITCH & CONNECTOR
98-S-15 98-S-15
REPLACE BRAKE KIT PER RECALL
98S15 RECALL -
PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR, CPN, 98S15, 98S15B, 0.5, ADMIN, 0.1, CC RECAL
REPL DEACTIVATION SWITCH PER RECALL
98S15 SWITCH-CONNECTOR 98S15
PERFORMED RECALL 98S15
PERFORMED RECALL 98S15
PERFORMED RECALL PERFORMED RECAL
PERFORM AS PER NOTIF
REPL SWITCH PER RECALL 98S15
8758 SPEED CONTROL RECALL
RECALL 98S15 RECALL REPLACE SWITCH
98S15 INSTALL BRAKE SWITCH AND CONNECTOR PER RECALL
84: PERFORM 98S15 RECALL

REPLACED THE SWITCH PER RECALL 98S16
8977 RECALL W REPLACE SWITCH AND PLUG GA
PERFORM RECALL 98S16
PERFORM SPEED CONTROL RECALL
COMPLETE RECALL 98S16
RECALL 98S15 98S15
INSPECT AND PERFORM RECALL

RECALL INSTALL DEACTIVATION SWITCH AS DIRECTED
SPEED CONTROL SWITCH 98S15 RECALL
OPEN RECALL PERFORMED RECALL
RECALL COMPLETED

PERFORM SPEED CONTROL DEACTIVATION RECALL

1 PERFORMED RECALL 98S15

PERFORMED RECALL 98S15

INSPECTED AND REPLACED BRAKE REPAIRS KIT AS NEEDED FOR RECALL REPAIRS

COMPLETE RECALL 98S15

MANUFACTURE REQUIREMENT INSPECTED & INSTALLED DEACTIVATION SWITCH

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

PERFORM RECALL F

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

64143 RECALL W PERFORMED RECALL 98S15

DID RECALL 98S15 ON SPEED CONTROL

98S15 RECALL COMPLETE

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION

REPLACED SWITCH AND HARD SHELL CONNECTOR. SPEED CONTROL IS INOP.

98S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION :

1 INSTALLED CRUISE SWITCH AND HARD SHELL

RECALL 98S15B

1 COMPLETED RECALL 98S15

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .8

COMPLETED RECALL

PERFORMED 98S15

PERFORM RECALL

106000 INSTALL NEW SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

RECALL - PERFORMED RECALL # 0836

98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

154788 PREFORM MODIFICATIONS PER 98S15

CAMPAIGN 98-S-15 COMPLETED AS PER RECALL INSTRUCTION.

REPLACE CRUISE CONTROL BRAKE SWITCH PER RECALL

PERFORMED 98S15 RECALL 98S15

COMPLETE RECALL

PERFORM RECALL 98S15B

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL

RECALL 98S15

RECALL 99S15 DEACTIVATION SWITCH FOR SPEED CONTROL REPLACED

REPLACE BRAKE PRESSURE SWITCH PER RECALL.

80984 RECALL (#17)-REPLACE SWITCH AND HARD SHELL AS PER RECALL, BLEED BRAKES.

78277 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST

REPLACE SPEED CONTROL SWITCH PER RECALL.

PERFORM RECALL 99S15

PERFORM RECALL

INCORRECT CONNECTOR SHELL AND WIRE TERMINALS WERE INSTALLED AT A PREVIOUS REPAIR. SOLDER IN CORRECT TERMINAL ENDS.

1 PERFORM RECALL 99S15

99S15 99S15

104000 RTECALL 99S15 COMPLETE RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL===== RECALL===== REPL CAB

99S15 REPLACED DEACTIVATOR SWITCH.

1 RECALL COMPLETE

SERVICE INSTALL KIT PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH, ETC.

100891 COMPLETE RECALL 99S15 AS PER RECALL

RECALL 99S15

80884 W REPLACE SWITCH RAT.

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

PERFORMED TSB 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

RECALL REPLACED DEACTIVATION SWITCH

PERFORMED 99S15

REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL REPLACE SWITCH

1 REPLACED SWITCH

77039 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745

99S15 99S15 RECALL W PERFORM RECALL 99S15

RECALL 99S15 SPEED CONTROL REPLACE SWITCH AND CONTOR PER RECALL RECK OK

PERFORM RECALL 99S15 PERFORMED RECAL

30036 RECALL W PERFORM RECALL TECH # 868

RECALL COMPLETE, REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL.

REPLACE SPEED CONTROL DEAVTIVATION SWITCH

RECALL 99S15

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

OPEN RECALL PERFORM RECALL

RECALL 99S15 PERFORMED, REPLACED SPEED CONTROL ACTIVATION SWITCH. 1

PERFORMED RECALL 99S15 WHEN REMOVING DEACTIVATION SWITCH THREADS OUT OF PROPORTIONING VALVE REPLACED HOOKED UP ABS ADAPTER

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
PERFORMED RECALL 99S15 INSTALLED CRUISE SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

127741 DID RECALL AND BLED BRAKES—.8 HRS
RECALL 99S15 REPLACED DEACTIVATION SWITCH.
PERFORM RECALL
OPEN RECALL PERFORM RECALL
75140 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
75140 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
PERFORM RECALL 99S15
RECALL 99S15 PERFORMED 1

INSTALL RECALL KIT.

RECALL 99S15B NEC TO PERFORM RECALL 99S15B
MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH
29884 99S15 WARR PERFORM RECALL, TEST DRIVE TO CK OPERATION OF SPEED CONTROL, OK.
REPLACED CRUISE CONTROL SWITCH
34925 RECALL W REPLACE SWITCH GA
71789 PERFORMED RECALL 99S15-SPEED CONTROL SWITCH.
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH ASSEMBLY
FACTORY RECALL COMPLETED RECALL
REPLACE DEACTIVATION SWITCH PER RECALL
RECALL PERFORMED RECALL 99S15
RECALL 99S15 PERFORMED RECALL 99S15 - REPLACED CRUISE CONTROL CUT OUT SWITCH
PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH
98707 99S15B .5 HR REPLACE DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
RECALL DID RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR, ROAD TEST.
DEFECTIVE REPLACED DEACTIVATION SWITCH AS PER RECALL
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
COMPLETE RECALL ON SPEED CONTROL SWITCH
38787 99S15B 0.5- ADMIN 0.1 RECALL
1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B .5
FACTORY RECALL COMPLETED RECALL
INSTALLED SWITCH PER RECALL
NGS TESTED TESTED FUEL INJECTOR FOUND NOT CONTRIBUTING REPLACED INJECTOR AND RETESTED
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED
DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE REPLACED DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
REPLACE CRUISE DE-ACTIVATION SWITCH AS PER RECALL
COMPLETED RECALL 99S15
RECALL 99S15 RECALL COMPLETED

1 RECALL COMPLETE
 PERFORM RECALL
 PERFORMED RECALL 98S15-INSTALL SWITCH
 98S15 98S15
 . COMPLETED RECALL
 PERFORMED RECALL 98S15
 PERFORMED RECALL 98S15
 108428 PERFORMED OPEN RECALL 98S15
 REPLACED CRUISE SWITCH
 PERFORM RECALL
 89412 INSTALL NEW SWITCH
 107400 98S15 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR
 INSTALLED KIT 98S15 RECALL PERFORMED
 RECALL 98S15
 COMPLETED RECALL 98S15
 75174 RECALL 98S15 5 W PERFORM RECALL 98S15
 PERFORMED RECALL
 REPLACED SPEED DEACTIVATION SWITCH
 98S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 98S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.
 REPLACE SWITCH
 98S15 98S15 RECALL COMPLETED
 1 PERFORMED RECALL
 PERFORMED RECALL 98S15
 PERFORM 98S15 RECALL
 98499 WARRANTY RECALL 98S15 REPLACE SWITCH AND WIRE PLUG
 CHECK AND REPAIR AS REQUIRED
 PERFORM SAFETY RECALL 98S15
 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 98S15
 REPLACED SWITCH PER RECALL 98S15
 PERFORMED RECALL F
 98S15 98S15 RECALL, REPLACE CRUISE CONTROL, DEACTIVATION SWITCH
 DO RECALL 98S15

 REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR AS PER RECALL
 78288 98S15B .5 .5 RECALL
 RECALL 98S15 PERFORM RECALL 98S15
 98S15 98S15
 PERFORMED SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SWITCH
 INSTALL SPEED CONTROL SWITCH

 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPLACE SPEED CONTROL PER RECALL

 98S15 REPLACE DEACTIVATION SWITCH
 79 REMOVE AND REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL
 98280 98S15 INSPECT AND REPLACE SWITCH
 RECALLED BY FORD MOTOR CO REPAIR AS NEEDED

98S15 98S15
PERFORM RECALL 98S15
RECALL PERFORM RECALL
64014 PERFORM 98S15
REMOVED AND REPLACED SPEED CONTROL CABLE
REPLACED CRUISE DEACT SWITCH

REPLACED SWITCH AND CONECTOR
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

WHEN DOING RECALL THREADS CAME OUT ORDERED DISTRIBUTION BLOCK R & R DISTRIBUTION BLOCK BLEED BRAKES TEST DROVE PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
COMPLETE RECALL 98S15
RECALL 98S15 RECALL PERFORME
REPLACE VALVE
110083 RECALL CRUISE DEACTIVATION SWITCH I DID REPLACE CONNECTOR AND SWITCH
1 REPLACED SPEED CONTROL SWITCH & CONNECTOR
PERFORMED RECALL 98S15B
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
COMPLETED RECALL 98S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 98S15
RECALL 98S15 RECALL COMPLETED
143812 PERFORMED RECALL 98S15
58214 RECALL PERFORM RECALL
REPLACED BRAKE DEAC SWITCH PER RECALL
57630 98S15 W PERFORMED SERVICE 98S15

98S15 .3 SECURED SWITCH 98S15B .5 REPLACED SWITCH & CONNECTOR PERFORMED DEACTIVATION OF SWITCH
86703 RECALL 98S15B 0.5 HRS. NEC TO PERFORM RECALL 98S15.
REPLACED THE SWITCH PER RECALL 98S15
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 98S15
INSTALL BRACKET
1 REPLACED SWITCH AND CONNECTOR
98216 INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL 98S15.
RECALL 98S15 RECALL
REPLACE SWITCH PER RECALL
RECALL PERFORM RECALL PER PROGRAM 98S15, DEACT SWITCH
REPLACED SWITCH TEST DRIVE WORKS FINE PER RECALL
RECALL 98S15 RECALL
REPLACED DEACTIVATION SWITCH
71137 RECALL 98S15 PERFORMED LABOR OPERATION 98S15B-0.5 HRS.
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
INSTALLED NEW SWITCH
PERFORMED RECALL 98S15
REPLACED SPEED CONTROL BRAKE SWITCH

RECALL PERFORM RECALL AS PER BOOK
RECALL 98S15 PERFORM RECALL 98S15

RECALL PERFORMD SPEED CONTROL DE-ACTIVATION SWIT
OPEN RECALL PERFORM RECALL
INSTALLED CRUISE DEACTIVATION SWITCH
77804 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15
COMPLETED RECALL
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .6

RECALL REPLACE DEACTIVATION SWITCH PER RECALL
77741 PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATI SWITCH
30037 98S15B 0.5 HRS. SPEED CONTROL RECAL
REPLACE SPEED CONTROL SWITCH
98354 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY AND HARNESS S CONNECTOR JH

98S15 98S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL COMPLETE
PERFORM RECALL PER MANUFACTURER PERFORMED RECAL
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S15
RECALL COMPLETED
INSTALL SWITCH BRKT
RECALL COMPLETED REPLACED SW
20334 RECALL 98S15 REPLACE DEACTIVATOR SWITCH AS PER RECALL
PERFORM RECALL 98S15
COMPLETED RECALL
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
INSTALL RECALL SWITCH
98S15 98S15
PERFORM RECALL 98S15
A DONE

REPLACE SPEED CONTROL SWITCH
RECALL COMPLETE
98S15 98S15
RECALL RECALL
RECALL 98S15
98398 INSTALL RECALL 98S15 WARRANTY INSTALL SWITCH AND WIREPLUG
REPLACED DEACTIVATION SWITCH
PERFORM RECALL
3 COMPLETED RECALL

REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL PERFORMED SPEED CONTROL DEACTIVATION SWTH

RECALL 99S15

REPLACED SPEED CONTROL CABLE

82607 PERFORM RECALL REPLACE DEACTIVATION SWTH

PERFORMED THE RECALL 99S15

PERFORMED RECALL 99S16

164578 RECALL 99S15, R&R DEACTIVATION SWITCH AND CONNECTOR, RETURNED PARTS

RECALL 99S15 RECALL DONE

90664 RECALL 99S15 WPC RECALL 99S15

R&R CRUISE CONTROL DEACTIVATION SWITCH AND HARNESSCONNECTOR PER RECALL 99S15

RECALL 99S15 RECALL

72708 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY

REPLACED DEACTIVATION SWITCH.

1 COMPLETED RECALL AS NEEDED 1

99S15B REPLACED DEACTIVATION SWITCH

REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 99S15 SPEED CONTROL CABLE

COMPLETE RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

11278 INSPECT VEHICLE FOR DEACTIVATION SWITCH. REMOVE AND REPLACE SWITCH AND CONNECTOR. AS PER RECALL 99S15.

103688 REPLACE SWITCH PER 99S15

99S15-3611 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

66666 RECALL R-R CRUISE SHUT-OFF SWITCH AS PER RECALL AND BLEED BRAKES

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

82138 PERFORMED RECALL

136546 REPLACED SW. AND CONECTOR.

OPEN RECALL COMPLETE RECALL

99S15B REPLACED SPEED CONTROL - CANCELLATION SWITCH & CONNECTOR SHELL AS

COMPLETE RECALL

PERFORM RECALL 99S15

62620 REPLACED SPEED CONTROL SWITCH, 8-2 8274

PERFORM RECALL 99S15 - -INSTALL SPEED CONTROL SWITCH

PERF. RECALL.

99S15B RECALL 99S15B RECALL

REPLACE SWITCH

G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPL SWITCH PER RECALL 99S15

99S15 99S15

REPLACE CRUISE SWITCH AS PER 99S15 RECALL. 1

PERFORMED RECALL 99S15

66400 RECALL 99S15 8310 REPLACE SWITCH & PLUG G

2 98S15B .5 ADMIN .1 INSTALLED NEW SWITCH PER RECALL
 REPLACE SPEED CONTROL CABLE AS PER RECALL 98S15
 INSTALL SWITCH AND PLUG CONN
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
 RECALL RECALL
 RECALL 98S15 INSTALLED MODIFICATION FOR CRUISE CONTROL
 INSTALL BRAKE SWITCH AND CONNECTOR
 PERFORM RECALL 98S15
 80102 REPLACED SPEED CONTROL SWITCH, S-2 2074
 98S15B .5 HR. REPLACE CRUISE CONTROL DEACTIVATION SWITCH.
 REPLACE SWITCH PER RECALL
 98S15 98S15
 98S15 98S15
 124058 RECALL 98S15 WR PERFORMED RECALL 98S15

PERFORM RECALL

— RECALL COMPLETED
 REPLACED SPEED CONTROL SWITCH

COMPLETED RECALL 98S15
 REPLACED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 98S15 RECALL
 OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15
 88035 PERFORM RECALL 98S15
 58177 LABOR OP 98S15B .5 HR
 132409 RECALL 98S15 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.
 COMPLETED RECALL
 PERFORM RECALL AS PER INSTRUCTIONS
 81834 98S15B 0.5 ADMIN 0.1
 98S15 98S15
 INSTALLED CRUISE CONTROL CANCEL SWITCH PER RECALL 98S15
 98S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

1 PREFORMED RECALL 98S15 REPLACED SPEED CONTROL SWITCH
 PERFORMED RECALL REPLACED THE SWITCH AND CONNECT OR
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 PERFORMED RECALL 98S15 INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH
 REPLACE BRAKE SWITCH AS PER RECALL
 REPLACED SWITCH & CONNECTOR PER RECALL
 COMPLETED RECALL 98S15 REPLACEMENT OF SPEED CONTROL SWITCH -DID 98S15B.
 RECALL 98S15 28000 MILES RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
 111570 98S15B 0.5 HRS. SPEED CONTROL RECALL
 RECALLED BY FORD PERFORMED RECALL
 85601 98S15 W REPLACED SPD CTRL DEACTIVATE SW. 2745
 REPLACED SWITCH AND CONNECTOR.
 TECH 150 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND WIRING CONNECTOR AS PER RECALL 98S1
 PERFORM RECALL 98S15

88970 98S15 W REPLACED SWITCH
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 INSTALL DEACTIVATION SWITCH
 PERFORM RECALL 1
 PERFORMED RECALL 98S15 PERFORMED RECALL 98S15B
 PERFORM RECALL
 PERFORM RECALL 98S15 A89
 REPL CONNECTOR 98S15
 RECALL IS REQUIRED COMPLETE RECALL
 REPLACED CRUISE SWITCH PER RECALL 98S15
 PERFORMED 98S15 RECALL
 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.
 RECALL REPLACE DEAC SWITCH PER RECALL
 DIAG AND PERFORMED RECALL 98S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW
 REPLACE BRAKE SWITCH AS PER RECALL
 1 INSTALL UPDATED CRUISE RECALL SWITCH
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTION
 78578 RECALL .5 PERFORMED REPAIR PER RECALL
 PERFORM RECALL PER FORD NOTICE
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B 0.5, ADMIN 0.1
 44533 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
 PERFORM RECALL 98S15 REPLACE SWITCH
 98S15 COMPLETED
 PERFORM RECALL 98S15
 REPLACED DEACTIVATION SWITCH
 43310 .5 INSTALLED NEW DEACTIVATION SWITCH
 105525 RECALL 98S15 WIR RECALL 98S15
 REPLACED SWITCH AND CONNECTOR
 REPLACE CRUISE CONTROL SWITCH AND CONNECTORS AS PER RECALL
 REPLACE BRAKE LIGHT SWITCH
 PERFORMED RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15
 SPEED CONT REPL CABLE
 RECALL 98S15 RECALL 98S15
 - MODIFY PER RECALL 98S15
 98S15 98S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

 77517 REPLACE SPEED CONTROL SWITCH AND CONECTOR RECAL 98S15B
 94587 RECALL REPLACE DEACTIVATION SWITCH
 REPLACE SPEED CONTROL SWITCH AS PER RECALL 98S15

 PERFORM RECALL.....
 132- SPD CONTROL SWITCH RECALL - 98S15-INSPECT & REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH
 32009 98S15 W PERFORMED SERVICE 98S15
 REPLACED SWITCH AND CONNECTOR
 REPLACE SPEED SWITCH AS PER RECALL

REMOVED AND REPLACED SWITCH AND CONNECTOR AS PER RECALL
INSPECT FOR RECALL. INSTALL SPEED CNTRL DEACTIVATION SWITCH RECALL COMPLETE
PERFORM RECALL
REPLACE SWITCH
99S15 RPL SPEED CONTROL DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL 99S15
134874 PERF RECALL
REPL SPEED CONTROL DEACTIVATION SWITCH AND CONN
RECALL. PERFORMED RECALL
REPLACE SWITCH RECALL 99S15
DOES NOT OPERATE PROPERLY. INSTALLED DEAVTIVATION AS PER RECALL
PERFORM RECALL
REPLACED SPEED CONTROL SWITCH AS PER RECALL
REPLACED DISENGAGE SWITCH PER RECALL 99S15.

INSTALL CRUISE CONTROL DEACTIVATION SWITCH
RECALL 99S15 REPLACE C-C SW
48263 99S15 COMPLETED RECALL
REPLACE SWITCH
PERFORMED RECALL. REPLACED CRUISE SWITCH
REPL SWITCH PER RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH CONNECTOR AS PER RECALL 99S15
PERFORM RECALL 99S15
R&R CRUISE CNTRL SWITCH AND CONN
R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
PERFORMED RECALL. PERFORMED RECALL
REPLACE SPEED CONTROL SWITCH
62839 RECALL 99S15 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.
67064 RECALL. INSTALL DEACTIVATION SWITCH
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORM RECALL
99S15 RECALL. 99S15 RECALL COMPLETE
REPLACED SPEED CONTROL SWITCH
PERFORM RECALL 99S15
112862 SPEED CONTROL DEACT. S-W REPLACED PER RECALL
93262 99S15 W REPLACED SPD CTRL DEACTIVATE SW 2745

REPLACE SWITCH
RECALL 99S15 RECALL
RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT
104660 RECALL CRUISE DEACTIVATION SWITCH I DID REPLACE SWITCH AND CONNECTOR TEST DROVE VEHICLE OK DRIVERS SEAT ON VEHICLE IS BRC
134011 RECALL. INSTALL SWITCH AND PLUG PER RECALL
124866 .5 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 6562
PERFORMED 99S15 RECALL
RECALL. PERFORMED RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
REPLACE SPEED CONTROL DEACTIVATION SWITCH.
PERFORMED RECALL

1 REPLACE SWITCH AS PER RECALL

PERFORM RECALL 99S16

PERFORM RECALL 99S15

1 PERFORMED RECALL

REPLACED BRAKE SWITCH PER RECALL, BLEED REAR BRAK

REPL SPEED CONTROL SWITCH

123318 PERFORM 99S15 RECALL DONE

1 PERFORM RECALL AS OUTLINE

12 REPLACED CONNECTOR AND DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH AS PER 99S15

REPLACED SWITCH

COMPLETED RECALL 99S15 PER PROGRAM

PERFORMED RECALL AS PER 99S15

REPLACE SWITCH AND HARNESS PER RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL 82073 REPLACE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 COMPLETED RECALL

APPLIED RECALL 99S15

PERF. RECALL

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

78121 RECALL AND STRIPPED SWITCH BLOCK REPLACED DEACTIVATION SWITCH AND HARDSHELL DURING SWITCH REPLACEMENT THREADS CAME OUT

PERFORM RECALL-INSTALL SHIELDS

99S15 RECALL SPEED CONTROL DEACT SWITCH PERFORMED 99S15 RECALL

123069 RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S15 COMPLETED RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPL SPD CNTRL DEACTIVATION SW

PERFORMED RECALL

1 INSTALLED SWITCH

REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S16B .5 REMOVED TAPED AND SET
TECH 31 PERFORMED RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED A SAFETY RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AND BRAKE SYSTEM

REPLACED SWITCH AS PER RECALL 99S15

93989 RECALL REPLACED SWITCH AND WIRE PLUG PER RECALL 99S15

99S15 99S15 REPLACED DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

53818 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
PERFORM RECALL

A SHORT IN THE SPEED CONTROL SWTH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE
INSTALLED SWITCH AS PER RECALL 1

70380 W REPLACE SWITCH GA

RECALL 98S15 PERFORM RECALL 98S15

RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15

A SHORT IN THE SPEED CONTROL SWTH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

TECH 33 PERFORMED RECALL 98S15 REPLACE SPEED CO NTROL CABLE

REPLACE SPEED CONTROL SWITCH #8088

REPLACED SC DEACTIVATION SWITCH 98S15

RECALL RECALL

94778 PERFORMED RECALL 98S15 REPLACEMENT OF SPEED CONTROL DEACTIVATION SWITCH AND SWITCH HARD SHEILD PLUG.

98S15 98S15

98S15 RECALL 98S15 RECALL REPLACE BRAKE SWITCH AND REWIRE CONNECTOR

134806 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

31778 PERFORMED RECALL 98S15

PERFORMED RECALL

98S15 REPLACED SWITCH AND CONNECTOR

PERFORM RECALL 98S15 COMMENT GEAR SHIFT HARD TO MOVE BEFORE REPAIRS

OPEN CONTROL ASSEMBLY-AIR CONDITIONER - REPLACE

1 PERFORMED 98S15 RECALL

PERFORM SPEED CONTROL SW RECALL 98S15

REPLAED CRUISE CONTROL SWITCH FOR RECALL

SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SPOED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
COMPELTED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PERFORMED 98S15B

RECALL 98S15 COMPLETED RECAL

REPLACE PRESSURE SWITCH PER RECALL

INSTALLED CRUISE RECALL 98S15.

INSTALLED SWITCH AND CONNECTOR

REPLACED SPEED DEACTIVATION SWITCH

RECALL COMPLETED

REPLACE CRUISE CONTROL DIACTIVATION SWITCH

RECALL 98S15 INSTALLED SWITCH PER RECALL

1 INSTALL KIT

REPLACE SWITCH AND HARNESS PER RECALL

98S15 98S15

REP SPEED CONTROL CABLE AS PER RECALL

REPAIR AS PER RECALL

98S15 RECALL 98S15 RECALL COMPLETE

97880 98S15 RECALL REPLACE SW AND SHELL

1 REPLACED DEACTIVATION SWITCH PER VEHICLE RECALL

. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACE SPEED CONTROL SWITCH AND PLUG
 UNKNOWN INSTALL SWITCH AND CONNECTOR PER 99S15
 RECALL RECALL
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15.
 PERFORM RECALL 99S15
 REPLACE SPEED CONTROL SWITCH
 RECALL -- PERFORMED RECALL # 08378
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 DIAGNOSE AND REPLACED CRUISE CONTROL SWITCHES
 RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS
 REPLACE DEACTIVATOR SWITCH PER RECALL
 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 . REPLACED SPEED CONTROL DEACTIVATION SWITCH
 INSTALLED KIT 99S15 RECALL PERFORMED
 99S15 99S15 COMPLETED
 PERFORM SPEED CONTROL DEACTIVATION RECALL
 1 INSTALL KIT
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL SWITCH AND PLUG AS PER RECALL
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
 REPLACE CRUISE CONTROL SWITCH
 99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
 X PERFORMED RECALL
 PERFORMED 99S15 RECALL
 PERFORMED RECALL 99S15 CHECK AND REPLACED CRUISE CONTROL CABLE
 PERFORMED RECALL 99S15 PER INSTRUCTIONS
 RECALL DH R R DEACTIVATION SWITCH PER 99S15
 R AND R SPEED CTRL CONNECTOR AND SWITCH ASSEMBLY
 PERFORMED RECALL INSTALLED BOP PARTS
 1 COMPLETED RECALL 99S15 SPEED CONTROL
 48897 99S15 RECALL W RR DEACTIVATION SWITCH PER 99S15 RECALL
 INSTALL NEW SWITCH
 REPLACED SWITCH AND CONNECTOR PER RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
 RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

 99S15 PERFORMED 99S15 RECALL

 REMOVED AND REPLACED CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL
 INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK TO RELEASE
 RECALL 99S15
 REPLACE SWITCH
 RECALL RECALL
 188492 RECALL 99S15 PERFORM RECALL 99S15
 REPLACE SWITCH PER 99S15
 99S15 99S15
 PERFORMED RECALL AS PER INSTRUCTIONS

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL

60281 PERFORM RECALL

PERFORM RECALL

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE
PERFORMED RECALL

85186 RECALL 99S15 RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORMED RECALL 99S15 REPLACED CONTROL SWITCH AND CONNECTOR

FACTORY RECALL COMPLETED

82448 CC RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH ROAD TEST ALL OK RECALL 99S15

INSTALL CRUISE SWITCH PER RECALL

RECALL

99S15 RECALL

R AND R CONNECTOR AND SWITCH AS PER RECALL

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE

RECALL

REPLACED SPEED CONTROL SWITCH AS PER RECALL

TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDELI

RECALL DH REPLACE DEACTIVATION SWITCH AND CONNECTOR

90181 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH

PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH, PER 99S15

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPL CRUISE CONTROL SWITCH

RECALL

RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES PER RECALL

RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL

REPAIRED AS PER RECALL 99S15

PERFORMED RECALL

RECALL 99S15 PERFORM RECALL 99S15

RECALL

99S15 - B - RECALL

77472 RECALL 99S15 PERFORMED RECALL 99S15 AS PER FORD

PERFORMED RECALL 99S15

PERFORM RECALL

AS PER RECALL

99S15 RECALL TO REPLACE HARDSHELL CONNECTOR

INSTALLED MASTER CYLINDER SWTH

REPLACE SPEED CONTROL SWITCH

REPLACE BRAKE PRESSURE SWITCH PER RECALL

REPLACE SPEED CONTROL SWITCH

58720 INSTALL SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

NA

99S15 REPLACED SWITCH

COMPLETE RECALL

29411 PERFORM RECALL 99S15

PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15B .5 ADMIN .1 PERFORM RECALL 99S15, INSTALL SWITCH AND CONNECTOR END

99S15 RECALL

PERFORM RECALL 99S15

63243 PERFORMED RECALL 99S15

85219 WARR PERF RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

UNKNOWN RECALL COMPLETE

REPLACE SPEED CONTROL CABLE AS PER RECALL 99S185

REPLACED DEACTIVATION SWITCH AND CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM

1 PERFORMED RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

REPLACE BRAKE SWITCH AS PER RECALL

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE

REPL DEACTIVATION SWITCH 99S15

99S15

RECALL

99S15 INSTALLED SWITCH PER RECALL

PERFORMED RECALL

COMPLETE RECALL

01

RECALL 99S15

101785 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

PERFORMED RECALL

1 COMPLETED RECALL 99S15

R&R SPEED CONTROL SWITCH AS PER 99S15

PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

TEST GEM REPL CTM PER OASIS

CRUISE CONT 99S15 INST SWITCH

REPLACED DEACTIVATION SWITCH

99S15E

PERFORMED RECALL-INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 INSTALL SWITCH

RECALL 99S15

99S15 REPLACE SPEED CONTROL SWITCH

OPEN RECALL

PERFORMED RECAL

INSTALL DEACTIVATION SWITCH 1

99S15

99S15

RECALL

99S15 REPLACED SWITCH

REPLACE SWITCH

PERFORM RECALL AND REPAIR RELATED DAMAGE. OPERATION CODES: 9818A & 14526A THESE ARE THE RELATED DAMAGE

COMPLETED 99S15 RECALL 99S15B .5 ADMIN .1 1

INSTALL AS PER RECALL 99S15

RECALL 99S15 RENEW CRUISE DEACT SWITCH AND CONN

R AND R CRUISE SWITCH AND CONNECTOR ASSEMBLY

PERFORMED RECALL

86726 SAFETY RECALL INSPECTED AND REPLACED BRAKE SWITCH DEACTIVATOR AND CONNECTOR

PERFORMED RECALL

15066 COMPLETED RECALL 99S15

DO THE RECALL

INSTALL NEW SWITCH PER RECALL
67378 RECALL 99S15 RECALL 99S15
INSTALLED SPEED CONTROL CABLE AS PER RECALL
COMPLETED RECALL 99S15, SPEED CONTROL SWITCH
PERFORMED RECALL 99S15
77090 PERFORMED RECALL 99S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
CHECK AND REPLACE SWITCH PER RECALL
RECALL COMPLETED
40012 99S15B 0.5 ADMIN 0.1
PERFORMED RECALL 99S15
REPLACE AS PER RECALL 99S15
INSPECTED CRUISE CONTROL SWITCH OPERATION AND REPLACED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIR
PERFORM RECALL 99S15 SPEED CONTROL

PERFORMED RECALL
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
REPLACE CRUISE CONTROL DEACT SWITCH
71904 99S15B-.5 .5 REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH.
51155 PERFORMED RECALL 99S15.
RECALL 99S15 INSTALL SWITCH
CK OUT FOUND DEACTIVATION SWITCH FAULTY REMOVE AND REPLACE SWITCH
INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
1 REPLACED CRUISE DEACTIVATION SWITCH PERFORMED RECALL 99S15B
99S15 99S15
PERFORMED RECALL
RECALL 99S15
PERFORM RECALL
PERFORMED RECALL
54582 RECALL 99S15 B .5
RECALL COMPLETED
PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION

RECALL 99S15

PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL 99S15
R&R CRUISE DEACTIVATOR
REPL DEACTIVATION SWITCH
PERFORMED RECALL 99S15
OPEN RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH
COMPLETE REPLACED SPEED CONTROL BRAKE DEACTIVATOR SWITCH & CONNECTOR AS PER RECALL
75201 MALFUNCTIONING DEACTIVATION SW R+R SW AND HARD SHELL CONNECTOR
RECALL 99S15 COMPLETED
REPLACED SPEED CONTROL SWITCH PER RECALL

PERFORMED RECALL 99S15
PERF RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL COMPLETED

99-S-15 99-S-15 COMPLET
RECALL COMPLETED
RECALL 99S15 PERFORMED 1
RECALL 99S15 RECALL
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL
99S15 REPLACED SWITCH AND CONNECTOR
REPAIR PER 99S15 RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

93545 99S15B 0.5 ADMIN 0.1

RECALL REPLACE SWITCH PER RECALL
77097 INSTALL KIT RETURN OLD PARTS TO NATE
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL
INSTALLED DEACTIVATION SWITCH.
78291 RECALL 99S15 REPLACE SW AND ROAD TEST
PERFORMED RECALL
RECALL RECALL
INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORMED SPEED CONTROL RECALL
COMPLETE RECALL 99S15
1 PERFORMED RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AND BRAKE SYSTEM
99448 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
RECALL COMPLETED
PERFORM RECALL 99S15
PERFORMED RECALL 99S15-INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH
RECALL 99S15 PERFORMED RECALL 99S15
1 INSTALLED SPEED CONTROL SWITCH
99S15 RECALL 99S15 COMPLETE
PERFORMED 99S15 RECALL

RECALL 99S15 REPLACE C-C SW
REPLACE SWITCH AND CONN PER PROGRAM
RECALLED BY FORD PERFORMED RECALL 99S15
99S15 REPLACE SWITCH
PERFORM RECALL 99S15 CRUISE SWITCH REPLACEMENT.
COMPLETED RECALL 99S15, SPEED CONTROL SWITCH

PERFORMED CRUISE CONTROL RECALL
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

REPLACED SWITCH AND CONNECTOR PER RECALL 98S15
RECALL SPEED DEACT SWITCH MODIFICATION
INSTALL SPEED CONTROL DEACTIVATION SWITCH 1
REPLACED SENDER & CONNECTOR PER RECALL 98S15
53866 PERFORM RECALL
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
RECALL 98S15 PERFORMED RECALL 98S15
PERFORM RECALL 98S15

RECALL 98S15 AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
1 PERFORMED RECALL 98S15

RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH
RECOMMENDED REPAIR REPLACE SWITCH AND CONNECTOR
RECALL 98S15
98S15 98S15
RECALL 98S15 PERFORMED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACE SWITCH AND HARD SHELL
REPLACED SPEED CONTROL SWITCH AS PER RECALL
COMPLETE RECALL
98S15 98S15 PERFORM RECALL
ORECALL RECALL
RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
SPEED CTRL DEACTIVATION SWITCH 98S15 REPAIR PER RECALL
REPLACED THE SPEED CONTROL SWITCH PER RECALL
SWITCH 98S15 DEACTIVATION SWITCH
CHECKED AND VERIFIED CONCERN, RAN CIRCUIT TESTING, FOUND OPE N CIRCUIT AT SWITCH,, REMOVED AND REPLACED SWITCH
COMPLETE REPLACED CRUISE DEASTVATOR SWITCH & CONNECTOR
REPLACED SPEED SONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15
DO RECALL 98S15
PERFORMED RECALL 98S15
RECALL
REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH AND REPLACE CONNECTOR END PER RECALL 98S15.
COMPLETED RECALL
PERFORMED RECALL
RECALL 98S15, REPLACE DISINGAGEMENT SWITCH
83764 RECALL REPLACE SWITCH AND CONNECTOR PER RECALL
83858 RECALL W REPLACE SWITCH GA
PERFORMED RECALL 98S15 REPLACE SPEED CONTROL DE ACTIVATION SWITCH
RECALL 98S15 INSTALLED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

1 REPLACE CRUISE CONTROL SWITCH.

RECALL RECALL

COMPLETED RECALL

OPEN RECALL PERFORMED RECALL

PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH

00 99S15B

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

98629 RECALL 99S15 INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL INSTRUCTIONS

1 REMOVE TAPE AND SECURE DEACTIVATION SWITCH 99S15E 3

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

7 PERFORM RECALL 99S15 CRUISE CONTROL SWITCH REPL

RECALL 99S15 PERFORMED RECALL 99S15

RECALL COMPLETED

PERFORMED RECALL

RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL 99S15 REPLACED CRUISE CONTROL SWITCH

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

COMPLETE RECALL

00 99S15B

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL 99S15

RECALL COMPLETED

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACE CONNECTOR AND SWITCH PER RECALL

94717 INSTALL REVISED PRESSURE SWITCH (SPEED CONTROL DEACTIVATION SW.) KIT.

REPLACED PER RECALL

99S15 RECALL

PERFORMED RECALL 99S15

99S15 RECALL REPLACE SWITCH AS PER RECALL

INSTALL CRUISE CONTROL SWITCH PER RECALL

PERFORM 99S15 RECALL REPLACE DEACTIVATION SWITCH

RECALL RECALL

RECALL 95201 REPLACE SWITCH AND CONNECTOR

22838 W REPLACE SWITCH GA

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.

70168 W REPLACE SWITCH ME

INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRE CONNECTOR.

1 COMPLETED RECALL 99S15 SPEED CONTROL RECALL

INSTALLED DEACTIVATION SWITCH PER INSTRUCTIONS ON RECALL 99S15

045 DIAGNOSIS AND REPLACED CRUISE DEACTIVATION SWITCH

RECALL 99S15 INSTALLED SWITCH

INSTALL NEW SWITCH

REPLACED SPEED CONTROL CABLE PER RECALL 99S15

1 PERFORM RECALL
 INSTALLED SWITCH PER RECALL
 SPEED CONTROL PERFORMED RECALL 99S15 R AND R DEACTIVATION SWITCH AND CONNE AND BLEED ALL FOUR BRAKES
 REPLACED THE SPEED CONTROL DEACTICATION SWITCH AS PER RECALL
 RECALL 99S15
 PERFORMED RECALL 99S15
 FACTORY RECALL COMPLETED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETE RECALL 99S15
 RECALL 99S15 - B - RECALL
 RECALL 99S15 PERFORMED RECALL 99S15
 PERFORMED SAFETY RECALL 99S15
 REPLACE COMPLETED

1 ACCESS INSPECT & REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15
 PERFORMED RECALL
 PERFORMED RECALL
 1 PERFORMED RECALL
 REPLACED DISENGAGE SWITCH PER RECALL 99S15.
 E RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 REPLACED SWITCH AS PER RECALL
 DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH OK NOW DISABLED ON RO 28729 THIS ON RO 28729 VOIDED BECAUSE OF DATE
 REPLACE SWITCH AND HARDSHELL PER RECALL
 99S15 99S15
 RECALL -- PERFORMED RECALL # 0038
 108728 RECALL WR RECALL 99S15
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 RECALL 99S15 COMPLETED
 PERFORMED RECALL
 PERFORM RECALL 99S15B REPLACE THE SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 RECALL 99S15
 RECALL 99S15 RECALL COMPLETED 99S15 RECALL COMPLETED
 1 PERFORMED RECALL 99S15 - INSTALLED SWITCH
 RECALL 99S15 INSTALLED SWITCH
 TECH INSTALLED NEW CRUISE SWITCH PER FORD RECALL
 TECH INSTALLED NEW CRUISE CONTROL SWITCH PER FORD RECALL
 PERFORM RECALL
 INSTALLED SWITC
 UNKNOWN RECALL COMPLETE
 PERFORMED SAFETY RECALL 99S15
 90736 RECALL REPLACE DEACTIVATION SWITCH PER RECALL
 REPLACE SWITCH AND CONNECTOR PER RECALL
 102079 REPL.SW.
 PERFORMED RECALL
 78966 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOAD TEST JH
 127101 RECALL 99S15 WARR REPLACED DEACTIVATION SWITCH
 60030 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL.
 COMPLETED RECALL
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

30330 RECALL W REPLACE SWITCH GA

PERFORM RECALL 99S15

REPLACE DEACTIVATION SWITCH 1

47280 REPLACE BRAKE SWITCH AND CONNECTOR

INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL

RECALL

DID RECALL

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL SWITCH

PERFORMED RECALL

70960 99S15B 0.5 ADMIN 0.1

50003 RECALL W 99S15 REPLACED DEACTIVATION SWIT

COMPLETE INSTALLED SWITCH AS PER RECALL

INSTALL SWITCH AND HARD SHELL

21448 99S15 W REPLACED-CONTROL-DEACTIVATION-SWITCH-99S52

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 99S15

1 ACCESS & REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15

99018 PERFORMED RECALL 99S15

REPLD CRUISE DEACTIVATION SWITCH 99S15

INSTALLED DEACTIVATION SWITCH AS PER RECALL

99S15 SPEED CONTROL DEACTIVATION 99S15 SPEED CONTROL DEACTIVATION

PERFORM RECALL.....

RECALL

DID RECALL

REPLACE SWITCH AS PER 99S15

99S15B

99S15B

REPLACE SWITCH AS PER RECALL

75959 REPLACE SPEED CONTROL DEACTIVATION SWITC

1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG

RPL SPEED CONTROL DEACTIVATIONSWITCH AND CONNECT

83089 RECALL RECALL 99S15

99S15

99S15 PERFORMED RECALL

PERFORMED RECALL

PERFORM RECALL

99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL 99S15 COMPLETED

DIH INSTALL DEACTIVATION SWITCH PER RECALL 99S15

REPAIRED AS PER RECALL

INSTALL SWITCH PER INSTRUCTIONS ON RECALL 99S15

PERFORM RECALL

OTHER

99S15 PERFORM RECALL

REPLACE DEACTIVATION SWITCH-WARRANTY-RECALL-BILL

118287 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED THE SPEED CONTROL SWITCH PER RECALL
PERFORM RECALL 98S15
PERFORM RECALL 98S15 REPLACE SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL
PERFORMED RECALL 98S15
RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH CONNECTOR
98S15 R&R DEACTIVATION SWITCH
98S15 98S15 RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
PERFORMED RECALL
178808 RECALL #98S15 PERFORM RECALL #98S15 REPLACING CRUISE CONTROL DEACTIVATION SWITCH *5 WP
1 DO 98S15 RECALL
RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
PERFORMED RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH
RECALL 98S15 PERFORMED RECALL 98S15
PERFORMED RECALL 98S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
REPLACE DEACTIVATION SWITCH PER RECALL 98S15
58262 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
RECALL 98S15
PERFORMED RECALL AS NEEDED ALL OK

106883 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
78882 INSTALLED NEW DEAC SW AND HARDSHELL CONN AS PER RECALL
PERFORMED RECALL
RECALL RECALL
INSTALLED NEW ACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL 98S15
94788 98S15 COMPLETED DEACTIVATION SWITCH RECAL
106253 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH.
REPL SWITCH
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 98S15
- MODIFY PER RECALL 98S15
PER NOTIFICATION 98S15 INSTALLED BRAKE REPAIR KIT PER RECALL INSTRUCTIONS
VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT
REPLACED DEACTIVATION SWITCH

COMPLETED RECALL

OTHER 98S15 PERFORM RECALL
REMOVE & REPLACE CRUISE DEACTIVATION SWITCH
REPLACED SWITCH AND CONNECTOR
INSTALL DEACTIVATION SWITCH AND CONNECTOR
128215 98S15 WARR REPLACED SWITCH
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL

COMPLETED RECALL
REPLACED DEACTIVATION SWITCH.
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
48819 RECALL W REPL CRUISE SWITCH PER RECALL 98S15

98S15 98S15
RECALL 98S15
PERFORM RECALL
120777 INSTALLED DEACTIVATION SW AS PER RECALL 98S15
RECALL 98S15 COMPLETED
RECALL DONE
RECALL 98S15 REPLACED SWITCH
RENEW SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL AS REQUESTED
INSTALLED DEACTIVATION SWITCH AS PER RECALL

94546 COMPLETE RECALL 98S15
98S55 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
1 PROFORMED RECALL 98S15 REPLACED DEACTIVATION SWITCH CRUISE CONTROL AND CONNECTOR

51320 PERFORM RECALL SPED CONTROL SWITCH
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E
INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL INSTRUCTIONS

98S15 98S15
INSTALL SPEED CONTROL
REPL DEACTIVATION SWITCH
120898 RECALL REPLACED CRUISE SWITCH 98S15B— .5 HR.
98S15 98S15
105009 OPEN RECALL 98S15 REPLACE SWITCH DONE
RECALL 98S15 COMPLETED

RECALL 98X15
RECALL 98S15 INSTALL RECALL KIT
PERFORMED RECALL
REPLACE BRAKE PRESSURE SWITCH PER RECALL
REPLACED SWITCH AND BLEED
REPLACED DEACTIVATION SWITCH
PERFORMED RECALL 98S15
71847 RECALLED REPLACED SWITCH AND WIRE PER RECALL
RECALL PERFORM RECALL 98S15
PERFORM RECALL 98S15

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5
UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 98S15
RECALL 98S15 REPLACE DEACTIVATION SW
REPLACED BRAKE DEACTIVATION SWITCH PER RECALL

98S15 RECALL SPEED CONTROL DEACT SWITCH
 RECALLED BY FORD PERFORMED RECAL
 72386 98S15 W REPLACED SPEED CONTROL SW 2745
 REPLACE SPEED CONTROL CABLE PER RECALL 98S15
 REPLACED SPEED CONTROL SWITCH PER RECALL
 REPLACED DEACTIVATION SWITCH
 88830 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL
 RECALL ADD ON
 RECALL RECALL
 RECALL PERFORM RECALL PER PROGRAM 98S15, DEAC SWITCH
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5
 80830 RECALL WT DONE
 PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM
 98S15 RECALL 98S15 RECALL COMPLETE
 98S15 98S15
 98S15 RECALL
 RECALL 98S15 - COMPLET
 1 COMPLETED RECALL 98S15
 INSTALL NEW SWITCH AND WIRE CONNECTOR
 PERFORM SAFETY RECALL
 98S15B RECALL
 98S15 RECALL 98S15 RECALL COMPLETE
 PERFORMED RECALL 98S15
 AS PER RECALL 98S15 RECALL TO SECURE DEACTIVATION SWITCH
 PERFORMED RECALL 98S15-INSTALL SWITCH
 FORD RECALL PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL
 E RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 BOX B REPLACED SPECIAL ORDERED X CABLE FOR RECALL AND BLEED SYSTEM LN 51 CUT CABLE
 COMPLETED RECALL
 RECALL 98S15 COMPLETED
 REPLACED SWITC AND CONNECTOR PER RECALL
 REPAIR AS PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 RNR ACTIVATION SWITCH PERFORM RECALL 98S15
 RNR SWITCH PERFORM RECALL 98S15
 RECALL 98S15
 PERFORMED RECALL # 98S15
 REPLACE SWITCH PER RECALL LETTER
 REPLACED DEACTIVATION SWITCH
 98S15 98S15
 DID RECALL 98S15
 REPLACED DEACTIVATION SWITCH
 PERFORM RECALL
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 113444 RECALL INSTALLED RECALL ON BRAKE SWITCH
 RECALL IS REQUIRED COMPLETE RECALL
 COMPLETED RECALL
 RECALL 98S15 INSTALLED SWITCH

PERFORMED RECALL E
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S168 .5) COMPLETED

PERFORMED RECALL 99S15

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

59903 RECALL INSTALLED SPEED CONTROL RECALL

UNKNOWN INSTALL SWITCH AND CONNECTOR PER 99S15

REPLACE SWITCH AND CONNECTOR PER RECALL

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORM RECALL REPLACE DEACTIVATION SWITCH

PERFORM RECALL

DID RECALL 99S15

REPLACED SPEED CONTROL SWITCH PER RECALL

REPLACED DISENGAGE SWITCH PER RECALL 99S15

RECALL INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH

REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15.

RECALL CRUISE CONTROL RECALL 99S15

99S15 99S15

SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S

PERFORMED RECALL 99S15 - REPLACED CRUISE CONTROL DEACTIVATION SWITCH

99S15 99S15

INSTALL SW AND CONN

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL COMPLETED

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

REPL SWITCH PER RECALL 99S15

1 PERFORMED RECALL 1

REPLACED DEACTIVATION SWITCH

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL

OPEN RECALL PERFORM RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORMED RECALL

PERFORMED RECALL 99S15

77262 W RNR SPEED DEACTIVATION SWITCH AND CONNECTOR

PERFORM 99S15

PERFORM RECALL

99S15 99S15 W REPLACE SPEED CTRL DEACTIVATE SW 2745

117478 INSTALLED NEW ACTIVATION SWITCH AND CONNECTOR

RECALL 99S15 99S15

93018 PERFORM RECALL 99S15

99S15 RECALL 99S15 RECALL REPLACED DEACTIVATION SPEED CONTROL SWITCH AND CONNE

REPLACE SPEED CONTROL SWITCH

COMPLETED RECALL

99S15 99S15 REPLACE CRUISE SWITCH PER RECALL

CHECK AND PERFORMED RECALL 99S15

RECALL 99S15

RECALL 99S15 RECALL 99S15

PERFORMED RECALL

INSTALLED CRUISE SWITCH AS TO RECALL
PERFORMED RECALL 98S16 INSTALL CRUISE DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH
PERFORM CRUISE SWITCH RECALL PER INSTRUCTIONS
PERFORM RECALL 98S15

REPLACE SWITCH & CONN
RECALL COMPLETED
REPLACE SWITCH PER RECALL

RECALL REPLACE DEACT SWITCH
98S15 RECALL 98S16 RECALL
1 08 REPLACED SWITCH

DEACTIVATION SWITCH OUT OF RANGE
6000 W 98S16 REPLACE SWITCH AND CONNECTOR PER RECALL GA
PERFORM RECALL 98S16 CRUISE DEACTIVATION SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 98S16
REPLACE SPEED CONTROL CONTROL DEACTIVATION SWITCH PER RECALL 98S16
98S16 REPLACED SAFETY SWITCH AND REPLACED WIRES
OPEN RECALL PERFORM RECALL

47820 78 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

RECALL 98S15
60760 98S15B 0.5 0.5 PERFORM 98S16
PERFORMED RECALL
SPEED CONTROL SWITCH 98S15 REPLACE SWITCH
RECALL 98S15 RECALL 98S15
PERFORMED RECALL REPLACED THE SWITCH AND CONNec TOR
X PERFORMED RECAL
37490 RC98S15 PERF RC98S15
67000 RECALL INSTALL DEACTVATE SWITCH AND HARDSHELL CONNECTOR RETURN ORIGINAL PART IN TO PARTS DEPT
RECALL PERFORM RECALL PER PROGRAM 98S16, DEAC SWITCH

RECALL 98S16 RECALL
CRUISE RECALL COMPLETED AS PER RECALL 98S15
CRUISE SWITCH 98S16 INSTALL CRUISE SWITCH AND CONNECTOR
PERFORMED RECALL 98S16-INSTALL SWITCH
66845 REPLACED SWITCH & CONECTOR PER RECALL
APPLIED RECALL 98S15
PERFORMED RECALL 98S15
INSTALLED DEACTIVATION SWITCH PER RECALL
PERFORM RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S16

PERFORM SPEED CONTROL RECALL

REPAIR AS PER RECALL

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

76382 RECALL 98S15 PERFORM RECALL 98S15

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

UNKNOWN INSTALL SWITCH AND CONNECTOR PER 98S15

PERFORMED RECALL REPLACE SENSOR AS PER RECALL 9 98S15

PERFORMED RECALL 98S15

RECALL RECALL

111216 DEACTIVATION RECALL WT DONE

COMPLETED CAMPAIGN COMPLETED OP 98S15B

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S16.

REPL SWITCH PER RECALL 98S15

ONP 98S15 ONP 98S15 SPEED CONTROL DEACTIVATION SWITCH

REPLACED PARTS PER RECALL

X COMPLETED

98S16 98S15

98S15 RECALL

REPL SWITCH PER RECALL 98S15

RECALL PERFORMED 1

98S15B REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

REPLACED DEACTIVATION SWITCH AND CONNECTOR

100448 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

REPL SWITCH PER RECALL 98S15

1 RECALL COMPLETE

INSTALL NEW SPEED DEACTIVATION SWITCH REPLACE W IRE AND BLEED BRAKES AS PER RECALL 98S15

COMPLETED AS PER RECALL

RECALL COMPLETED

118108 RECALL 98S15 W PERFORM RECALL 98S15 REPLACE THE CONECTOR

RECALLED BY FORD MOTOR CO REPAIR AS NEEDED

PERFORMED RECALL 98 S 15 FOR CRUISE SWITCH.

REPLACE SWITCH

118178 DO RECALL 98S15

INSTALL SWITCH AND NEW HARD SHELL CONNECTOR AS OUTLINED IN RECALL

98S15 RECALL

REPLACED SPEED CONTROL SWITCH

INSTALLED NEW SWITCH PER RECALL

RECALL 98S15 COMPLETED

RECALL 98S15

RECALL COMPLETED

NOTE: EST \$ 610 SEAT TRACK ASSY

SWITCH 98S15

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION

88800 REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL 98S15 98S15

PERFORMED RECALL 98S15

92552 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR. SWITCH WAS SEIZED IN LINE BLOCK.
1 PERFORMED RECALL 99S15 INSTALL BRAKES SW. CONNECTOR 99S15B

1 PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL 99S15 RECALL

63487 INSTALLED CONNECTOR AND SWITCH

99S15 99S15

REPL SWITCH PER RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

PERFORM 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL

RPLC SPEED CTRL DEACTIVATION SWITCH PER 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

PERFORM RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

REPLACE SPEED CONTROL ACTIVATION SWITCH AS PER RECALL 99S15

PERFORMED RECALL

COMPLETED RECALL

84582 99S15 W REPLACED SPEED CONTROL 2745

INSTALLED SPEED DEACTIVATION SWITCH AS PER RECAL

PERFORM PER RECALL 99S15

PREFORM 99S15 AS INSTRUCTED

REPLACED DEACTIVATION SWITCH-WARRANTY-RECALL-BILL NOTE-CHECK ENGINE LIGHT IS ON

PERFORMED RECALL 99S15

REPLACE BRAKE SWITCH AND CONECTOR

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL

REPLACED DEACTIVATION SWITCH

PERFORM RECALL 99S15

REPLACE SWITCH PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

INSTALL SPEED ACTIVATION SWITCH

RECALL 99S15 RECALL COMPLETE

REPLACE PRESSURE SWITCH AND CONNECTOR

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL

RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR, RETEST OK AT THIS TIME

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PRFORM RECALL

REPL SWITCH PER RECALL 99S15

PERFORMED RECALL REPLACED THE SWITCH AND CONNEC OR

RECALL 99S15 PERFORMED RECALL 99S15

INSTALL SWITCH AND CONN

99S15 REPLAE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

1 REPLACED SWITCH AS PER 99S15 1

RECALL 98S15 INSTALL SWITCH

88600 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLED NEW UPDATED SPEED CONTROL DISABLE SWITCH AND CONNECTOR TO VEH
X INSTALLED CRUISE DEACTIVATION SWITCH

88834 REPLACE SWITCH AND CONNECTOR PER RECALL
COMPLETE RECALL

REPLACED SPEED CONTROL SWITCH.

RECALL 98S15 REPLACED CRUISE CONTROL DEACTIVATION SW
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15
AS PER RECALL 98S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL
RECALL 98S15 RECALL 98S15B
PERFORM RECALL 98S15

- MODIFY PER RECALL 98S15

1 PERFORM RECALL

PERFORM 98S15 RECALL AS INSTRUCTED

A DONE

PERFORM RECALL

PERFORM RECALL

A DONE

RECALLED BY FORD PERFORMED BY FO

57855 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

COMPLETED RECALL

1 PERFORMED RECALL

RECALL 98S15 RECALL 98S15

COMPLETED AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

RECALL 98S15 COMPLETED

UNKNOWN INSTALL CRUISE DEACTIVATION SWITCH AND CONNECTOR PER 98S15

REPLACE CRUISE CONTROL SWITCH

88228 RECALL WARRANTY PERFORMED RECALL 98S15

APPLIED RECALL 98S15

PERFORM RECALL

REPAIR AS PER RECALL 98S15.

RECALL 98S15 REPLACED SWITCH

REPLACE BRAKE PRESSURE SWITCH PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

RNR DEACTIVATION SWITCH PERFORM RECALL

TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 98S15

INSPECT & REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN
PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISECONTROL DEACTIVATION SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
REPLACED DEACTIVATION SWITCH

REPLACED CONTROL DEACTIVATION SWITCH
RECALL 99S15
REPLACED DISENGAGE SWITCH PER RECALL 99S15
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
SAFETY RECALL 99S15 -REPAIR PER RECALL
RECALL 99S15 PERFORM RECALL 99S15

99S15 RECALL
99S15 SPEED CONTROL DEACTIVATION SWITCH
REPLACE CRUISE CONTROL SWITCH
COMPLETED RECALL RECALL 99S15

58838 REPLACED DEACTIVATION SWITCH,CONNECTOR PER RECALL
REPLACE SPEED CONTROL SWITCH AND CONNECTOR
PERFORMED RECALL 99S15, INSTALLED NEW SPEED CONTROL DEAC. SWITCH AND CONECTOR.
COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
REPLACED SPEED CONTROL CABLE AS PER RECALL
58481 RECAL, REPLACE BRAKE SWITCH AND HARDSHELL CONNECTOR: 5383,2843

106624 99S15 RECALL 99S15 REPLACE DEACTVATOR SWITCH
101474 INSTALLED RECALL 99S15, BRAKE PRESSURE SWITCH.
PREFORM 99S15 AS INSTRUCTED
ONP 99S15 ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHEL
82501 COMPLETED RECALL NUM 99S15
PERFORM RECALL
97859 RECALLED REPLACED SWITCH AND WIRE CONNECTOR PER RECALL
PERFORM RECALL 99S15
REPAIR PER RECALL
RECALL 99S15 REPLACED SWITCH.

REPLACED THE SWITCH PER RECALL 99S15
PERFORME 99S15
REPLACED SWITCH AS PER RECALL 99S15

REPLACE DEACTIVATION SWITCH RECALL 99S15.
80778 REPLACE SWITCH AND CONNECTOR PER RECALL
99S15 RECALL 99S15 REPAIR AS PER RECALL
RECALL 99S15 99S15

RECALL COMPLETED
REPAIR AS PER 99S15

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE.ALSO A FIRE COULD DEVOPE. REMOVE,T

TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 98S15

PERFORME 98S15

RNR CRUISE SWITCH

PERFORM RECALL 98S15

RECALLED BY FORD

PERFORMED RECAL

98S15B

PERFORMED RECAL

UNKNOWN

INSTALL CRUISE SWITCH AND CONNECTOR PER 98S15

98S15B

REPLACED

98S15,RR CONNECTOR AND DEACTIVATION SWITCH

REPLACED SWITCH

CUSTOMER PAID REPAIRS 1

PERFORM RECALL PER MANUFACTURER PERFORMED RECAL

REPLACED SPEED CONTROL DEACTIVATIONM SWITCH AS PERRECALL 98S15

REPLACE SPEED CONTROL SWITCH

RECALL 98S15 COMPLETED

REPL DEACTIVATION SWITCH PER RECALL

98S15 R&R DEACTIVATION SWITCH

PERFORMED RECALL 98S15

INSTALLED NEW SWITCH PER RECALL

88214 RECALL INSTAL SWITCH AND CONNECTER AS PER RECALL 98S15

REPLACE SPEED CTRL DECT SWITCH AND SHELL CONNECTOR

RECALL 98S15

PERFORMED RECALL # 98S15

RECALL 98S15

PERFORM RECALL 98S15

1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS PERFORM RECALL 98S15-B

DN REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL 98S15

COMPLETED AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

PERFORMED RECALL 98S15 REPLACED SPEED CONTORL SWITCH BLEED BRAKES

RECALL COMPLETED COMPLETED RECALL 98S15B FOR .5 AND .1 FOR ADMIN. TIME

REPLACE CRUISE CONTROL CABLE

REPLACED KIT PER RECALL T

98S15 RECALL PERFORMED

REPLACE SWITCH AND CONNECTOR PER RECALL

REPLACED DEACTIVATION SWITCH

78108 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH

1 PERFORM RECALL

1 PERFORM RECALL 98S15 BRAKE SWITCH

98S15

98S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORMED RECALL#98S15

RECALL 98S15 98S15

REPLACE SPEED CONTROL SWITCH

COMPLETED AS PER RECALL

COMPLETED RECALL 99S15 DEACTIVATION SWITCH
REPLACED DEACTIVATION SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL
1 COMPLETED RECALL 99S15 SPEED CONTROL
REPL SWITCH PER RECALL 99S15
REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE
RECALL REPLACE DEAC SWITCH PER RECALL
57592 RECALL INSTALLED NEW BRAKE SWITCH AND CONNECTOR TEST DROVE, CRUISE WORKS OK
REPLACE SPEED CONTROL CABLE AS PER RECALL
RECALL 99S15. REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15.

COMPLETED RECALL
REPLACED DEACTIVATION SWITCH

REPLACED SPEED CONTROL SWITCH AS PER RECALL
PERFORM RECALL
RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

23712 REPLACE SPEED CONTROL DEACTIVATION SWITCH TEST DRIVE OK
99S15 RECALL 99S15 RECALL PERFORMED
RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
RECALL 99S15 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL
RECALL 99S15
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.
REPLACE SWITCH AND CONNECTOR
PERFORM 99S15
PERFORMED RECALL 99S15
99S15 99S15 PERFORM RECALL
RECALL REPLACE DEACT SWITCH PER RECALL
99S34 99S15 COMPLETED DEACTIVATION SWITCH RECAL
PERFORM 99S15

REPLACE CONNECTOR AND SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

REPAIR AS PER RECALL
COMPLETED RECALL
RECALL RECALL
76573 RECALL REPLACED SPEED CONTROL DE-ACTIVATION SWITCH AND TEST DROVE WORKS NORMAL
REPLACE SWITCH AND CONNECTOR
REPLACE BRAKE PRESSURE SWITCH PER RECALL
82373 RECALL INSPECT AND PERFORM RECALL
RECALL REPLACE DEACT SWITCH PER RECALL
RECALL 99S15 COMPLETED

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WIL
99S15 RECALL SPEED CONTROL SWITCH

98S15

1 PERFORMED SWITCH AND CONNECTOR RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

REPAIR AS PER RECALL 98S15.

PERFORMED RECALL 98S15

REPAIR AS PER RECALL

INSTALL SWITCH AND CONNECTOR

53769 RECALL 98S15 W/REPLACED DEACTIVATION SWIT

RECALL 98S15

REPLACED CRUISE DEACTIVATION SWITCH

RECALL 98S15

RECALL 98S15

REPLACED SPEED CONTROL CABLE PER RECALL.

PERFORM RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

PERFORMED RECALL 98S15 BRAKE RELEASE

66854 RECALL WPB80 PERFORM 98S15 CRUISE SWITCH REPLACEMENT

REPLACED SWITCH PER RECALL

PERFORM RECALL 98S15

98S15B RECALL REPLACED DEACTIVAT.98S15B RECALL REPLACED DEACTIVATION SWITCH

REPLACE SWITCH AND CONNECTOR PER RECALL 98S15 1

PERFORM RECALL 98 S 15 . INSTALL CRUISE DEACTIVATION SWITCH

VEHICLE HAS AN OPEN RECALL PERFORM RECALL

SPEED CONTROL DEACTIVATOR TECH REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15

REPLACED BRAKE DEACTIVATION SWITCH

98S15 REPLACED SWITCH

INSTALLED SWITCH PER RECALL

REPLACED SWITCH PER RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACED C CONTROL DEACTIVATION SWITCH PER 98S15 RECALL

PERFORMED RECALL

PERFORM RECALL-INSTALL SPEED CONTROL DEACTIVAT ION SWITCH

INSTALL SWITCH AND CONNECTOR PER RECALL

PERFORMED 98S15B

98S15 RECALL

101112 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15

REPLACE SPEED CONTROL CANCEL SWITCH PER RECALL

COMPLETE RECALL #98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

INSTALL SPEED CONTROL SWITCH

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

007 COMPLETED RECALL 98S15

PERFORM RECALL

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .6

67279 PERFORMED RECALL,INSTALLED PRESSURE SITCH

44792 WARR REPLACED 98S15 SPEED CONTROL SWITCH
 COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SWITCH FOR RECALL
 PERFORMED RECALL 98S15
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 1 PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
 REPLACE DEACTIVATION SWITCH PER RECALL
 PERF RECALL 98S15
 78880 WARR INSTALL CRUISE DEACTIVATION SWITCH
 PREFORM RECALL
 94090 REPLACE SPEED CONTROL SWITCH PER RECALL

RECALL 98S15 PERFORMED RECALL 98S15
 86280 COMPLETED SPEED CONTROL DISABLE SWITCH. INSTALLED NEW UPDATED SPEED CONTROL DISABLE SWITCH.
 107489 RECALL 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL
 RECALL PERFORM RECALL
 REPLACE SPEED CONTROL SWITCH PER RECALL. WAITN
 AS PER RECALL 98S15 RECALL TO REPLACE SPEED CONTROL CABLE
 COMPLETED OPEN RECALL 98S15
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .5
 OPEN RECALL. COMPLETED
 98S15 RECALL PERFORMED
 RECALLED 98S15 PERFORMED
 98S15 98S15 PERFORM RECALL
 RECALL 98S15
 PERFORMED RECALL
 COMPLETED RECALL. REPLACED BRAKE SWITCH PER CAMPAIGN
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR...PERMANENT REPAIR.
 78107 98S15 RECALL W PERFORMED 98S15 RECALL. INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH.
 OPEN RECALL. COMPLETE RECALL
 SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 98S15
 98S15 98S15
 RECALL 98S15 SPEED CONTROL DEACTREPLACE DEACTIVATION SWITCH AND CONNECTOR, RECALL PERFORMED.
 1 PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH PER RECALL 98S15

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 INSTALLED SWITCH & CONNECTOR
 PERFORM RECALL ON SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 PERFORMED CRUISE CONTROL SWITCH RECALL 98S15
 204240 RECALL PERFORMED RECALL 98S15 - REPLACED DEACTIVATOR SWITCH AND CONNECTOR
 RECALL RECALL
 RECALL 98S15 PERFORMED RECALL 98S15
 PERFORM RECALL

142484 RECALL WARR RECALL 99S15 REPLAGE CONTROL DEACTIVATION - SWITCH
 NAC PERFORMED RECALL
 679231 REPLACED THE CRUISE DEACTIVATION SWITCH AND PLUG PER RECALL 99S15
 RECALL COMPLETED
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 PERF RECALL 99S15
 REPLACE SWITCH
 RECALL COMPLETED
 0 99S15 PROGRAM
 RECALL 99S15 99S15 PERFORMED RECALL
 PERFORM RECALL 99S15B
 57475 RECALL W REPLACE SWITCH AND PLUG GA
 RECALL RECALL
 RECALL 99S15 COMPLETED
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 1 JOB COMPLETED
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL
 PERF RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 OPEN RECALL PERFORM 99S15 RECALL
 PERFORMED RECALL
 78865 INSTALLED BRAKE SWITCH RECALL
 RECALL 99S15B
 SPEED CONTROL STICKING PERFORMED 99S15 RECALL

 INSTALLED SWITCH PER RECALL
 1 PERFORMED RECALL 99S15, INSTALLED CRUISE CONTROL SWITCH AS PER RECALL
 RPL CRUISE DEACTIVATION SWITCH
 99S15 99S15
 99S15 SWITCH CONNECTOR 99S15
 1 PERFORMED RECALL
 REPLACED SWITCH PER RECALL
 PERFORMED RECALL
 RECALL 99S15 COMPLETED
 PERFORMED RECALL
 20365 PERFORMED RECALL 99S15 3
 INSTALL BRAKE REPAIR CONN KIT
 PERF RECALL
 PERFORMED RECALL 99S19
 1 COMPLETED RECALL 99S15
 REPLACE DEACTIVATION SWITCH AS PER RECALL

RECALL DONE
 PERFORM DEACTIVATION SWT.
 REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15
 INSTALLED DEACTIVATION SWITCH AS PER RECALL
 99S15 99S15 RFORMED

1002-025 0325

X RECALL
 1 REPL DEACTIVATION SWITCH. 1
 41335 DID RECALL 99S15 TECH 3213
 99S15 RECALL 99S15 RECALL COMPLETE
 REPLACE CRUISE SWITCH
 24487 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH
 RECALL 99S15 COMPLETED
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 113082 99S15 99S15 .5 COMPLETED RECALL AS PER 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH K
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
 PERFORMED RECALL
 PERFORM RECALL 99S15 DEACTIVATION SWITCH RECHECK OPERATION SYSTEM OK 99S15B .5 ADMIN .1
 FACTORY RECALL COMPLETED RECALL
 INSTALLED KIT 99S15 RECALL PERFORMED
 87940 INSTALL SWITCH AND CONNECTOR
 REPLACE SWITCH AS PER RECALL
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR
 PER NOTIFICATION 99S15 REPLACE SWITCH AND HARNESS CONNECTOR PER RECALL INSTRUCTIONS
 77779 REPLACED DEACTIVATION SWITCH AND CONNECTOR
 21825 RECALL REPLACE CRUISE CONTROL SWITCH
 RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 99S15 99S15
 99S15 99S15 PERF 99S15, .5+.1=.5
 DIAGNOSIS AND INSPECT FOR CAMPAIGN INSTALLED SWITCH PERFORM CAMPAIGN AS PER NOTICE
 99S15 99S15
 PERFORM RECALL
 RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL
 83705 99S15B 0.5- ADMIN 0.1 RECALL
 COMPLETED CAMPAIGN REPLACED SWITCH

 RECALL 99S15 REPLACE SWITCH AND CONNECTOR
 99S15 99S15
 X REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 99S15 INSTALLED SWITCH PER RECALL
 99S15 RECALL 99S15 WARR REPLACED DEACTIVATOR SWITCH AND CONNECTOR PER RECALL 99S15
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

 PERFORMED RECALL PER SPECS
 FACTORY RECALL COMPLETED RECALL

 VEHICLE HAS AN OPEN RECALL PERFORM RECALL
 PERFORMED RECALL RENEW SWITCH AND HARDSHELL CONNECTOR.
 74012 RECALL REPLACE DEACTIVATION SWITCH
 CRUISE RECALL 99S15 INSTALL CRUISE SWITCH AND CONNECTOR
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 1 INSTALL SPEED CONTROL MODIFICATIONS

REPLACE SWITCH

REPLACE DEACTIVATION SWITCH

RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH INSPECTED SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
PERFORMED RECALL PERFORMED RECALL

REPLACED SPEED CONTROL SWITCH & CONNECTOR
REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH REPLACED SPEED CONTROL DE-ACTIVATION SWITCH AND CONNECTOR
63038 99S15 REPAIR ACCORDING TO 99S15
PERFORM 99S15 RECALL CRUISE CONTROL

CAMPAIGN 99-S-15 COMPLETED AS PER RECALL INSTRUCTION.
COMPLETE RECALL
COMPLETED OPEN RECALL 99S15
REPLACE SWITCH
1 RECALL 99S15 PERFORMED
PERFORM RECALL

RECALL COMPLETED. REPLACED CONNECTOR AND SWITCH. ROAD TEST.

99S15 RECALL

PERFORMED OPEN RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL RECALL

REPLACE SWITCH AND HARD SHELL

REPAIR AS PER RECALL 99S15.

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

REPAIR AS PER RECALL 99S15.

42 99S15

1 REPLACE DEACTIVATION SWITCH AND CONNECTOR

99S15 99S15

99S15 99S15

RECALL PERFORMED RECALL 99S15.

134420 RECALL 99S15, REPLACE SWITCH AND CONNECTOR

INSTALL DEACTIVATION SWITCH

99S15E PERFORMED RECALL. INSTALLED NEW CRUISE

81201 REPLACED SWITCH 0.5

SPEED CONTROL SWITCH 99S15 RECALL

RECALL DONE

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED CRUISE DEACTIVATION SWITCH

INSTALL SPEED CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL 99S15

87645 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH.

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RNR SWITCH PERFORM RECALL 99S15
1 PERFORMED RECALL
PERFORMED RECALL 99S15
40044 COMPLETED 99S15 REPL SWITCH
REPLACED SWITCH AND CONN
REPLACED DEACTIVATION SWITCH AND HARD SHELL
R-R SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15 RECALL REPLACE SWITCH
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
REPLACE CRUISE DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH.
PERFORM RECALL
RECALL DONE
RECALL PERFORMED RECAL

REPLACE SWITCH AND HARD SHELL
SWITCH MAY DEVELOP A RESISTIVE SHORT CIRCUIT. REPLACED CONNECTOR AND SWITCH
99S15 REPL DEACTIVATION SWITCH
COMPLETED RECALL

104669 RECALL 99S15 WR PERFORM RECALL 99S15

PERFORMED RECALL PERFORMED RECAL
RECALL 99S15 REPLACE DEACTIVATOR SWITCH
99S15B PERFORMED RECALL - REPLACED SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL 99S15
PERFORMED.
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
RECALL RECALL
90001 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH
78700 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
99S15 —
RPL CRUISE DEACTIVATION SWITCH
PERFORM RECALL 99S15B

97349 PERFORM RECALL 99S15
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
9 #90099S15
REPAIR AS PER RECALL
PERFORM RECALL
PERFORMED RECALL AS PER INSTRUCTIONS
PERFORMED RECALL CODE 42

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL 99S15 INSTALLED CRUISE CONTROL SWITCH AND CONNECTOR
111000 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR AS PER 99S15

99S15 SPEED CONTROL DEACTIVATION REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
REPLACED SC DEACTIVATION SWITCH 99S15
REPLACED SWITCH AND PLUG

REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 PERFORM RECALL 99S15

PERFORMED RECALL 99S15 - REPLACED PART

PERFORM RECALL

RECALL RECALL

RECALL COMPLETED -DID 99S15B.

PERFORM RECALL 99S15

RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG PER RECALL

93021 PERFORMED RECAL REPLACED SWITCH AND CONN

PERFORMED RECALL REPLACED SPEED CONTROL SWITCHC

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

99S15 SPEED CONTROL SWITCH 99S15 REPLACED SPEED CONTROL SWITCH

INSTALL DEACTIVATION SWITCH

PERFORM RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

REPLACED DEACTIVATION SWITCH 99S15 REPAIRED PER RECALL

99S15 99S15

PERFORMED RECALL

PERFORMED RECALL 99S15

RECALL COMPLETE

PERFORMED 99S11 DEACTIVATED CRUIZ CONTROL

PERFORM DIAGNOSIS,ROAD TEST,SWITCH DEFECTIC? REPLACE SWITCH

49247 REPLACED DEACTIVATION SWITCH AND CONNECTOR, PER RECALL

PERFORM RECALL 99S15

RECALL 99S15 COMPLETED

RECALL 99S15 COMPLETED

99S16 RECALL 99S16 RECALL COMPLETE

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED E

106440 PERFORMED RECALL

RECALL COMPLETED

125851 PERFORM RECALL PER RECALL 99S15 INSTALL CRUISE DIACIVATOR SWITCH AND CONNECTOR

94642 REPL CRUISE BRAKE SWITCH

REPLACE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

130671 INSTALLED SWITCH AND HARDSHELL PER BULLITIN.

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORM RECALL

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 99S15B .5

REPLACE CRUISE DEACTIVATION SWITCH

RECALL COMPLETE

72000 I PERFORMED RECALL 99S15

PERF RECALL 99S15

27768 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR SHELL 0.5 HR LABOR 0.1 ADM

1 PERFORMED RECALL 99S15

REPLACED SC DEACTIVATION SWITCH 99S15

COMPLETED RECALL 99S15

RECALL 99S15 COMPLETED

REPLACED SC DEACTIVATION SWITCH 99S15

RECALL 99S15

99S15 PERFORMED-REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNEC

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15

REPLACE CRUISE DEACTIVATION SWITCH..RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

99S15 REPLACE CRUISE DEACTIVATION SWITCH

99S15 RECALL 99S15 RECALL COMPLETED

REPLACE SPEED CONTROL SWITCH

78141 RECALL 99S15, SPEED CONTROL SWITCH

RECALL 99S15 RECALL INSTALL CONNECTOR & SWITCH

RECALL COMPLETED

INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS OUTLINED IN REC ASLL 99S15 ALL OK TO RELEASE

OPEN RECALL PERFORMED RECALL

PERFORMED RECALL 99S15-INSTALL SWITCH

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL COMPLETED 99S15 RECALL

99S15 99S15

104879 PERFORM RECALL 99S15 OP 99S15B

INSTALL CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

REPLACED THE SWITCH PER RECALL 99S15

PERFORM RECALL 99S15

RECALL 99S15 COMPLETED

REPLACED SPEED CONTROL SWITCH

024 REPLACE CRUISE DEACTIVATOR SWITCH

PERFORMED RECALL 99S15

SAFETY RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 INSTALLED SPEED CONTROL SWITCH & CONNECTOR

DO RECALL 99S15

DID CRUISE RECALL

99S15 99S15

99S15 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 1

FACTORY RECALL COMPLETED RECALL

70860 RECALL 99S15 PERFORMED RECALL 99S15

66808 RECALL 99S15 PERFORMED RECALL 99S15

REPLACED SWITCH AND CONNECTOR

INSTALLED SWITCH

71104 RECALL 99S15 WR PERFORM RECALL 99S14 SPEED CONTROL INSTALL NEW ONE AND REPAIR WIRE FOUND THAT ABS LIGHT ON AND BRAKE LIGHT
PERFORMED RECALL
INSTALLED DEACTIVATION SWITCH AS PER RECALL, REPAIRED WIRE HARNESS TO SWITCH, HAD AFTERMARKET CONNECTOR, INSTALLED
72877 CAMPAIGN 99S15 SPEED CONTROL DEACTIVATION SWITCH 99S15E .3HRS .3HRS REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15
SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S

RECALL 99S15 COMPLETED
52896 RECALL PERFORM RECALL 99S15 REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL 99S15
PERF RECALL 99S15
PERFORM RECALL
REPL DEACTIVATION SWITCH PER RECALL
POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED RECALL 99S15 FOR SPEED CONTROL DE-ACTIVATION
99S15 99S15-INSTALL SWITCH AND CONNECTOR
PERFORMED RECALL 99S15
RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
- REPLACED SWITCH
99S15 RECALL
DO RECALL 99S15 CK ONLY IS OK
99S15 RECALL 99S15 RECALL COMPLETE
89710 RECALL R-R CRUISE SWITCH AND BLEED BRAKES AS PER RECALL
99S15 DO RECALL
1 INSTALLED BRAKE DEACTIVATION SWITCH AS PER RECALL 99S15.
PERFORMED RECALL
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACED SWITCH AND CONNECTOR PER RECALL 99S15
RECALL 99S15 RECALL 99S15
RECALL 99S15 PERFORMED RECALL 99S15B

REPLACE SWITCH AND CONNECTOR
INSTALL CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15 RECALL 99S15, REPLACE DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
RECALL REPLACED BRAKE SWITCH
RECALL 99S15 COMPLETE
78301 PERFORMED RECALL ADDED BRAKE FLUID AND PR STR FLUID WASHED ENGINE
PERFORMED RECALL 99S15
COMPLETE RECALL
PERFORMED 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
125829 PERFORM RECALL 99S15 C-C SWITCH
INSTALL SWITCH PER RECALL

167066 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR. 99S15B 0.5 HR LABOR
DID RECALL 99S15. SPEED CONTROL DEACTIVATION SWITCH

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL
REPLACED SWITCH AND CONNECTOR
R AND R SWITCH PER RECALL
RECALL 99S15 INSTALLED SWITCH
REPAIRED AS PER PROGRAM
R&R SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER RECALL

114406 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
COMPLETED RECALL 99S15
PERFORMED SAFETY RECALL 99S15
PERFORM 99S15 RECALL CRUISE SWITCHES
RECALL PERFORM RECALL
X COMPLETED COMPLETED
OPEN RECALL PERFORM RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B
REPLACED CRUISE CONTROL SWITCH
REPLACED BRAKE SWITCH FOR SPEED CONTROL AS PER RECALL
REPL SWITCH PER RECALL

COMPLETE RECALL 99S15
REPLACED CONTROL SWITCH
118968 RECALL 99S15 W PERFORMED RECALL INSTALLED UPDATED SWITCH AND TEST OK SEE OTHER LINE FOR REPAIRS NEEDED TO TEST SYSTEM FOR
PERFORM RECALL PER MANUFACTURER RECALL PERFORME
PERFORM RECALL
99S15 99S15 RECALL
PERFORMED RECALL
COMPLETE RECALL 99S15.
PERFORMED RECALL

RECALL PERFORM RECALL
99-S-15 99-S-15 COMPLET
OK REPL SWITCH
PERFORM RECALL INSTALL SWITCH
NEC TO REPLACE DEACTIVATION SWITCH
REPLACED SC DEACTIVATION SWITCH 99S15
INERTIA SWITCH PER RECALL 99S15
PER RECALL 99S15
99S15 REPL DEACTIVATION SWITCH
1 COMPLETE RECALL
99S15 99S15
REPLACED SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 98S15.
PERFORM RECALL

INSTALLED DEACTIVATION SWITCH
RECALL PERFORMED RECALL 98S15B SPEED CONTROL DEACTIVATION
PER THE OASIS PERFROM RECALL #98S15.

RECALL COMPLETED ALL OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL 98S15
COMPLETED 98S15
RECALL 98S15 PERFORM RECALL 98S15
REPLACED DEACTIVATION SWITCH
98S15 RECALL 98S15 RECALL COMPLETE
105533 REPLACED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR..
RECALL 67031 REPLACE SWITCH AND CONNECTOR

OPEN RECALL COMPLETE RECALL 98S15
PERFORMED 98S15
98S15 98S15 RECALL DO
RECALL 98S15
RECALL COMPLETE
RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
REPL SWITCH PER RECALL 98S15
129652 98S15 INSTALLED CONNECTOR AND CRUISE SWITCH AS OUTLINED IN 98S15
103250 REMOVED OLD SPEED SWITCH AND REPLACED IT WITH THE NEW SPEED DEACTIVATION SWITCH
REPLACED CRUISE SHUT OFF SWITCH

60142 RECALL REPL- SPEED CONTROL DEACT SWITCH & & PLUG 98S15B 0.5
REPLACED SPEED CONTROL DEACTIVATION SWITCH
62574 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
REPLACE DEACTIVATION SWITCH, RECALL
REPL CRUISE SWITCH 98S15
98S15 RECALL 98S15 REPAIRED AS PER RECALL
59578 REPLACED SWITCH
98S15 98S15
PERFORM RECALL
REPLACED SWITCH AND CONNECTOR
PERFORMED RECALL, PERFORMED RECALL
1 INSTALL DEACTIVATION SWITCH 1
98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL REPLACE CRUISE SWITCH
PERFORM RECALL
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
98S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORM RECALL REPL DEACTIVATION SWITCH
REPLACED C CONTROL DEACTIVATION SWITCH PER 99S15 RECALL
COMPLETED 99S15 RECALL

PERFORM RECALL 99S15 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
REPLACE AS PER RECALL 99S15
PERFORM RECALL INSTALL SWITCH
99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
1 COMPLETED RECALL 99S15
REPL SWITCH PER RECALL
99S15 RECALL
REPLACED CRUISE SWITCH

1 INSTALL SPEED CONTROL DEACTIVATION SWITCH 1
99S15 RECALL
RECALL PERFORMED RECALL
54006 INSTALLED A NEW SWITCH PER RECALL NOTICE.
JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15
PERFORM RECALL 99S15
23956 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL GA
INSTALL NEW CRUISE CONTROL BRAKE SWITCH PER RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORM RECALL
REPLACE SWITCH AND HARD SHELL

74019 PERFORM RECALL, REPLACE SWITCH 99S15B .5
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
ONP 99S15 ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHL
1 PERFORMED RECALL 99S15 1
REPLACE SPEED CONTROL PER RECALL

RECALL REPLACESWITCHAND CONNECTOR
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
FACTORY RECALL COMPLETED RECALL
99S15 99S15B
RECALL COMPLETED

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE
99S15 99S15B
INSTALLED CRUISE KIT PER RECALL
PERFORM RECALL 99S15
99S15 RECALL 99S15 REPAIRED A PER RECALL

INSTALLED NEW DEACTIVATION
44331 PERFORMED SPEED CONTROL DEACTIVATION SW. RECALL

RECALL COMPLETE

INSTALL DEACTIVATION SWITCH

PERFORM RECALL REPLACE SWITCH AND CONNECTOR 99S15 BLEED AND ROAD TEST VERIFY REPAIRS

X PERFORMED RECALL

88283 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR END

REPL SWITCH PER RECALL 99S15

RECALL 99S15 PERFORM RECALL 99S15

REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 99S15 PERFORM RECALL 99S15

COMPLETE RECALL 99S15

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

D RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

26428 REPLACE SWITCH AND CONNECTOR PER 99S15 87

99S15 RECALL PERFORMED

99S15 RECALL 99S15 RECALL COMPLETE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

INSTALL CRUISE DEACTIVATION SWITCH

RECALL PERFORMED RECALL 99S15

1 PERFORMED RECALL

91403 INSTALLED A NEW SPEED CONTROL PRESSURE SWITCH PER RECALL NOTICE

RECALL 99S15

RECALL 99S15 RECALL

RECALL RECALL

DID RECALL 99S15

REPLACE DEACTIVATION SWITCH

38902 REPLACED THE DEACTIVATION SWITCH ALONG WITH THE PROPORTIONING VALVE BECAUSE THE VALVE WAS DAMAGED WHEN THE SWITCH WAS

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

RECALL COMPLETED

1 RECALL COMPLETE

REPLACE SPEED CONTROL DEACTIVE SWITCH

APPLIED RECALL 99S15

RECALL REPLACE CRUISE SWITCH

W DISCONNECTED SPEED CONTROL AND ORDERED NEW DEACTIVATION SWITCH

COMPLETED RECALL 99S15, SPEED CONTROL DEACTIVATION

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ASSY AS PER 99S15 RECALL

RECALL RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

REPL SWITCH PER RECALL 99S15

RECALL COMPLETE

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPL SWITCH & CONNECTOR PER RECALL 99S15

70882 PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH
RECALL #99S15 RECALL #99S15
PER RECALL 99S15 OASIS DOWN INSTALL NEW DEACTIVATION SWITCH PER RECALL 99S15
99S15 REPLACE CRUISE CONTROL BRAKE SWITCH
FACTORY RECALL COMPLETED RECALL
PERFORM RECALL ON SPEED CONTROL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL SENT BY WPI
PERFORM RECALL 99S15
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
110152 DID RECALL 99S15 REPLACED CONNECTOR AND SWITCH
COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 99S15B .5 + .1
PERFORM RECALL
PERFORMED RECALL
REPAIR AS PER RECALL
A99 99S15 82 99S15B - 810 - LABOR .3 ADMIN .1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH
DEACT SWITCH #99S15
PERFORM RECALL 99S15
PERFORM RECALL 99S15
99S15 99S15
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
60117 99S15 W INSPECTED AND REPLACED SPEED CONTROL RECALL PER 99S15 8115
REPLACE SWITCH & CONNECTOR
RECALL 99S15 RECALL - REPLACED SPEED CONTROL DEACTIVATION SWITCH
99S15B REPLACE SWITCH RECALL
INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH
99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL
PERFORMED RECALL
RECALL 99S15 - B - RECALL
PERFORMED RECALL
99S15 RECALL 99S15 RECALL 99S15 JH

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
81901 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
99S15 R&R DEACTIVATION SWITCH
COMPLETED 99S15 RECALL
REPLACED DEACTIVATION SWITCH AND CONNECTOR
REPLACE SPEED CONTROL DEACTIVATION SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH
COMPLETE RECALL 99S15
PERFORM RECALL 99S15

99S15 RECALL 99S15 RECALL COMPLETE
1 PERMANENT FIX - REPLACE DEACTIVATION SWITCH AND CONNECTOR. 99S15B 0.5 HRS

REPLACE SPEED CONTROL DEACTIVATION SWITCH
RECALL REPAIR AS PER RECALL 98S15 SPEED DEACTIVATION SWITCH REPLACEMENT
98S15 RECALL 98S15 RECALL COMPLETED
REPAIR PER FOMOCO
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

98S15 98S15 PERFORM RECALL
98S15B RECALL 98S15B REPLACED CRUISE ACTIVATION SWITCH
58138 REPLACED SWITCH
PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND CHECK OK
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER 98S15 RECALL
RECALL COMPLETE
98S15
98S15B RECALL 98S15B RECALL REPLACED CRUISE DEACTIVATION SWITCH
80277 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH
REPLACED DEACTIVATION SWITCH
FACTORY RECALL COMPLETED RECALL
RECALL PERFORM RECALL
PERFORM 98S15
RECALL COMPLETE
FACTORY RECALL COMPLETED RECALL
COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH E
COMPLETED FACTORY RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 98S15 CAMPAIGN
1 REPLACE CRUISE SWITCH AND BLEED BRAKES
INSTALL DEACTIVATION SWITCH
PERFORM RECALL
PERFORMED RECALL

30761 PERFORMED RECALL 98S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR BLEED BRAKES AND TEST DROVE ALL OK
PERFORM RECALL
PERFORMED RECALL 98S15
AS PER RECALL # 98S15
OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15
98S15 98S15
1 INSPECTED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
COMPLETE RECALL 98S15
PERFORMED RECALL
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTED
RECALL REPLACED DEACTIVATION SWITCH PER RECALL
98S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION I
110089 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
PERFORM RECALL AS PER LETTER
REPLACE DEACTIVATION SWITCH PER RECALL
RECALL 98S15 MIL 21821 DID RECALL 98S15 REPLACE SWITCH & CONNECTOR
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
REPL SPEED CONTROL SWITCH 98S15 RECALL

PERFORM RECALL 99S15
 50739 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACE CRUISE SWITCH PER RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH
 99S15 99S15
 REPL SWITCH PER RECALL
 PERFORMED RECALL 99S15
 REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SE
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 RECALL REPAIR
 69790 RECALL 99S15 INSTALL NEW SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 72365 RECALL 99S15B 0.50 INSTALL NEW BRAKE DEACTIVATION SWITCH
 99S15 99S15 PERFORM RECALL
 1 PERFORMED 99S15 RECALL
 RECALL COMPLETE
 COMPLETED RECALL 99S15
 PERFORMED RECALL 99S15
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPLACED PARTS PER RECALL
 REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR

 PERFORM RECALL 99S15 RECHECK OK 1
 PERFORM RECALL 99S15
 PERFORMED RECALL AS PER INSTRUCTIONS
 RECALL INSPECT AND REPLACE SWITCH PER RECALL
 PERFORMED RECALL PER BULLETIN
 INSTLL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 69380 INSTALLED RECALL
 COMPLETE 99S15
 REPLACED DEACTIVATION SWITCH
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 99S19
 PERFORMED RECALL
 ISNTALL KIT FOR DEACTIVATION SWITCH
 REPLACED CRUISE SWITCH
 99S15 RECALL
 RENEW DEACTIVATION SWITCH
 PERFORM SPEED CONTROL MODIFICATION PER RECALL
 PERFORMED RECALL 99S15

 99S15B RECALL COMPLETE
 RECALL COMPLETE
 RECALL 99S15 99S15
 REPLACED CRUISE CONTROL BRAKE SWITCH AND CONNECTORPER RECALL

99S15 RMR SWITCH
COMPLETED RECALL

PERFORM RECALL 99S15

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

99S15 99S15 REPLACED SWITCH AND CONNECTOR

C INSTALL SWITCH AS PER RECALL

PERFORMED RECALL

31823 PERFORMED RECALL 99S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE ALL O

REPL CRUISE CONTROL SWITCH ASY

PERFORMED RECALL AS BY FACTORY PERFORMED RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.

DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH ALL OK WITH CRUISE NOW

PERFORM RECALL 99S15

44456 PERFORMED RECALL 99S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE OK
SWITCH AND CONNECTOR INSTALLED

COMPLETED

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15

REPLACE DEACTIVATION SWITCH 1

71705 99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND PLUG IN CONNECTOR

RECALL 99S15

REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

RECALL SPEED CONTROL DEACTIVATION SWITCH

108932 RECALL 99S15 INSPECTED AND INSTALLED CRUISE DEACTIVATION SW. SEE LINE D..

99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S

REPLACE SPEED CONTROL PER RECALL

RECALL COMPLETED

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL CABLE PER RECALL.

RECALL 99S15

1 PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL SWITCH

PERFORMED RECALL

99S15 99S15 REPLACE CRUISE SWITCH PER RECALL 99S15

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15

INSTALL SWITCH PER RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

PERFORM RECALL AS PER FACTORY REQUIREMENTS

99S15 RECALL PERFORMED

99S15 99S15

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

83210 REPLACED CRUISE CONTROL SWITCH 99S15

RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
37300 RECALL REPLACED DEACTIVATION SWITCH 150
REPLACED DEACTIVATION SWITCH

67721 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15
RECALL----- REPLACED SPEED CONTROL DEACTIVATION SWITCH PERMANENT REPAIR
RECALL 98S15 RECALL COMPLETE
REPLACE DEACTIVATION SWITCH, RECALL
98S15 98S15
98S01 PERFORMED RECALL 98S15
RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
AS PER RECALL 98S15 RECALL TO REPLACED DEACTIVATION SWITCH

RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15
REPL DEACTIVATION SWITCH PER RECALL
PERFORM RECALL 98S15
1 TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S15 T
PERFORM SAFETY RECALL 98S15

94821 REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARDSHELL AND BLEED BRAKES AS PER RECALL
INSPECTED ALREADY DISCONNECTED REPLACED SWITCH PER RECALL
1 REPLACE CRUISE CONTROL SWITCH AS NEEDED
PERFORMED RECALL 98S15

38252 PERFORMED 98S15 RECALL
PERFORMED SPEED CONTROL RECALL TECH 9208
PERFORM RECALL 98S15B PERFORM RECALL 98S15B
RPLC CRUISE DEACTIVATION SWITCH PER 98S15
REPL SPEED CONTROL SWITCHES
REPLACE AS PER RECALL 98S15
91280 RECALL TECH 9177 PERFORM RECALL 98S15 INSTALL SWITCH AND CONNECTOR
REPLACE AS PER RECALL REMOVE AND REPLACE AS PER RECALL (98S15B)
43157 PERFORM RECALL AS PER RECALL
REPLACE DEACTIVATION SWITCH 98S15 RECALL PER FORD INSTRUCTIONS
REPLACED DEACTIVATION SWITCH
98S15 RPL SPEED CONTROL DEACTIVATION SWITCH
1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
COMPLETED 98S15
RPL CRUISE DEACTIVATION SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
98S15 REPL DEACTIVATION SWITCH 98S15 COMPLETED - REPLACED DEACTIVATION SWITCH
PERFORM RECALL 98S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH
COMPLETED RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 98S15

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 PERFORMED RECALL 99S15 AND CHECKS OK
 REPLACED CRUISE SWITCH
 55860 99S15B 0.5 ADMIN 0.1
 INSTALLED DEACTIVATION SWITCH
 PERF RECALL
 REPLACED SWITCH PER RECALL
 . REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR 99S15B .5
 . MODIFY PER RECALL 99S15
 RECALL COMPLETE
 TECH CHECK AND REPLACED AS REQUIRED
 REPLACED CRUISE BRAKE KIT .F
 OPEN CAMPAIGN 99S15 REMOVE AND REPLACE SPEED CONTROL SWITCH AS PER CAMPAIGN, PERFORM LABOR OPERATION 99S15B
 INSTALL SPEED CONTROL PART PER RECALL
 99S15 PERFORMED RECAL
 95881 RECALL 99S15E 0.3L PERFORMED RECALL
 RECALL COMPLETED

99S15 REPLACE SWITCH AND CONNECTOR PER RECALL
 COMPLETED RECALL 99S15
 110449 RECALL REPLACE DEACTIVATION SWITCH PER RECALL 99S15
 95721 PERFORMED CRUISE RECALL WHEN REPLACING SWITCH THREADS PULLED OUT OF BLOCK ORDERED PRESURE BLOCK REMOVED FUSE BLOCK ,F
 1 PERFORM RECALL
 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL

RECALL RECALL
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 99S15B INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 COMPLETED RECALL
 RECALL COMPLETED 99S15 RECALL

PERFORMED RECALL 99S15
 FACTORY RECALL COMPLETED RECALL

REPLACE CRUISE SWITCH PER RECALL
 PERFORMED RECALL 99S15
 REPLACED PER RECALL
 PERFORMED INSPECTION AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 PERFORM RECALL
 REPLACE SWITH PER RECALL

??
 95142 RECALL 0.5 INSTALLED BRAKE PRESSURE SWITCH AND HARDSHELL CONNECTOR 99S15B
 95224 RECALL .5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
 THE CAR NEEDS A NEW FAN BELT AT \$63.00. CUST AWARE THE COOLANT BOTTLE IS EMPTY. BATTERY NEEDS SERVICE.
 99S15 99S15

CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL AS

INSPECTED AND REPLACED CRUISE SWITCH PER RECALL NOTICE

102050 RECALL 98S15 W RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOP OFF BRAKE FLUID AND BLEED BRAKES

REPLACE SPEED CONTROL SWITCH PER RECALL

PERFORMED RECALL 98S15: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

80000 RECALL WPG40 INSTALLED NEW SWITCH & WIRE CONNECTOR PER RECALL L 98S15 FINISHED

REPLACED SWITCH AND PLUG AS PER RECALL 98S15

INSTALLED CRUISE CONTROL KIT AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15

91786 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

F RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

PERFORM RECALL

PERFORMED RECALL 98S15-INSTALL SWITCH

88249 REPLACED SWITCH AND CONNECTOR

PERFORM RECALL 98S15 PERFORM RECALL

77544 DO RECALL 98S15

PERFORM RECALL 98S15 REPLACE CRUISE DEACTIVATION SWITCH

SPEED CONTROL DEACTIVATION SWITCH REPLACE 98S15B PERFORMED RECALL 98S15B

REPLACED DEACTIVATION SWITCH AS PER RECALL

157323 RECALL REPLACED SWITCH AND CONNECTOR RECALL 98S15B

1 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH 98S15B

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S

REPL SWITCH PER RECALL 98S15

PERFORM RECALL

PERFORM RECALL

RECALL 98S15: PERFORM RECALL 98S15

CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS

SPEED CNTRL DEACTVTN SWITCH REPLCMT/PERF SAFETY RECALL 98S15

86380 PERFORMED RECALL 98S15

COMPLETED OPEN RECALL 98S15

INSTALLED CRUISE SWITCH

33852 RECALL R+R DEACTIVATION SW AND REWIRED HARD SHELL CONN

90427 MAINT DID RECALL REPLACED SWITCH AND WIRES TECH 10

158858 98S15 SPEED CONTROL DEACTIVATION SWITCH PERFORM INSPECTION AND REPLACE SWITCH AND CONNECTOR AS PER RECALL

RECALL PERFORM RECALL 98S15

PERFORM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

FACTORY RECALL COMPLETED RECALL

98S15 SP-SWITCH INST

REPLACED THE SPEED CONTROL SWITCH PER RECALL

PERFORMED SPEED CONTROL RECALL

80158 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONICTOR TK372

PERFORM RECALL

A SHORT IN THE SPEED CONTROL SWTH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE,1

RECALL REPAIRED AS PER RECALL

98S15 98S15
 98S15 RECALL NOTIFICATION 98S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
 REPLACE BRAKES PRESSURE SWITCH PER RECALL 98S15
 RECALL 98S15 PERFORM RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL TECH 678 WAYNE WP REPLACED CRUISE CUT OFF SWITCH AS PER RECALL CAR ON DRIVE
 NAC 98S15
 RECALL 98S15 INSTALL KIT PER 98S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
 REPLACE SPEED CONTROL DEACTIVATION SW RECALL 98S
 RECALL PERFORMED
 INSTALL SWITCH
 PERFORMED RECALL
 INSTALL SWITCH AS PER RECALL
 1 REPACE SWITCH & CONNECTOR BLED BRAKES
 RECALL 98S15 98S15B .5 ADMIN .1 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL.
 RECALL 98S15
 RECALL 98S15
 98734 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR
 X 98S15
 RECALL 98S15 REPLACE SWITCH & CONNECTOR
 98820 98S15B .5 INSTALL SWITCH PER RECALL
 90387 PERFORMED RECALL 98S15
 115532 RECALL 0.5 98S15B INSTALLED RECALL
 90683 RECALL REPLACED SPEED CONTROL DEATVATER SWITCH AND CONNECTER CODE 42 TK574 SUGGESTED EGR TUBE,INJECTOR SERV,CLEAN IAB
 98S15 SPEED CONTROL RECALL

 REPLACED SPEED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15B
 114104 RECALL REPLACED SWITCH AS PER RECALL
 REPLACED SPEED CONTROL CABLE AS PER RECALL
 RECALL 98S15 COMPLETED
 1 08 REPLACED SWITCH
 CHECK AND REPLACE CRUISE CONTROL SWITCH PER RECALL
 98S15 RECALL 98S15 RECALL
 90218 PERFORM RECALL 98S15B, REPLACE SPEED CONTROL SWITCH.
 98524 RECALL REPLACE DEACTIVATION SW AND CONNECTOR
 PERFORMED RECALL 98S15
 RECALL 98S15 SWITCH
 40430 RECALL 98S15 COMPLETED
 RECALL 98S15 98S15
 RECALL 98S15 COMPLETED
 RECALL PERFORMED

 RECALL 98S15 COMPLETED
 RECALLED 98S15 PERFORMED
 CHECK AND REPAIR AS REQUIRED
 INSPECTED SYSTEM, REPAIRED IF NECESSARY PER RECA
 90152 REPL CRUISE DEACTIVATION SWITCH PER RECAL

PERFORMED RECALL 99S15 1

. PERFORM RECALL 99S15

PERFORMED RECALL 99S15

RECALL 99S15 INSTALLED SWITCH

INSTALL NEW BRAKE SWITCH CONNECTOR PER RECALL OK OP OK

100806 99S16 WARR REPLACED SWITCH AND CONN

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.

SPEED CONTROL SWITCH-1 99S15 RECALL

90580 RECALL 99S15B 0.5 HRS. NEC.TO PERFORM RECALL 99S15.

RECALL REPLACE SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL

INSPECTED AND REPLACED DEACTIVATION SWITCH AS PER RECALL

97000 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLE DNEW SPEED DISABLE SWITCH TO VEHICL

REPLACE SPEED SWITCH AS PER RECALL

RECALL 99S16

PERFORM RECALL INSTALL SWITCH

99S15B 0.5

COMPLETE RECALL 99S15

102093 REPLACED SWITCH AND CONNECTOR PER RECALL

RECALL PERFORMED RECAL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15.

SERVICE DIAG AND REPLACED SERVO ACCUMULATOR

PERFORMED RECALL 99S15. REPLACED CRUISE DE-ACTIVATION SWITCH. 99S15B .5

AS PER RECALL 99S16 RECALL TO INSTALL DEACTIVATION SWITCH

101431 RECALL DEACTIVATION SWITCH INSTALLED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES 3 COMPLETED

124205 RECALL 99S15 COMPLETED

PERFORMED 99S16 RECALL

1 PERFORM SERVICE

PERFORMED RECALL AS NEEDED REPLACED SWITCH

PERFORM RECALL SPEED CONTROL SWITCH

PERFORM RECALL 99S16

RECALL 99S15 RECALL 99S16

99S16 99S16 RECALL

RECALL 99S15

47148 RECALL W 7208 REPLACED SPEED CONTROL DEACTIVATE PER RECALL 99S15

RECALL 99S15 DONE

99S16 SPEED CONTROL RECALL

99S15 - PERFORMED RECALL REPLACED SWITCH & CONNECTOR & RD.TEST.

66077 99S16 PERFORM RECALL FALLS INTO AFFECTED DATE, REPLACE SWITCH AND CONNECTOR, BLEED SYSTEM.

INSTALL SENDER & CONNECTOR PER RECALL 99S15

RECALL 99S15 RECALL

REMOVE AND REPLACE SPEED CONTROL SWITCH

RECALL REPAIR AS PER RECALL 99S16 CRUISE CONTROL CABLE REPLACEMENT

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 REPAIRED PER RECALL
 00 99S15
 99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION :
 REPAIRED AS PER RECALL SPEED CONTROL
 RECALL PERFORMED CAMPAIGN 99 S 15 CRUISE DEACTIVATION SWITCH
 PROGRAM CODE 99S15.
 COMPLETED RECALL 99S15.
 RECALL 99S15 COMPLETED RECALL 99S15
 74945 RECALL 99S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL
 REPLACE DEACTIVATION SWITCH
 RECALL COMPLETED
 REPLACED SWITCH & CONNECTOR
 RECALL RECALL
 117939 REPLACED SWITCH & CONNECTOR PER RECALL
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8
 99S15 REPLACED SWITCH PER RECALL
 REPLACE DEACTIVATION SWITCH PER RECALL

PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUC
 81189 RECALL 99S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL
 PERFORMED RECALL
 RECALL 99S16- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 VERIFY R&R CABLE PER RECALL
 RECALL COMPLETED

REPLACE CRUISE SWITCH PER RECALL 99S15
 RECALL 99S15 E REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
 TECH 241 PERFORMED 99S15 RECALL
 102580 PERFORM 99S15 RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
 1 REPLACE CRUISE CONTROL SWITCH
 REPLACE SWITCH PER RECALL
 DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE INSTALLED SWITCH
 REPL SWITCH PER RECALL 99S15
 - MODIFY PER RECALL 99S15
 COMPLETE RECALL AS DIRECTED

99S15 REPL SWITCH
 REPLACED BRAKE DEACTIVATION SWITCH
 RECALL 99S15 COMPLETED RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15
 CPN,99062,99S15B,0.5,ADMIN,0.1,CC RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL
 4370-PROGRAM CODE 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH WITH UPDATED PART - PER INSTRUCTIONS

RECALL 99S14 RECALL
PERFORMED RECALL 99S15
REPLACED SWITCH ASSEMBLY PER RECALL

COMPLETED RECALL

RECALL 99S15
RECALLED 99S16 PERFORMED
INSPECT AND SECURE SWITCH PER RECALL
CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL AK
129271 RECALL 99S15E, MX, 14200A 1.5L PERFORMED RECALL WIRING REPAIR DO TO NEW CONNECTOR PUT ON AND SWITCH REPLACED BEFORE, HAD T
RECALL 99S15 COMPLETED
PERFORM RECALL 99S15
0 99S16 PROGRAM
RECALLED BY FORD PERFORMED RECALL
PERFORMED RECALL

PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
115287 RECALL REPLACED C C DEACTIVATOR SWITCH AND CONECTOR X99 RECALL
TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH 1
INSPECT, REPLACE CONNECTOR PER 99S15
1 TECH REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15
99S15 RECALL PERFORMED
RECALL 99S15 PERFORM RECALL 99S15
RECALL 99S15
PERFORMED RECALL
100222 INSTALLED THE NEW SWITCH AND CONNECTOR PER RECALL
1 REPLACED DEACTIVATOR SWITCH AND CONNECTOR
RECALL 99S15 RECALL
94869 PERFORMED CRUISE SWITCH RECALL
99S15 SPEED CONTROL RECALL
99S15 99S15
INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL
X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
PERFORMED RECALL 99S15 SPEED CONTROL PER FACTORY
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
RECALL 99S15 REPL SWITCH PER RECALL

1 INSTALL KIT
99S15 COMPLETED SECURED SWITCH
99S15
COMPLETED RECALL PER INSTRUCTIONS
98720 RECALL 99S15 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.
99S15 REPLACE SWITCH
99S15 99S15 RECALL DO

RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.
RECALL COMPLETED
RECALL REPAIR

98S15 RECALL
PERFORM RECALL
1 1 COMPLETED RECALL
RECALL COMPLETED
RECALL 98S15 COMPLETED RECALL 98S15
REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR
REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR
RECALL 98S15 DONE
RECALL 98S15 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 98S15
RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
FACTORY RECALL COMPLETED RECALL
RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS REPLACED DEACTIVATOR SWITCH
47008 INSTALLED KIT
COMPLETED RECALL
INSTALLED SWITCH PER RECALL
REPLACE DEACTIVATION SWITCH
DID RECALL 98S15
127532 RECALL REPLACED CRUISE DEACTIVATION SWITCH AND BLEED REAR BRAKES AS PER RECALL
REPLACED DEACTIVATION SWITCH AS PER RECALL

1 PERFORMED RECALL 98S15
1 INSTALL DEACTIVATION SWITCH PER RECALL

INSTALLED DEACTIVATION SWITCH AND CONNECTOR
COMPLETED RECALL
AS PER RECALL, REPLACED CRUISE DEACTIVATION SWITCH
RECALL 98S15 PERFORMED 98S15
PERFORM RECALL 98S15

98S15 RECALL
135842 REPLACED SPEED DEACTIVATION SW- AND CONNECTOR PER RECALL 98S15.
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
C 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
PERFORM RECALL
RECALL 98S15 COMPLETED REPLACE SENSOR AND HARD SHELL CONNECTOR WIRE WAS MANGLED
83302 98S15 W PERFORMED SERVICE 98S15
RECALL PERFORMED RECALL
1 PERFORMED RECALL 98S15 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR

98S15B 0.5
RECALL 98S15 COMPLETED
RECALL 98S15
COMPLETED 98S15 RECALL

RECALL 98S15 PERFORM RECALL 98S15
REPLACED SENDER & CONNECTOR PER RECALL 98S15
REPLACE CRUISE CONTROL

PERFORMED RECALL
 SERVICE PUBLICATION 99S15 REPLACED SWITCH
 REPLACE DEACTIVATION SWITCH PER RECALL
 99S15 99S15
 PERFORMED RECALL PER FACTORY
 99S15 99S15 REPLACE SWITCH
 58485 REPLACED CRUISE DEACTIVATION SW AND CONNECTOR PER RECALL 99S15.
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 . INSTALL SWITCH AS PER RECALL
 99S15 RECALL 99S15 RECALL COMPLETE
 PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL SPEED CONTROL DEACTIVATIONREPLACE SWITCH
 83284 RECALL#99S15 SPEED CONTROL DEACTIVATION SWITCH. INSTALLED DEACTIVATION SWITCH AND CONNECTOR PER RECALL.#99S15.
 CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.
 RECALL 99S15 INSTALLED SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPLACED DEACTIVATION SWITCH
 1 1 REPL SWITCH AND CONNECTOR.
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 78249 REPLACE SPEED CONTROL DEACTIVATE SWITCH AND CONNECTOR PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
 OPEN RECALL PERFORMED RECALL
 REPLACED SWITCH AND CONNECTOR
 REPLACED THE CRUISE DEACTIVATION SWITCH COMPLETED RECALL
 REPLACE SWITCH AS PER RECALL
 CHECK AND REPAIR AS REQUIRED
 PERFORM RECALL

 RECALL 99S15 PREFORMED RECALL 99S15
 PERFORMED RECALL
 REPLACED SWITCH AND CONENCTOR
 RECALL RECALL
 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH, RETESTED OK.
 COMPLETED RECALL 99S15, REMOVED DEACTIVATION SWITCH AND OLD CONNECTOR, REPLACED BOTH PARTS AND ALL TESTED FINE.
 REPLACED SWITCH AND CONNECTOR PER RECALL 99S15
 RECALL 99S15 RECALL 99S15
 RECALL 99S15

 RECALL 99S15 RECALL 99S15

 RECALL 99S15 COMPLETED
 4238 RECALL 99S15 REPLACED VACUUM SWITCH FOR CRUISE CONTROL
 REPLACE BRAKE PRESSURE SWITCH PER RECALL.
 REPLACE SPEED CONTROL SWITCH

 RECALL PERFORM RECALL
 RECALL 99S15

RECALL 99S15 NOTICE
INSTALLED KIT

RECALL 99S15 PERFORMED
99S15 RECALL PERFORMED

38088 99S15 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR.

RECALL 99S15

1 1 REPL SWITCH.

53586 RECALL 99S15 PERFORMED RECALL 99S15 CRUISE CONTROL

RECOMMENDATIONS AIR & FUEL FILTERS...\$ 78.00..TRANSMISSION SERVICE...\$ 170.00....SERPENTINE BELT...\$ 84.00...COOLANT SERVICE...\$ 85.00+TAX

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD S-HELL CONNECTO

RECALL PERFORM RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15 REPLACE DEACTIVATION SWITCH

93311 REPLACED DEACTIVATOR SWITCH.

PERFORMED RECALL

PERFORMED RECALL 99S15

RECALL REPAIR PER FORD

PERFORMED RECALL 99S15

1 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SWITCH AND CONNECTOR

1 PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE,T

REPLACED THE SPEED CONTROL SWITCH PER RECALL

71056 RECALL .5 REPLACE SWITCH AND HARDSHELL CONNECTOR PER RECALL

99S15 SPEED CONTROL RECALL

RECALL 99S15 NOTICE RECALL 99S15 PERFORMED

RECALL COMPLETED

RECALL 99S15 COMPLETED RECALL 99S15

INSPECTED INSTALLED KIT TO COMPLETE

RECALL COMPLETED.

83773 W 99S15 REPLACE SPEED CONTROL DEACTIVATE SWITCH PER RECALL 99S15B .5

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

1 PERFORMED RECALL

RECALL 99S15 COMPLETED RECALL 99S15

REPLACE SPEED CONTROL SWITCH

X PERFORM RECALL- SPEED CONTROL SWITCH

PERFORM RECALL 99S15 R&R SWITCH PER RECALL 99S15

99894 REPLACED SWITCH & CONNECTOR PER RECALL

R&R SPEED CONTROL SWITCH..TEST DROVE TO VERIFY & REPAIR

RECALL PERFORMED RECALL 99S15

PERFORMED RECALL 99S15.

COMPLETED CAMPAIGN COMPLETED OP 99S15B

1 COMPLETED RECALL 99S15

RECALL 99S15
REPLACE DEACTIVATION SWITCH, RECALL
REPLACE SPEED CONTROL SWITCH AND CONNECTOR
RECALL 99S15 REPLACED SWITCH
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS
REPLACE SWITCH AND HARD SHELL

PERFORMED RECALL
99S15 RECALL 99S15 RECALL
PERFORM RECALL 99S15 PER INSTRUCTIONS
REPLACE CRUISE CONTROL SWITCH
RECALL 99S15 COMPLETED RECALL 99S15
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
REPLACED SWITCH AND CONNECTOR PER RECALL
RECALL 99S15 NOTICE RECALL 99S15 PERFORMED
99712 99S15 99S15B .5 .5 99S15B REPLACE SPEED CONTROL SWITCH, CONECTOR
PERFORMED RECALL
86284 RECALL .5 REPLACESPEEDCONTROL DEACTIVATION SWITCH PER RECALL 99S15B
99S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL 99S15
PERFORM RECALL PER FACTORY, INSTALL UPDATED CRUISE CONTROL DEACTIVATION SWITCH, RE-CK OK
99S15B .5 PERFORM RECALL
99934 0.5 OPERATION 99S15B REPLACED SPEEDCONTROL DEACTIVATION SWITCH TEST DROVE AND CHECKED SPEEDCONTROL OPERATION OK

RECALL 99S15
99S15 SPEED CONTROL RECALL
PREFROMD RECALL
99S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH
REPL SWITCH PER RECALL 99S15
114813 RECALL 0.5 RECALL
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
NAC 99S15
RECALL 99S15. PERFORMED RECALL 99S15.

REPLACE SWITCH PER RECALL

99S15 REPLACED DEACTIVATION SWITCH AS PER RECALL
RECALL PERFORMED RECALL
REPLACED SPEED CONTROL DEACTIVATION SWITCH
INSTALLED SWITCH PER RECALL
REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE
CHECK AND REPAIR AS REQUIRED
REPALCE SWITCH AND HARD SHELL
65108 RECALL .50 .10ADMD 99S15-B UPDATED DEACTIVATION SWITCH N CONNECTOR
CRUISE CONTROL 99S15 PERFORM RECALL
99S15 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

RECALL 99S15 PERFORMED RECALL

99S15B 0.5

INSTALLED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

FACTORY RECALL COMPLETED RECALL

REPLACE BRAKE DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL

185877 RECALL WARR. RECALL 99S15 PERFORMED.

PERFORMED RECALL

RECALL 99S15

RECALL COMPLETED.

REPLACE SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15 SPEED CONTROL

REPLACE DEACTIVATION SWITCH

116950 W REPLACE SPEED CONTROL SWITCH AND CONNECTOR 99S15B RECALL

99S15 99S15

152322 RECALL 99S15 PERFORM RECALL 99S15, REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP

99S15B 99S15B

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS

SPEED CONTROL DEACTIVATION SWITCHES MAY DEVELOP RESISTIVE SHORT IN ELECTRICAL CIRCUIT THAT MAY CAUSE UNDERHOOD FIRE. REPLACED 5

PERFORM RECALL

REPLACE KIT PER RECALL

RECALL 99S15

COMPLETED RECALL 99S15

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15

119278 PERFORMED RECALL AND DURING DEACTIVATION SWITCH REPLACEMENT BRAKE VALVE BLOCK WAS DAMAGED REPLACED SWITCH AND CONNE

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

REMOVED AND REPLACED SWITCH PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL JS 1

99S15 COMPLETED

RECALL COMPLETED.

99S15 99S15

REPLACE KIT PER RECALL

REPLACE CRUISE SWITCH PER RECALL 99S15

PERFORM RECALL 99S15

F PERFORM SAFETY RECALL

PERFORM RECALL INSTALL SWITCH

99S15 99S15

78044 RECALL 99S15 WARR INSTALL CRUISE DEACTIVATION SWITCH

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15.

105600 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL

EEC TEST PASS NG8 PID MONITOR AND RECORD. CHECK OASIS FOR TSB-SSM LONG FUEL TRIM GO NEGATIVE AT HIGHWAY SPEEDS REPLACE MAF SENS

1 REMOVE, TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH - 99S15E .3

RECALL TECH 687 MILES OUT 25060 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 08 REPLACED SWITCH

INSTALLED DEACTIVATION SWITCH

98S15 RECALL 98S15 COMPLETED RECALL

REPLACE SWITCH AND CONNECTOR

PERFORMED RECALL 98S15 INSTALLED SWITCH AND CONNECTOR PER RECALL 98S15

COMPLETED RECALL 98S15-INSTALLED SPEED CONTROL DEACTIVATION SWITCH.

98S16B 0.5

REPLACED SWITCH AND CONNECTOR

PERFORM RECALL PER MANUFACTURER DID RECALL

PERFORM 98S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

98S15 98S15 REPLACED SWITCH

AS PER RECALL 98S15 RECALL TO INSTALL DEACTIVATION SWITCH

RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15

PERFORM RECALL 98S15

97817 RECALL REPLACE DEACTIVATION SWITCH

PERFORMED RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

RECALL 98S15

120434 RECALL 98S15 REPLACE SPEED CONTROL SWITCH PER RECALL

98S15 RECALL 98S15 REPAIRED AS PER RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 98S15

98S15 REPLACE DEACTIVATION SWITCH

RECALL COMPLETED

REPLACED CRUISE CONTROL CABLE PER RECALL 98S15

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 98S15

PERF RECALL 98S15

PERFORM RECALL 98S15

INSTALLED DEACTIVATION SWITCH RECALL 98S15

RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH

68069 DID RECALL 98S15B 0.5 HRS

98S15 RECALL INSTALL DEACTIVATION SWITCH

G RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

98S15 RECALL 98S15 RECALL COMPLETE

INSTALL KIT PER RECALL 98S15

PERFORMED RECALL

INSTALL DEACTIVATION SWITCH

AS PER RECALL 98S15 RECALL TO INSTALL SPEED CONTROL SWITCH

RECALL COMPLETED 98-S-

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

X PERFORMED RECAL

PERFORMED RECALL 98S15

98S15B=0.5 ADMIN=0.1 CHANGED SPEED CONTROL DEACTIVATION SWITCH AS OUTLINED IN RECALL 98S15

PERFORM RECALL 98S15 TEST DRIVE TO CHECK OK 1

INSTALLED DISENGAGE SWITCH PER RECALL 98S15.

REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL
 129M2 RECALL WP40 PERFORMED RECALL, REPLACE BRAKE PRESSURE SWITCH
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE SWITCH AND CONNECTOR PER RECALL
 PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH AND BLEED BRAKES PER RECALL
 PERFORM RECALL
 1 INSTALL SWITCH AS PER RECALL
 RECALL PERFORMED RECALL
 REPL SPD CNTRL DEACTIVATION SW
 PERFORMED RECALL
 PERFORM RECALL 99S15, REPLACE CRUISE DEACTIVATION SWITCH
 SAFETY RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH
 OPEN RECALL PERFORMED RECALL
 PERFORM 99S15 RECALL
 99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR
 1 PERFORM RECALL
 99S15 RECALL INSTALL SWITCH AS PER RECALL
 REPLACED SPEED CONTROL SWITCH AND CONNECTOR
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1
 AS PER RECALL 99S15 RECALL ON SPEED CONTROL SWITCH
 REPLACE SWITCH RECALL, 99S15
 RECALL 99S15 - B - RECALL
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECALL
 RECALL RECALL
 FACTORY RECALL COMPLETED FACTORY RECALL
 COMPLETE RECALL #99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 PERFORM RECALL
 99S15 REPLACED SWITCH AND CONNECTOR PER RECALL
 99S15 RECALL 99S15 RECALL
 REPLACE SWITCH AS PER RECALL
 PERFORM RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

 40579 99S15 B .5 .5 RECALL
 REPLACED SPEED CONTROL DEACT SWITCH AND HARD SHELL CONN AS PER RECALL 99S15
 CHECK AND REPAIR AS REQUIRED
 REPLACED SWITCH AS PER RECALL
 COMPLETE 99S15
 TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH
 99S15E .3 SECURED SWITCH 99S15B .5 REPLACED SWITCH AND CONNECTOR PERFORMED DEACTIVATION OF SWITCH

1 REPLACED SPEED CONTROL SWITCH & CONNECTOR

COMP. RECALL 99S15

CORRE. INSTALL DEACTIVATION SW.

APRX TIME 0.5

PERFORM RECALL
 RECALL COMPLETED

RECALL REPLACE SWITCH AND CONNECTOR

PERFORM RECALL

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 99S15B .5 + .1

RECALL 99S15

INSTALLED DEACTIVATION SWITCH.

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SE

1 COMPLETED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

MODIFY SPEED CONTROL DEACTIVATION SWITCH PER CAMPAIGN

116882 RECALL WARR, 99S15 DONE

PERFORMED RECALL

99S15

99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE

REPLACE SWITCH PER RECALL

PERFORM RECALL 99S15

108168 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH NOTE PRIOR TO REPAIRS AIR BAG LIGHT FLASHING NO HORN ANTI LOCK LAMP ON CUI

PERFORM RECALL AND REPLACE THE SWITCH

1 99S15B .5 ADMIN .1

REPLACE SWITCH AND CONNECTOR

99S15

99S15 RECALL

COMPLETE RECALL 99S15

99S15

99S15 REPLACED SWITCH AND CONNECTOR

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL PROFROMED RECALL PER LETTER

REPLACE DEACTIVATION SWITCH PER RECALL

99S15

99S15

RECALL COMPLETE

78702 RECALL 99S15 WARR REPLACED SPEED CONTROL DEACTIVATION SWITCH RD TEST AFTER

REPLACED SWITCH AND PLUG IN PER RECALL

OPEN RECALL

PERFORMED RECAL

1 PERFORMED RECALL

REPLACE AS PER RECALL 99S15

INSTALL DEACTIVATION SWITCH PER 99S15

PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15B PERFORMED RECALL

RECALL ~~PERFORMED RECALL~~ RECALL ~~PERFORMED RECALL~~

84756 PERFORMED RECALL 99S15. REPLACEMENT OF SPEED CONTROL DEACT. SWITCH AND HARDSHELL CONN.

PERFORMED RECALL

REPLACE SPEED CONTROL SWITCH

INSTALLED DEACTIVATION SWITCH

78

REPLACE BRAKE SWITCH AND CONECTOR PER RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL
SPEED CONTROL SWITCH 99S15 RECALL
99S15 99S15 PERFORM RECALL
PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL INSTALLED SWITCH
REPLACED DEACTIVATION SWITCH PER RECALL 99S15
REPLACE SWITCH
82782 W REPLACE SWITCH AND CONNECTOR PER RECALL 99S15 GA
PERFORMED RECALL 99S15 99S15B .5HRS LABOR
84705 RECALL TECH 9177 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR
RC RC
REPAIR PER 99S15 RECALL
SWITCH 99S15
RECALL 99S15 PERFORM RECALL 99S15
OTHER REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL
AS PER RECALL 99S15 RECALL TO REPLACE SPEED CONTROL SWITCH
REPLACED DEACTIVATION SWITCH.

CONNECTOR PER FORD RECALL

97183 PERFORM 99S15 RECALL , REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

78088 REPLACED SPEED CONTROL RECALL SWITCH 99S15.
1 PERFORM RECALL
PERFORM RECALL
PERFORMED RECALL
PERFORM RECALL 99S15 RECHECK OK 99S15B .5 ADMIN .1
121442 TECH 113 99S15B 0.5 REPLACE SWITCH AND CONNECTOR PER FORD
REPLACED SWITCH AND HARNESS
82345 PERF. RECALL 99S15 W PERF. RECALL 99S15. REPLACE SWITCH. BLEED SYSTEM ROAD TEST PASSED
PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH
31382 99S15 W REPLACED SPEED CONTROL SWITCH AND CONECTOR
1 99S15B .5 ADMIN .1
REPLACED DISENGAGE SWITCH PER RECALL 99S15.
99S15E REMOVE TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED
PERFORM RECALL
RECALL PERFORMED RECALL
REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL AND PICK TAIL CONN
RECALL COMPLETED
REPLACED SPEED CONTROL SWITCH AND CONECTOR
RECALL 99S15 RECALL 99S15
TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH
PERFORM RECALL
99S15 RECALL PERFORMED

RWECALL RECALL 98S15 SPEED CONTROL COMPLETED
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15.
RECALL 98S15 RECALL
PERFORMED RECALL

REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH & PLUG IN PERFORMED RECALL 98S15

PERFORMED RECALL 98S15

PERFORM RECALL 98S15
REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL
REPLACE DEACTIVATION SWITCH
PER NOTIFICATION 98S15 INSTALLED BRAKE REPAIR KIT AS PER RECALL INSTRUCTIONS
PERFORMED RECALL
37711 REPLACE SWITCH AS PER RECALL

INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN
REPLACED PARTS PER RECALL
90001 TECH 1984 REMOVED AND REPLACED DEACTIVATION SWITCH AS PER RECALL
PERFORMED RECALL DEACTIVATION SWITCH AND CONNECT
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORM RECALL 98S15

PERFORM RECALL
PERFORMED RECALL

RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 98S15B .5 - ADMIN .1
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
1 PERFORMED RECALL 98S15

94758 RECALL 98S15 WRT PERFORMED RECALL 98S15

113391 TECH 101-RECALL-98S15B-0.5 REPLACE PRESURE SWITCH & CONECTOR.
REPLACED RECALLED BRAKE SWITCH.

X REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFROM RECALL AND REPLACE THE SWITCH
INSTALLED CRUISE SWITCH AND CONNECTOR PER RECALL
RECALL DONE

- 98S15 RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

98S15 98S15

RECALL 98S15 REPLACE SWITCH AND CONNECTOR

PERFORM RECALL INSTALL SWITCH

RECALL RECALL

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE. ALSO A FIRE COULD DEVOPE. REMOVE,7

RECALL 98S15 REPLACE SWITCH AND CONNECTER

98S15 98S15

REPLACE CONNECTOR SHELL AND SWITCH AS PER RECALL 98S15,,,KS

REPLACE SPEED CONTROL DEACTIVATION SWITCH

RECALL COMPLETE

RECALL COMPLETE

INSTALLED SWITCH PER RECALL

PERFORMED RECALL 99S15. 99S15B .5HRS LABOR
CRUISE RECALL 99S15 INSTALL SWITCH AND CONNECTOR

REPL BRK PRESS SWITCH
PERFORM RECALL 99S15B
SPEED CONTROL SWITCH 99S15 RECALL
RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME
PERFORM RECALL REPLACE SWITCH
RECALL REPLACE SWITCH & HARDSHELL CONNECTOR & BLEED BRAKES
REPLACED DEACTIVATION SWITCH AND CONNECTOR.
99S15 99S15 REPLACED CRUISE SWITCH
123121 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL, BLEED SYSTEM AS PER RECALL
REPLACE SPEED CONTROL REPAIR KIT AS PER RECALL
RECALL 99S15 DONE
1 PERFORMED RECALL AS PER QASIS
COMPLETE RECALL

X REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR
102536 REPLACED CRUISE CONNECTOR AND SWITCH AS PER RECALL
99S15
PERFORMED RECALL
INSTALLED SWITCH PER RECALL
99S15 RECALL 99S15 COMPLETED RECALL
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
RECALL R-R DEAC SW, INSTALLED NEW CONN, RECD O
1 4801 INSPECT AND NECESSARY TO INSTALL CRUISE CONTROL CABLE AS PER RECALL
INSTALL NEW SWITCH
COMPLETE RECALL

78203 99S15 99S15 .5 REPLACE SPEED CONTROL SWITCH & CONNECTOR, BLEED BRAKES
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
1 PERFORM CRUISE RECALL
RECALL NEEDED REPLACE CRUISE SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION
PERFORM RECALL 99S15
REPL SWITCH PER RECALL 99S15
99S15 99S15
99S15 PERFORM RECALL 99S15
99S15 99S15
RECALL 99S15 PERFORM RECALL 99S15
PERFORMED RECALL
RECALL PERFORMED RECALL
PERFORMED RECALL ACCORDING TO INSTRUCTIONS
RECALL 99S15
RECALL 99S15 COMPLETED RECALL 99S15
RECALL DID RECALL
99S15 99S15
PERFORM RECALL PER MANUFACTURER PERFORMED RECALL
COMPLETE RECALL 99S15

70006 RECALL REPL- SPEED CONTROL DEACTIVATION SWITCH & PLUG - 98S15B 0.5
 RECALL 98S15 SPEED CONTROL SWITCHREPLACE SWITCH AND HARDSHELL CONNECTOR.
 PERFORMED RECALL
 RECALL 98S15B NEC TO PERFORM RECALL 98S15B
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
 RECALL COMPLETE
 RPL SPEED CONTROL SWITCH PER 98S15
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 PERFORMED RECALL
 RECALL 98S15
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACED SWITCH AND PLUG.
 SPEED CTRL DEACTIVATION SW RECALL98S15 REPAIR PER RECALL
 98S15 98S15
 PERFORMED RECALL 98S15
 RECALL PERFORM RECALL AS REQUIRED
 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH
 1 98S15B.5 ADMIN.1
 40067 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15
 PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH
 REPLACED SWITCH AND CONECTOR
 DID RECALL AS PRE INSTRUCTED
 RECALL R-R DEAC SW, INSTALLED NEW, CONN. RECKD OK.
 PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
 PERFORMED RECALL 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 PER RECALL 98S15 -RECALLED
 REPL HARD SHELL CONNECTOR PER 98S15
 RECALL RECALL

 RECALL COMPLETE
 REPLACE SWITCH AND HARD SHELL
 INSTALL CRUISE SWITCH AND CONNECTOR
 124381 DUE RECALL 98S15
 98S15 98S15
 REPLACE DEACTIVATION SWITCH AS PER 98S15
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
 PERFORMED RECALL
 RECALL 98S15
 PERFORM RECALL REPLACE SWITCH
 INSTALL SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
 INSTALL SWITCH
 PERFORM RECALL
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL

RECALL R-R DEAC SW, INSTALLED NEW CONN, RECD O
108711 PERFORMED RECALL *****NOTE: BRAKES PULSATE*****

PERFORMED RECALL 99S15

INSTALL CRUISE SWITCH AND CONNECTOR

PERFORM RECALL 99S15

99S15 RECALL 99S15B REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR FOR RECALL 99S15B

RECALL SPEED CONTROL SWITCH PERFORM RECALL 99S15, REPLACE SPEED CONTROL SWITCH

107508 RECALL 99S15B.5 PERFORM RECALL INSTALL CONN. AND SWITCH DISPATCH ERROR ON TIME RAN

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACE SWITCH AND CONNECTOR

99S15

99S15

RECALL COMPLETE

REPLACED DEACTIVATION SWITCH

113201 PERFORMED RECALL

PERFORMED RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

SWITCH

REPL SPEED CONTROL DEACTIVATION SWITCH

OPEN RECALL. PERFORMED 99S15 RECALL

PERFORMED RECALL

99S15

99S15 REPLACED CRUISE SWITCH

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORMED 99S15

INSTALL NEW SWITCH AND CONNECTOR 99S15

RECALL INSTALLED SWITCH

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR 99S15B .5 + .1

1 --COMPLETED SPEED CONTROL RECALL

0

99S15 PROGRAM

PERFORM RECALL 99S15

REMOVE & REPLACE CRUISE DEACTIVATION SWITCH

72907 DID RECALL REPLACED SWITCH

RECALL 99S15

1 COMPLETED RECALL 99S15

-- RECALL COMPLETED

COMPLETED RECALL 99S15

RECALL

99S15B PERFORM RECALL 99S15B

INSPECT AND REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 REPLACED DEACTIVATOR SWITCH AND PLUG PER RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR. 5

REPLACED SPEED CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH

99S15

IPR AND EBP OUT OF SPEC FOLLOWED PERFORMANCE SHEET 1-14 REPLACED IPR AND TEST DROVE CODE 470 PID DIAG EBP 38 PSI OUT OF RANGE RE

FACTORY RECALL COMPLETED RECALL

REPLACED SPEED CONTROL BRAKE KIT

99S15

99S15 REPLACED SWITCH