

EA02-025

FORD 10/27/03

APPENDIX N

BOOKS 9 OF 61

PART 2 OF 4

7/14/1992 07-NOV-92
4/13/1992 11-MAY-92
5/11/1992 27-MAY-92
8/4/1992 29-AUG-92
8/2/1992 06-OCT-92
3/3/1992 20-MAR-92
8/21/1992 14-MAY-94
06/1992 30-JUN-92
2/12/1992 12-JUN-92
8/13/1992 13-OCT-92
4/13/1992 07-MAY-92
2/14/1992 28-FEB-92
4/1/1992 27-MAY-92
11/13/1992 02-DEC-92
8/5/1992 24-AUG-92
11/18/1992 02-DEC-92
5/11/1992 02-JUN-92
3/8/1992 18-MAR-92
12/5/1991 15-JAN-92
8/9/1992 24-JUN-92
10/14/1992 23-DEC-92
8/2/1992 30-OCT-92
8/5/1992 28-AUG-93
10/30/1992 23-DEC-92
3/17/1992 27-JUL-92
9/9/1992 23-NOV-93
8/25/1992 23-NOV-93
12/8/1991 04-JUL-92
3/17/1992 30-MAY-92
12/10/1991 30-JAN-92
9/18/1992 30-SEP-92
8/18/1992 13-OCT-92
6/28/1992 25-JUL-92
7/29/1992 28-AUG-92
2/24/1992 09-MAR-92
5/28/1992 30-JUN-92
8/9/1992 18-NOV-92
3/5/1992 23-MAR-92
6/19/1992 04-JUN-92
2/20/1992 22-MAR-92
8/12/1992 22-SEP-92
9/28/1992 08-OCT-92
3/24/1992 08-APR-92
12/11/1991 01-JAN-92
8/28/1992 11-JUL-92
8/28/1992 10-MAR-93

4/21/1992 17-AUG-92
4/24/1992 01-JUN-92
5/4/1992 10-JUN-92
2/10/1992 28-FEB-92
3/17/1992 02-APR-92
10/27/1992 03-MAR-93
2/21/1992 13-MAR-92
4/29/1992 15-MAY-92
7/23/1992 30-SEP-92
8/21/1992 18-NOV-93
3/3/1992 02-APR-92
8/15/1992 18-NOV-92
2/14/1992 29-FEB-92
2/4/1992 31-MAR-92
2/25/1992 10-MAR-92
8/20/1992 18-JAN-93
4/6/1992 23-JUL-92
11/8/1992 25-NOV-92
2/20/1992 08-MAR-92
12/12/1991 20-DEC-91
8/26/1992 08-FEB-93
4/28/1992 20-OCT-92
12/12/1991 20-DEC-91
8/25/1992 22-FEB-93
4/16/1992 08-MAY-92
7/2/1992 14-SEP-92
10/2/1992 18-OCT-92
3/23/1992 13-APR-92
3/6/1992 25-JUL-92
11/27/1991 03-DEC-91
10/22/1992 15-NOV-92
4/29/1992 25-AUG-92
8/20/1992 02-FEB-93
2/27/1992 28-DEC-92
6/4/1992 22-JUL-92
8/16/1992 23-JUN-92
5/8/1992 23-MAY-92
8/24/1992 15-JAN-93
10/22/1992 30-NOV-93
1/24/1992 23-MAY-92
3/13/1992 31-MAR-92
8/21/1992 20-OCT-92
7/31/1992 23-SEP-92
5/1/1992 23-SEP-92
8/25/1992 19-DEC-92
10/6/1992 20-OCT-92

10/7/1992 21-OCT-92
 8/11/1992 04-AUG-92
 8/24/1992 31-MAY-93
 3/31/1992 01-JUL-92
 6/12/1992 12-SEP-92
 7/29/1992 28-AUG-92
 3/28/1992 15-APR-92
 2/13/1992 28-FEB-92
 10/8/1992 20-NOV-92
 5/22/1992 10-OCT-92
 2/27/1992 24-MAR-92
 3/18/1992 30-APR-92
 3/3/1992 18-JUL-92
 10/7/1992 25-JAN-93
 10/28/1992 25-APR-93
 8/24/1992 22-JUL-92
 8/12/1992 13-FEB-93
 8/28/1992 31-JUL-92
 12/2/1991 11-DEC-91
 2/18/1992 03-MAR-92
 12/19/1991 27-JUN-92
 11/17/1992 11-JAN-93
 3/6/1992 14-SEP-92
 6/1/1992 17-JUN-92
 10/21/1992 17-JUL-93
 7/29/1992 11-SEP-92
 6/22/1992 21-JUL-92
 12/4/1991 22-DEC-91
 6/23/1992 08-JUL-92
 9/2/1992 09-NOV-92
 8/17/1992 14-SEP-92
 3/11/1992 06-APR-92
 10/1/1992 31-DEC-92
 3/30/1992 23-JUN-92
 8/20/1992 12-FEB-93
 6/26/1992 21-AUG-92
 1/15/1992 22-JAN-92
 10/27/1992 19-NOV-92
 3/8/1992 25-MAR-92
 10/28/1992 20-NOV-92
 8/13/1992 20-JAN-93
 7/21/1992 03-SEP-92
 6/11/1992 26-SEP-92
 6/11/1992 22-JUL-92
 12/5/1991 10-MAR-92
 3/9/1992 03-AUG-92

11/13/1992 01-DEC-92
 2/20/1992 01-APR-92
 9/4/1992 03-DEC-92
 11/10/1992 01-APR-93
 10/21/1992 09-NOV-92
 9/10/1992 22-SEP-92
 3/18/1992 03-SEP-92
 11/22/1991 28-DEC-91
 8/18/1992 05-JUL-92
 8/10/1992 27-OCT-92
 3/18/1992 23-JUN-92
 9/28/1992 11-FEB-93
 7/1/1992 25-JUL-92
 9/9/1992 20-OCT-92
 5/18/1992 31-AUG-92
 2/12/1992 02-MAR-92
 10/20/1992 03-MAR-94
 5/13/1992 28-MAY-92
 4/18/1992 09-MAY-92
 3/29/1992 10-APR-92
 3/31/1992 16-APR-92
 2/25/1992 10-MAR-92
 4/15/1992 20-SEP-92
 11/27/1992 22-JAN-93
 11/20/1992 03-MAR-93
 3/18/1992 20-APR-93
 9/10/1992 26-SEP-92
 5/6/1992 11-JUL-92
 9/21/1992 26-MAY-93
 3/30/1992 17-APR-92
 12/10/1991 27-JAN-92
 8/4/1992 24-AUG-92
 10/30/1992 20-NOV-92
 8/8/1992 14-JUL-92
 11/10/1992 11-NOV-93
 3/13/1992 11-JUL-92
 3/9/1992 10-JUL-92
 12/11/1991 10-JAN-92
 3/23/1992 08-MAY-92
 8/2/1992 21-JUN-92
 10/2/1992 17-OCT-92
 10/1/1992 17-OCT-92
 12/17/1991 05-JAN-92
 8/5/1992 30-JUN-92
 9/18/1992 02-OCT-92
 10/19/1992 27-JUL-93

4/28/1992 22-OCT-92
9/23/1992 23-OCT-92
11/25/1991 08-JAN-92
11/15/1992 25-NOV-92
10/1/1992 12-APR-93
8/17/1992 16-SEP-92
5/29/1992 17-JUN-92
9/17/1992 06-OCT-92
9/22/1992 07-OCT-92
9/18/1992 06-OCT-92
6/15/1992 13-AUG-92
8/19/1992 27-MAR-92
9/22/1992 08-APR-93
9/23/1992 10-JUN-93
9/1/1992 04-SEP-92
5/20/1992 02-JUN-92
12/3/1991 30-APR-92
7/17/1992 02-JAN-93
4/6/1992 23-APR-92
5/24/1992 21-NOV-92
2/28/1992 20-MAR-92
11/19/1992 04-DEC-92
11/30/1992 17-DEC-92
8/12/1992 25-JAN-93
7/29/1992 13-AUG-92
7/29/1992 13-AUG-92
4/3/1992 17-JUL-92
8/28/1992 12-JUL-92
8/28/1992 15-SEP-92
3/28/1992 28-MAY-92
9/28/1992 29-MAR-93
11/27/1991 07-FEB-92
10/28/1992 13-NOV-93
11/12/1992 27-FEB-93
5/28/1992 02-JUL-92
3/4/1992 25-MAR-92
7/27/1992 27-AUG-92
5/14/1992 27-MAY-92
9/2/1992 24-SEP-92
1/13/1992 04-MAY-92
11/19/1991 04-FEB-92
7/30/1992 25-AUG-92
12/8/1991 03-MAR-92
7/10/1992 31-AUG-92
4/2/1992 17-APR-92
2/12/1992 02-MAR-92

ENC2-828 11517

12/5/1991 18-DEC-91
8/16/1992 22-SEP-92
3/18/1992 30-JUL-92
9/4/1992 05-NOV-92
7/14/1992 31-JUL-92
2/21/1992 24-MAY-92
6/6/1992 08-APR-93
8/10/1992 17-OCT-92
5/28/1992 19-SEP-92
11/18/1992 04-DEC-92
10/29/1992 07-DEC-92
7/9/1992 15-AUG-92
8/4/1992 19-AUG-92
8/7/1992 14-OCT-92
8/6/1992 09-NOV-92
8/7/1992 10-SEP-92
2/10/1992 26-FEB-92
3/19/1992 04-MAY-92
7/18/1992 01-AUG-92
8/7/1992 12-NOV-93
8/6/1992 16-SEP-92
8/23/1992 08-APR-92
1/17/1992 05-FEB-92
7/31/1992 21-SEP-92
9/21/1992 07-APR-93
9/9/1992 31-OCT-92
7/7/1992 31-AUG-92
11/22/1991 04-AUG-92
2/27/1992 29-JUL-92
4/13/1992 15-MAY-92
6/19/1992 10-AUG-92
3/24/1992 09-APR-92
9/18/1992 23-OCT-92
6/18/1992 30-OCT-92
7/24/1992 27-AUG-92
6/24/1992 13-JUL-92
8/21/1992 18-NOV-92
12/12/1991 09-JAN-92
1/21/1992 29-FEB-92
6/16/1992 22-SEP-92
8/10/1992 21-SEP-92
10/18/1992 04-NOV-92
5/20/1992 11-SEP-92
11/23/1992 08-DEC-92
12/10/1991 21-DEC-91
3/28/1992 14-MAY-92

2/24/1992 07-MAY-92
 8/16/1992 08-SEP-92
 4/29/1992 18-MAY-92
 8/17/1992 17-FEB-93
 10/28/1992 30-NOV-92
 8/31/1992 31-OCT-92
 7/6/1992 14-AUG-92
 3/20/1992 07-APR-92
 7/27/1992 31-JUL-92
 10/8/1992 17-DEC-92
 3/4/1992 27-AUG-92
 10/28/1992 22-FEB-93
 5/21/1992 02-JUN-92
 3/31/1992 07-JUL-92
 6/8/1992 28-MAY-92
 5/7/1992 07-JUL-92
 3/8/1992 17-OCT-92
 6/19/1992 11-JUL-92
 11/10/1992 16-NOV-92
 6/4/1992 19-JUN-92
 11/6/1992 07-JAN-93
 8/2/1992 08-MAY-93
 3/5/1992 30-APR-92
 8/10/1992 28-SEP-92
 4/14/1992 19-MAY-92
 3/13/1992 05-MAY-92
 12/3/1991 20-DEC-91
 8/17/1992 21-MAY-93
 11/20/1992 06-DEC-92
 12/20/1991 04-JAN-92
 3/30/1992 15-APR-92
 3/30/1992 13-MAY-92
 8/22/1992 08-OCT-92
 3/25/1992 27-JUL-92
 2/28/1992 30-APR-92
 8/9/1992 19-JUL-93
 8/2/1992 18-SEP-92
 8/2/1992 08-APR-93
 11/11/1992 02-MAR-93
 4/10/1992 08-JUL-92
 2/13/1992 03-MAR-92
 7/20/1992 21-SEP-92
 3/2/1992 10-MAR-92
 11/13/1992 02-DEC-92
 2/19/1992 28-FEB-92
 3/11/1992 15-APR-92

C2

3/18/1992 06-MAY-92
 12/6/1991 25-DEC-91
 11/18/1991 11-DEC-91
 12/6/1991 16-JAN-92
 8/12/1992 14-APR-93
 10/18/1992 09-FEB-93
 11/28/1992 08-JUL-93
 3/12/1992 31-MAR-92
 6/22/1992 05-SEP-92
 9/6/1992 22-JUL-93
 6/8/1992 24-JUN-92
 10/20/1992 17-MAR-93
 10/28/1992 22-JAN-93
 6/27/1992 12-JUN-92
 9/6/1992 24-SEP-92
 6/16/1992 22-OCT-92
 9/6/1992 09-JUN-93
 1/24/1992 31-AUG-92
 9/6/1992 01-NOV-93
 6/30/1992 27-JUL-92
 7/1/1992 24-SEP-92
 3/23/1992 07-APR-92
 12/10/1991 22-JAN-92
 7/2/1992 17-JUL-92
 6/29/1992 14-JUL-92
 3/17/1992 26-DEC-92
 1/23/1992 20-FEB-92
 3/17/1992 21-MAY-92
 5/26/1992 13-JUN-92
 6/18/1992 21-SEP-92
 8/6/1992 14-SEP-92
 12/11/1991 31-DEC-91
 2/7/1992 24-MAR-92
 6/18/1992 25-AUG-92
 6/17/1992 07-AUG-92
 7/17/1992 31-JUL-92
 3/25/1992 15-JUN-92
 6/4/1992 29-MAY-92
 6/18/1992 07-JUL-92
 2/27/1992 14-APR-92
 10/20/1992 26-JUL-93
 12/13/1991 01-JAN-92
 11/24/1992 10-DEC-92
 11/13/1992 27-NOV-92
 6/30/1992 05-AUG-92
 12/16/1991 05-JAN-92

10/28/1992 12-NOV-92
5/20/1992 07-JUL-92
7/27/1992 10-AUG-92
6/26/1992 21-OCT-92
10/13/1992 21-MAY-93
2/18/1992 03-MAR-92
8/4/1992 26-SEP-92
4/30/1992 22-MAY-92
11/25/1992 15-DEC-92
11/30/1992 17-DEC-92
2/18/1992 09-MAR-92
5/28/1992 13-JUN-92
2/27/1992 03-APR-92
6/5/1992 20-JUN-92
5/27/1992 12-JUN-92
4/9/1992 25-APR-92
7/8/1992 30-SEP-92
6/11/1992 14-APR-93
8/28/1992 17-SEP-93
5/6/1992 26-MAY-92
12/20/1991 05-JAN-92
9/24/1992 03-MAR-93
5/11/1992 27-JUL-92
8/11/1992 13-AUG-92
6/26/1992 11-JUL-92
6/2/1992 26-AUG-92
6/22/1992 29-AUG-92
11/11/1991 22-JAN-92
2/4/1992 21-FEB-92
11/29/1992 25-NOV-92
4/13/1992 29-APR-92
7/10/1992 15-SEP-92
2/28/1992 17-MAR-92
1/13/1992 01-FEB-92
4/13/1992 30-APR-92
10/12/1992 28-OCT-92
12/4/1991 01-JAN-92
8/3/1992 15-MAR-93
2/28/1992 21-MAR-92
11/30/1992 04-SEP-93
10/1/1992 08-MAY-93
3/10/1992 27-MAR-92
12/6/1991 05-FEB-92
8/5/1992 06-OCT-92
5/4/1992 20-MAY-92
8/14/1992 08-OCT-92

0/11/1992 23-SEP-92
 3/8/1992 25-MAR-92
 3/12/1992 20-MAR-92
 4/8/1992 06-MAY-92
 11/17/1992 03-DEC-92
 10/16/1992 29-DEC-92
 3/9/1992 16-APR-92
 9/24/1992 08-SEP-93
 5/16/1992 02-JUN-92
 10/30/1992 14-NOV-92
 9/24/1992 13-OCT-92
 7/10/1992 14-AUG-92
 10/28/1992 22-MAY-93
 7/29/1992 31-AUG-92
 8/10/1992 18-SEP-92
 4/3/1992 29-SEP-92
 5/25/1992 09-JUN-92
 6/10/1992 21-AUG-92
 8/19/1992 03-SEP-92
 11/17/1992 15-DEC-92
 7/21/1992 31-AUG-92
 7/1/1992 15-OCT-92
 8/10/1992 26-JUN-92
 8/25/1992 05-AUG-93
 8/3/1992 18-JUN-92
 8/9/1992 24-JUN-92
 8/25/1992 09-APR-92
 9/28/1992 13-OCT-92
 4/24/1992 18-MAY-92
 9/29/1992 25-JAN-93
 9/18/1992 14-MAY-93
 3/20/1992 07-APR-92
 11/17/1992 29-DEC-92
 11/17/1992 25-FEB-93
 3/18/1992 10-JUN-92
 8/21/1992 08-SEP-92
 3/19/1992 27-APR-92
 4/10/1992 28-APR-92
 3/2/1992 30-MAR-92
 1/22/1992 06-FEB-92
 8/18/1992 07-JUL-92
 10/2/1992 16-OCT-92
 3/3/1992 19-MAR-92
 8/22/1992 31-OCT-92
 8/24/1992 08-SEP-92
 10/28/1992 12-NOV-92

EM02-028 11592

4/7/1992 02-MAY-92
4/28/1992 01-OCT-92
8/20/1992 17-NOV-92
10/19/1992 13-DEC-92
9/15/1992 04-NOV-92
7/16/1992 12-AUG-92
3/25/1992 30-SEP-92
4/6/1992 16-SEP-92
8/20/1992 21-MAY-93
10/27/1992 28-NOV-92
11/5/1992 14-DEC-92
4/1/1992 16-APR-92
6/19/1992 22-AUG-92
5/4/1992 19-MAY-92
8/12/1992 25-AUG-92
3/3/1992 12-MAR-92
5/4/1992 10-AUG-92
8/14/1992 20-MAY-93
4/23/1992 09-JUN-92
10/20/1992 17-DEC-92
3/31/1992 30-MAY-92
3/13/1992 28-MAR-92
8/25/1992 10-MAR-93
3/5/1992 15-APR-92
11/18/1992 19-DEC-92
8/12/1992 08-OCT-92
8/10/1992 31-OCT-92
11/28/1991 16-JAN-92
4/6/1992 15-APR-92
5/7/1992 01-JUN-92
4/8/1992 26-OCT-92
12/2/1991 31-JAN-92
2/25/1992 13-MAR-92
10/29/1992 11-MAY-93
2/25/1992 14-MAR-92
5/11/1992 12-SEP-92
2/26/1992 31-MAR-92
10/30/1992 18-NOV-92
8/24/1992 30-MAY-92
10/9/1992 30-OCT-92
10/28/1992 13-NOV-92
3/11/1992 30-MAY-92
10/28/1992 11-DEC-92
7/8/1992 16-OCT-92
4/1/1992 16-APR-92
3/10/1992 15-JUN-92

6/3/1992 22-JUN-92
 8/28/1992 30-OCT-92
 7/29/1992 25-AUG-92
 8/5/1992 11-SEP-92
 11/12/1992 13-DEC-92
 10/18/1992 28-OCT-92
 10/18/1992 18-OCT-93
 3/20/1992 15-APR-92
 3/11/1992 05-JAN-93
 10/21/1992 14-JAN-93
 7/27/1992 24-FEB-93
 8/31/1992 30-JUL-93
 8/23/1992 14-OCT-92
 5/19/1992 28-SEP-92
 7/23/1992 27-AUG-92
 5/11/1992 27-MAY-92
 10/13/1992 10-NOV-92
 4/9/1992 31-AUG-92
 11/18/1992 04-DEC-92
 2/18/1992 30-JUN-92
 5/20/1992 01-JUN-92
 6/22/1992 08-JUL-92
 8/11/1992 28-JAN-93
 5/15/1992 28-MAY-92
 8/11/1992 11-JUL-93
 8/7/1992 22-AUG-92
 11/19/1992 28-SEP-93
 3/10/1992 17-MAR-92
 8/24/1992 30-SEP-92
 10/15/1992 12-JUN-93
 11/20/1991 08-JAN-92
 4/21/1992 29-APR-92
 4/21/1992 22-MAY-92
 4/3/1992 28-APR-92
 5/12/1992 03-JUN-92
 3/25/1992 09-APR-92
 10/28/1992 11-NOV-92
 6/29/1992 17-JUN-92
 8/23/1992 19-NOV-92
 10/19/1992 01-DEC-92
 9/29/1992 14-OCT-92
 8/20/1992 05-JUN-92
 8/20/1992 31-AUG-92
 8/2/1992 01-OCT-92
 8/31/1992 13-OCT-92
 11/12/1992 04-MAR-93

8/5/1992 28-AUG-92
11/13/1992 02-JAN-93
4/24/1992 08-MAY-92
9/1/1992 23-SEP-93
2/14/1992 03-MAR-92
5/16/1992 14-AUG-92
11/27/1992 16-DEC-92
10/19/1992 30-OCT-92
11/12/1992 30-NOV-92
11/13/1992 27-JAN-93
9/15/1992 14-OCT-92
10/2/1992 17-OCT-92
2/29/1992 02-APR-92
11/23/1992 12-DEC-92
12/13/1991 02-JAN-92
9/15/1992 05-JAN-93
1/23/1992 07-APR-92
9/17/1992 01-OCT-92
8/20/1992 16-SEP-92
7/1/1992 12-AUG-92
11/18/1992 30-NOV-92
11/19/1992 23-NOV-92
10/1/1992 31-MAR-93
8/20/1992 15-SEP-92
9/21/1992 22-DEC-92
8/28/1992 15-SEP-92
3/13/1992 30-MAR-92
2/3/1992 03-MAR-92
5/5/1992 20-NOV-92
10/22/1992 18-DEC-92
8/27/1992 02-SEP-92
9/23/1992 21-APR-93
8/15/1992 30-JUN-92
8/27/1992 14-APR-93
8/28/1992 02-JUL-92
3/9/1992 17-MAR-92
8/10/1992 02-AUG-92
12/2/1991 29-JAN-92
4/13/1992 30-APR-92
12/19/1991 04-JAN-92
9/28/1992 16-NOV-92
11/18/1992 20-JAN-93
5/14/1992 29-MAY-92
2/5/1992 20-MAR-92
8/20/1992 19-MAY-93
9/30/1992 19-OCT-92

10/27/1992 13-NOV-92
 9/1/1992 09-OCT-92
 8/24/1992 09-JUL-92
 10/19/1992 12-DEC-92
 8/19/1992 22-JUL-92
 5/13/1992 29-MAY-92
 8/21/1992 31-OCT-92
 8/28/1992 07-AUG-92
 2/8/1992 25-FEB-92
 10/28/1992 10-FEB-93
 4/16/1992 30-MAY-92
 10/22/1992 08-NOV-92
 5/13/1992 29-MAY-92
 3/9/1992 24-MAR-92
 4/13/1992 30-APR-92
 11/19/1992 04-DEC-92
 10/21/1992 08-APR-93
 8/12/1992 20-OCT-92
 2/18/1992 12-MAY-92
 7/14/1992 28-JUL-92
 3/12/1992 01-APR-92
 10/20/1992 01-MAR-93
 8/8/1992 08-MAY-93
 8/17/1992 08-OCT-92
 10/30/1992 08-DEC-92
 11/3/1992 11-FEB-93
 9/8/1992 24-SEP-92
 8/18/1992 28-SEP-92
 10/15/1992 27-MAR-93
 2/13/1992 03-MAR-92
 9/17/1992 19-JAN-93
 8/7/1992 22-FEB-93
 5/14/1992 13-JUL-92
 2/14/1992 08-MAR-92
 8/29/1992 15-JUL-92
 8/20/1992 20-APR-94
 7/31/1992 15-AUG-92
 8/29/1992 13-JUN-92
 9/14/1992 30-SEP-92
 11/20/1991 08-DEC-91
 2/4/1992 19-MAR-92
 3/23/1992 11-APR-92
 9/30/1992 11-NOV-92
 2/6/1992 15-APR-92
 3/13/1992 31-MAR-92
 11/19/1992 31-JAN-93

7/13/1992 02-AUG-92
8/5/1992 18-SEP-92
5/20/1992 31-JUL-92
6/29/1992 17-JUL-92
11/22/1991 14-DEC-91
4/3/1992 15-MAY-92
3/3/1992 20-MAR-92
11/24/1992 08-DEC-92
9/30/1992 28-OCT-92
9/24/1992 18-JAN-93
12/12/1991 08-JAN-92
6/30/1992 03-OCT-92
1/22/1992 03-MAR-92
11/25/1991 18-DEC-91
4/8/1992 21-APR-92
4/8/1992 23-APR-92
11/5/1992 14-DEC-92
11/25/1992 18-JUL-93
11/12/1992 22-OCT-93
8/19/1992 24-MAY-93
2/28/1992 20-JUN-92
2/27/1992 25-APR-92
3/5/1992 20-JUN-92
9/18/1992 08-OCT-92
4/8/1992 23-APR-92
12/17/1991 10-JAN-92
10/1/1992 31-JUL-93
8/3/1992 25-AUG-92
9/21/1992 08-NOV-92
5/28/1992 12-JUN-92
9/29/1992 20-JUL-92
3/19/1992 27-MAR-92
10/21/1992 29-OCT-92
2/5/1992 02-MAR-92
3/31/1992 23-APR-92
7/8/1992 29-JUL-92
12/2/1991 11-DEC-91
11/25/1992 11-DEC-92
8/28/1992 18-SEP-92
6/12/1992 05-OCT-92
8/2/1992 23-JUN-92
4/13/1992 04-JUN-92
2/9/1992 05-MAR-92
2/18/1992 12-MAR-92
9/21/1992 30-JAN-93
11/27/1992 01-DEC-92

ENR2-828 11827

5/13/1992 14-DEC-92
6/22/1992 27-JUL-92
10/25/1992 13-NOV-92
8/9/1992 14-OCT-92
3/25/1992 19-MAY-92
10/12/1992 29-OCT-92
8/24/1992 17-NOV-92
8/30/1992 18-MAR-93
10/13/1992 24-OCT-92
3/18/1992 30-MAR-92
10/21/1992 27-APR-93
11/12/1992 24-FEB-93
5/5/1992 28-MAY-92
3/10/1992 24-MAR-92
10/27/1992 15-NOV-92
10/22/1992 03-NOV-92
4/8/1992 27-APR-92
4/15/1992 29-APR-92
5/21/1992 05-JUN-92
8/13/1992 29-OCT-92
3/10/1992 27-MAR-92
8/4/1992 08-OCT-92
2/7/1992 11-MAR-92
4/21/1992 14-MAY-92
8/22/1992 14-OCT-92
10/12/1992 27-OCT-92
11/19/1992 29-JAN-93
3/10/1992 18-MAR-92
4/15/1992 19-JUL-92
7/10/1992 25-JUL-92
11/4/1992 22-DEC-92
11/3/1992 30-DEC-92
3/16/1992 27-JUN-92
4/8/1992 25-APR-92
6/15/1992 28-OCT-92
2/11/1992 01-MAR-92
3/18/1992 23-JUL-92
8/13/1992 10-MAY-93
8/26/1992 24-OCT-92
4/27/1992 12-MAY-92
5/29/1992 13-JUN-92
8/17/1992 20-AUG-92
11/19/1992 28-DEC-92
9/10/1992 24-SEP-92
1/21/1992 30-JAN-92
10/15/1992 08-APR-93

9/10/1992 29-SEP-92
3/5/1992 10-MAY-92
5/22/1992 10-JUN-92
9/22/1992 14-MAY-93
5/20/1992 17-JUN-92
2/18/1992 05-MAR-92
1/5/1992 14-NOV-92
2/13/1992 02-MAR-92
11/24/1992 19-APR-93
6/30/1992 21-JUL-92
12/12/1991 20-DEC-91
11/23/1992 04-FEB-93
8/27/1992 05-AUG-93
10/28/1992 13-NOV-92
8/21/1992 27-MAY-93
6/19/1992 24-AUG-92
11/5/1992 18-DEC-92
4/8/1992 23-APR-92
3/3/1992 29-MAY-92
11/10/1992 31-JAN-93
4/30/1992 30-JUN-92
7/23/1992 12-NOV-92
3/13/1992 24-MAR-92
8/23/1992 09-OCT-92
7/6/1992 21-SEP-92
5/4/1992 12-JUN-92
5/29/1992 17-JUN-92
8/15/1992 01-JUL-92
3/27/1992 27-APR-92
5/7/1992 28-MAY-92
10/5/1992 15-OCT-92
10/26/1992 18-JAN-93
5/7/1992 22-MAY-92
3/30/1992 24-SEP-92
8/25/1992 11-JUL-92
6/13/1992 28-MAY-92
2/19/1992 02-MAR-92
10/22/1992 18-FEB-93
5/13/1992 28-MAY-92
3/10/1992 01-APR-92
11/11/1991 05-DEC-91
11/11/1991 10-FEB-92
7/29/1992 24-AUG-92
3/12/1992 01-JUN-92
5/21/1992 05-JUN-92
8/2/1992 12-OCT-92

4/8/1992 24-SEP-92
 11/23/1992 22-FEB-93
 8/14/1992 31-MAR-93
 2/18/1992 24-MAR-92
 11/13/1992 04-DEC-92
 9/3/1992 14-SEP-92
 10/23/1992 04-NOV-92
 8/7/1992 22-AUG-92
 4/14/1992 31-JUL-92
 10/14/1992 02-FEB-93
 10/28/1992 05-NOV-92
 4/22/1992 18-JAN-93
 6/18/1992 11-FEB-93
 9/11/1992 10-NOV-92
 8/19/1992 28-AUG-92
 8/30/1992 06-AUG-92
 8/8/1992 02-SEP-92
 7/15/1992 24-JAN-93
 7/28/1992 02-SEP-92
 10/21/1992 04-DEC-92
 8/5/1992 11-JUL-92
 9/22/1992 15-OCT-92
 2/11/1992 28-FEB-92
 11/19/1992 08-DEC-92
 3/17/1992 04-JUN-92
 7/27/1992 31-DEC-92
 6/22/1992 10-JUN-92
 11/22/1991 18-DEC-91
 9/29/1992 03-SEP-92
 4/8/1992 11-APR-92
 5/18/1992 17-JUL-92
 8/4/1992 10-SEP-92
 1/22/1992 31-JAN-92
 6/4/1992 22-MAY-92
 7/22/1992 21-SEP-92
 12/13/1991 07-JAN-92
 11/30/1992 29-JAN-93
 8/18/1992 05-JUN-93
 8/27/1992 04-SEP-92
 9/14/1992 07-MAY-93
 1/23/1992 03-MAR-92
 8/30/1992 15-JUL-92
 2/20/1992 09-MAR-92
 7/7/1992 20-JAN-93
 5/1/1992 21-MAY-92
 4/3/1992 25-JUL-92

2002-028 11500

4/2/1992 14-APR-92
 6/18/1992 16-SEP-92
 10/30/1992 18-JAN-93
 7/8/1992 24-JUL-92
 6/4/1992 16-JUN-92
 3/5/1992 23-JUN-92
 6/27/1992 29-JUN-92
 7/29/1992 11-SEP-92
 10/30/1992 20-FEB-93
 9/24/1992 09-NOV-92
 9/25/1992 15-MAY-93
 7/10/1992 26-JUL-92
 3/4/1992 09-MAY-92
 12/2/1991 31-JAN-92
 6/2/1992 18-JUN-92
 10/30/1992 01-DEC-92
 6/25/1992 05-SEP-92
 7/7/1992 16-OCT-92
 10/20/1992 21-JAN-93
 3/9/1992 18-MAR-92
 9/1/1992 27-OCT-92
 4/8/1992 10-JUL-92
 10/12/1992 28-OCT-92
 3/9/1992 20-MAR-92
 9/23/1992 22-JUL-93
 6/18/1992 30-JUL-92
 2/26/1992 06-MAR-92
 10/27/1992 08-DEC-92
 7/29/1992 12-SEP-92
 3/3/1992 21-MAR-92
 9/29/1992 23-JUL-93
 3/2/1992 17-MAR-92
 6/5/1992 06-JUL-92
 5/13/1992 29-MAY-92
 8/13/1992 22-DEC-92
 11/18/1992 04-DEC-92
 2/20/1992 03-APR-92
 5/19/1992 04-JUN-92
 6/19/1992 08-JUL-92
 8/13/1992 27-SEP-92
 6/10/1992 20-OCT-92
 4/15/1992 18-JUN-92
 2/20/1992 28-AUG-92
 6/7/1992 28-AUG-92
 6/5/1992 25-SEP-92
 10/14/1992 06-FEB-93

3/17/1992 13-JUN-92
11/19/1992 08-DEC-92
6/15/1992 14-SEP-92
6/8/1992 24-JUN-92
7/7/1992 03-AUG-92
11/20/1991 10-DEC-91
11/20/1991 03-DEC-91
4/16/1992 04-MAY-92
6/10/1992 25-JUN-92
12/10/1991 15-JAN-92
7/31/1992 29-AUG-92
8/3/1992 09-OCT-92
8/30/1992 24-APR-93
6/25/1992 04-AUG-92
3/17/1992 10-JUL-92
2/24/1992 10-MAR-92
10/18/1992 04-NOV-92
6/10/1992 07-AUG-92
11/22/1991 24-DEC-91
11/10/1992 28-NOV-92
8/5/1992 21-JUL-92
2/5/1992 28-FEB-92
11/28/1992 30-JAN-93
4/30/1992 26-MAY-92
12/13/1991 04-JAN-92
8/25/1992 25-AUG-92
3/4/1992 25-MAR-92
5/1/1992 06-JUN-92
11/12/1992 01-MAY-93
7/1/1992 21-SEP-92
6/30/1992 19-JUL-92
6/12/1992 30-JUN-92
6/26/1992 11-JUN-92
6/16/1992 31-JUL-92
11/13/1992 01-DEC-92
10/28/1992 09-NOV-92
5/1/1992 08-OCT-92
10/13/1992 29-OCT-92
7/6/1992 08-AUG-92
11/11/1992 08-MAR-93
5/22/1992 06-JUN-92
6/18/1992 10-JUL-92
3/31/1992 01-OCT-92
11/20/1992 28-JUN-93
2/5/1992 12-JUL-92
8/25/1992 30-JAN-93

7/9/1992 30-JUL-92
 3/8/1992 25-MAR-92
 12/18/1991 05-JAN-92
 4/23/1992 25-SEP-92
 9/22/1992 27-NOV-92
 4/1/1992 17-APR-92
 11/11/1991 22-JAN-92
 8/19/1992 07-JAN-93
 12/20/1991 04-JAN-92
 7/7/1992 10-APR-93
 11/20/1992 07-DEC-92
 4/30/1992 20-JUN-92
 8/5/1992 30-SEP-92
 5/5/1992 29-MAY-92
 10/9/1992 27-OCT-92
 3/17/1992 19-MAY-92
 10/28/1992 14-NOV-92
 11/13/1992 01-FEB-93
 9/1/1992 21-NOV-92
 7/30/1992 31-OCT-92
 8/21/1992 14-DEC-92
 8/14/1992 21-OCT-92
 8/11/1992 31-OCT-92
 7/31/1992 15-AUG-92
 2/7/1992 25-APR-92
 11/18/1992 04-DEC-92
 8/18/1992 22-DEC-92
 3/11/1992 27-MAR-92
 10/1/1992 08-DEC-92
 2/26/1992 14-MAR-92
 8/18/1992 08-JUL-92
 11/3/1992 19-NOV-92
 11/19/1992 30-APR-93
 8/13/1992 19-SEP-92
 8/12/1992 09-APR-93
 8/19/1992 30-SEP-92
 8/4/1992 24-SEP-92
 11/19/1992 07-DEC-92
 4/2/1992 22-MAY-92
 4/24/1992 12-MAY-92
 10/28/1992 14-DEC-92
 8/28/1992 15-SEP-92
 8/24/1992 18-SEP-92
 3/18/1992 01-APR-92
 8/22/1992 10-AUG-92
 4/30/1992 16-MAY-92

8/7/1992 16-SEP-92
4/23/1992 20-JUL-92
11/4/1992 16-NOV-92
10/22/1992 07-NOV-92
8/28/1992 31-JUL-92
6/30/1992 17-JUL-92
5/28/1992 28-OCT-92
10/20/1992 05-NOV-92
10/18/1992 06-DEC-92
11/24/1992 10-DEC-92
11/8/1992 22-NOV-92
3/13/1992 31-MAR-92
6/15/1992 30-SEP-92
3/23/1992 15-APR-92
8/17/1992 08-OCT-92
8/24/1992 17-FEB-93
10/14/1992 04-NOV-92
10/27/1992 27-MAY-93
10/18/1992 30-OCT-92
6/11/1992 21-SEP-92
3/8/1992 11-SEP-92
8/28/1992 11-NOV-92
11/10/1992 19-JAN-93
5/5/1992 24-MAY-92
12/10/1991 31-DEC-91
8/25/1992 14-OCT-92
4/3/1992 23-APR-92
3/31/1992 08-JUN-92
11/23/1992 08-DEC-92
10/16/1992 28-JAN-93
8/25/1992 18-DEC-92
8/8/1992 20-AUG-92
4/7/1992 22-MAY-92
3/19/1992 08-APR-92
4/3/1992 23-JUL-92
2/18/1992 02-MAR-92
12/4/1991 08-APR-92
6/4/1992 19-JUN-92
3/10/1992 08-JUN-92
4/23/1992 30-AUG-92
5/8/1992 28-MAY-92
2/28/1992 18-MAR-92
5/29/1992 13-JUN-92
5/28/1992 12-JUN-92
3/20/1992 05-JUN-92
11/17/1992 15-DEC-92

8/5/1992 23-AUG-92
 9/14/1992 05-NOV-93
 3/24/1992 20-MAY-92
 10/2/1992 28-NOV-92
 8/10/1992 01-DEC-92
 12/5/1991 18-FEB-92
 12/8/1991 26-DEC-91
 11/17/1992 03-DEC-92
 8/17/1992 27-AUG-93
 4/15/1992 22-MAY-92
 2/20/1992 03-MAR-92
 11/19/1991 05-FEB-92
 5/29/1992 13-JUN-92
 4/14/1992 12-AUG-92
 6/15/1992 28-JUL-92
 11/22/1991 14-APR-92
 10/23/1992 05-NOV-92
 1/24/1992 23-MAY-92
 5/13/1992 29-JUN-92
 2/11/1992 27-MAR-92
 9/28/1992 07-OCT-92
 8/24/1992 07-AUG-93
 6/2/1992 17-JUN-92
 9/10/1992 28-SEP-92
 11/23/1992 01-DEC-92
 5/22/1992 10-JUN-92
 4/30/1992 18-MAY-92
 12/13/1991 08-JAN-92
 8/24/1992 30-DEC-92
 10/18/1992 31-MAY-93
 6/24/1992 10-AUG-92
 8/4/1992 08-DEC-92
 6/2/1992 03-SEP-92
 11/12/1992 04-FEB-93
 7/2/1992 31-AUG-92
 4/23/1992 20-JUL-92
 4/27/1992 01-JUL-92
 12/18/1991 01-JAN-92
 3/25/1992 10-APR-92
 2/24/1992 25-APR-92
 5/27/1992 11-JUN-92
 2/28/1992 22-JUN-92
 7/16/1992 11-SEP-92
 12/2/1991 31-DEC-91
 3/3/1992 17-APR-92
 2/28/1992 11-MAR-92

6/1/1992 31-AUG-92
3/27/1992 27-APR-92
5/29/1992 16-JUN-92
12/20/1991 04-JAN-92
10/8/1992 22-SEP-92
8/8/1992 10-JUL-92
6/24/1992 11-JUL-92
6/1/1992 17-JUN-92
2/25/1992 17-OCT-92
6/3/1992 16-JUN-92
11/30/1992 15-DEC-92
3/11/1992 08-MAY-92
12/20/1991 02-FEB-92
11/11/1991 30-NOV-91
7/10/1992 08-SEP-92
4/7/1992 02-JUN-92
3/11/1992 12-JUN-92
8/26/1992 14-JUN-93
6/16/1992 24-AUG-92
10/1/1992 28-OCT-92
12/5/1991 03-MAR-92
4/6/1992 04-MAY-92
11/18/1991 10-DEC-91
11/27/1991 28-MAR-92
6/22/1992 17-OCT-92
6/25/1992 19-SEP-92
1/17/1992 08-FEB-92
7/7/1992 18-SEP-92
4/23/1992 25-JUN-92
7/14/1992 30-JUL-92
7/23/1992 22-SEP-92
4/3/1992 05-SEP-92
6/21/1992 15-SEP-92
5/20/1992 05-JUN-92
6/9/1992 26-SEP-92
6/19/1992 04-JUN-92
6/19/1992 04-JUN-92
3/5/1992 10-MAR-92
2/25/1992 20-JUN-92
2/24/1992 09-MAR-92
11/20/1992 06-DEC-92
4/7/1992 15-JUN-92
3/26/1992 23-MAY-92
10/21/1992 23-JUN-93
10/2/1992 20-NOV-92
9/11/1992 31-DEC-92

6/3/1992 18-JUN-92
6/16/1992 19-SEP-92
5/22/1992 12-JUN-92
11/26/1991 27-DEC-91
3/24/1992 29-MAY-92
10/18/1992 09-NOV-92
5/4/1992 19-MAY-92
2/28/1992 26-MAR-92
8/7/1992 10-MAR-93
2/19/1992 04-MAR-92
6/15/1992 30-SEP-92
11/8/1992 24-NOV-92
5/5/1992 28-SEP-92
8/7/1992 31-DEC-92
8/17/1992 16-JUL-92
0/10/1992 02-JUL-92
4/1/1992 15-APR-92
11/12/1992 23-MAR-93
8/22/1992 11-JUL-92
11/30/1992 11-DEC-92
4/8/1992 10-JUL-92
8/25/1992 12-JUL-92
9/24/1992 18-DEC-92
8/11/1992 30-SEP-92
11/30/1992 15-DEC-92
4/2/1992 30-SEP-92
5/13/1992 29-MAY-92
8/10/1992 28-AUG-92
11/12/1992 19-NOV-92
3/26/1992 08-APR-92
9/8/1992 27-SEP-92
3/8/1992 01-MAY-92
7/17/1992 27-FEB-93
11/18/1992 03-DEC-92
9/21/1992 07-OCT-92
7/30/1992 15-SEP-92
10/1/1992 20-OCT-92
11/11/1992 21-DEC-92
8/11/1992 09-NOV-92
8/11/1992 27-JUN-92
3/8/1992 22-MAR-92
2/12/1992 12-MAR-92
8/8/1992 21-AUG-92
8/8/1992 21-AUG-92
8/2/1992 18-SEP-92
7/15/1992 31-JUL-92

8/12/1992 08-SEP-92
 3/13/1992 30-JUN-92
 8/13/1992 01-FEB-93
 10/19/1992 11-NOV-92
 10/23/1992 03-JUN-93
 9/10/1992 25-JUN-92
 8/25/1992 24-OCT-92
 8/18/1992 05-JUN-92
 8/21/1992 25-JUL-93
 2/10/1992 29-FEB-92
 4/15/1992 14-MAY-92
 8/26/1992 22-JAN-93
 10/30/1992 23-JUN-93
 8/4/1992 18-DEC-92
 8/11/1992 30-SEP-92
 10/20/1992 08-NOV-92
 2/28/1992 10-AUG-92
 2/21/1992 09-MAR-92
 4/7/1992 04-MAY-92
 9/11/1992 01-OCT-92
 11/12/1992 08-JAN-93
 11/25/1992 24-DEC-92
 10/14/1992 18-DEC-92
 6/16/1992 11-AUG-92
 11/9/1992 25-NOV-92
 11/17/1992 22-MAR-93
 1/23/1992 25-FEB-92
 5/28/1992 13-JUN-92
 7/22/1992 23-DEC-92
 6/9/1992 28-SEP-92
 7/10/1992 31-JUL-92
 5/25/1992 17-JUN-92
 3/5/1992 22-MAY-92
 12/3/1991 31-DEC-91
 10/23/1992 17-MAR-93
 10/27/1992 25-NOV-92
 9/23/1992 12-OCT-92
 5/8/1992 08-JUN-92
 4/30/1992 13-MAY-92
 2/24/1992 03-MAR-92
 2/24/1992 11-MAR-92
 8/25/1992 23-JUL-92
 9/28/1992 04-NOV-93
 3/5/1992 12-SEP-92
 8/24/1992 09-JUL-92
 1/13/1992 09-FEB-92

5/12/1992 12-AUG-92
 12/19/1991 21-FEB-92
 6/23/1992 24-JUL-92
 2/25/1992 03-MAR-92
 5/20/1992 01-JUN-92
 11/20/1992 10-JUN-93
 3/25/1992 29-MAY-92
 4/15/1992 23-APR-92
 3/10/1992 29-MAR-92
 7/29/1992 12-AUG-92
 7/29/1992 13-AUG-92
 4/1/1992 18-APR-92
 6/22/1992 08-JUL-92
 6/12/1992 13-JUL-92
 9/15/1992 22-OCT-92
 9/24/1992 05-OCT-92
 10/22/1992 31-DEC-92
 2/20/1992 15-MAR-92
 6/8/1992 23-JUN-92
 11/3/1992 16-DEC-92
 6/16/1992 15-JUL-92
 9/17/1992 09-OCT-92
 9/24/1992 05-MAY-93
 8/18/1992 10-MAR-93
 7/8/1992 24-SEP-92
 3/31/1992 18-OCT-92
 5/21/1992 29-MAY-92
 2/27/1992 15-MAR-92
 11/27/1992 14-DEC-92
 4/18/1992 18-MAY-92
 6/21/1992 15-SEP-92
 6/20/1992 13-NOV-92
 2/14/1992 04-MAR-92
 6/8/1992 06-JUL-92
 3/16/1992 15-APR-92
 11/23/1992 09-DEC-92
 9/14/1992 29-SEP-92
 2/21/1992 10-MAR-92
 6/2/1992 07-SEP-92
 3/2/1992 24-MAR-92
 10/21/1992 31-DEC-92
 9/17/1992 01-OCT-92
 2/28/1992 04-MAR-92
 5/27/1992 12-SEP-92
 4/30/1992 30-MAY-92
 7/1/1992 28-SEP-92

6/17/1992 20-JUL-92
3/27/1992 21-APR-92
10/22/1992 17-JUN-93
9/21/1992 08-OCT-92
6/16/1992 08-JUL-92
11/6/1992 23-NOV-92
5/5/1992 07-JUL-92
2/3/1992 28-FEB-92
3/18/1992 08-APR-92
7/27/1992 22-SEP-92
11/10/1992 26-NOV-92
10/16/1992 28-JAN-93
9/25/1992 17-NOV-92
2/28/1992 21-SEP-92
12/3/1991 28-JAN-92
4/18/1992 07-MAY-92
12/8/1991 27-JAN-92
11/2/1992 28-JAN-93
10/8/1992 24-OCT-92
3/3/1992 19-MAY-92
4/7/1992 22-APR-92
11/19/1992 19-JAN-93
11/25/1992 07-APR-93
7/27/1992 11-AUG-92
10/30/1992 29-NOV-92
1/16/1992 28-JAN-92
12/6/1991 08-JAN-92
8/4/1992 01-SEP-92
11/27/1991 28-DEC-91
7/29/1992 22-SEP-92
10/20/1992 03-NOV-92
9/8/1992 10-JUN-93
12/9/1991 11-FEB-92
9/28/1992 17-DEC-92
6/17/1992 30-JUN-92
6/9/1992 24-JUN-92
6/9/1992 13-OCT-92
2/29/1992 28-MAR-92
6/8/1992 24-JUN-92
5/21/1992 22-JUL-92
3/12/1992 25-MAR-92
2/19/1992 13-SEP-92
9/16/1992 12-FEB-93
2/28/1992 02-JUN-92
5/4/1992 18-MAY-92
7/28/1992 22-AUG-92

4/24/1992 17-JUL-92
 6/7/1992 06-APR-94
 6/8/1992 12-NOV-92
 5/20/1992 20-JUN-92
 8/4/1992 22-AUG-92
 4/23/1992 08-MAY-92
 7/1/1992 16-JUL-92
 2/10/1992 23-MAR-92
 3/19/1992 07-APR-92
 11/16/1992 17-DEC-92
 3/23/1992 06-APR-92
 8/24/1992 29-OCT-92
 9/30/1992 06-MAY-93
 9/21/1992 18-MAY-93
 8/4/1992 31-JUL-92
 12/10/1991 29-DEC-91
 9/18/1992 28-MAR-93
 5/18/1992 01-JUN-92
 11/11/1992 18-MAR-93
 8/11/1992 02-NOV-92
 9/2/1992 17-MAR-92
 9/28/1992 15-OCT-92
 5/22/1992 10-JUN-92
 5/18/1992 15-JUN-92
 11/19/1992 09-DEC-92
 4/3/1992 17-JUN-92
 10/21/1992 06-NOV-92
 4/8/1992 00-JUN-92
 2/20/1992 08-MAR-92
 4/28/1992 23-MAY-92
 5/4/1992 20-MAY-92
 9/28/1992 20-OCT-92
 3/24/1992 02-SEP-92
 10/20/1992 11-NOV-92
 9/15/1992 17-DEC-92
 9/15/1992 02-DEC-92
 2/17/1992 02-MAR-92
 5/22/1992 11-JUN-92
 11/24/1992 20-MAY-93
 4/10/1992 28-APR-92
 4/30/1992 14-MAY-92
 5/1/1992 15-AUG-92
 5/1/1992 08-OCT-92
 10/26/1992 07-NOV-92
 5/7/1992 28-JUN-92
 9/23/1992 28-MAY-93

11/17/1992 30-JAN-93
 12/17/1991 28-FEB-92
 7/24/1992 02-SEP-92
 4/2/1992 14-APR-92
 8/17/1992 22-SEP-93
 3/30/1992 08-JUN-92
 5/28/1992 30-NOV-92
 8/22/1992 08-JUL-92
 5/28/1992 09-JUN-92
 5/28/1992 16-SEP-92
 8/13/1992 07-DEC-92
 8/17/1992 10-AUG-92
 12/19/1991 08-JAN-92
 7/24/1992 19-AUG-92
 5/8/1992 13-JUN-92
 8/13/1992 18-NOV-92
 2/28/1992 12-MAR-92
 8/25/1992 11-JUL-92
 7/27/1992 31-AUG-92
 11/13/1992 12-JUL-93
 8/2/1992 22-SEP-92
 10/9/1992 23-OCT-92
 8/24/1992 09-JUL-92
 10/30/1992 18-DEC-92
 4/14/1992 29-APR-92
 11/27/1992 17-DEC-92
 9/2/1992 17-SEP-92
 10/20/1992 07-NOV-92
 9/3/1992 09-NOV-92
 11/30/1992 09-DEC-92
 5/19/1992 21-SEP-92
 11/12/1992 30-APR-93
 8/17/1992 23-JUL-92
 5/29/1992 20-AUG-92
 2/20/1992 18-OCT-92
 8/8/1992 25-AUG-92
 5/22/1992 06-JUN-92
 8/10/1992 16-OCT-92
 8/5/1992 25-SEP-92
 10/13/1992 14-NOV-92
 4/14/1992 30-APR-92
 8/8/1992 25-JUN-92
 8/15/1992 02-AUG-92
 8/8/1992 27-AUG-92
 8/10/1992 26-JUN-92
 5/28/1992 18-DEC-92

4/22/1992 21-OCT-92
10/29/1992 03-JAN-94
5/21/1992 06-JUN-92
4/14/1992 27-APR-92
8/24/1992 23-AUG-93
11/27/1992 09-DEC-92
10/19/1992 04-NOV-92
8/28/1992 28-SEP-92
2/25/1992 09-SEP-92
11/26/1992 15-DEC-92
8/24/1992 15-SEP-92
10/23/1992 08-NOV-92
12/17/1991 24-DEC-91
9/29/1992 29-SEP-92
9/14/1992 17-MAY-93
11/12/1992 29-MAR-93
5/4/1992 21-MAY-92
6/18/1992 13-JUL-92
8/8/1992 25-JUL-92
5/7/1992 28-MAY-92
9/15/1992 05-OCT-92
9/22/1992 04-DEC-92
12/19/1991 29-MAY-92
8/1/1992 13-OCT-92
3/31/1992 31-AUG-92
9/18/1992 07-OCT-92
4/2/1992 23-APR-92
3/9/1992 18-SEP-92
10/30/1992 30-NOV-92
11/20/1992 04-DEC-92
8/5/1992 07-OCT-92
11/12/1992 11-JUN-93
10/29/1992 15-NOV-92
9/29/1992 06-OCT-92
11/19/1992 18-MAY-93
7/13/1992 30-JUL-92
9/18/1992 12-OCT-92
5/7/1992 12-JUN-92
4/10/1992 07-AUG-92
7/20/1992 05-FEB-93
3/3/1992 31-JUL-92
8/11/1992 15-JUL-92
9/9/1992 09-DEC-92
3/23/1992 27-JUN-92
3/25/1992 28-MAY-92
8/13/1992 05-NOV-92

4/21/1992 12-SEP-92
 11/16/1992 28-JAN-93
 11/11/1992 12-JAN-93
 3/25/1992 08-OCT-92
 2/18/1992 01-APR-92
 6/19/1992 29-OCT-92
 8/15/1992 20-AUG-92
 8/22/1992 21-NOV-92
 10/1/1992 18-NOV-92
 9/2/1992 16-SEP-92
 8/14/1992 01-SEP-92
 11/18/1992 21-OCT-93
 8/11/1992 20-OCT-92
 8/18/1992 29-SEP-92
 3/19/1992 17-JUN-92
 10/30/1992 20-JAN-93
 8/18/1992 27-DEC-92
 9/8/1992 25-AUG-93
 8/23/1992 08-JUL-92
 8/8/1992 22-SEP-92
 8/5/1992 18-AUG-92
 4/13/1992 29-APR-92
 12/12/1991 10-JAN-92
 8/24/1992 01-DEC-92
 7/1/1992 16-JUL-92
 3/24/1992 30-APR-92
 4/8/1992 20-OCT-92
 6/1/1992 19-MAY-92
 11/24/1992 10-DEC-92
 10/27/1992 10-NOV-92
 8/17/1992 21-DEC-92
 8/12/1992 26-JUN-92
 8/31/1992 15-SEP-92
 9/2/1992 26-MAR-93
 3/5/1992 04-APR-92
 11/8/1992 17-MAR-93
 3/20/1992 30-APR-92
 8/31/1992 08-OCT-93
 11/27/1992 12-DEC-92
 8/3/1992 18-JUN-92
 7/7/1992 26-AUG-92
 3/24/1992 01-JUL-92
 1/13/1992 31-JAN-92
 10/15/1992 24-OCT-92
 8/20/1992 21-SEP-92
 8/8/1992 03-SEP-92

6/22/1992 07-JUL-92
 10/18/1992 04-NOV-92
 4/15/1992 25-MAY-92
 7/16/1992 31-JUL-92
 6/18/1992 23-AUG-92
 5/18/1992 23-SEP-92
 7/28/1992 12-AUG-92
 10/13/1992 25-FEB-93
 11/19/1991 05-DEC-91
 1/15/1992 21-SEP-92
 6/12/1992 01-JUL-92
 2/19/1992 15-JUL-92
 6/11/1992 30-JUN-92
 4/10/1992 05-MAY-92
 3/8/1992 20-MAR-92
 11/2/1992 17-NOV-92
 9/28/1992 13-OCT-92
 9/8/1992 30-NOV-92
 8/3/1992 24-JUL-92
 8/20/1992 28-JAN-94
 2/12/1992 02-MAR-92
 5/20/1992 20-JUN-92
 9/14/1992 30-NOV-92
 9/28/1992 15-OCT-92
 3/5/1992 31-MAR-92
 2/28/1992 01-MAY-92
 12/10/1991 15-JAN-92
 10/14/1992 30-JAN-93
 3/23/1992 08-APR-92
 9/21/1992 05-AUG-93
 11/24/1992 14-NOV-92
 9/29/1992 23-FEB-93
 3/5/1992 16-MAR-92
 6/20/1992 21-SEP-92
 5/19/1992 13-JUL-92
 2/13/1992 02-MAR-92
 11/25/1992 30-JAN-93
 9/1/1992 30-APR-94
 11/25/1992 23-DEC-92
 6/18/1992 28-SEP-92
 10/2/1992 16-OCT-92
 8/31/1992 17-OCT-92
 5/23/1992 22-JUN-92
 11/24/1992 16-DEC-92
 4/7/1992 24-APR-92
 8/10/1992 21-SEP-92

11/17/1992 15-DEC-92
 5/29/1992 13-JUN-92
 11/10/1992 21-DEC-92
 3/4/1992 10-SEP-92
 5/8/1992 15-JAN-93
 5/29/1992 22-JUL-92
 8/17/1992 05-APR-93
 8/19/1992 20-AUG-92
 4/10/1992 03-JUN-92
 3/4/1992 12-AUG-92
 7/5/1992 21-JUL-92
 2/28/1992 03-APR-92
 5/14/1992 28-SEP-92
 12/19/1991 25-JAN-92
 8/13/1992 18-JAN-93
 9/29/1992 29-OCT-92
 5/14/1992 29-MAY-92
 5/1/1992 08-JUL-92
 11/11/1991 03-NOV-92
 1/13/1992 08-FEB-92
 5/25/1992 30-JUN-92
 3/11/1992 19-OCT-92
 3/21/1992 18-MAR-92
 3/18/1992 22-MAY-92
 8/22/1992 13-AUG-92
 10/14/1992 29-OCT-92
 8/3/1992 05-SEP-92
 8/13/1992 01-SEP-92
 10/14/1992 29-DEC-92
 8/8/1992 23-JUN-92
 1/17/1992 09-FEB-92
 6/10/1992 29-SEP-92
 8/18/1992 29-SEP-92
 4/22/1992 07-AUG-92
 4/24/1992 02-SEP-92
 3/23/1992 07-APR-92
 4/11/1992 24-JUN-92
 4/21/1992 12-JUN-92
 10/23/1992 19-JUL-93
 5/29/1992 13-JUN-92
 3/19/1992 24-SEP-92
 10/16/1992 01-NOV-92
 11/22/1991 09-APR-92
 8/24/1992 06-OCT-92
 2/21/1992 23-JUL-92
 10/16/1992 19-JUN-93

11/10/1992 27-NOV-92
 12/12/1991 05-FEB-92
 10/2/1992 21-OCT-92
 5/22/1992 14-AUG-92
 5/22/1992 17-JUN-92
 6/9/1992 03-NOV-92
 10/23/1992 08-NOV-92
 11/27/1991 21-MAR-92
 9/15/1992 05-OCT-92
 2/26/1992 17-JUN-92
 10/7/1992 18-DEC-92
 11/27/1991 04-FEB-92
 11/5/1992 20-MAR-93
 3/5/1992 01-APR-92
 11/18/1992 13-AUG-93
 3/30/1992 15-JUN-92
 10/2/1992 21-OCT-92
 8/7/1992 30-SEP-92
 4/10/1992 28-APR-92
 7/18/1992 10-AUG-92
 7/7/1992 20-AUG-92
 2/28/1992 31-JUL-92
 11/9/1992 01-DEC-92
 10/13/1992 29-OCT-92
 3/9/1992 10-JUL-92
 3/17/1992 19-MAY-92
 2/4/1992 24-AUG-92
 9/12/1992 18-AUG-92
 7/24/1992 11-AUG-92
 7/27/1992 12-AUG-92
 9/17/1992 06-OCT-92
 3/13/1992 31-MAR-92
 1/13/1992 31-JAN-92
 9/8/1992 24-SEP-92
 9/29/1992 29-JUL-92
 4/3/1992 27-AUG-92
 12/3/1991 15-JAN-92
 10/14/1992 04-NOV-92
 7/10/1992 11-AUG-92
 3/9/1992 31-MAR-92
 5/14/1992 23-MAY-92
 11/11/1991 30-NOV-91
 5/21/1992 29-SEP-92
 11/16/1991 07-DEC-91
 8/5/1992 12-NOV-93
 7/31/1992 15-AUG-92

7/20/1992 31-JUL-92
2/13/1992 29-APR-92
4/16/1992 21-NOV-92
3/24/1992 15-APR-92
11/4/1992 08-AUG-93
8/3/1992 19-NOV-92
7/14/1992 31-JUL-92
2/10/1992 05-MAR-92
6/10/1992 22-JUL-92
9/28/1992 30-OCT-92
7/18/1992 31-JUL-92
11/22/1991 13-DEC-91
10/23/1992 10-DEC-92
11/18/1992 29-MAY-93
9/10/1992 12-OCT-92
4/24/1992 28-SEP-92
10/27/1992 11-NOV-92
9/28/1992 08-JUL-92
3/23/1992 08-APR-92
4/28/1992 28-NOV-92
6/28/1992 29-JUL-92
8/20/1992 14-NOV-92
6/23/1992 14-JUL-92
8/24/1992 01-MAY-93
6/10/1992 25-JUN-92
8/6/1992 15-SEP-92
8/31/1992 13-AUG-93
8/28/1992 24-MAY-93
8/18/1992 28-JAN-93
7/23/1992 29-AUG-92
9/18/1992 23-DEC-92
10/2/1992 17-OCT-92
6/25/1992 22-SEP-92
11/13/1992 07-DEC-92
9/16/1992 24-JUN-93
7/10/1992 27-JUL-92
6/26/1992 21-SEP-92
3/6/1992 31-MAR-92
10/19/1992 30-OCT-92
7/18/1992 10-SEP-92
6/28/1992 08-AUG-92
1/24/1992 13-FEB-92
4/6/1992 21-APR-92
8/10/1992 28-AUG-92
3/3/1992 27-JUL-92
2/28/1992 30-APR-92

10/21/1992 08-FEB-93
 6/4/1992 20-JUN-92
 4/9/1992 25-AUG-92
 4/23/1992 08-JUN-92
 12/2/1991 18-DEC-91
 8/27/1992 04-JAN-93
 7/28/1992 25-SEP-92
 6/11/1992 11-SEP-92
 8/25/1992 20-OCT-92
 7/9/1992 21-JUL-92
 8/13/1992 10-SEP-92
 3/12/1992 31-MAR-92
 9/9/1992 19-JUN-93
 2/28/1992 07-MAR-92
 7/14/1992 27-JUL-92
 3/9/1992 24-MAR-92
 9/21/1992 24-MAR-93
 8/19/1992 11-OCT-92
 11/10/1992 21-APR-93
 11/13/1992 01-DEC-92
 6/3/1992 31-JUL-92
 3/27/1992 02-JUN-92
 11/10/1992 25-NOV-92
 3/20/1992 23-APR-92
 8/6/1992 21-SEP-92
 7/22/1992 05-AUG-92
 10/12/1992 28-OCT-92
 4/18/1992 29-JUL-92
 10/13/1992 15-JAN-93
 9/16/1992 07-MAR-93
 4/18/1992 25-JUL-92
 8/10/1992 09-OCT-92
 3/16/1992 18-MAY-92
 7/30/1992 25-AUG-92
 4/28/1992 08-SEP-92
 4/1/1992 08-OCT-92
 4/27/1992 18-MAY-92
 3/23/1992 31-MAR-92
 11/17/1992 10-MAR-93
 7/2/1992 17-JUL-92
 7/30/1992 31-AUG-92
 7/14/1992 02-SEP-92
 5/19/1992 04-JUN-92
 10/23/1992 22-FEB-93
 11/10/1992 01-JUN-93
 5/21/1992 05-JUN-92

5/22/1992 10-JUN-92
 3/18/1992 15-OCT-92
 9/23/1992 18-MAY-93
 3/18/1992 12-OCT-92
 3/25/1992 09-OCT-92
 5/11/1992 28-AUG-92
 2/21/1992 25-MAR-92
 2/21/1992 09-MAR-92
 4/28/1992 27-MAY-92
 6/18/1992 07-JUL-92
 2/7/1992 02-MAR-92
 6/28/1992 08-JUL-92
 8/5/1992 19-AUG-92
 4/28/1992 12-JUN-92
 3/25/1992 22-APR-92
 6/25/1992 06-OCT-92
 6/3/1992 02-SEP-92
 9/18/1992 06-OCT-92
 1/24/1992 22-JUN-92
 10/28/1992 07-NOV-92
 10/28/1992 04-NOV-92
 9/23/1992 30-OCT-92
 7/30/1992 28-AUG-92
 8/24/1992 11-JUL-92
 3/18/1992 30-APR-92
 7/5/1992 13-AUG-92
 10/28/1992 21-NOV-92
 11/13/1992 21-DEC-92
 12/3/1991 20-DEC-91
 11/13/1992 28-DEC-92
 4/8/1992 10-JUN-92
 6/18/1992 31-JUL-92
 4/13/1992 29-APR-92
 9/11/1992 10-OCT-92
 2/5/1992 21-FEB-92
 3/16/1992 20-MAR-92
 3/17/1992 18-OCT-92
 4/18/1992 08-MAY-92
 11/18/1991 22-FEB-92
 8/1/1992 15-SEP-92
 11/21/1991 25-MAR-92
 10/28/1992 11-JUN-93
 10/18/1992 30-NOV-92
 9/23/1992 08-SEP-92
 3/10/1992 30-APR-92
 9/24/1992 17-SEP-93

11/19/1991 08-DEC-91
 10/28/1992 21-NOV-92
 6/10/1992 28-AUG-92
 8/18/1992 16-OCT-92
 10/12/1992 30-DEC-92
 6/9/1992 10-AUG-92
 10/14/1992 28-OCT-92
 4/21/1992 28-APR-92
 8/5/1992 07-NOV-92
 8/7/1992 12-SEP-92
 8/4/1992 01-SEP-92
 2/10/1992 29-FEB-92
 3/31/1992 02-MAY-92
 9/25/1992 18-OCT-92
 8/10/1992 30-AUG-92
 6/11/1992 29-JUN-92
 11/21/1991 13-DEC-91
 2/4/1992 25-FEB-92
 11/30/1992 11-DEC-92
 5/20/1992 06-JUN-92
 2/28/1992 23-MAR-92
 4/3/1992 22-MAY-92
 4/29/1992 14-MAY-92
 2/12/1992 29-FEB-92
 8/27/1992 10-SEP-92
 8/5/1992 14-JUN-93
 4/29/1992 21-MAY-92
 5/1/1992 18-MAY-92
 11/3/1992 28-NOV-92
 11/24/1992 03-DEC-92
 3/6/1992 18-MAR-92
 10/7/1992 22-OCT-92
 2/17/1992 08-MAR-92
 6/12/1992 07-JUL-92
 11/27/1991 15-DEC-91
 12/17/1991 01-JAN-92
 9/18/1992 02-OCT-92
 11/25/1991 04-FEB-92
 11/8/1992 22-NOV-92
 3/3/1992 02-JUL-92
 5/6/1992 28-JUN-92
 8/7/1992 08-SEP-92
 11/25/1992 14-DEC-92
 8/24/1992 13-JUL-92
 5/25/1992 18-JUL-92
 6/24/1992 11-JUL-92

7/30/1992 29-AUG-92
 3/2/1992 01-APR-92
 6/3/1992 15-JUN-92
 3/27/1992 07-JUN-92
 12/18/1991 25-MAR-92
 8/14/1992 30-JAN-93
 7/16/1992 15-AUG-92
 1/18/1992 01-FEB-92
 1/13/1992 01-FEB-92
 10/9/1992 24-OCT-92
 12/20/1991 10-JAN-92
 8/22/1992 06-JUL-92
 3/31/1992 16-APR-92
 1/13/1992 19-JUN-92
 8/7/1992 05-NOV-92
 5/13/1992 02-JUN-92
 8/5/1992 24-SEP-92
 2/12/1992 02-MAR-92
 10/14/1992 28-NOV-92
 8/29/1992 23-OCT-92
 5/19/1992 05-JUN-92
 9/18/1992 30-OCT-92
 8/12/1992 01-OCT-92
 8/3/1992 17-SEP-92
 10/23/1992 05-NOV-92
 11/28/1991 07-FEB-92
 7/23/1992 09-SEP-92
 11/25/1991 27-DEC-91
 2/10/1992 29-JUN-92
 2/17/1992 05-MAR-92
 11/25/1992 16-DEC-92
 6/27/1992 13-JUN-92
 11/28/1991 23-DEC-91
 7/13/1992 13-AUG-92
 7/28/1992 19-SEP-92
 8/26/1992 07-SEP-92
 2/13/1992 18-MAY-92
 3/4/1992 25-SEP-92
 7/29/1992 15-SEP-92
 8/28/1992 12-OCT-92
 7/20/1992 31-JUL-92
 11/27/1991 11-DEC-91
 8/24/1992 13-JUL-92
 10/30/1992 21-MAY-93
 8/14/1992 27-NOV-92
 4/15/1992 23-MAY-92

10/29/1992 14-NOV-92
 11/20/1992 16-MAR-93
 6/2/1992 23-SEP-92
 8/19/1992 19-NOV-93
 7/28/1992 31-AUG-92
 9/3/1992 15-OCT-92
 5/13/1992 29-MAY-92
 5/13/1992 30-MAY-92
 11/13/1992 02-DEC-92
 11/13/1992 02-DEC-92
 10/16/1992 24-OCT-92
 7/21/1992 31-AUG-92
 4/2/1992 25-APR-92
 8/18/1992 18-JUL-93
 10/19/1992 30-JUL-93
 7/21/1992 12-AUG-92
 11/21/1991 20-DEC-91
 2/13/1992 29-FEB-92
 7/21/1992 08-SEP-92
 9/29/1992 20-DEC-92
 2/14/1992 24-FEB-92
 2/5/1992 30-APR-92
 4/8/1992 29-AUG-92
 3/6/1992 16-SEP-92
 10/6/1992 22-OCT-92
 3/3/1992 01-APR-92
 11/27/1991 09-JAN-92
 8/22/1992 08-JUL-92
 8/24/1992 13-JUL-92
 3/2/1992 29-MAR-92
 10/7/1992 19-NOV-92
 8/26/1992 28-AUG-92
 2/20/1992 03-MAR-92
 1/13/1992 01-FEB-92
 7/18/1992 14-SEP-92
 10/2/1992 20-JUL-93
 2/7/1992 28-FEB-92
 10/28/1992 17-NOV-92
 2/7/1992 24-FEB-92
 7/29/1992 13-AUG-92
 4/2/1992 04-SEP-92
 11/18/1992 04-DEC-92
 10/14/1992 05-APR-93
 8/9/1992 22-SEP-92
 8/10/1992 25-JUN-92
 2/11/1992 28-FEB-92

3/18/1992 04-JUN-92
 12/10/1991 31-DEC-91
 1/22/1992 18-FEB-92
 9/14/1992 04-NOV-92
 1/22/1992 27-FEB-92
 9/18/1992 05-OCT-92
 11/8/1992 21-NOV-92
 9/18/1992 05-OCT-92
 10/9/1992 13-NOV-92
 11/18/1991 11-MAR-92
 4/15/1992 30-APR-92
 2/18/1992 28-MAR-92
 11/21/1991 10-DEC-91
 11/3/1992 04-OCT-92
 7/21/1992 12-AUG-92
 4/3/1992 08-JUN-92
 6/11/1992 25-JUN-92
 6/18/1992 01-JUN-92
 9/11/1992 15-APR-93
 9/30/1992 16-DEC-92
 7/24/1992 24-AUG-92
 3/4/1992 27-MAR-92
 9/15/1992 14-OCT-92
 12/13/1991 02-JAN-92
 11/5/1992 12-MAR-93
 5/25/1992 14-MAY-93
 8/28/1992 24-SEP-92
 5/22/1992 09-JUN-92
 5/4/1992 19-MAY-92
 6/24/1992 13-JUL-92
 3/25/1992 02-MAY-92
 4/13/1992 29-APR-92
 4/13/1992 29-APR-92
 11/20/1991 31-JAN-92
 2/8/1992 23-FEB-92
 7/30/1992 16-SEP-92
 2/26/1992 05-MAR-92
 12/9/1991 08-FEB-92
 10/15/1992 28-DEC-92
 1/22/1992 30-JUN-92
 8/18/1992 09-SEP-92
 1/22/1992 18-MAY-92
 7/14/1992 28-AUG-92
 11/24/1992 15-DEC-92
 4/8/1992 29-JUL-92
 6/23/1992 11-JUL-92

11/25/1992 05-MAR-93
 11/20/1992 31-DEC-92
 9/2/1992 27-MAR-92
 11/5/1992 28-DEC-92
 1/24/1992 30-JUN-92
 8/27/1992 25-SEP-92
 5/29/1992 13-JUN-92
 8/15/1992 01-OCT-92
 3/12/1992 20-MAR-92
 3/18/1992 30-APR-92
 2/25/1992 15-MAR-92
 12/19/1991 01-JAN-92
 4/9/1992 02-SEP-92
 4/9/1992 02-MAY-92
 7/30/1992 27-AUG-92
 12/9/1991 15-JAN-92
 2/21/1992 25-APR-92
 10/5/1992 31-OCT-92
 8/5/1992 23-JUN-92
 8/31/1992 24-SEP-92
 12/20/1991 01-FEB-92
 4/15/1992 21-APR-92
 8/5/1992 22-SEP-92
 2/12/1992 28-AUG-92
 7/28/1992 19-NOV-92
 10/12/1992 29-OCT-92
 5/15/1992 02-JUN-92
 12/9/1991 17-MAR-92
 8/9/1992 14-JUL-92
 1/17/1992 11-FEB-92
 11/16/1992 01-FEB-93
 6/9/1992 24-JUN-92
 8/4/1992 06-SEP-92
 9/30/1992 23-OCT-92
 11/4/1992 11-JAN-93
 9/8/1992 24-SEP-92
 11/20/1991 06-DEC-91
 11/3/1992 28-JAN-93
 10/19/1992 04-NOV-92
 5/5/1992 23-JUL-92
 12/13/1991 08-JAN-92
 6/10/1992 28-OCT-92
 11/25/1992 16-DEC-92
 5/29/1992 13-JUN-92
 8/18/1992 04-NOV-92
 2/5/1992 28-FEB-92

8/27/1992 07-AUG-92
 10/7/1992 21-OCT-92
 12/18/1991 11-FEB-92
 10/12/1992 29-OCT-92
 4/1/1992 22-MAY-92
 2/10/1992 17-MAR-92
 6/9/1992 24-JUN-92
 1/21/1992 08-FEB-92
 1/22/1992 09-FEB-92
 8/8/1992 13-FEB-93
 4/28/1992 20-MAY-92
 4/28/1992 14-MAY-92
 5/18/1992 01-JUN-92
 8/28/1992 17-OCT-92
 11/21/1991 08-DEC-91
 10/22/1992 07-NOV-92
 8/19/1992 07-JUL-92
 7/14/1992 30-JUL-92
 11/28/1991 20-NOV-91
 3/19/1992 27-MAR-92
 12/18/1991 19-FEB-92
 5/5/1992 02-JUN-92
 2/26/1992 15-MAR-92
 7/27/1992 06-OCT-92
 7/28/1992 15-OCT-92
 10/7/1992 28-NOV-92
 10/7/1992 19-FEB-93
 8/14/1992 27-AUG-93
 6/23/1992 30-JUL-92
 2/5/1992 25-APR-92
 8/12/1992 22-NOV-93
 3/27/1992 03-NOV-92
 2/21/1992 03-APR-92
 8/21/1992 06-JAN-93
 3/2/1992 18-MAR-92
 11/18/1992 04-DEC-92
 4/2/1992 17-APR-92
 10/13/1992 08-AUG-93
 1/24/1992 02-MAR-92
 2/10/1992 01-MAR-92
 11/19/1992 09-DEC-92
 6/19/1992 04-JUN-92
 11/23/1992 06-DEC-92
 3/20/1992 21-JUL-92
 11/8/1992 22-NOV-92
 7/24/1992 31-AUG-92

7/18/1992 29-AUG-92
 11/26/1991 11-JUL-92
 5/8/1992 11-SEP-92
 7/15/1992 24-AUG-92
 11/11/1991 18-MAR-92
 12/3/1991 28-FEB-92
 2/4/1992 21-MAR-92
 6/26/1992 08-JUL-92
 8/12/1992 16-SEP-92
 2/5/1992 18-FEB-92
 10/27/1992 12-NOV-92
 1/13/1992 24-MAR-92
 6/2/1992 10-JUL-92
 3/30/1992 31-AUG-92
 10/12/1992 18-DEC-92
 6/4/1992 03-NOV-92
 6/11/1992 18-JUL-92
 12/10/1991 27-DEC-91
 4/23/1992 08-MAY-92
 11/4/1992 20-NOV-92
 10/19/1992 21-JAN-93
 5/18/1992 21-FEB-94
 5/2/1992 11-MAY-92
 11/5/1992 01-DEC-92
 10/5/1992 29-JUN-93
 11/24/1992 10-DEC-92
 10/2/1992 08-OCT-92
 2/17/1992 08-MAR-92
 11/10/1992 28-NOV-92
 4/8/1992 25-APR-92
 3/13/1992 22-MAR-92
 1/24/1992 07-FEB-92
 1/24/1992 30-APR-92
 4/9/1992 25-APR-92
 10/5/1992 14-JUL-93
 5/7/1992 11-JUN-92
 6/1/1992 18-JUN-92
 8/1/1992 08-OCT-92
 3/30/1992 12-JUN-92
 7/27/1992 04-SEP-92
 4/2/1992 21-APR-92
 6/25/1992 10-JUL-92
 3/10/1992 02-OCT-92
 6/4/1992 22-SEP-92
 8/28/1992 14-OCT-92
 9/23/1992 15-OCT-92

2/10/1992 27-FEB-92
 4/29/1992 15-MAY-92
 11/17/1992 03-DEC-92
 3/18/1992 20-MAY-92
 2/12/1992 03-MAR-92
 5/20/1992 10-JUN-92
 7/13/1992 11-AUG-92
 8/10/1992 23-OCT-92
 11/18/1992 01-MAY-93
 8/7/1992 02-NOV-92
 9/10/1992 25-SEP-92
 4/28/1992 14-MAY-92
 3/18/1992 31-MAR-92
 2/14/1992 03-MAR-92
 10/2/1992 23-OCT-92
 10/5/1992 23-OCT-92
 11/24/1992 22-DEC-92
 12/18/1991 30-DEC-91
 1/10/1992 31-DEC-92
 2/4/1992 07-MAY-92
 11/25/1991 04-JAN-92
 2/3/1992 26-MAR-92
 4/5/1992 22-APR-92
 3/27/1992 11-APR-92
 3/20/1992 30-JUN-92
 10/28/1992 09-OCT-93
 10/28/1992 08-DEC-92
 12/18/1991 05-JAN-92
 2/4/1992 20-FEB-92
 5/11/1992 25-MAY-92
 2/28/1992 17-MAR-92
 8/11/1992 12-OCT-92
 8/18/1992 16-DEC-93
 11/13/1992 03-DEC-92
 2/11/1992 17-MAR-92
 9/3/1992 20-OCT-92
 3/12/1992 18-APR-92
 12/4/1991 25-JAN-92
 2/19/1992 27-MAR-92
 1/17/1992 02-JUL-92
 10/2/1992 17-NOV-92
 11/4/1992 15-NOV-92
 10/2/1992 02-NOV-92
 8/20/1992 31-JUL-92
 11/4/1992 17-JUN-93
 10/18/1992 15-NOV-92

3/31/1992 21-APR-92
 2/20/1992 06-MAR-92
 7/24/1992 08-NOV-92
 10/2/1992 17-OCT-92
 3/17/1992 28-MAR-92
 11/09/1992 17-NOV-92
 7/15/1992 15-AUG-92
 2/19/1992 05-MAR-92
 8/15/1992 15-AUG-92
 5/4/1992 01-AUG-92
 8/21/1992 06-OCT-92
 12/16/1991 31-JAN-92
 11/30/1992 14-DEC-92
 8/12/1992 22-MAY-92
 3/27/1992 30-APR-92
 8/1/1992 15-OCT-92
 8/22/1992 08-OCT-92
 10/15/1992 23-OCT-92
 4/16/1992 06-MAY-92
 2/27/1992 16-MAR-92
 6/11/1992 28-MAY-92
 7/17/1992 01-AUG-92
 7/17/1992 01-AUG-92
 6/8/1992 28-AUG-92
 11/13/1992 01-DEC-92
 11/18/1991 18-DEC-91
 3/31/1992 13-MAY-92
 4/23/1992 01-MAY-92
 8/28/1992 22-OCT-92
 9/28/1992 13-OCT-92
 1/22/1992 15-FEB-92
 6/11/1992 30-JUN-92
 6/16/1992 12-SEP-92
 10/18/1992 15-NOV-92
 2/14/1992 02-MAR-92
 11/3/1992 18-NOV-92
 1/23/1992 17-FEB-92
 3/5/1992 08-APR-92
 12/17/1991 29-DEC-91
 11/22/1991 29-DEC-91
 11/23/1992 21-DEC-92
 3/2/1992 31-MAR-92
 3/5/1992 18-MAR-92
 8/11/1992 28-AUG-92
 2/20/1992 11-MAR-92
 8/21/1992 05-OCT-92

10/8/1992 28-APR-93
 12/19/1991 31-JAN-92
 8/1/1992 20-MAY-93
 8/3/1992 19-JUN-92
 5/13/1992 21-AUG-92
 8/14/1992 07-JAN-93
 8/1/1992 18-JUN-92
 8/2/1992 23-JUN-93
 4/1/1992 28-APR-92
 11/20/1991 01-DEC-91
 2/19/1993 03-APR-93
 1/16/1992 01-FEB-92
 12/9/1991 02-JAN-92
 11/2/1992 18-NOV-92
 12/9/1991 25-JAN-92
 1/21/1992 08-FEB-92
 5/20/1992 20-JUN-92
 4/27/1992 13-MAY-92
 4/21/1992 19-SEP-92
 8/6/1992 11-MAR-93
 11/3/1992 30-NOV-92
 8/4/1992 21-SEP-92
 2/13/1992 08-MAR-92
 3/16/1992 25-MAR-92
 11/23/1992 28-MAY-93
 10/23/1992 08-NOV-92
 10/5/1992 16-OCT-92
 9/17/1992 23-OCT-92
 4/9/1992 25-APR-92
 11/8/1992 22-NOV-92
 9/10/1992 05-OCT-92
 3/20/1992 28-MAR-92
 2/3/1992 04-ALIG-92
 6/24/1992 19-SEP-92
 6/26/1992 17-JUL-92
 3/29/1992 08-JUL-92
 6/26/1992 13-JUL-92
 11/20/1991 30-APR-92
 4/2/1992 26-MAY-92
 3/10/1992 29-MAY-92
 4/24/1992 13-JUN-92
 9/28/1992 13-OCT-92
 8/5/1992 01-APR-93
 11/20/1992 22-FEB-93
 8/13/1992 02-OCT-92
 3/13/1992 16-MAY-92

D02

D8

11999
 12000
 12001
 12002
 12003
 12004
 12005
 12006
 12007
 12008
 12009
 12010
 12011
 12012
 12013
 12014
 12015
 12016
 12017
 12018
 12019
 12020
 12021
 12022
 12023
 12024
 12025
 12026
 12027
 12028
 12029
 12030
 12031
 12032
 12033
 12034
 12035
 12036
 12037
 12038
 12039
 12040
 12041
 12042
 12043
 12044
 12045
 12046
 12047
 12048
 12049
 12050
 12051
 12052
 12053
 12054
 12055
 12056
 12057
 12058
 12059
 12060
 12061
 12062
 12063
 12064
 12065
 12066
 12067
 12068
 12069
 12070
 12071
 12072
 12073
 12074
 12075
 12076
 12077
 12078
 12079
 12080
 12081
 12082
 12083
 12084
 12085
 12086
 12087
 12088
 12089
 12090
 12091
 12092
 12093
 12094
 12095
 12096
 12097
 12098
 12099
 12100
 12101
 12102
 12103
 12104
 12105
 12106
 12107
 12108
 12109
 12110
 12111
 12112
 12113
 12114
 12115
 12116
 12117
 12118
 12119
 12120
 12121
 12122
 12123
 12124
 12125
 12126
 12127
 12128
 12129
 12130
 12131
 12132
 12133
 12134
 12135
 12136
 12137
 12138
 12139
 12140
 12141
 12142
 12143
 12144
 12145
 12146
 12147
 12148
 12149
 12150
 12151
 12152
 12153
 12154
 12155
 12156
 12157
 12158
 12159
 12160
 12161
 12162
 12163
 12164
 12165
 12166
 12167
 12168
 12169
 12170
 12171
 12172
 12173
 12174
 12175
 12176
 12177
 12178
 12179
 12180
 12181
 12182
 12183
 12184
 12185
 12186
 12187
 12188
 12189
 12190
 12191
 12192
 12193
 12194
 12195
 12196
 12197
 12198
 12199
 12200
 12201
 12202
 12203
 12204
 12205
 12206
 12207
 12208
 12209
 12210
 12211
 12212
 12213
 12214
 12215
 12216
 12217
 12218
 12219
 12220
 12221
 12222
 12223
 12224
 12225
 12226
 12227
 12228
 12229
 12230
 12231
 12232
 12233
 12234
 12235
 12236
 12237
 12238
 12239
 12240
 12241
 12242
 12243
 12244
 12245
 12246
 12247
 12248
 12249
 12250
 12251
 12252
 12253
 12254
 12255
 12256
 12257
 12258
 12259
 12260
 12261
 12262
 12263
 12264
 12265
 12266
 12267
 12268
 12269
 12270
 12271
 12272
 12273
 12274
 12275
 12276
 12277
 12278
 12279
 12280
 12281
 12282
 12283
 12284
 12285
 12286
 12287
 12288
 12289
 12290
 12291
 12292
 12293
 12294
 12295
 12296
 12297
 12298
 12299
 12300
 12301
 12302
 12303
 12304
 12305
 12306
 12307
 12308
 12309
 12310
 12311
 12312
 12313
 12314
 12315
 12316
 12317
 12318
 12319
 12320
 12321
 12322
 12323
 12324
 12325
 12326
 12327
 12328
 12329
 12330
 12331
 12332
 12333
 12334
 12335
 12336
 12337
 12338
 12339
 12340
 12341
 12342
 12343
 12344
 12345
 12346
 12347
 12348
 12349
 12350
 12351
 12352
 12353
 12354
 12355
 12356
 12357
 12358
 12359
 12360
 12361
 12362
 12363
 12364
 12365
 12366
 12367
 12368
 12369
 12370
 12371
 12372
 12373
 12374
 12375
 12376
 12377
 12378
 12379
 12380
 12381
 12382
 12383
 12384
 12385
 12386
 12387
 12388
 12389
 12390
 12391
 12392
 12393
 12394
 12395
 12396
 12397
 12398
 12399
 12400
 12401
 12402
 12403
 12404
 12405
 12406
 12407
 12408
 12409
 12410
 12411
 12412
 12413
 12414
 12415
 12416
 12417
 12418
 12419
 12420
 12421
 12422
 12423
 12424
 12425
 12426
 12427
 12428
 12429
 12430
 12431
 12432
 12433
 12434
 12435
 12436
 12437
 12438
 12439
 12440
 12441
 12442
 12443
 12444
 12445
 12446
 12447
 12448
 12449
 12450
 12451
 12452
 12453
 12454
 12455
 12456
 12457
 12458
 12459
 12460
 12461
 12462
 12463
 12464
 12465
 12466
 12467
 12468
 12469
 12470
 12471
 12472
 12473
 12474
 12475
 12476
 12477
 12478
 12479
 12480
 12481
 12482
 12483
 12484
 12485
 12486
 12487
 12488
 12489
 12490
 12491
 12492
 12493
 12494
 12495
 12496
 12497
 12498
 12499
 12500
 12501
 12502
 12503
 12504
 12505
 12506
 12507
 12508
 12509
 12510
 12511
 12512
 12513
 12514
 12515
 12516
 12517
 12518
 12519
 12520
 12521
 12522
 12523
 12524
 12525
 12526
 12527
 12528
 12529
 12530
 12531
 12532
 12533
 12534
 12535
 12536
 12537
 12538
 12539
 12540
 12541
 12542
 12543
 12544
 12545
 12546
 12547
 12548
 12549
 12550
 12551
 12552
 12553
 12554
 12555
 12556
 12557
 12558
 12559
 12560
 12561
 12562
 12563
 12564
 12565
 12566
 12567
 12568
 12569
 12570
 12571
 12572
 12573
 12574
 12575
 12576
 12577
 12578
 12579
 12580
 12581
 12582
 12583
 12584
 12585
 12586
 12587
 12588
 12589
 12590
 12591
 12592
 12593
 12594
 12595
 12596
 12597
 12598
 12599
 12600
 12601
 12602
 12603
 12604
 12605
 12606
 12607
 12608
 12609
 12610
 12611
 12612
 12613
 12614
 12615
 12616
 12617
 12618
 12619
 12620
 12621
 12622
 12623
 12624
 12625
 12626
 12627
 12628
 12629
 12630
 12631
 12632
 12633
 12634
 12635
 12636
 12637
 12638
 12639
 12640
 12641
 12642
 12643
 12644
 12645
 12646
 12647
 12648
 12649
 12650
 12651
 12652
 12653
 12654
 12655
 12656
 12657
 12658
 12659
 12660
 12661
 12662
 12663
 12664
 12665
 12666
 12667
 12668
 12669
 12670
 12671
 12672
 12673
 12674
 12675
 12676
 12677
 12678
 12679
 12680
 12681
 12682
 12683
 12684
 12685
 12686
 12687
 12688
 12689
 12690
 12691
 12692
 12693
 12694
 12695
 12696
 12697
 12698
 12699
 12700
 12701
 12702
 12703
 12704
 12705
 12706
 12707
 12708
 12709
 12710
 12711
 12712
 12713
 12714
 12715
 12716
 12717
 12718
 12719
 12720
 12721
 12722
 12723
 12724
 12725
 12726
 12727
 12728
 12729
 12730
 12731
 12732
 12733
 12734
 12735
 12736
 12737
 12738
 12739
 12740
 12741
 12742
 12743
 12744
 12745
 12746
 12747
 12748
 12749
 12750
 12751
 12752
 12753
 12754
 12755
 12756
 12757
 12758
 12759
 12760
 12761
 12762
 12763
 12764
 12765
 12766
 12767
 12768
 12769
 12770
 12771
 12772
 12773
 12774
 12775
 12776
 12777
 12778
 12779
 12780
 12781
 12782
 12783
 12784
 12785
 12786
 12787
 12788
 12789
 12790
 12791
 12792
 12793
 12794
 12795
 12796
 12797
 12798
 12799
 12800
 12801
 12802
 12803
 12804
 12805
 12806
 12807
 12808
 12809
 12810
 12811
 12812
 12813
 12814
 12815
 12816
 12817
 12818
 12819
 12820
 12821
 12822
 12823
 12824
 12825
 12826
 12827
 12828
 12829
 12830
 12831
 12832
 12833
 12834
 12835
 12836
 12837
 12838
 12839
 12840
 12841
 12842
 12843
 12844
 12845
 12846
 12847
 12848
 12849
 12850
 12851
 12852
 12853
 12854
 12855
 12856
 12857
 12858
 12859
 12860
 12861
 12862
 12863
 12864
 12865
 12866
 12867
 12868
 12869
 12870
 12871
 12872
 12873
 12874
 12875
 12876
 12877
 12878
 12879
 12880
 12881
 12882
 12883
 12884
 12885
 12886
 12887
 12888
 12889
 12890
 12891
 12892
 12893
 12894
 12895
 12896
 12897
 12898
 12899
 12900
 12901
 12902
 12903
 12904
 12905
 12906
 12907
 12908
 12909
 12910
 12911
 12912
 12913
 12914
 12915
 12916
 12917
 12918
 12919
 12920
 12921
 12922
 12923
 12924
 12925
 12926
 12927
 12928
 12929
 12930
 12931
 12932
 12933
 12934
 12935
 12936
 12937
 12938
 12939
 12940
 12941
 12942
 12943
 12944
 12945
 12946
 12947
 12948
 12949
 12950
 12951
 12952
 12953
 12954
 12955
 12956
 12957
 12958
 12959
 12960
 12961
 12962
 12963
 12964
 12965
 12966
 12967
 12968
 12969
 12970
 12971
 12972
 12973
 12974
 12975
 12976
 12977
 12978
 12979
 12980
 12981
 12982
 12983
 12984
 12985
 12986
 12987
 12988
 12989
 12990
 12991
 12992
 12993
 12994
 12995
 12996
 12997
 12998
 12999
 13000
 13001
 13002
 13003
 13004
 13005
 13006
 13007
 13008
 13009
 13010
 13011
 13012
 13013
 13014
 13015
 13016
 13017
 13018
 13019
 13020
 13021
 13022
 13023
 13024
 13025
 13026
 13027
 13028
 13029
 13030
 13031
 13032
 13033
 13034
 13035
 13036
 13037
 13038
 13039
 13040
 13041
 13042
 13043
 13044
 13045
 13046
 13047
 13048
 13049
 13050
 13051
 13052
 13053
 13054
 13055
 13056
 13057
 13058
 13059
 13060
 13061
 13062
 13063
 13064
 13065
 13066
 13067
 13068
 13069
 13070
 13071
 13072
 13073
 13074
 13075
 13076
 13077
 13078
 13079
 13080
 13081
 13082
 13083
 13084
 13085
 13086
 13087
 13088
 13089
 13090
 13091
 13092
 13093
 13094
 13095
 13096
 13097
 13098
 13099
 13100
 13101
 13102
 13103
 13104
 13105
 13106
 13107
 13108
 13109
 13110
 13111
 13112
 13113
 13114
 13115
 13116

8/14/1992 19-APR-93
 1/22/1992 14-FEB-92
 9/14/1992 29-SEP-92
 8/14/1992 29-SEP-92
 1/22/1992 23-MAY-92
 2/4/1992 29-FEB-92
 10/7/1992 23-DEC-92
 8/31/1992 15-SEP-92
 11/24/1992 10-DEC-92
 4/10/1992 07-JUL-92
 3/27/1992 11-APR-92
 7/29/1992 15-AUG-92
 2/27/1992 23-APR-92
 10/12/1992 21-OCT-92
 11/30/1992 12-MAR-93
 3/10/1992 22-MAY-92
 11/28/1992 25-DEC-92
 8/1/1992 14-AUG-92
 4/1/1992 09-MAY-92
 8/9/1992 10-SEP-92
 2/10/1992 29-FEB-92
 7/21/1992 31-AUG-92
 12/13/1991 25-DEC-91
 10/22/1992 07-NOV-92
 5/9/1992 30-JUN-92
 8/15/1992 09-OCT-92
 12/17/1991 31-DEC-91
 11/9/1992 23-NOV-92
 9/19/1992 02-OCT-92
 3/29/1992 11-APR-92
 8/25/1992 11-JUL-92
 11/11/1992 28-JUL-93
 11/18/1992 23-FEB-93
 11/25/1991 06-JAN-92
 12/3/1991 15-JAN-92
 7/29/1992 16-AUG-92
 8/3/1992 19-JUN-92
 3/29/1992 08-JUN-92
 11/30/1992 10-DEC-92
 4/13/1992 27-AUG-92
 12/9/1991 25-DEC-91
 1/19/1992 14-FEB-92
 1/17/1992 04-FEB-92
 12/12/1991 31-DEC-91
 1/23/1992 12-MAY-92
 12/18/1991 08-JAN-92

1/18/1992 24-FEB-92
 11/20/1991 04-SEP-92
 1/22/1992 29-FEB-92
 2/5/1992 07-MAR-92
 12/17/1991 01-FEB-92
 11/20/1991 03-DEC-91
 12/9/1991 16-JAN-92
 12/12/1991 20-JAN-92
 2/25/1992 14-MAR-92
 12/18/1991 30-DEC-91
 1/15/1992 22-JAN-92
 12/9/1991 08-JAN-92
 1/21/1992 25-MAR-92
 1/24/1992 27-FEB-92
 12/12/1991 17-JAN-92
 12/19/1991 16-JAN-92
 1/17/1992 29-FEB-92
 11/20/1991 31-JAN-92
 12/11/1991 19-DEC-91
 2/21/1992 09-JUN-92
 12/12/1991 31-DEC-91
 12/19/1991 07-JAN-92
 1/13/1992 01-FEB-92
 1/21/1992 24-FEB-92
 11/20/1991 09-JAN-92
 11/27/1991 09-SEP-92
 2/11/1992 13-SEP-92
 12/5/1991 04-APR-92
 12/9/1991 22-JAN-92
 2/24/1992 29-APR-92
 12/19/1991 07-JAN-92
 12/20/1991 02-FEB-92
 1/19/1992 31-JAN-92
 1/15/1992 22-JAN-92
 2/21/1992 30-MAY-92
 1/24/1992 31-AUG-92
 12/13/1991 04-JAN-92
 12/13/1991 24-AUG-92
 11/25/1991 06-JAN-92
 12/4/1991 17-DEC-91
 1/18/1992 23-JAN-92
 2/16/1992 08-OCT-92
 12/13/1991 21-DEC-91
 2/28/1992 15-MAR-92
 1/13/1992 28-FEB-92
 11/27/1991 14-JAN-92

END-025 11992

12/31/1991 29-FEB-92
 11/11/1991 21-DEC-91
 11/28/1991 03-DEC-91
 2/26/1992 17-MAR-92
 11/21/1991 15-JAN-92
 1/21/1992 24-MAR-92
 1/17/1992 02-MAR-92
 12/16/1991 31-DEC-91
 11/22/1991 11-DEC-91
 12/18/1991 22-JAN-92
 12/18/1991 04-JAN-92
 1/23/1992 25-JUN-92
 12/31/1991 14-JAN-92
 2/24/1992 10-NOV-92
 2/10/1992 14-APR-92
 4/15/1992 15-MAY-92
 1/13/1992 02-FEB-92
 1/21/1992 17-MAR-92
 12/18/1991 04-JAN-92
 2/28/1992 05-JUN-92
 11/11/1991 22-JAN-92
 2/25/1992 06-JUL-92
 2/10/1992 25-APR-92
 12/18/1991 30-DEC-91
 12/18/1991 31-JAN-92
 2/24/1992 28-FEB-92
 1/23/1992 17-APR-92
 2/28/1992 15-MAR-92
 1/13/1992 02-MAR-92
 12/19/1991 28-FEB-92
 12/12/1991 05-FEB-92
 2/8/1992 21-SEP-92
 2/24/1992 18-MAR-92
 2/25/1992 06-MAR-92
 2/21/1992 05-MAR-92
 12/6/1991 17-FEB-92
 12/8/1991 31-DEC-91
 6/12/1992 27-MAY-92
 12/5/1991 18-MAR-92
 11/18/1991 06-DEC-91
 12/5/1991 15-JAN-92
 12/20/1991 03-MAR-92
 12/31/1991 08-FEB-92
 12/4/1991 02-SEP-92
 2/20/1992 18-MAR-92
 2/8/1992 22-MAY-92

boxfiles_OLD1

12/20/1991 01-FEB-92
1/21/1992 06-FEB-92
2/27/1992 15-MAR-92
11/28/1991 10-DEC-91
2/18/1992 01-JUL-92
2/21/1992 03-MAY-92
2/28/1992 17-AUG-92
12/8/1991 16-JAN-92
12/4/1991 19-DEC-91
2/28/1992 23-MAY-92
12/8/1991 21-DEC-91
11/28/1991 10-JAN-92
11/21/1991 15-DEC-91

2002-028 1.1964

TECH_COMMENTS

REPLACED DEACTIVATION SWITCH
 DIAGNOSED AS LEAKING FROM NEW SWITCH THAT WAS INSTALLED FROM RECALL 98S15, REMOVE AND REPLACE WITH ANOTHER ONE AND CLEAN UP FLUID MESS
 116483 DEACTIVATION SWITCH LEAKING PULL ALL WHEELS OK BRAKES AND LINES REPLACE BRAKE SWITCH DEACTIVATION SWITCH
 REPAIR DEACTIVATION SWITCH SPEED CONTROL ODDME VEHICLE NEVER LEFT BUILDING
 R AND R FAULTY DEACTIVATION SWITCH PER SERVICE PARTS
 90548 HAD TO REPLACE DEACTIVATION SWITCH PER NEW ONE LEAKING
 INSPECTED, REPLACED DEFECTIVE CRUISE SWITCH
 DIAGNOSIS ELECTRONIC TRANS TEST REMOVED TRANS AND REPLACED DEFECTIVE TORQUE CONVERTER, RETEST
 SWITCH VERIFIED CONCERN AND REPLACED REPLACED SWITCH # 0836
 SPW SPEED CONTROL DEACTIVATION SWITCH LINE 3
 A25 42 SPW RO 68804 DT 7-8-99 MI 58198 REPLACE BRAKE DEACTIVATION SWITCH
 54598 SERVICE PARTS REPLACEMENT W REPLACE CRUISE CONTROL DEACTIVATION SWITCH, WAS LEAKING BRAKE FLUID
 59752 LACK OF TECH TIME DUE TO DISPATCH ERROR*** SPW***R-O 107504***ACCRUED 25 MILES**7-15-99** LABOR 2284A.3***BASIC 98852***CC-01***VERIFIED FL
 PRESSURE SWITCH LEAKING REPLACE PRESSURE SWITCH, LEAKING AROUND CRIMP
 O-RING NOT SEATING R/R DEACTIVATION SWITCH
 OPEN CIRCUIT IN BREAK PRESSURE SWITCH WHICH CHANGED IN RECALL REPLACE SWITCH & HARDSHELL CONNECTOR
 REPLACE SWITCH AND BLEED SYSTEM
 OASIS PERFORM RECALL 98S15 INSTALL SWITCH PART WAS BROKEN IN THE BOX
 SWITCH FAILURE REPLACE SPEED CONTROL ACTIVATION SWITCH
 98062-42, BRAKE PEDAL SPONGY AFTER RECALL BRAKE SWITCH LEAKING BUT TIGHT REPL SWITCH BLEED BRA KES ROAD TEST OK
 VERIFY CONCERN AND FOUND THAT THE SPEED CONTROL SWITCH IS CAUSING THE CONCERN-REPLACE AS NEEDED.
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 52541 SPEED CONTROL DIAGNOSIS 9818A 0.7 REPLACE SPEED CONTROL SWITCH 9818A2 0.2 CC 42
 CLIPS BROKEN REPLACE CRUISE CONNECTOR
 1 REPLACED LEAKING SPEED CONTROL DEACTIVATION SWITCH SERVICE REPLACED TO RO 58987, DATE 8-18-99, MILES 93048
 RPL DEACTIVATION SWITCH KIT
 THREADS DAMAGED REPLACED CRUISE CONTROL SWITCH, BLEED FRONT BRAKES
 TEST CRUISE, PINPOINT TEST A1-A5, SERVICE INSTALL DEFECTIVE SWITCH FROM RECALL 98S15 SWITCH OPEN. PART#F2VY-9F924-A IS IN KIT PART#XW7Z-9G852-
 REPLACED DEACTIVATION SWITCH
 REPLACE LEAKING BRAKE SWITCH
 RR ALL WHEELS TO INSPECT BRAKES, FOUND FLUID LOW, CHECKED FOR LEAK AT PRESSURE SWITCH, REPLACE SWITCH, BLEED BRAKES AND CLEAN AREA AROUND
 INOP REPLACE SPEED CONTROL DEACTIVATOR SWITCH-DEFECTIVE
 BRAKE PEDAL GOES TO FLOOR REPLACE DEFECTIVE SPEED CONTROL DISENGAGEMENT SWITCH
 INOP SWITCH SPEED CONTROL - TEST
 PERFORMED 98S15 8-8-99 RO68071 70488 MILES. CRUISE DEACTIVATION SWITCH REPLACED AT THAT TIME. SERVICE INSTALLED PART WARRANTY. REMOVED AND
 RECHECK - RED BRAKE LITE ON REPL SWITCH - AFTER RECALL
 INSTALL CRUISE CONTROL SWITCHED PER RECALL RECALL CLOSED DURING PROCESSING GOODWILL RECOVERY TO DEALER
 51742 RECALL R AND R DEACTIVATOR SWITCH AND CONNECTOR PER RECALL BLEED REAR BRAKES.

B REPLACE SWITCH-
 98S10 INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 024 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

RECALL PERFORMED RECALL 99S15

RECALL PERFORMED RECALL # 99S15

PERFORMED RECALL 99S15

1 PERFORMED RECALL

REPLACE SWITCH AND CONNECTOR.

REPLACED DEACTIVATION SWITCH

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

94412 RECALL WP40 REPLACE SPEED CONTROL PRESSURE SWITCH

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

REPLACE BRAKE PRESSURE DEACTIVATION SWITCH AND HARDSHELL

SPEED CONTROL STICKING PERFORMED 99S15B RECALL

134481 REPLACED THE DEACTIVATION SWITCH AND WIRING CONNECTOR. OK. RECALL 99S15

99S01 99S15

E METERING BLOCK STRIPPED WHILE PERFORMING RECALL. INSTALLED NEW METERING BLOCK AND PERFORMED RECALL 99S15B .5 ADMIN .1 MTIME WAS NEI

REPLACE CRUISE CONTROL CUT OFF SWITCH

1 REPLACE BRAKE SWITCH PER RECALL

RECALL PERFORM 99S15 RECALL

REPLACED SC DEACTIVATION SWITCH 99S15

95265 PERFORMED 99S15 RECALL

COMPLETED RECALL

1 PERFORMED RECALL 99S15

PERFORM RECALL

PERFORMED RECALL 99S15 AND CHECKS OK

REPLACE CRUISE CONTROL SWITCH

81683 RECALL 99S15 INSPECT AND PERFORM RECALL

SPEED CONTROL RECALL

PERFORMED RECALL

109115 RECALL 99S15

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

VERIFIED CONCERN REPLACED CRUISE CONTROL SWITCH

PERFORMED RECALL

PERFORMED RECALL REPLACED SWITCH CIGS OK

122181 RECALL 99S15B 0.5 0.5 RECALL

99S15 RECALL

99S15 RECALL, REPLACED SEED CONTROL DEACTIVATION SWITCH

47180 RECALL 99S15 RECALL 99S15

REPLACE PRESSURE SWITCH AND CONNECTOR.

PERFORMED RECALL 99S15

RECALL 99S15

REPLACE CABLE 99S15

100654 R&R SWITCH ASSY.
 INSTALL HARDSHELL CONNECTOR AND PRESSURE SWITCH
 CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPLACED SPEED CONTROL DEACTIVATION SWITCH, INSP CONNECTOR.
 PERFORMED RECALL
 REPLACE SWITCH
 110032 BRAKE KIT RECALL
 RECALL 99S15 RECALL
 RECALL 99S15
 . PERFORM RECALL
 RECALL SWITCH

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I
 RECALL PERFORMED SPEED CONTROL DEACTIVATION SWIT
 114714 PERFORMED RECALL
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 161741 RECALL WPG40 REPLACE NEW WIRE CONNENCTOR & CENCER PER RECALL 99S15 FINISHED
 PERFORMED RECALL 99S15.TEC 120 WARR
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 FORD RECALL PERFORMED CRUISE DEACTIVATION SWITCH RECALL
 PERFORMED SAFETY RECALL 99S15
 PERFORMED RECALL PERFORMED RECALL INSTALLED NEW SWITCH
 PERFORMED RECALL 99S15, REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTION
 PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION
 RECALL 99S15
 119696 RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL
 R & R SWITCH & CONNECTOR
 RECALL 99S15 99S15 COMPLETED RECALL
 REPLACED DEACTIVATION SWITCH
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 78448 REPLACED DEACTIVATION SWITCH,REPLACED HARNESS CONNECTER,TOPPED OFF BRAKE FLUID AND TEST DROVE OK
 PERFORM RECALL
 1 PERFORMED RECALL
 REPLACE BRAKE KIT PER RECALL

68483 RECALL 99S15 W PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATI ON SWITCH.
 91929 WARR DONE RECALL 99S15 INSTALL BRAKE REPAIR KIT
 99S15 RECALL REPL CRUISE DEACTIVATION SWITCH
 99S15 CRUISE
 RECALL REPLACE SPEED CONTROL SWITCH
 120852 99S15 WARR REPLACED SWITCH AND CONN
 INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99S15B .30
 RECALL COMPLETED
 RECALL PERFORMED
 PERFORM RECALL 99S15
 70632 PERFORM RECALL 99S15
 PERFORMED RECALL

REPL BRK PRSS SWITCH
PERFORMED RECALL 99S15
99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH A
DONE RECALL 99S15

INSTALL KIT PER RECALL
PERFORMED RECALL
1 PERFORM RECALL
99S15 99S15
RECALL 99S15 RECALL PERFORME

AS PER RECALL 99S15 RECALL TO INSTALL SWITCH AND HARDSHELL CONNECTOR
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
RECALL 99S15
1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X5
COMPLETED RECALL
REPLACED CRUISE CONTROL SWITCH
99S15 PERFORMED RECALL
PER RECALL PERF RECALL
82252 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW AND CONN PER RECALL
PERFORMED RECALL
PERFORMED RECALL 99S15, 99S15B .5HRS
INSTALLED SWITCH
PERFORM RECALL
101213 RECALL 99S15, R&R DEACTIVATION SWITCH, AND CONNECTOR, RETURNED PARTS
RECALL PERFORMED
99S15 REPLACED DEACTIVATION SWITCH
PERFORM RECALL
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15
48328 99S15B .0 99S15B.0 .0 REPLACE SPEED CONTROL SWITCH
PERFORM RECALL
INSTALL SWITCH PER RECALL 99S15 A99
99S15B 0.5
REPLACE SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION
RECALL COMPLETED
PERFORMED 99S15B
29141 RECALL 99S15B 0.5, ADMIN 0.1 R&R DEACTIVATION SWITCH & CONNECTOR PER RECALL
REPLACED CRUISE DEACTIVATION SWITCH AND HARDSHELL FOR CONNECTOR
INSTALLED SWITCH AS PER RECALL
99S15 99S15 REPLACE SWITCHED CONNECTOR
INSTALLED NEW DEACTIVATION SWITCH AND CONNECTOR
PERFORMED RECALL 99S15
REPLACED DEACTIVATION SWITCH PER SAFTEY RECALL 99S15.
REPLACE SWITCH AND HARD SHELL CONNECTOR LABOR OF 99S15B, BILLING TIME .5, TECH TIME .5 PROGRAM CODE 99S15
1 PERFORMED RECALL

1007-025 11558

DONE RECALL COMPLETED
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 PERFORMED RECALL 99S15
 RECALL 99S15. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.
 81848 99S15 SPEED CONTROL RECALL PERFORMED
 PERFORM RECALL 99S15
 - PERFORM RECALL
 REPLACED PARTS PER RECALL
 RECALL 99S15; PERFORM RECALL 99S15; REPL BRK-PRESS. SWITCH;
 INSTALL SWITCH PER RECALL
 RECALL. REPLACED BRAKE PRESSURE SWITCH AND BLEED BRAKE SYSTEM.
 RECALL 99S15
 PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH AND CONNECTOR, BLEE
 INSP AND REPL SWTH AND CONN PER RECALL
 PERFORM RECALL 99S15 REPLACED PRESSURE SWITCH PER RECALL 99S15
 PERFORMED RECALL

PERFORM RECALL 99S15-INSTALL SWITCH AND CONNECT OR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

42 99S15
 99S15 99S15
 1 PERFORM 99S15 AS PER LETTER
 RECALL 99S15 99S15 COMPLETED RECALL
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 RECALL 99S15
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 PERFORMED RECALL
 REPLACED CRUISE CONTROL CUT OFF SWITCH.....
 REPLACE SW.
 REPLACED BRAKE SWITCH M TIME REPLACED BRAKE SWITCH
 RECALL 99S15 CRUISE CONTROL
 83484 99S15B .5 INSTALL KIT

REPLACED SPEED CONTROL SWITCH
 REPLACE SWITCH
 RECALL 99S15
 AS PER RECALL 99S15 REPLACE SWITCH AND HARDSHELL CONNECTOR
 INSPECTED SPEED CONTROL AND INSTALLED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIRS
 COMPLETE RECALL 99S15

RECALL 99S15 RECALL, REPLACED DEACTIVATION SWITCH
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

RECALL COMPLETE.
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15

PERFORMED RECALL REPLACED SWITCH CKS OK
 RECALL COMPLETED

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
 REPLACED SC DEACTIVATION SWITCH 99S15
 PERFORM RECALL

112588 PERFORMED RECALL 99S15

REPLACED DEACTIVATION SWITCH.

PERFORMED RECALL 99S15

RECALLED 99S15 PERFORMED

COMPLETED RECALL 99S15

99S15 RECALL

REPLACE DEACTIVATION SWITCH AND CONNECTOR

SPEED DEACTIVATION SWITCH RECALL L.O.C. 99S15B

REPLACED DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15

INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99S15B .50

30500 RECALL WF PERFORM RECALL AS INSTRUCTED

1 COMPLETED REACTIVATION OF CRUISE CONTROL SYST

1 PERFORMED REPAIR PER RECALL

REPLACED CRUISE CONTROL DEACTIVATION

INSPECT AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

INSTALLED SWITCH KIT

RECALL 99S15 RECALL PERFORME

REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL

PERFORM RECALL

83589 PERFORMED RECALL

81190 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS PER RECAL

99S15 99S15

PERFORM RECALL ON CRUISE CONTROL SWITCH

84210 RECALL 99S15

RECALL PERFORMED RECAL

99S15 RECALL 99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNE

RECALL 99S15B _ REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

PER PCSB PERFORMED RECALL 99S15 PERFORM REPAIR W-KIT.

MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH

RECALL COMPLETE.

RECALL 99S15 COMPLETED

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

COMPLETED AS PER RECALL

PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK

RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

RECALL NOTIFICATION

PERFORMED RECALL
 PERFORMED RECALL 99S15
 PERFORM 99S15 RECALL
 RECALL PERFORMED
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 92171 0.50 PERFORMED RECALL 99S15 DEACTIVATION SWITCH
 78663 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 99907 RECALL 99S15 INSTALLED NEW HARDSHELL CONNECTOR AND SWITCH. TEST DROVE TO VERIFY REPAIR.

81160 RECALL 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 86888 99S158 WARR .5 REPLACED SWITCH AND WIRE CONNECTOR
 109308 REPL DEACTIVATION
 PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION
 1 PERFORMED RECALL AND REPLACED CRUISE CABLE
 REPLACE SWITCH AND CONNECTOR
 RECALL 99S15 99S15 COMPLETED RECALL
 PERFORMED RECALL 99S15 DEACTIVATION SWITCH

PERFORM RECALL 99S15-INSTALL SPEED CONTROL SWITCH AND CONNECTOR
 99S15 RECALL INSTALL SWITCH AS PER RECALL

82128 PERFORM RECALL 99S15
 99S15, REPLACE SWITCH AND WIRE COND
 REPLACE SWITCH
 SWITCH 99S15
 PERFORMED RECALL
 83638 PERFORMED RECALL 99S15
 REPAIR PER 99S15 RECALL
 99S15 RECALL INSTALL BRAKE SWITCH AND HARD SHELL CONECTOR
 40943 PERFORM RECALL
 RECALL 99S15 RECALL
 REPLACED CRUISE CONTROL SWITCH FOR RECALL
 1 COMPLETED RECALL
 COMPLETED SPEED CONTROL RECALL
 1 PERFORM RECALL 99S15
 PERFORM RECALL PER INST
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION
 RECALL PERFORMED RECALL
 1 PERFORMED RECALL 99S15
 REPLACED SWITCH
 PERF. RECALL
 MODIFIED SPEED CONTROL PER RECALL
 77967 RECALL 99S15 REMOVE OLD DEACTIVATION SWITCH AND INSTALL NEW BLEED REAR BRAKES
 RECALL CRUISE CONTROL
 PERFORM RECALL

5982-825 11571

98S15 98S15
74808 RECALL WA PERFORM RECALL, REPLACE DEACTIVATOR SWITCH AND CONNECTOR
PERFORMED RECALL 98S15
REPLACE CRUISE DEACTIVATION SWITCH
TECH REPLACED CRUISE CONTROL SWITCH AS PER RECAL
RECALL 98S15 RECALL
77548 RECALL W PERFORMED RECALL 98S15 REPLACED BRAKE DEACTIVATION SWITCH
DO RECALL 98S15

COMPLETED RECALL
REPLACE SPEED CONTROL DEACTIVATION AND HARD SHEEL CONNECTOR

PERFORM 98S15
114060 RECALL 98S15 PERFORMED RECALL
RECALL 98S15
90000 REPLACE SPEED CONTROL DEACTIVATION SWITCH
98S15 RECALL 98S15 REPLACE SPEED CONTROL SWITCH AS PER RECALL
PERFORMED RECALL
C REPLACED BROKEN DEACTIVATOR SWITCH

1 COMPLETED RECALL
REPLACED DEACTIVATION SWITCH
138810 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNNECTOR

PREFRD RECALL 98S15

1 PERFORMED RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
PERFORMED RECALL 98S15
REPAIR AS PER RECALL
REPLACED SWITCH AND CONNECTOR PER RECALL
28841 98S15B 0.5 HR8. SPEED CONTROL RECALL
PERFORMED RECALL 98S15

PERFORM RECALL 98S15- INSTALL CRUISE CONTROL PARTS

08200 RECALL 98S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR
PERFORMED RECALL 98S15 PER LETTER OF INSTRUCTION
118040 PERFORM RECALL FOR SPEED CONTROL DEACTIVATION SWITCH. WHEN INSTALLING SWITCH, THREADS STRIPPED IN BRAKE LINE BLOCK. INSTALL NRW B1
PERFORMED RECALL 98S15
PERFORM RECALL
REPAIR PER 98S15 RECALL
98S15 98S15-REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH
RECALL 98S15
PERFORMED RECALL 98S15B

104270 WPR40 98S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH POST TEST,POST ROAD TEST

6002-625 11572

COMPLETED RECALL 99S15

RECALL 99S15 99S15 RECALL REPLACE SWITCH
RECALL 99S15 RECALL 99S15B

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15 PERFORMED 99S15 RECALL
PERFORM RECALL 99S15 INSTALL BRAKE KIT PER RECALL 99S15
ORDERED DEACTIVATION SWITCH 99S15 99S15
99S15 RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
REPLACED SWITCH CODE 42
SPEED CONT REPL SWITCH

PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
101313 RECALL WARR R AND R SPEED CONTROL DEACTIVATOR SWITCH PER RECALL INSTRUCTIONS.
INSTALL DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL

1 PERFORMED RECALL 99S15
1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
RECALL R-R DEAC SW, R-R HARDSHELL CONN. INSTALLED NEW, RECD OK.
62006 PERFORM RECALL 99S15, INSTALL SOP S.C. DEACTIVATION SWITCH.
78314 INSTALL NEW SWITCH AND HARNESS END PER RECALL 99S15
REPLACE CRUISE CONTROL SWITCH PER RECALL
SPEED CONTROL RECALL
RECALL 99S15 RECALL
138279 PERFORMED RECALL 0.5
RECALL 99S15
RECALL 99S15 COMPLETED
1 REPLACE BRAKE SWITCH AND CONN PER RECALL
CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15
COMPLETED RECALL
1 COMPLETED RECALL

INSTALL SWITCH AS PER RECALL

1 REMOVE AND REPLACE DEACTIVATION SWITCH AND CONNECTOR
RECALL 99S15 99S15 COMPLETED RECALL
RECALLED 99S15 PERFORMED
1 PERFORMED RECALL
PERFORMED RECALL 99S09
RECALL COMPLETE

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

99S15 99S15 PERFORM RECALL

COMPLETED RECALL

COMPLETED RECALL

REPLACED SWITCH PER RECALL

RECALL 99S15

99S15 PERFORM 99S15 RECALL

COMPLETED AS PER RECALL

PERFORM RECALL 99S15

RECALL 99S15

99S15 RECALL DEACTIVATION SWITCH

PERFORMED RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

94557 RECALL WARRANTY REMOVED DEACTIVATION SWITCH AND REPLACED THEN INSTALLED NEW PLUG PER RECALL

PERFORM RECALL 99S15 INSTALLED BRAKE SWITCH PER RECALL 99S15

RECALL 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15

99S15 RECALL

RECALL 99S15

RR CRUISE CONTROL DEACTIVATION SWITCH

91120 RECALL 99S15 WARR. REPLACED DEACT SW. & HARDSHELL CONN. PER RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

1 REPLACED CRUISE SWITCH AND CONNECTOR BLEAD BRAKES AND TEST DROVE

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

90237 PERFORMED RECALL TEST DROVE OK

COMPLETED RECALL 99S15

99S15 RECALL

PERFORM RECALL

1 CAMPAIGN COMPLETED

94856 99S15 .5L RR CRUISE DEACTIVATOR SWITCH AND CONNECTOR

PERF. RECALL

PERFORMED RECALL 99S15

RECALL 99S-15 - REPLACED CRUISE DEACTIVATION SW PER RECALL 99S15B .5 ADMIN .1

REPLACE SPEED CONTROL SWITCH

PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION

PERFORMED RECALL AS REQUIRED 99S15

94580 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0637

49408 REPLACE SWITCH PER LETTER

PERFORM SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

RECALL SWITCH

110166 DEACTIVATION SWITCH RECALL PERFORMED RECALL

35827 99S15B 0.5 HRS. SPEED CONTROL RECAL

RECALL 98S15 PERFORMED RECALL 98S15, INSTALLED KIT 98S52, BLEED BRAKE SYS VERIFY.

1 INSTALL SWITCH

24967 INSPECT AND REPLACE SWITCH AND CONNECTOR AS PER RECALL 98S15, ALSO HAD TO RESOLDER NEW ENDS ON WIRES DUE TO END BEING BAD

VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT

REPLACE CRUISE SWT PER RECALL

RECALL REPLACED DEACTIVATION SWITCH

REPLACED CRUISE DEACTIVATION SWITCH PER 98S15 RECALL

RECALL STILL SHOWING OPEN ON OASIS. PREVIOUS REPAIR WAS AN INSPECTION ONLY.

PERFORM RECALL 98S15

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

98S15 REPLACE SWITCH

OPEN RECALL, PERFORM RECALL

TECH REPLACED CRUISE CONTROL CABLE AS PER RECALL

REPLACED NEW SPEED CONTROL KIT..INOP..PARTS WARR

REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL

REPLACE CRUISE DEACTIVATION SWITCH

REPLACED THE SWITCH PER RECALL INSTRUCTIONS

PERFORMED RECALL 98S15

PERFORMED RECALL 98S15

98S15 98 S 15 RECALL REPLACED CRUISE DEACTIVATION SWITCH & CONNECTOR

RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH.

42889 RECALL WARR COMPLETE. REPLACED SWITCH AS PER RECALL

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

98788 REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL 98S15

PERFORMED RECALL 98S15

PERFORMED RECALL

RECALL 98S15 98S15 COMPLETED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH RECALL 98S15

RECALL REQUIRED RECALL PERFORMED REPLACED CRUISE SWITCH AND CONNECTOR

52221 RECALL 98S15 DID RECALL

CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPL SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTOR.

RECALL RECALL

REPL SPD CNTRL DEACTIVATION SW

98739 RECALL PERFORMED RECALL 98S15

PERFORMED RECALL

47233 RECALL DEACT SWITCH AS PER RECALL R&R SWITCH

RECALL 98S15

PERFORMED OPEN RECALL

INSTALL SWITCH AND CONNECYOR

REPLACE CRUISE CONTROL SWITCH AND CONNECTOR

OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15

26736 PERFORM RECALL

025 PERFORMED RECALL. REPLACED SWITCH AND WIRE CONNECTOR
99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL
RECALL. REPLACED DEACTIVATION SWITCH PER RECALL

99S15 99S15

SPEED CONTROL RECALL

99S15 RECALL 99S15 REPAIRED AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL S15 0.5
PERFORM RECALL

REPLACED SPEED CONTROL SWITCH PER RECALL 99S15

119403 RECALL 99S15 .5

99224 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY
SEE ADVISOR FOR INFORMATION.

RECALL 99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

111698 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

97525 RECALL 99S15 REPL SWITCH AND CONECTOR ROAD TEST OK CRUISE OK

70760 RECALL .5 99S15B INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL

INSTALL CRUISE DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS

RECALL REPLACE SWITCH AS PER RECALL 99S15

PERFORM RECALL

INSTALLED KIT TO COMPLETE

PERF RECALL 99S15

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

97220 RECALL REMOVED AND REPLACED DEACTIVATOR SWITCH, BLEED SYS, AND REPLACED CONN. COURTESY WASH

REPLACED CRUISE SWITCH

FACTORY RECALL. REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

148148 99S15

RECALL REPLACE SWITCH AS PER RECALL

PERFORM RECALL 99S15 DEACTIVATION SWITCH RECHECK OK 1

1 COMPLETED RECALL PER INSTRUCTIONS

PERFORM RECALL

RECALL INSTALL SWITCH

INSTALLED NEW CRUISE DEACTIVATION SWITCH AND CONN., BLEED REAR BRAKES, TEST DRIVE OK

PERFORMED 99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

FORD SAFETY RECALL REPLACED SPEED DEACTIVATION SWITCH

INSTALLED CONNECTOR

RECALL 99S15 COMPLETED RECALL

FACTORY RECALL COMPLETED RECALL

ENR2-825 11076

REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 COMPLETE RECALL 99S15
 PERFORMED SPEED CONTROL RECALL
 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT
 25390 99S15B 0.5 0.5 PERFORM 99S15

RECALL R-R DEAC SW, AND CONNECTOR, RECKD OK.
 99S15 REPLACE SWITCH & CONN
 RPLCD SWITCH AND CONNECTOR
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL PERFORMED RECALL 99S15
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
 79101 PERFORM RECALL 99S15
 RECALL 99S15 REPLACE SWITCH CONNECTOR
 PERFORM RECALL INSTALL SWITCH
 REPLACE SPEED CONTROL DISABLE SWITCH AND HARDSHELL PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND PLUG
 PERFORMED RECALL 99S15 DEACTIVATION SWITCH
 PERFORM RECALL 99S15
 REPL CRUISE CONTROL SWITCH
 DID RECALL
 PERFORM RECALL 9777
 99174 99S15B .5 PERFORM RECALL 99S15
 REPLACE DEACTIVATION SWITCH
 RECALL 99S15 COMPLETED RECALL 99S15
 RECALL COMPLETE
 COMPLETE SPEED CONTROL RECALL
 COMPLETE RECALL
 1 REPLACE SWITCH AND SHELL
 99S05 NOTE:BEFORE ATTEMPTING TO WORK ON CAR AFTER BATTERY INSTALLED,CHECK ENGINE LITE WAS ON TECH 678 INSTALLED BATTERY MOVED TO STALL ()
 PERFORMED 99S15 INSTALLED UPDATED SPEED CONTROL DEACTIVATION SWITCH
 99707 RECALL WARRANTY INSTALL SPEED CONTROL DEACTIVATION SWITCH
 99S15 REPLACE SWITCH & CONN
 PERFORM RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 74285 INSTALLED A 99S15 CONNECTOR 4517
 99399 REPLACE SWITCH PER RECALL 99S15
 1 PERFORMED RECALL 99S15
 SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL REPLACE CRUISE DEACTIVATION SWITCH
 99040 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH
 124893 RECALL 99S15 REPLACE SPD CONTROL ACTIVATION SWITCH AS PER 99S15
 173150 PERFORMED RECALL REPLACED SWITCH & CONNECTOR
 1 PERFORM RECALL 99S15
 A RECALL COMPLETE

RECALL 99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 99S15 RECALL
 PERFORM SPEED CONTROL DEACT SW RECALL 99S15
 78233 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY JH
 1 REPAIRED AS PER RECALL 99S15

CORRECTION: COMPLETED RECALL AS PER FACTORY SPECS. REPL SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR.

INSPECT & REPLACED SPEED CONTROL DEACTIVATION SWITCH
 D
 INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99S15B .50
 RECALL R RECALL
 PERFORM RECALL 99S15 TECH 6780
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 REPLACED SPEED CONTROL DEACTIVATION SWITCH.
 99181 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15
 PERFORM RECALL 99S15
 REPLACED SWITCH PER RECALL
 99S15 - PERFORMED RECALL, REPLACED SWITCH & CONNECTOR & RD, TEST.
 RECALL, REPLACED DEACTIVATION SWITCH PER RECALL
 PERFORM RECALL PER ALL DEALER LETTER
 RECALL REPAIR PER REALL 99S15

A RECALLC OMPLEET
 RECALL, REPLACED SPEED CONTROL DEACTIVATION SWITCH.
 99330 REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15 PERFORMED RECAL
 AS PER RECALL 99S15 RECALL TO INSTALL SWITCH AND HARDSHELL CONNECTOR
 INSTALL SWITCH
 COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.
 - DONE 99S15
 PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION
 REPLACE ACTIVATION SWITCH PER RECALL
 PERFORMED SAFETY RECALL 99S15
 PERFORM RECALL 99S15 SPEED CONTROL
 COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER 99S15 RECALL

REPLACE DEACTIVATION SWITCH AND BLEED BRAKES
 RECALL 99S16 99S15B
 INSTALL UPDATE
 RECALL 99S15 COMPLETED RECAL
 PERFORM RECALL 99S15

PERFORM SPEED CONTROL DEACT SW RECALL

REPLACED BRAKE DEACTIVATION SWITCH
 RECALL 99S15 INSTALLED CRUISE DEACTIVATION SWITCH
 RECALL 99S15 PERFORM RECALL 99S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 105083 PERFORM 99S15
 48459 99S15 WF REPLACE SWITCH AND CONNECTOR PER RECALL
 RECALL 99S15
 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 PER RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL 99S15
 130185 RECALL 99S15 PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR
 PERFORM RECALL PER ALL DEALER LETTER
 1 INSTALL SWITCH FOR CRUISE CONTROL
 REPLACE DEACTIVATION SWITCH
 99S15 99S15

64612 RECALL 99S15 R/R SWITCH BLEED SYSTEM 2028
 PERFORM RECALL DEACTIVATION SWITCH
 PERFORMED AS PER RECALL
 1 RECALL COMPLETED 1
 REPLACED PRESSURE SWITCH AND CONNECTOR HARDSHELL PER RECALL
 RPELAC ECONNECTOR AND SWITCH FOR CC CRTL.

80125 INSTALLED SPEED CONTROL SWITCH

PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15
 PERFORM RECALL 99S15
 25882 RECALL REPLACED CRUISE SWITCH 99S15B— J5 HR.

1 PERFORM RECALL REPLACE DEACTIVATOR SWITCH

PERF RECALL 99S15
 1 INSTALLED SWITCH
 1 COMPLETED RECALL 99S15
 73853 .50 DID PER RECALL
 RECALL 99S15

INSPECT AND PERFORM RECALL
 RECALL REPLACE SPEED CONTROL SWITCH
 RECALL REPLACED CRUISE SW
 RECALL RECALL
 OPEN RECALL 99S15 RECALL

25882-823 11579

98815 88815 CRUISE CONTROL RECALL
 PERFORM RECALL PER PROGRAM
 RECALL 88815 REPLACED SPEED CONTROL SWITCH PER RECALL
 REPL SWITCH PER RECALL
 PERFORM RECALL
 REPLACE SWITCH 88815
 INSTALL SWITCH AND CONNECTOR
 INSTALLED CRUISE SWITCH
 1 PER RECALL REPLACE CRUISE DEACTIVATION SWITCH AND WIRING. OK
 COMPLETE RECALL
 88280 RECALL 88815 RECALL 88815
 128476 SERVICE WRITE UP INCORRECT, THIS RECALL IS FOR CRUISE SWITCH. INSTALLED CRUISE SWITCH AND CONNECTOR AS PER RECALL

RECALL RECALL
 PERFORMED RECALL
 98806 DID RECALL 88815 TECH 3213
 PERFORMED RECALL 88815
 REPL SWITCH PER RECALL
 38852 INSTALLED SWITCH LABOR OP88815B .5 HR

RECALL 88815B RECALL 88815B C-C ASS CORR 42
 88815 REPLACED SWITCH AND CONNECTOR
 DEACTIVATION SWITCH 88815
 RECALL PERFORM RECALL 88815
 1 PERFORM RECALL
 PERFORM RECALL
 REPLACED RECALL PART
 REPLACED CRUISE CUT OFF SWITCH PERFORMED RECALL 88815
 PER RECALL REPLACE THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 88815
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 28370 PERFORM RECALL 88815, REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 88889 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH ASSY
 1 REPLACED SWITCH BLEED BRAKES
 58350 PERF 88815, INST KIT.
 REPLACED CRUISE CABLE AS PER RECALL 88815
 COMPLETED RECALL
 PERFORMED RECALL
 117141 PERFORMED RECALL 88815. REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 88815 88815 RECALL
 PERFORMED RECALL 88815
 REPLACED CRUISE CONTROL SWITCH

1 INSTALL NEW SWITCH AND CONNECTOR
 87182 RECALL WARR INSTALLED 80 PARTS AS PER RECALL
 75172 REPLACED BRAKE SWITCH AS PER RECALL

RECALL-----BLEED BRAKES RECALL-----

SPEED CONTROL RECALL?

D

38878 RECALL W PERFORM 98S15 RECALL

107952 COMPLETED RECALL AS PER 98S15 INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

100831 INSTALLED SW. AND SHELL AS PER RECALL

RECALL RECALL

PERFORM RECALL

REPL DEACTIVATION SWITCH PER RECALL

113294 REPLACE BRAKE DEACTIVATION SWITCH

PERFORM RECALL

RECALL 98S15 RECALL 98S15

FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL.

98S15 RECALL

INSTALL DEACTIVATION SWITCH PER RECALL

81712 98S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH TEST DRIVE CRUISE RESTORED

98730 98S15 RECALL INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SW AND HARNESS PLUG AS PER RECALL 98S15

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

REPLACED SWITCH AS PER RECALL

REPLACED SPEED CONTROL SWITCH AS PER CAMPAIGN

OTHER 98S15 PERFORM RECALL

88301 LABOR 98S15***J***ADMIN***1*** COMPLETED RECALL 98S15*****

98907 RECALL W PERFORMED RECALL 98S15 JH

PERFORM 98S15

RECALL 98S15

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

DID RECALL, REPLACED THE SWITCH AND THE CONNECTO

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE. ALSO A FIRE COULD DEVOPE, REPLACE SPEED C

PERFORMED RECALL

REPLACE SPEED CONTROL PER RECALL 98S15

SPEED CONTROL RECALL

PERFORM RECALL

PERFORM RECALL CLOSED BY WPL

RECALL COMPLETE RECALL

REPLACE SWITCH AND CONNECTOR

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

SWITCH 98S15

PERFORMED RECALL

PERFORMED RECALL FOR CRUISE CONTROL MODIFICATION

PERFORMED RECALL 98S15

104484 RECALL REPL CRUISE SWITCH PER RECALL 87

38212 COMPLETED RECALL AS PER 98S15 INSTRUCTIONS

SWITCH REPL, SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15 R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR & BLEED BRAKE SYSTEM
 PERFORM RECALL PER FORD NOTICE
 OPEN RECALL 99S15B

PERFORM RECALL

1 PERFORM RECALL 99S15

RECALL 99S15 REPLACED SWITCH

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE BLEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL PERFORM RECALL 99S15

PERFORM RECALL 99S15

RECALL 99S15 PERFORMED RECALL 99S15

115194 RIR RECALL 99S15

PERFORMED RECALL

164710 99S15 INSTALL BRAKE SWITCH

REPLACE SWITCH PER RECALL 99S15

RECALL 99S15 R&R SWITCH & CONNECTOR

SPEED CNTRL DEACTVTN SWITCH REPLCMITPERF SAFETY RECALL 99S15

97410 RECALL WARR. REPLACE SWITCH AND CONNECTOR SHELL PER 99S15.

99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

99S15 REPLACE CRUISE SWITCH PER RECALL

PERFORMED 99S15 RECALL

00 99S15

PERFORMED RECALL

168225 REPLACED SWITCH PER RECALL TECH 806

RECALL 99S15 REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL 99S15 RECALL 99S15

PERFORM RECALL

74716 REPLACED SPEED CONTROL SWITCH AND CON, S-2 8274

99S15 RECALL PERFORMED 99S15

NOT OPERATING PROPERLY SPEED CONTROL - TEST

81890 PERFORMED 99S15, INSTALLED NEW SWITCH AND CONNECTOR, RETEST OK.

RECALL INSTALL SWITCH

PERFORMED RECALL

RECALL DID RECALL

RECALL 99S15

REPLACE SWITCH PER RECALL ADMIN.1

RECALL 99S15 RECALL PERFORME

REPLACE SWITCH AND HARDSHELL

RECALL 99S15 RECALL

ROAD TEST, PIN POINT TEST AS PER SHOP MANUAL, REPLACE DEACTIVATOR SWITCH TO CORRECT CONCERN, ROAD TEST OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH

77618 PERFORMED RECALL 99S15

A99 99S15

94811 RECALL RECALL REPLACED SPEED CONTROL DISENGAGE PRESSURE SWITCH AND CONNECTOR PER 99615 RECALL.
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPLACED SWITCH & CONNECTOR PER RECALL
 REPLACED SWITCH AND CONNECTORS PER RECALL
 RECALL NOTICE
 DIAG AND PERFORMED 99S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW
 RECALL 99S15 99S15
 PERF. RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SWITCH AS PER RECALL
 PERFORMED RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION
 COMPLETE RECALL
 INSTALL DEACTIVATION SWITCH AS PER RECALL
 INSTALL SPEED CONTROL DEACTIVATION SWITCH & CONNECTORS PER 99S15 RECALL SPECS.
 71465 TECH 879 PERFORMED RECALL 99S15 CRUISE SWITCH
 113856 REPLACE SWITCH AND CONNECTOR PER RECALL

PERFORMED RECALL 99S15
 99S15 99S15
 REPLACE SWITCH
 RECALL COMPLETE
 X RECALL

PERFORM RECALL 99S15
 RECALL 99S15 REPLACED SWITCH
 PERFORMED RECALL 99S15
 RECALL 99S15 DONE REPLACED SWITCH
 FACTORY RECALL COMPLETED RECALL
 INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS

REPLACED PARTS PER RECALL
 PERFORMED 99S15B

INSTALLED SWITCH AND CONNECTOR
 PERFORM RECALL 99S15
 99S15, PERFORMED RECALL
 99S15 RECALL PERFORMED
 RECALL 99S15 REPLACED SWITCH
 99S15 INSTALL SPEED CONTROL SWITCH
 CAMPAIGN COMPLETED
 RECALL 99S15 REPLACED SWITCH
 104830 RECALL 99S15 0.5
 REPLACE SPEED CONTROL SWITCH PER RECALL

88909 RECALL 0.5 INSTALLED NEW BRAKE SWITCH AND CONNECTOR 99815B
 RECALL 99815 RECALL 99815
 PREFORM RECALL 99815
 PREFORM RECALL PER BULLITIN
 RECALL 99815
 188857 REPLACED BRAKE SWITCH
 REPLACED DEACTIVATION SWITCH
 C 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 PERFORM RECALL 99815 INSTALL BRAKE PRESSURE SWITCH PER RECALL 99815
 1 PERFORM RECALL 99815
 DO RECALL 99815
 1 PERFORM RECALL
 1 PERFORM RECALL
 RECALL 99815B
 RECALL 99815 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99815
 REPLACED DEACTIVATION SWITCH
 X 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 PERFORMED CRUISE CONTROL RECALL PER FORD
 REPLACED CONNECTOR AND SWITCH PER RECALL
 RECALL REPAIR
 A89 99815
 PER RECALL
 PERFORM RECALL AS PER NOTICE
 RECALL 99815 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
 PERFORM RECALL
 77784 INSTALL NEW SW7.
 RECALL COMPLETED
 RECALL NOTICE
 88902 PREFORM RECALL PER LETTER

57547 PERFORMED RECALL 99815 BRAKE SWITCH OK FW. SEE P-A FOR MAIN. SER. P-A 23.
 REPLACE SWITCH AS PER RECALL
 X 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 DEACTIVATION SWITCH AND CONNECTOR. REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 PERFORM RECALL
 R AND R SWITCH PER RECALL.
 RECALL 99815 COMPLETE RECALL 99815
 INSTALLED DEACTIVATION SWITCH
 80609 RECALL 99815 INSTALL CRUISE DEACT SWITCH
 RECALL 99815 REPLACED SWITCH
 PERFORMED RECALL
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL T
 RECALL PERFORMED
 RECALL 99815 REPLACED SWITCH

REPLACE SWITCH AND HARD SHELL
 PERFORM RECALL RECALL PERFORME
 1 PERFORMED RECALL 98S15 DEACTIVATION SWITCH CONNECTOR AND SWITCH
INSTALL SWITCH AND CONNECTOR AS PER RECALL
 RECALL 98S15 RECALL 98S15
 34194 DUE 98S15 RECALL NOTE TRANS FLUID SHOULD HAVE BEEN CHANGED AT 30000 AND FLUID TURNING BROWN NEEDS TRANS SERVICE SOOZN THROTTLE B1
 1 RECALL COMPLETED

98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 98S15 PERFORMED RECALL
 PREFORM 98S15 AS INSTRUCTED
 REPL CRUISE CONTROL SWITCH
 48177 WF RENEW HARD SHELL CONNECTOR AND SWITCH
 RECALLED 98S15 PERFORMED
 RECALL PERE FORM RECALL 98S15
 98143 RECALL COMPLETE. REPLACED SWITCH AND CONNECTOR.
 REPLACE SWITCH

REPLACED DEACTIVATION SWITCH
 RECALL 98S15 RECALL, REPLACED SWITCH
 OK AND REPAIR PER RECALL INFO

RECALL 98S15 REPLACED SWITCH
 REPLACE SWITCH AND HARD SHELL
 PERFORMED CAMPAIGN 98S15B DONE
 PERFORMED 98S15B
 INSTALL SWITCH AND HARD SHELL

COMPLETE RECALL
 85780 PERFORMED RECALL 98S15 - REPLACED SWITCH
 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 PERFORMED RECALL
 104044 REPLACED CRUISE SWITCH
 PERFORMED RECALL 98S15 PERFORM PERMANENT REPAIR ON CRUISE CONTROL-AS PER RECALL REPLACED BRAKE PRESSURE SWITCH
 RECALL 98S15 REPLACED SWITCH
 OPEN RECALL 98S15 PERFORMED RECALL 98S15
 RECALL R-R DEAC SW, R-R CONNECTOR, INSTALLED NEW, RECKD OK.

PERFORMED RECALL
 48903 98S15B 0.5 HRS. SPEED CONTROL RECALL

COMPLETE RECALL
 PERFORMED RECALL 98S15 AND CHECKS OK
 SPEED CONTROL SWITCH 98S15 RECALL
 REPLACED BRAKE DEACTIVATION SWITCH

RECALL REPLACE DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 X 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 REPLACED SWITCH PER RECALL
 REPLACE SWITCH PER RECALL
 PERFORM RECALL 99815 CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 99815 RECALL 99815
 99815B REPLACE DEACTIVATION SWITCH

 99815 99815 RECALL, INSTALL NEW SWITCH & CONNECTOR
 COMPLETE RECALL
 77732 RECALL 99815, REPLACE CRUISE SWITCH AND CONNECTOR
 RECALL PERFORMED RECALL-CRUISE INOP. NOT CONNECTED WITH RECALL NO REPAIRS MADE AT THIS TIME
 PERFORMED 99815 RECALL REPLACE CRUISE DEACTIVATION SWITCH 1
 PERFORM RECALL AS PER NOTICE
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99815
 PERFORM RECALL ON CRUISE DEACT SWITCH

 COMPLETED RECALL, REPLACED DEACTIVATION SWITCH
 CHECKED OASIS. REPLACE SPEED CONTROL DEACTIVATION SWITCH ROADTEST
 BOXB REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 75427 REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACED SPEED CONTROL SWITCH FOR RECALL
 REPAIR AS PER RECALL
 59980 99815 RECALL WARRANTY REMOVED SPEED CONTROL SWITCH AND CONNECTOR AND REPLACED THEM WITH NEW 3314
 MODIFIED PER RECALL

 PERFORMED RECALL
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99815
 PERFORMED RECALL 99815
 113728 INSTALLED CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 RECALL 99815 DONE
 99815 CRUISE CONTROL 99815
 COMPLETE RECALL

 PERFORM RECALL
 PERFORMED RECALL 99815
 RECALL 99815 - REPLACE DEACTIVATION SWITCH COMPLETE
 82497 REPLACE SWITCH AND CONNECTOR PER 99815
 NO PARTS IN STK. COMPLETED RECALL AS OUTLINED REMOVED DEACTIVATION SWITCH AND INSTALLED NEW SWITCH AND CONN. THANK YOU
 99815 PERFORMED RECALL
 99815 99815 REPLACED CRUISE DEACTIVATION SWITCH
 RECALL REPAIR
 PERFORM RECALL PER INSTRUCTIONS
 RECALL REPLACE CRUISE DEACT SWITCH

98S15 98S15
 REPLACED DEACTIVATION SWITCH
 136361 R-R SW PER RECALL
 RPL SWITCH PER 98S15
 SPEED CNTRL DEACTVTN SWITCH RPLCMNTPERF SAFETY RECALL 98S15

RECALL 98S15
 RECALL DONE
 98S15 REPLACE SWITCH
 RECALL 98S15 REPLACED SWITCH AND CONNECTOR PER RECALL
 PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK
 COMPLETED RECALL
 PERFORM RECALL KIT B
 PERFORM RECALL 98S15B
 PERFORMED RECALL
 98S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR

COMPLETE RECALL
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 98S15 98S15
 PERFORM RECALL
 RECALL CRUISE CONTROL RECALL 98S15
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15
 COMPLETE RECALL
 INSTALLED SPEED DEACTIVATION SENSOR
 RECALL 98S15 COMPLETED
 48620 98S15 PERFORMED RECALL
 R&R CRUISE SWITCH
 RECALL 98S15
 PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH.
 REPLACE DEACTIVATION SWITCH
 90090 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR
 98S15 98S15
 PERMITS-AUTH# PER FORD RECALL HOTLINE CHECKED UNIT AND FOUND UNIT HAD FIRE DAMAGE-ADVISED FORD TECH INSPECTED UNIT AND REPLACED MAIN ENG
 REPLACED SPEED CONTROL ACT SWITCH AND HARD SHELL CONN. PER RECALL 7548
 REPAIR AS PER RECALL 98S15.
 INSTALLED DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 98S15B RECALL 3 PERFORM RECALL

RECALL 98S15
 PERFORMED 98S15B
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

024 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH
PERFORMED RECALL AS PER FORD SPECIFICATIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH SWITCH WITH UPDATED KIT
PERFORMED RECALL AS PER INSTRUCTIONS 98S15

PERFORMED 98S15 RECALL
PERFORMED RECALL 98S15

98S15 PERFORM RECALL 98S15 REPLACE DEACTIVATION SWIC
PERFORM RECALL
98S15 98S15 RECALL, R/R CRUISE CONTROL BRAKE CANCEL SWITCH
98S15 RECALL RECALL 98S15
PERFORM RECALL INSTALL SWITCH
RECALL 98S15

CRUISE SWITCH RECALL
PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
RECALL COMPLETED

31574 INSTALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORMED RECALL

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
VEHICLE WAS TOWED IN SWITCH BURNT UP AND MELTED ALL THREE HARNESS WIRES ABOVE IT PERFORMED RECALL AND ALSO CHANGE ALL THREE MAIN HARNE

98S15 REPAIRED AS PER RECALL
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS
REPLACE SWITCH AND HARD SHELL
PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABEL AND RECHECK OK
PERFORM RECALL 98S15 REPL SWT AND CONNECTOR.
REPLACE BRAKE PRESSURE SWITCH PER RECALL
RECALL COMPLETE
REPLACED DEACTIVATION SWITCH AS PER RECALL

RECALL 98S15 REPLACED SWITCH
INSTALL BRAKE KIT #BX##
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS PER FORD
PERFORMED RECALL
COMPLETED 98S15
INSTALL DEACTIVATION SWITCH 98S15 RECALL PER FORD INSTRUCTIONS
98S15 98S15
PERFORM RECALL. REPLACE CRUISE CONTROL DEACTIVATION SWITCH.

COMPLETED RECALL, INSTALLED DEACTIVATION SWITCH AND CONN ASSY
 88: PERFORMED 98S15 RECALL, REPLACE BRAKE SENS
 REPL CRUISE CONTROL SWITCH
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 70783 98S16B 0.5 HRS. SPEED CONTROL RECALL
 RECALL REPLACE SWITCH AND CONNECTOR PER RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL RECALL
 PERFORMED RECALL 98S15
 98S15 98S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
 REPLACE SWITCH AND CONNECTOR
 COMPLETE RECALL 98S15
 44742 PARTS REPL SPEED CONTROL DEACTIVATION SWITCH 98S15 THREADS STRIPPED

RECALL CRUISE SWITCH
 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL
 51076 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL
 COMPLETED RECALL
 98S15 REPLACED DEACTIVATION SWITCH
 1 PERFORM RECALL

PERFORM RECALL 98S15
 122230 INSTALLED BRAKE KIT PER RECALL
 REPLACE FAILED SWITCH
 RECALL SPEED CONT REPLACE DEACTIVATION SWITCH
 INSTALLED NEW SWITCH PER RECALL
 PERFORMED RECALL
 SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 1 REPLACED SPEED CONTROL SWITCH PER RECALL
 INSTALLED SWITCH PER RECALL
 RECALL COMPLETED
 PERFORMED RECALL 98S15 - CHECK AND REPLACED CRUISE CONTROL CABLE

REPLACED DEACTIVATION SWITCH PRE RECALL 98S15
 98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
 FORD RECALL REPLACED DEACTIVATION SWITCH
 RECALL REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL 98S15 INSTALLED BRAKE PRESSURE SWITCH. ROAD TEST AFTER RECALL
 REPLACED SWITCH
 RECALL COMPLETED

52870 PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
 98S15 98S15

PERFORMED RECALL
 PERFORM RECALL. REPLACE SPEED CONTROL DEACTIVATION SWITCH 99S15
 REPAIR AS PER RECALL 99S15.
 PERFORMED RECALL 99S15
 REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 1 REPLACED SPEED CONTROL SWITCH PER RECALL
 128110 RECALL DONE
 99S15 PERFORMED RECALL
 91518 WARR INSTALLED SPEED CONTROL DEACT SWITCH AS PER RECALL 99S15
 RECALL CRUISE CUT OFF SWITCH
 1 PERFORM RECALL AS PER INSTRUCTIONS
 RECALL 99S15 REPLACED CRUISE DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15
 83404 99S15.8

43341 REPLACE DEACTIVATION SWITCH 99S15B 0.5 ADMIN 0.1
 1 REPLACE BRAKE SWITCH AND CONN PER RECALL
 1 PERFORMED RECALL
 SERVICE INSTALLED SWITCH PER RECALL

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH K1
 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 99S15 RECALL PERFORM RECALL

PERFORMED RECALL
 OPEN RECALL PERFORMED RECALL 99S15
 PER NOTIFICATION RECALL 99S15 RENEW CRUISE CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15 INSTRUCTIONS
 REPLACE DEACTIVATION SWITCH
 CRUISE RECALL DONE PER FACTORY
 COMPLETE RECALL
 120035 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0937
 1 PERFORM RECALL
 1 PERFORM RECALL
 PERFORM RECALL
 130072 REPAIR PER 99S15B 0.5
 ...REPLACE SWITCH AND CONNECTOR AS PER RECALL # 99S15
 1 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCHS 99S15B
 99S15 99S15
 99999 DID RECALL 99S15 LABOR OP.— 99S15B— 11.5 HRS. 8-27-89
 INSTALL SWITCH PER RECALL 99S15
 COMPLETE RECALL 99S15, SWITCH AND CONNECTOR
 1 COMPLETED RECALL 99S15
 112287 INSTALL RECALL PIECES
 C INSTALL SWITCH AS PER RECALL
 RECALL PERFORMED
 RECALL COMPLETE

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS
1 PERFORM RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

REPLACED BRAKE DEACTIVATION SWITCH

RECALL 98S15 PERFORMED RECAL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 98S15 REPLACED SPEED CONTROL SWITCH

51251 WARR RECALL; REPLACE DEACTIVATOR SWITCH AND CONNECTOR

PERFORM RECALL 98S15

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.

93219 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15 TEST OK

50046 RECALL W INSPECT REPLACE DEACTIVATION SWITCH AND CONNECT OR PER 98S15 \$4 9830

REPLACED SWITCH

1 RECALL COMPLETED

RECALL COMPLETED

37577 REPLACE THE CRUISE DEACTIVATOR SWITCH 98S15B 0.5 HRS. TECH 2112

REPLACE DEACTIVATION SWITCH AS PER RECALL

98S15 98S15

OWNER NOTIFICATION CRUISE CONTROL RECALL 98S15

REPLACED DEACTIVATION SWITCH

1 REPLACED SWITCH PER RECALL

CAMPAIGN COMPLETED

1 PERFORMED 98S15 RECALL 794 WARRANTY

1 REPLACE DEACTIVATION SWITCH

RECALL COMPLETED CRUISE SWITCH RECALL

COMPLETE INSTALLED SWITCH AS PER RECALL

82874 WT RECALL 98S15

CHECKED OASIS. INSTALLED SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

91442 98S15 INSTALLED A BRAKE KIT PER THE RECALL,RETESTED OK

R AND R SPEED CONTROL SWT PER RECALL

104363 RECALL 98S15 REPLACED DEACTIVATION SWITCH PER RECALL.

84734 RECALL 98S15 RECALL 98S15

. REMOVE TAPE AND SECURE DEACTIVATION SWITCH 98S15E .3

PERFORMED RECALL

REPLACE SWITCH PER RECALL

REPLACE DEACTIVATION SWITCH PER 98S15

PERFORMED RECALL 98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

INSTALLED BRACKET.

RECALL SW REPL

COMPLETE RECALL 99S15
 INSTALL DEACTIVATION SWITCH
 RECALL 99S15B DONE REPLACED CABLE
 PERFORM RECALL
 RECALL SW REPL
 REPLACED DEACTIVATION SWITCH PER RECALL
 99S15B RECALL W PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15

122821 RECALL 99S15 PERFORMED 99S15 PER INSTRUCTIONS
 1 REPLACED SPEED CONTROL SWITCH
 92312 R-R SW
 RECALL 99S15 PERFORMED 1
 RECALL COMPLETE
 99S15 99S15
 106632 RECALL WPP40 INSTALL CRUISE CONTROL DISCONNECT SWITCH.
 PERFORM RECALL
 RECALL 99S15
 RECALL REPLACE BRAKE SWITCH AND PLUG HARNESS PER RECALL
 REPLACE BRAKE PART PER 99S15

99S15 99S15B 0.5 ADMIN 0.1
 99S15B 0.5 ADMIN 0.1 REPLACE SPEED CONTROL SWITCH
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

1 REPLACE SWITCH AND SHELL

32573 RECALL 99S15 RECALL 99S15 DEACTIVATION SWITCH
 PERFORMED RECALL
 RECALL REPLACE SWITCH; BLEED BRAKES
 X 99S14 REPLACE WIRE CONNECTOR AND INSPECT FOR HEAT DAMAGE
 PERFORMED RECALL 99S15
 RECALL SW REPL
 99S15 WT REPLACED BRAKE SWITCH
 PERFORMED OPEN RECALL
 49880 RECALL 99S15 0.5 HRS DID RECALL 99S15B
 PERFORM RECALL
 1 PERFORM RECALL
 REPAIR AS PER RECALL
 PERFORM RECALL
 PERFORM RECALL 99S15
 1 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 RECALL CRUISE CUT OFF SWITCH
 COMPLETE RECALL 99S15
 INSTALLED KIT TO COMPLETE

99S15-925 11992

80258 REPL CRUISE DEACTIVATION SWITCH PER RECAL

RECALL 98815 REPLACED SPEED CONTROL SWITCH PER RECALL
27114 INSTALL SPEED CONTROL SWITCH PER RECALL

INSTALLWS KIT 98815 RECALL PERFORMED

98815B

RECALL

CRUISE SW

SPEED CNTRL DEACTVTN SWITCH REPLCMTPERF SAFETY RECALL 98815

RECALL REPAIR

REPLACE SPEED CONTROL SWITCH, BRAKE ADAPTOR CRACKED AND HAD TO BE REPLACED.

REPLACE SPEED CONTROL SWITCH, BRAKE ADAPTOR CRACKED AND HAD TO BE REPLACED.

1 REPLACE DEACTIVATION SWITCH

UNK

PERFORMED RECAL

1 INSTALLED KIT RECALL COMPLETED

COMPLETE RECALL 98815

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98815

REPLACE SPEED CONTROL DEACTIVATION SWITCH

98815

CRUISE

PERFORM RECALL 98815

RECALL 98815

1 REPLACED SPEED CONTROL SWITCH 98815 RECALL

REPLACED SWITCH AND CONNECTORS

98815

PERFORM RECALL 98815

65079 WAIR DONE RECALL 98815 REPLACE BRAKE REPAIR KIT

REPLACE SWITCH

98815

98815

REPL SWITCH

98815

PERFORMED RECALL

RECALL

INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

NAC REWORK AS PER RECALL

0

RECALL 98815

PERFORM RECALL 98815-REPLACE SPEED CONTROL SWITCH AND CONNECTOR

58595 0.50 PERFORM RECALL 98815 AND REPLACE HARD SHELL CONNECTOR

RECALL CRUISE SW

SW REPL

RECALL

PERFORM RECALL 98815 SPEED CONTROL

REPLACED DEACTIVATION SWITCH AND REPAIRED CONNE CTOR

167252 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL

1 PER RECALL REPLACE SWITCH

98815 COMPLETE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL PERFORM RECALL # 0636

67335 INSTALLED NEW CRUISE DEACT. SWITCH AND CONNEC.

RECALL COMPLETE

1 PERFORMED RECALL 99S15. REPLACE DEACTIVATION SWITCH.
 PERFORMED OPEN RECALL
 UNK PERFORMED RECAL
 RECALL REPAIR
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 COMPLETE RECALL 99S15
 44683 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
 95D17 99S15 S-W RECALL WT REPLACED SPEED CONTROL DEACTIVATION S-W AND CONNECTOR PER RECALL
 RECALL 99S15 REPLACE C-C SW
 PERFORMED RECALL
 COMPLETE RECALL 99S16 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPLACE SPEED CONTROL SWITCH
 1 PERFORMED RECALL 99S15.TEC 128 WARR
 REPLACED SWITCH AS PER RECALL 99S15
 FORD CAMPAIGN MI OUT 67,417 REPLACE SPEED CONTROL BRAKE SWITCH PER RECALL 99S15.
 RECALL 99S15
 49055 RECALL W-F REPLACE SWITCH.
 RECALL 99S15
 RECALL REPAIR
 REPLACE DEACTIVATION SWITCH
 RECALL 99S15 RECALL 99S15
 68094 99S15 B 0.6 REPL SW
 70882 W.. REPLACE CRUISE SWITCH PER RECALL

 PERFORMED RECALL
 RECALL 99S15
 PERFORMED RECALL 99S15
 RECALL INSTALLED BRAKE KIT AS PER RECALL
 PERFORM RECALL
 58849 PERFORM RECALL 99S15, REPLACE CRUISE CONTROL SWITCH WITH NEW CONNECTOR.
 REPLACED DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH AND REPAIRED WIRE
 PERFORMED RECALL
 INSTALL SWITCH PER RECALL
 PERFORM 99S15 RECALL REPLACED SWITCH AND CONNECT
 PERFORMED RECALL 99S15
 RECALL COMPLETED
 99S16 99S15
 REPLACED SWITCH

 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION
 28338 99S15 W REPLACE SPEED CONT. SWITCH
 1 RECALL PERFORMED
 RECALL CRUISE REPL SW
 REPLACED DEACTIVATION SWITCH PER RECALL
 PERFORMED RECALL AS PER 99S15

41005 99S15 PERFORMED RECALL 99S15
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15
 PERFORM RECALL 99S15
 PERFORMED RECALL
 39531 RECALL 99S15 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL
 REPLACE DEACTIVATION SWITCH PER RECALL 99S15
 PERFORMED RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 R AND R SPEED CONTROL CABLE AS PER RECALL

CAMPAIGN COMPLETED
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

99S15 99S15
 RECALL 99S15 REPLACED SPEED CONTROL SWITCH
 RECALL REPLACE SWITCH PER RECALL
 INSTALLED DEACTIVATION SWITCH AND HARDSHELL PER 99S15 RECALL
 INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
 INSTALL DEACTIVATION SWITCH PER 99S15
 92911 99S15B 0.5 - ADMIN 0.1 RECALL
 180198 99S15 RECALL WARRANTY REMOVED SPEED CONTROL DEACTIVATION SWITCH AND REPLACED IT AND THE CONNECTOR WITH NEW 3314

INSTALL CRUISE DEACTIVATION SWITCH AS NOTED IN RECALL 99S15 ALL OK TO RELEASE
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15.
 08 COMPLETE RECALL
 113831 RECALL 99S15 REPLACED CRUISE CONTROL DEACTIVATE SWITCH AND CONNECTOR AS PER RECALL
 1 REPLACED SWITCH AND CONNECTOR AS PER 99S15 RECALL
 RECALL 99S15 RECALL DONE

REPLACE SWITCH
 PERFORMED RECALL
 V 99S15 PERFORMED RECALL
 PERFORM RECALL
 REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL 4827

PERFORM RECALL
 SPEED CONTROL STICKING PERFORMED 99S15 RECALL
 RECALL DONE
 39531 NOT APPLICABLE
 99S15 SPEED CONTROL RECALL
 14001 W. REPLACE CRUISE SWITCH PER RECALL (CG82)
 136772 RECALL 99S15B 0.5 REPLACE DEACTIVATION SPEED CONTROL SWITCH
 PERFORM RECALL
 99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH A
 64045 W PERFORM RECALL

08727 REPLACED CRUISE SWITCH PER RECALL
 SERVICE PUBLICATION 98815 REPLACED SWITCH
 PERFORMED RECALL 98815
 REPLACE CONNECTOR AND SWITCH
 RECALL COMPLETED
 PERFORMED RECALL 98815
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 988
 90485 RECALL W-F REPLACE SPEED CONTROL SWITCH.
 REPLACED SWITCH AND CONNECTOR AS PER RECALL

SPEED CONTROL DEACTIVATION SWITCH REPLACE 98815B PERFORMED RECALL 98815B
 PERFORM RECALL 98815
 RECALL 98815 PERFORMED RECAL
 98815 RECALL
 PERFORMED RECALL 98815 1
 RECALL CRUISE SW REPL
 40473 INSTALL SOP RECALL 98815, DEACTIVATION KI
 REPLACE SPEED CONTROL CABLE AS PER RECALL 98815
 49284 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH
 1 PERFORM RECALL 98815
 REPLACE DEACTIVATION SWITCH PER RECALL 98815
 RECALL 98815

RECALL 98815 PERFORMED
 118108 RECALL#98815 SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACT SWITCH AND CONNECT OR PER RECALL#98815.
 SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 PERFORM RECALL PER INSTRUCTION RECALL PERFORMED PER INSTRUCTION .3 98815E .3
 RECALL RECALL
 98815
 98738 RECALL 98815B 0.5 REPLACED SPEED DEACTIVATION SWITCH PER RECALL 98815.

REPLACE CRUISE CONTACT SWITCH
 REPLACED SWITCH
 78781 RECALL. INSTALLED CRUISE DEACTIVATION SWITCH AND CONNECTOR
 130795 RECALL WPB40 INSTALL CRUISE CONTROL DISCONNECT SWITCH
 X 98815
 REPLACED DEACTIVATION SWITCH.
 REPLACE DEACTIVATION SWITCH AS PER RECALL
 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 98815B .5 - ADMIN .1
 RECALL

REPLACE CRUISE CONTROL SWITCH
 RECALL COMPLETED
 RECALL 98815 COMPLETED RECALL 98815 (CRUISE CONTROL SWITCH) HAS BEEN COMPLETED
 98815 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN.
 INSTALLED PARTS AS PER RECALL

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SOEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PERFORM RECALL

99S15 99S15 RECALL

133238 R-R SW
RECALL CAMPAIGN PERFORMED RECALL CAMPAIGN, REPLACED DEACTIVATION SWITCH
REPLACE DEACTIVATION SWITCH

D
77813 WF REPLACED RECALL
RECALL REPAIR

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
114157 PERFORMED RECALL 99S15.
REPLACE SWITCH AND HARD SHELL
REPL SPD CNTRL DEACTIVATION SW
SPEED CONTROL DEACTIVATION SWITCH99S15
APPLIED RECALL 99S15
RECALL 99S15
COMPLETE RECALL 99S15
PERFORMED RECALL 99S15, 99S15B .5HRS LABOR
RECALL RECALL

28867 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONECTOR TK372
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15.
REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR,BLEED BRAKES.
PERFORM RECALL 99S15

130647 RECALL 99S15B 0.0 REPLACED CRUISE CONTROL DEACTIVATION SWITCH.
R & R CRUISE CONTROL DEACTIVATION SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL
REPLACE SWITCH AND HARNESS PER RECALL
REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL
PERFORMED RECALL AS PER INSTRUCTIONS
RECALL COMPLETED -DID 99S15B.
99S15-SPEED CONTROL 99S15-SPEED CONTROL
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
RECALL 99S15 - B - RECALL

81671 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATOR SWITCH & HARDSHELL CONNECTOR 5 WP
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SOEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED
RECALL 99S15
RECALL 99S15 REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15
PERFORM RECALL 99S15 99S15 00
RECALL 99S15 PERFORM RECALL 99S15
D

53024 PERFORMED RECALL 99S15 INSTALLED CRUISE K
REPLACED SPEED CONTROL SWITCH
RECALL 99S15 R&R SPEED CONTROL SWITCH
PERFORMED RECALL 99S15
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL RECALL COMPLETE
COMPLETE RECALL 99S15
92926 COMPLETED RECALL 99S15
REPLACE CRUISE DEACTIVATION SWITCH PER 99 S 15

99S15 RECALL RECALL
RECALL 99S15
PERFORM RECALL 99S15

OPEN RECALL PERFORM RECALL
95480 REPLACED DEACTIVATION SWITCH & CONNECTOR

RPLC DEACTIVATION SWITCH PER 99S15
REPLACE DEACTIVATION SWITCH
RECALL 99S15 PERFORMED 1
INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL REPAIR
110020 RECALL 99S15 REPLACE THE SPEED DEACTIVATION SWIT REPLACED THE SPEED DEACTIVATION SWITCH
38867 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPLACE DEACTIVATION SWITCH PER RECALL
58183 AS PER RECALL
83532 RECALL W REPLACE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.
CHECK AND PERFORM 99S15 DEACTIVATION
PERFORMED RECALL 99S15
RECALL 99S15 COMPLETED

1 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH AND CONNECTOR
77709 PERFORM RECALL 99S15

94783 99S15 RECALL 99S15 REPLACE DEACTIVATION SWITCH
1 COMPLETED RECALL PER INSTRUCTIONS
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
99S15 99S15
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRING HARD SHELL CONNECTOR BLEED BRAKES.
RECALL PERFORM RECALL 99S15
28765 REPLACE CRUISE BRAKE SWITCH
REPL DEACTIVATION SWITCH PER RECALL
RPLC CRUISE CTRL DEACTIVATION SWITCH PER 99S15
62940 PERFORMED 99S15 RECALL
RECALL 99S15 CRUISE CONTROL
REPLACE CRUISE CONTROL SWITCH

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
RECALL RECALL
PERFORMED RECALL
REPLACE SWITCH CONNECTION PER 99S15.

99S34 99S15 WARR REPLACED PARTS PER 99S15 RECAL
REPLACE SPEED SWITCH
INSTALL SWITCHG AND CONNECTOR PER RECALL

95216 99S15 R&R CRUISE CONTROL SWITCH
PERFORM RECALL

REPLACED DEACTIVATION SWITCH PER SAFTEY RECALL 99S15.
REPLACE CRUISE SWITCH PER RECALL
75410 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
PRDG 99S15 BRAKE REPAIR KIT
AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

UNK PERFORMED RECAL
REPLACE CRUISE SWITCHES PER RECALL 99S15
RECALL 99S15 RECALL
RECALL PERFORMED
INSTALLED DEACTIVATION SWITCH AS PER RECALL
RECALL RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
39S11 WARR PERFORM RECALL 99S15 SPEED CONTROL SWITCH AND CONNECTOR
RECALL 99S15 - B - RECALL

PERFORM RECALL REPLACE SWITCH
1 INSTALLED SWITCH
REPLACE CRUISE CONTROL SWITCH
99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
99S15 RECALL 99S15 REPAIRED AS PER RECALL
REPLACED SWITCH
REPLACED CRUISE CONTROL DEACTIVATION SWITCH
COMPLETED RECALL
NAC 99S15
INSTALL SPEED CONTROL SWITCH AND SWITCH CONTROLLER, AS PER 99S15 CAMP.

R&R DEACTIVATION SWITCH
COMPLETE RECALL 99S15
75941 REPLACE SWITCH AND HARD SHELL CONNECTOR AS OUTLINED IN RECALL
PERFORMED RECALL
99S15 REPL DEACTIVATION SWITCH
99S15 RECALL

ENR2-025 11000

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 REPLACE SWITCH PER FORD RECALL
 PERFORMED RECALL 99S15
 RECALL 99S15B
 FACTORY RECALL COMPLETED RECALL
 1 COMPLETED RECALL PER FORD INSTRUCTIONS. REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH.
 RECALL PERFORMED RECALL 99S15.
 141117 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 6115
 RECALL PERFORMED
 INSTAL SWITCH
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
 1 PERFORMED RECALL 99S15, INSTALLED NEW DEACTIVATION SWITCH
 99S15 99S15
 RECALL PERFORM RECALL 00S15
 REPLACED DEACTIVATION SWITCH PER INSTRUCTIONS.
 REPLACE SPEED CONTROL SWITCH PER RECALL
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15 PER INSTRUCTIONS
 PERFORM RECALL
 RECALL 00S15 RECALL 00S15
 REPLACE CRUISE SWITCH PER RECALL
 RECALL 99S15 REPLACE C-C SW
 INSTALLED DEACTIVATION KIT

1 INSTALL SPEED CONTROL SWITCH
 INSPECT AND REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACED CRUISE SWITCHCH PER RECALL

REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15
 RECALL PERFORMED RECALL 99S15.
 75465 00S15 W REPLACED SPEED CONTROL 0037
 COMPLETED FACTORY RECALL
 99S15B PERFORMED RECALL - REPLACED SWITCH
 PERFORM RECALL 99S15. INSTALL DEACTIVATION SWITC
 PERFORM RECALL-REPLACE SWITCH
 FACTORY RECALL COMPLETED RECALL
 1 REMOVE AND REPLACE CRUISE CONTROL SWITCH PER RECALL
 RENEW SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.
 INSPECT AND REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL 99S15
 PERFORM RECALL
 RECALL REPLACED CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL.

24741 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH

REPLACE DEACTIVATION SWITCH PER RECALL
39490 RECALL 99S15 6310 REPLACE SWITCH & PLUG G
PERFORM RECALL 99S15
08731 R-R SW PER RECALL
49299 I DID THE RECALL 99S15.
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
PERFORM RECALL 99S15 REPLACE CONNECTOR AND SWIT

RECALL 99S15 PERFORM RECALL 99S15
REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL
REPLACED CRUISE DEACTIVATION SWITCH
PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH PER 99S15
105801 PERFORM RECALL 99S15 REMOVED SPEED CONTROL CUT OFF SWITCH AS PER RECALL THREADS INSIDE CONNECTING BLOCK CAME OUT WITH SWITCH L
OPEN RECALL PERFORM RECALL
131078 RECALL 0.5 REPLACED SPEED CONTROL SWITCH
99S15 REPLACED DEACTIVATION SWITCH
PERFORM RECALL
52790 W REPLACE SWITCH 99S15 ME
TECH REPLACED DEACTIVATION SWITCH AS REQUIRED
117108 RECALL 99S15 PERFORMED RECALL
PERF RECALL 99S15
RECALL PERFORMED
SPEED CONTROL DEACT. SWITCH R/R DEACTIVATION SWITCH AS DIRECTED
REMOVE AND REPLACE CRUISE CONTROL DEACTIVATION K
99S15 RECALL
RECALL 99S15 COMPLETED
PERFORMED RECALL
PERFORM RECALL 99S15 RECHECK OPERATION SYSTEM OK
PERFORM RECALL
1 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR OPER 99S15B
REPL SPEED CONTROL DEACTIVATION 99S15
PERFORM SPEED CONTROL DEACT SW RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 99S15
REPLACE SWITCH

PERFORM 99S15 CRUISE CONTROL RECALL
PER RECALL PERF RECALL
AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL
REPLACE DEACTIVATION SWITCH
RECALL PERFORMED RECALL # 0838
RECALL 99S15 REPLACED SWITCH
PERFORMED RECALL AS PER 99S15
83674 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15
73489 PERFORMED RECALL 99S15
REPLACE SPD. CONTROL DEACTIVATION SWITCH

0903-020 11001

RECALL COMPLETE
PERFORMED RECALL
33385 RECALL - CRUISE CONTROL SWITCH REPLACE SWITCH & CONNECTOR AS PER RECALL
98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN.

REPLACED SWITCH
REPLACE SWITCH AND HARNESS PER RECALL

PERFORM RECALL INSTALL REPAIR KIT
122548 98S15 W BCD SWITCH GA
83582 RECALL 98S15 INSTALL SWITCH AND CONNECTOR
1 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
REPLACE SWITCH AND HARD SHELL
98S15 RECALL 98S15 REPAIRED AS PER RECALL
REPLACE BRAKE SWITCH & BLEED BRAKES
APPLIED RECALL 98S15
PERFORMED RECALL PERFORM RECALL, REPLACE PRESSURE SWITCH AND CONECTOR.

REPLACE DEACTIVATION SWITCH PER RECALL

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR PER RECALL
REPLACE DEACTIVATION SWITCH
RECALL 98S15 PERFORM RECALL 98S15
52806 REPLACED THE SWITCH AND THE CONNECTOR FOR RECALL 98S15
98S15 RECALL 98S15 REPAIRED AS PER RECALL
1 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
RECALL REPAIR
88022 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

REPLACE PER RECALL

PERFORMED RECALL
REPLACE SWITCH AND CONNECTOR
42 REPLACED DEACTIVATION SWITCH AND RETESTED
PERFORM 98S15 RECALL
PERFORM RECALL
88018 SWITCH RECALL RECALL COMPLETED
REPLACED SPEED CONTROL SWITCH
PERFORM RECALL 98S15
98S15 98S15 REPLACED DEACTIVATION SWITCH
PERFORM RECALL 98S15-SPEED CONTROL DEACTIVATION SWITCH
PERFORMED RECALL 98S15
RECALL 98S15 98S15 COMPLETED RECALL
REPLACE SW.

48550 PERFORMED RECALL AND INSTALLED NEW SWITCH AND CONNECTOR FOR SPEED CONTROL
99S15-1827 REPLACED SPEED CONTROL DEACTIVATION SWITCH

111080 PERFORM 99S15 RECALL

PERFORMED RECALL

1 PERFORM RECALL 99S15

PERFORM RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

INSTALL SPEED CONTROL SWITCH

95258 REPLACED SWITCH PER RECALL

REPLACED BRAKE PRESSURE-SPEED CONTROL DE-ACTIVATION SW. AND CONNECTOR PER RECALL 99S15.

PERFORMED RECALL 99S15 REPLACED SWITCH PROPORTIONING VALVE WAS STRIPPED OUT HAD TO REPLACE DIFFERENTIAL VALVE ASSEMBLY BLEED SYSTEM

1 08 REPLACED DEACTIVATION SWITCH PER RECALL

AS PER RECALL 99S15 RECALL TO REPLACED DEACTIVATION SWITCH & HARDSHELL CONNECTO

OPEN RECALL PERFORMED RECALL 99S15

RECALL 99S15 PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPLACED CONNECTOR

PERFORM RECALL

99S15 RECALL PERFORMED.

INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATOR SWITCH PER CUSTOMER NOTIFICATION

99S15 99S15

PERFORMED RECALL PER FORD NOTICE

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL #99S15 RECALL #99S15

COMPLETED RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

RECALL 99S15

PERFORMED RECALL 99S15

PERFORMED RECALL

45223 WARRI PERFORMED RECALL 99S15

116307 RECALL PERFORM RECALL 99S15 AS PER INSTRUCTIONS ROAD TEST AND CHECK SPEED CONTROL OPERATION FOUND OK

PERFORMED RECALL 99S15

117719 INSTALLED RECALL

REPLACE KIT PER RECALL

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE SWITCH.

62961 RECALL 99S15 WR RECALL 99S15 SPEED CONTROL ACTIVATION. REPLACE CONNECTOR AND PRESSURE SWITCH RECHECK,PASS OK
 PREFROM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH 1
 E PERFORM RECALL
 1 REPLACED DEACTIVATION AND CONNECTOR AS PER RECALL 99-S-15
 OPEN RECALL COMPLETE RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH.

TECH 145 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL 99S1
 99S15 99S15 PERFORM RECALL REPLACED SWITCH
 118232 PERFORM RECALL, REPLACE SWITCH AND CONNECTOR M
 RECALL 99S15 REPLACE BRACKET FOR INERTIA SWITCH
 78815 RECALL DID RECALL 99S15
 1 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL
 REPLACED DEACTIVATION SWITCH 99S15 REPAIRED PER RECALL

REPAIR AS PER RECALL 99S15.

FACTORY RECALL COMPLETED RECALL
 PERFORM RECALL R, I SWITCH FOR CRUISE SYSTEM INSTALL NEW CONNECTOR

99S15 RECALL PERFORM RECALL
 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT
 99S15 INSTALL DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACED DISENGAGE SWITCH PER RECALL 99S15.
 RECALL; REPAIR PER RECA
 COMPLETED RECALL 99S15

A RECALL COMPLET
 COMPLETED RECALL 99S15
 RECALL REPLACE SWITCH
 59899 RECALL 99S15 0.5 REPLACED CRUISE CONNECTOR

PERFORM SPEED CONTROL MODIFICATION
 79536 RECALL WA PERFORM RECALL, REPLACE SWITCH AND CONNECTOR
 INSTALLED DEACTIVATION SWITCH KIT PER INSTRUCTIONS ADMIN
 REOKAGED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTORS AS PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 99S15 REPLACED SPEED DEACTIVATION SWITCH
 RECALL PERFORM RECALL 99S15
 INSTALLED SWITCH AND CONNECTOR

ADD 88S15
 REPLACED DEACTIVATION SWITCH
 COMPLETE RECALL 88S15
 RECALL 88S15. CARRY OUT FACTORY RECALL AS DESCRIBED BY BULLETIN

88S15 RECALL WARR REPLACE SWITCH AND CONNECTOR. SHELL PER 88S15.
 COMPLETED RECALL PER NOTIFICATION.
 RECALL 88S15 RECALL COMPLETED
 140584 RECALL .5 REPLACED SPEED CONTROL SWITCH PER RECALL
 111257 RECALL PERFORMED RECALL 88S15
 PERFORM RECALL 88S15

ADD 88S15
 REPLACE SWITCH PER RECALL
 RECALL COMPLETED
 COMPLETED RECALL 88S15
 PERFORMED RECALL

88S15 88S15
 PERFORM RECALL 88S15 --REPLACE SPEED CONTROL SWITCH
 PERFORM SPEED CONTROL RECALL
 INSTALLED SPEED CONTROL SWITCH
 RECALL REPLACE SWITCH
 58080 INSPECT & INSTALL CRUISE SWITCH & BLEED SYSTEM AS PER 88S15 RECALL.
 48805 PERFORMED RECALL RETESTED OK

88S15 88S15
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 COMPLETED RECALL
 VERIFY R&R SWITCH AND CONNECTOR PER RECALL
 PERFORM RECALL 88S15
 REPLACED SWITCH

PERFORMED RECALL 88S15
 1 ACCESS & REPLACE DEACTIVATION SWITCH AS PER RECALL 88S15
 42368 W PERFORM RECALL REPLACE DEACT SWITCH
 REPLACE KIT PER RECALL

PERFORMED RECALL
 PERFORMED RECALL 88S15 FOR SPEED CONTROL
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 88S15.
 INSTALL UPDATED SWITCH AND CONNECTOR

PERFORM RECALL
 PERFORMED RECALL 88S15
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 88S15 TO SPECIFICATIONS PER FORD MOTOR CO. REPLACED DEACTIVATION SWITCH AND HARD-
 INSTALL DEACTIVATION SWITCH
 PERFORM RECALL PER FORD NOTICE
 REMOVE TAPE AND SECURE LABOR OF 88S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 88S15B .5 REPLACED SPEED CONTROL DEAC
 PERFORM RECALL
 INSTALL KIT PER RECALL
 88S15 88S15 RECALL REPLACED CRUISE SWITCH

OWNER NOTIF PERFORMED RECAL

PERFORM RECALL

PERFORMED 98S15 SPEED CONTROL DEACTIVATION SWITCH RECALL. INSPECTED. REPLACED SWITCH AND CONNECTOR AS PER RECALL. PERFORMED 98S15 SPE
REPL SWITCH PER RECALL.

REPLACE HARDBELL CONNECTOR & SWITCH PER RECALL

130312 PERFORMED RECALL 98S15 REPLACEMENT OF SPEED CONTROL DEACTIVATION SWITCH AND AND PLUG.

REPLACED CRUISE DEACTIVATION SWITCH AS PER RECAL

98S15 98S15

PERFORM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SWITCH

1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.

RECALL 98S15

REPLACE KIT PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH DUE TO RECALL

COMPLETED RECALL 98S15, CRUISE CONTROL SWITCH

PERFORMED RECALL 98S15 INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED DEACTIVATOR AND SWITCH 98S15 REPAIRED PER RECALL

72169 REPLACED DEACTIVATION SWITCH AS PER RECALL# 9815

COMPLETED RECALL

REPAIR AS PER RECALL

58886 SAFETY RECALL 98S15 LABOR OF 98S16B 0.5 HRS, REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 98S15

181214 PERFORM RECALL 98S15

SPEED CONTROL SWITCH 98S15 RECALL

RECALL PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATOR

98S15 SPEED CONTROL SWITCH RECALL. MIL.30667 REPLACED SPEED CONTROL SWITCH AND CONNECTOR AS PER RECALL

REPLACE KIT PER RECALL

INSTALLED SWITCH PER RECALL

RECALL REPLACED BRAKE SWITCH AS PER RECALL 98S15

49991 PARTS AND SERVICE FROM RO 360844 42 98952 FOUND DEACTIVATION SWITCH TO BE LEAKING R AND I NEW SWITCH

PERFORMED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

106327 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

PERFORM RECALL

RECALL 98S16 REPLACED SPEED CONTROL AS PER RECA
 90557 REPLACE SWITCH & CONNECTOR
 98S15 RECALL 98S15 RECALL COMPLETE
 REPLACED CRUISE DEACTIVATION SWITCH
 COMPLETE RECALL 98S15 REPLACE SPEED CONTROL SWITCH.
 PERFORMED RECALL
 INSTALL SWITCH AND CONNECTOR
 PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS

REPLACE SWITCH PER RECALL
 1 INSTALLED SWITCH RECALL COMPLETED
 98S15 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL PERFORMED RECAL
 PERFORMED RECALL AS OUTLINED 1
 CHECK FOR RECALLS 98S15 OPEN PERFORM RECALL F
 REPLACE SPEED CONTROL SWITCH PER RECALL
 INSTALL DEACTIVATION SWITCH PER RECALL 98S15 98S16B .50
 R & R SPEED DEACTIVATION SW PER RECALL 6189 T
 R&R SWITCH PER RECALL 98S15

REPLACE SWITCH AND CONNECTOR AS PER RECALL
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRING CONNECTOR HARD SHELL BLEED BRAKES.
 REPLACE SWITCH AND HARDSHELL CONNECTOR
 RECALL INSTALLED CRUISE DEACTIVATION SWITCH

CO42 RECALL 98S15 98S15B-0.5- 0.5 TOTAL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER 98S16 RECALL.
 RECALL 98S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH 98S15 PER RECAL

REPLACE KIT PER RECALL
 X COMPLETED
 MISC PERFORMED RECAL
 93070 RECALL DID RECALL 98S15
 94855 .50 DID PER REALL RIDE LIGHT ON DASH AND RUN VERY BAD
 PERFORMED RECALL 98S15.TEC 126 WARR
 74701 98S15 PERFORM RECALL REPLACE SWITCH AND CONNECTOR
 15733 PERFORM RECALL - BRAKE DE-ACTIVATION SWIT
 1 PERFORMED RECALL 98S15
 118254 OPEN RECALL 98S15 REPLACE SWITCH DONE REINSPECT OK
 REPLACED CRUISE DEACTIVATION SWITCH.
 PERFORM SPEED CONTROL RECALL

75820 RECALL .6 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S16B
 1 PERFORMED RECALL 98S15
 COMPLETED RECALL
 INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN
 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 22820 DEACTIVATION SWITCH RECALL R&R DEACTIVATION SWITCH AND CONNECTOR PER RECAL L,BLED BRAKES, AND CHECKED;OK

48548 REPLACE DE ACTIVATION SWITCH

F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 1 COMPLETED RECALL
 REPLACED SPEED CONTROL SWITCH AS PER RECALL 99S
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AD HARD-SHELL CONNECTOR

103886 REPLACED CRUISE SWITCH PER RECALL
 RECALL 99S15 COMPLETED
 RECALLED 99S15 PERFORMED
 RECALL 99S15 DONE
 80285 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL
 OTHER 99S15 PERFORM RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 REPLACED SWITCH AND CONECTOR
 REPLACE SW AND PLUG
 RECALL REPLACE SPEED CONT DEACTIVATION SWITCH
 PERFORMED THE RECALL 99S15

CHECKED AND FOUND VEH NEEDED CRUISE DEACT SWITCH PER RECALL 99S15 REPLACED SWITCH PER RECALL 99S15 CHECKED SYSTEM OK AT THIS T TIME
 REPLACE CABLE PER RECALL
 INSTALLED SWITCH AND HARD SHELL CONNECTOR
 121883 99S15S.B ADMIN .1
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 PERFORM RECALL
 PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 RECALL DONE
 99S15 VERIFIED 99S15 RECALL COMPLETED
 REPLACED DEACTIVATION SWITCH AS PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 REPLACED DISENGAGE SWITCH PER RECALL 99S15
 84388 70 PERFORM 99S15 R R SPEED COTTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST
 88819 PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 RECALL DONE
 REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
 RECALL DONE
 REPLACE SWITCH AND CONNECTOR
 RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT
 INSTALL NEW DEACTIVATION SWITCH AND HARSHHELL CONNECTOR 99S15
 118184 RECALL WP40 PERFORMED RECALL, REPLACED BRAKE PRESSURE SWITCH ASSY.
 PERFORM RECALL
 REPLACE CRUISE SWITCH PER RECALL WARR

11804 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
INSTALL DEACTIVATION SWITCH PER 99S15

RECALL PERFORMED RECALL
99S15 99S15

RECALL 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT
REPLACE CRUISE CONTROL CANCEL SWITCH

01149 RECALL 5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR AS REQUIRED.

82984 RECALL WARR R AND R SPEED CONTROL DEACTIVATOR SWITCH PER RECALL INSTRUCTIONS.
RECALL RECALL

42718 RECALL INSTALL RECALL

82532 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONECTOR TK372

111475 RECALL W PERFORM RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SW AND HARD SHELL CONNECTOR LABOR OF 99S15B .5HRS ADMIN .1HRS
99S15 99S15 RECALL

85088 RECALL 99S15 WARR INSTALL SWITCH PER RECA

1 PERFORMED PINPOINT TESTS FOUND DEFECTIVE DEACTIVATION SWITCH REMOVE AND REPLACE SWITCH
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.

PERFORMED 99S15

127720 99S15 INSTALL BRAKE SWITCH AND CONNECTOR

RECALL 99S15 COMPLETED RECALL 99S15

PERFORMED THE RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15

TECH COMPLETED RECALL AS REQUIRED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN

55438 COMPLETED RECALL 99S15

REPLACED CRUISE SWITCH AS PER RECALL 99S15

1 REPLACE CRUISE CONTROL DEACTIVATOR SWITCH PER RECALL 99S15

99S15 INSTALL KIT 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND BLEED SYSTEM

COMPLETED RECALL PER INSTRUCTIONS

RECALL 99S15 REPLACE SWITCH AND CONNECTOR

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

99S15 99S15 RECALL

1 INSTALLED CRUISE SWITCH

PERFORMED RECALL AS NEEDED ALL OK

REPLACE SWITCH PER RECALL

REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL

99S15 99S15 DONE

INSTALL SWITCH AND CONNECTOR

REPLACED THE SWITCH AND BLEED THE BRAKES

REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
99S15 99S15 RECALL DO

COMPLETED RECALL 99S15

43942 COMPLETED RECALL 99S15. 245

1 INSTALL SPEED CONTROL DEACTIVATION

REPL SPEC ORDER PARTS FOR RECALL

47879 RECALL 99S15 DONE DEACT SWITCH

REPLACED DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL 99S15

63011 99S15B 0.5 ADMIN 0.1

REPLACE PERISHER BRAKE VALVE

94178 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15 LABOR OF- 99S15B 0.3 HRS

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1

RECALL -99S15

PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH

48783 TECH 738 HAS FINISHED INSTALLING RECALL 99S15 ON SPEED CONTROL SWITCH.

PERFORMED RECALL 99S15 SPEED CONTROL DEAC SW REPLASWITCH

RECALL

REPLACE DEACTIVATION SWITCH PER RECAL

52888 99S15 RECALL WARR 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S15

PERFORM RECALL 99S15

87321 RECALL REPLACED SWITCH AND CONECTOR PER RECALL

REPLACED CRUISE CONTROL SWITCH

PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH ANDCONNECTOR

REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL

PERFORMED RECALL

PERFORM RECALL

PERFORM RECALL

PERFORM RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

PERFORMED THE RECALL 99S15

PERFORM RECALL 99S15

1 INSTALL DEACTIVATION SWITCH PER RECALL

99S15

REPLACED SWITCH

99S15-SPEED CONTROL

99S15-SPEED CONTROL

SWITCH

99S15 RECALL PERFORMED

REPLACE SPEED CONTROL DEACTIVATION SWITCH 1

RECALL 99S15

99S15 COMPLETED RECALL

RECALL 99S15

RECALL 99S15

58442 RECALL RECALL INSTALL DEACTIVATION SWITCH PER 99S15

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

RECALL COMPLETED

RECALL 99S15

PERFORM RECALL 99S15
 REPLACE SPEED CONTROL SWITCH AS PER RECALL
 RECALL 99S15
 PERFORM RECALL 99S15 SPEED CONTROL
 PERFORMED RECALL
 COMPLETED FACTORY RECALL
 RECALL 99S15 REPLACED SPEED CONTROL SWITCH
 101055 WARR 99S15B 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR
 PERFORMED RECALL
 RECALL PERFORMED
 REPL CRUISE CONTROL SWITCH
 RECALL PERFORM RECALL
 1 PERFORMED 99S15 RECALL
 PERFORM RECALL 99S15
 RECALL REPLACE DEACTIVATION SWITCH
 PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CO
 RECALL PERFORMED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 1 REPLACED DEACTIVATOR SWITCH
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 PERFORMED RECALL
 1 PERFORM RECALL
 REPLACE SWITCH PER RECALL LETTER
 PERFORM RECALL
 PERFORM 99S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORMED RECALL AS PER FORD SPECIFICATIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.
 99S15 99S15 REPLACED SWITCH AND CONNECTOR
 99S15B PERFORMED RECALL
 99S15 PERFORM RECALL 99S15, REPLACE SWITCH AND CONNECTOR
 INSTALL CRUISE SWITCH AND HARNESS PLUG AS PER 99S15 RECALL
 1 COMPLETED RECALL PER INSTRUCTIONS
 PERFORMED RECALL 99S15 AS PER FORD SPECIFICATION
 PERFORM RECALL 99S15
 99S15 RECALL PERFORMED 99S15 RECALL PERFORMED
 RECALL 99S15 PERFORM RECALL 99S15
 9 PERFORM RECALL 99S15
 1 PERFORMED 99S15 RECALL 794 WARRANTY
 REPLACED SPEED CONTROL-DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 INSTALLED NEW SPEED DEACTIVATION SWITCH PER FORD RECALL #99S15
 118540 PERFORM RECALL 99S15 REPL HARDSHELL CONNECTOR AND SWITCH CRUISE DEACTIVATION
 RECALL COMPLETED

 REPLACE SPEED SWITCH AND HARD COVER AS PER RECAL

PERFORM RECALL
RECALL 99S15

PERFORM RECALL 99S15 PER LETTER

80890 INSTALL SPEED CONTROL SWITCH PER RECALL

PERFORM RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 99S15 RECALL

CHECKED OASIS. REPLACED DEACTIVATION SWITCH

INSTALL CRUISE SWITCH

RECALL RECALL

PERFORMED RECALL

1 PERFORM RECALL

TEST CRUISE LOCATE AN OPEN CIRCUIT IN THE DEACTIVATION SWITCH REPLACED SWITCH REPAIR CONNECTION RETEST M1 TIME FOR NO LABOR OR AVAILABLE
REPLACED CABLE

SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CIRCUIT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVATION S

RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONTROLLER AS PER RECALL 99S15

REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL

PERFORMED RECALL

1 PERFORMED RECALL 99S15

REPLACED SWITCH AND CONNECTOR

RECALL 99S15 REPLACE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

COMPLETED OP 99S15B CAMPAIGN COMPLETED 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15

PERFORM RECALL 99S15

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACED SWITCH PER RECALL 99S15

99S15 REPLACE SWITCH AND CONNECTOR PER RECALL

99S15 REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL

REPLACED DEACTIVATION SWITCH PER RECALL 99S15

COMPLETED CAMPAIGN COMPLETED OP 99S15B

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

87498 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 0937

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

RECALL COMPLETED

99S15B-0.5- RECALL 99-S-15 (CC42) REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR

SPEED CNTRL DEACTIVN SWITCH REPLCMTPERF SAFETY RECALL 99S15

RECALL 99S15

RECALL

REPLACE BRAKE SWITCH AND INSPECT HARNESS PER RECALL

1 PERFORM RECALL

INSPECTED PER RECALL SWITCH AN HARNESS NOT REPLACED REPLACED SWITCH AN HARNESS ALL OK

INSTALL SWITCH BRKT

DEACTIVATION SWITCH AND CONNECTOR. REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

PERFORMED RECALL

RECALL PERFORMED RECALL
 RECALL 99815,CRUISE SWITCH
 1 REPLACED CRUISE SWITCH AND BLEED BRAKES. MILEAGE IS CORRECT
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER R ECALL.
 RECALL 99815 COMPLETED RECALL 99815
 REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99815 RECALL
 99815 PERFORMED RECALL
 115810 DONE WITH RECALL 99815 SPEED CONTROL SWITCH HAD TOO REPLACE PORPORTIONING VALVE AND BLEED BRAKES TEST DROVE AND WORKS FINE
 RECALL PERFORM RECALL 99815
 INSTALLED SPEED CONTROL SWITCH
 INSPECT AND PERFORM RECALL
 REPLACED CONNECTOR AND SWITCH BLEED BRAKES. RETEST OK
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
 PERFORMED RECALL 99815 SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL 99815
 99870 RECALL 99815 DONE SPEED CONTROL DEACT SWITCH
 PERFORM RECALL
 PERFORM RECALL
 1 REPLACED THE SPEED CONTROL DEACTIVATION AS PER FORD RECALL INSTRUCTION
 1 REPLACE C-C SWITCH
 REPLACED DEACTIVATION SWITCH.
 PERFORM RECALL 99815 T121
 99815 SPEED CONTROL DEACTIVATION 99815 SPEED CONTROL DEACTIVATION SWITCH

 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99815B
 R&R CRUISE DEACTIVATION SWITCH
 RECALL DONE
 99810 RECALL INSTALL NEW SWITCH AND CONNECTOR AS REQ
 PERFORMED RECALL
 PERFORMED RECALL 99815

 RECALL 99815
 REPLACE PROPORTIONING VALVE,THREADS FOR DEACTIVATION SWITCH STRIPPED,PERFORM RECALL
 DISCONNECTED SPEEDO CABLE AS PER RECALL INTERIM REPAIR
 RECALL PERFORM RECALL 99815
 PERFORMED RECALL 99815
 99815 99815 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 REPLACED DEACTIVATION SWITCH AS PER RECALL
 81874 99815 OK OUT AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 INSTALL SWITCH & CONNECTOR, BLEED AS PER RECALL 99815
 92780 RECALL 99815 INSPECT SPEED CONTROL SYSTEM. REMOVE AND REPA E THE DEACTVATING SWITCH PER RECALL.
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.
 REPLACE SW.
 RECALL 99815 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH
 REPLACED SWITCH AND CONECTOR

99678 PERFORM 99815 (99815B 0.5).

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

PERFORMED RECALL 99815

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99815

REPLACE CRUISE DEACTIVATION SWITCH CONNECTOR

99815 RECALL 99815 RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99815.

0000 99815B 0.5 - ADMIN 0.1 RECALL

REPLACE SPEED CONTROL SWITCH

X COMPLETED COMPLETED

RECALL PERFORM RECALL

CRUISE CONTROL

RECALL 99815

REPLACE SPEED CONTROL CABLE AND REPLACE PER RECA

RECALL. REPLACED DEACTIVATION SWITCH AS PER RECALL

99815 RECALL 99815 RECALL

04265 REPLACE SWITCH PER LETTER

RECALL CRUISE REPL SW.

PRMFD RECALL 99815

INSTALLED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

OPEN RECALL. COMPLETED OPEN RECALL

OPEN RECALL. PERFORMED RECALL 99815

PERFORM RECALL PER BULLITIN

REPLACE SPEED CONTROL DEACTIVATOR SWITCH PER RECALL.

REMOVE TAPE AND SECURE LABOR OP 99815E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99815B .5 REMOVED TAPED AND SECURED SI

RECALL 99815. REPLACED SWITCH AND CONNECTOR AS PER RECALL 99815

RECALL 99815 PERFORM AS INSTRUCTED

PERFORMED RECALL 99815B.

99815 RECALL 99815 REPAIRED AS PER RECALL

1. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 99815B .5

REPLACE SPEED CONTROL SWITCH PER RECALL 99815

99815 RECALL

REPL SPD CNTRL DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL

RECALL COMPLETE

99815 99815 REPLACED SWITCH AND CONNECTOR
 PERFORMED RECALL 99815
 COMPLETED RECALL 99815 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99815B .5 + .1
 PERFORM RECALL
 INSTALL DEACTIVATION SWITCH
 PERFORM RECALL 99815 T121

REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
 PERFORMED RECALL
 99815 99815 REPLACED SWITCH AND CONNECTOR
 RECALL 99815 PERFORM RECALL 99815 REPLACE SWITCH AND CONNECTOR.
 COMPLETED RECALL
 MODIFIED PER RECALL

RECALL RECALL COMPLETE
 PERFORM RECALL
 REPLACED SWITCH AND CONECTOR
 RECALL COMPLETE

REPLACE SPEED CONTROL SWITCH PER RECALL
 REPLACED CONNECTOR PER RECALL
 99857 PERFORMED RECALL 99815
 1 REPLACED SWITH BLEED BRAKES
 PERFORM RECALL 99815
 . INSTALL DEACTIVATION SWITCH AS PER 99815
 99815 99815
 1 PERFORMED RECALL 99815
 RECALL 99815 REPLACED DEACTVATER SWITCH AS PER RECALL 99815
 RECALL 99815 RECALL COMPLETED
 115745 PERFORM RECALL 99815 REPLACED SPEED DEACT SWITCH M5 TECH 522
 73229 PERFORMED RECALL, INSTALLED SPEED CONTROL DEACTIVATION SWITCH.
 INSTALL NEW SWITCH AND CONNECTOR AS PER RECALL 99815
 RECALL 99815

REPLACED SC DEACTIVATION SWITCH 99815
 1 REPLACE SWITCH AND CONNECTOR AS PER RECALL
 PERFORMED SERVICE CAMPAIGN . 99815 B .5 ADMIN .1
 99815 REPLACED BRAKE DEACTIVATION SWITCH AS PER RECALL
 SPEED CONTROL SWITCH RECALL
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 G RC 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE
 RECALL 99815B 99815B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL
 RECALL 99815 99815 COMPLETED RECALL
 REPLACED SWITCH PER RECALL
 COMPLETED RECALL 99815

2002-025 11619

RECALL 98815 REPLACED DEACTIVATION SWITCH
PERFORMED RECALL

0 RECALL 98815
98815 RECALL COMPLETE
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTED
9881583 REPLACE SWITCH AND HARDSHELL CONNECTOR
COMPLETED RECALL
PERFORM RECALL PER INSTRUCTION
80463 REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
INSTALL DEACTIVATION SWITCH PER RECALL 98815
PERFORMED RECALL, INSTALL SWITCH AND CONNECTOR
COMPLETE RECALL
97029 REPLACE SPEED CONTROL SWITCH AND HARD SHELL CONNECTOR
95787 RECALL 98815 INSTALLED RECALL
REPLACED SWITCH AND CONNECTOR
80085 R-R DEACTIVATOR SWITCH PER RECALL
98815 RECALL 98815 COMPLETED RECALL
13477 PERFORM RECALL 98815 REPLACE CUT OFF SWITCH AND PLUG FOR CRUISE
RECALL SW REPL CRUISE SW
REPLACED SPEED CONTROL SWITCH
70640 RECALL RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH.
REPLACE SWITCH

47808 RECALL PERFORM RECALL AS OUTLINED NECESSARY TO REMOVE INNER L-F FENDER TO GAIN ACCESS TO FROZEN DEACTIVATION SWITCH
PERFORMED RECALL
89423 PERFORM RECALL, REPL SWITCH 98615B .5
REPLACE SWITCH CONNECTOR AND FUSE PER RECALL 988
INSTALLED NEW CONNECTOR PER 98815 RECALL
71880 PERFORMED RECALL 98815.
REPLACED CRUISE SWITCH
1 PER RECALL R-R DEACTIVATION SWITCH AND CONNECTOR ON CRUISE CONTROL
PER NOTIFICATION RECALL 98815 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98815 RECALL INSTRUCTIONS
1 INSTALL CONNECTOR PER RECALL
RECALL RECALL COMPLETE
RECALL 98815 COMPLETED RECALL 98815
REPLACE SPEED CONTROL DEACTIVATION SWITCH
98815B 98815B
MODIFIED PER RECALL
70604 PERFORMED RECALL 0.5
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98815
PERFORMED RECALL #23 MM
38308 R-R DEACTIVATION SWITCH & CONNECTOR FOR RECALL

PERFORMED RECALL
COMPLETED RECALL

RECALL REPLACE CRUISE SWITCH AS PER RECALL
SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH
1 PERFF RECALL-REPLACE DEACTIVATION SWITCH
RECALL COMPLETE
REPLACE SWITCH RECALL 99S15
PERFORM RECALL

CRUISE CONT REPL SWITCH
RECALL AS PER LETTER
RECALL COMPLETED.
70245 42W W REPLACE SWITCH AND CONNECTOR PER RECALL 3472
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
PERFORMED RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL
RECALL CRUISE REPL SW
PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISECONTROL CABLE AND RECHECK OK
RECALL PERFORMED RECALL # 0636
RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15
1 PERFORMED RECALL 99S15.
99-S-15 99-S-15 COMPLET
REPLACE SPEED CONTROL SWITCH
99S75 REPLACED SWITCH AND HARDSHELL CONNECTOR PER RECALL.
RECALL 99S15
RECALL 99S15 REPLACE C-C SW
COMPLETE RECALL 99S15
RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR
48428 REPLACED SWITCH & CONNECTOR
53747 RECALL 99S15 W PERFORMED RECALL 99S15 INSTALLED PRESSURE SWITCH
REPLACED SWITCH PER RECALL
RECALL 99S15 RECALL COMPLETED
REPLACE BROKE SWITCH AND CONNECTOR PER RECALL
REPLACE SWITCH AND CONNECTOR
PERFORM RECALL 99S15
PERFORMED RECALL 99S15
67862 PERFORMED RECALL, REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED THE SWITCH PER RECALL 99S15
PERFORMED RECALL
RECALL AS PER LETTER
99S15 RMR DEACTIVATION SWITCH & CONNECTOR
99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL
INSTALLED SWITCH PER RECALL
RECALL 99S15 PERFORMED RECALL 99S15B
91236 REPLACE SWITCH AND HARD SHELL
RECALL DEACTIVATE SPEED CONTROL

ENR2-025 11017

COMPLETED RECALL

93071 99S15 B 0.5 REPL DEV CRUISE SW

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL

POSSIBLE SHORT CIRCUIT IN SPEED CONTROL DEACTIVATION SWITCH REPLACE SWITCH PER BULLETIN 99S15

PERFORMED RECALL

PERFORM RECALL 99S15 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

122602 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONECTOR TK372

118159 RECALL INSTALL SWITCH PER RECALL

X 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

PERFORMED RECALL 99S15 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

118904 DID RECALL

A DONE

REPLACE SWITCH AND HARNESS PER RECALL

REPLACE SPEED SWITCH AS PER RECALL

PERFORMED 99S15 RECALL

FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

RECALL REPLACE SWITCH & CONNECTOR

G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SWITCH PER RECALL LETTER

INSTALL CRUISE CABLE PER RECALL 99S15

PERF RECALL AS PERSCRIBED

RECALL AS PER CUSTOMERS LETTER

REPLACED SWITCH PER RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15 INSTRUCTIONS

47095 PERFORMED RECALL 99S15

62963 REPLACED SWITCH AND HARNESS END PER RECALL- TECH 642

REPLACE SWITCH

PERFORMED RECALL 99S15 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK

REPLACED DEACTIVATION SWITCH

PERFORM SAFETY RECALL

REPLACED SWITCH AND CONNECTOR

REPLACE DEACTIVATION SWITCH

RPL SPEED CONTROL BRAKE SWITCH PER 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH TO PREVENT CRUISE FROM SHORTING OUT COMPLETE

43662 WARR INSTALL CRUISE CONTROL DEACTIVATION SWITCH

FORD FACTORY RECALL NOTICE PERFORMED FACTORY RECALL AS PER RECALL NOTICE DONE

PERF RECALL 99S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

PERFORMED 99S15 RECALL

PERFORM RECALL 98S15

PERFORM 98S15

PERFORMED RECALL 00S15

84705 PERFORMED RECALL 98S15, R-R DEACTIVATION SWITCH AND CONNECTOR, BLEED RR BRAKE.

RECALL 00S15 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

73026 42 WP40 98S15 RECALL REPLACE SWITCH

OPEN RECALL PERFORMED RECALL 98S15

48811 98S15 W REPLACED SPD CONTROL DEACTIVATE SW 0897

PER NOTICE PERFORM RECALL

PERFORMED RECALL 98S15

POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH INSPECTED VEHICLE - HAS ONLY VACUUM OPERATED SYSTEM

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

REPLACE AFFECTED VECI LABELS REPLACE FAULTY DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPL SWITCH PER RECALL

OWNER NOTIFICATION 98S15B

PERFORM RECALL 98S15- REPLACE SPEED CONTROL SWITCH

103505 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B

PERFORMED RECALL

RECALL 98S15 RECALL, REPLACED DEACTIVATION SWITCH

RECALL 98S15 OPEN PERFORM RECALL

REPLACE SPEED CONTROL PER RECALL

REPLACE SWITCH

INSTALL SPEED CONTROL HARNESS

98S15 REPALCE SWITCH

128061 98S15 PERFORMED RECALL 98S15.

PERFORMED RECALL

REPLACED CRUISE DEACT SWITCH

98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL

RECALL 98S15 DONE

PERFORMED RECALL

77441 98S15 SPEED CONTROL SWITCH RENEW DEACTIVATION SWITCH FOR RECAL 23

PERFORMED RECALL

INSTALL SWITCH PER RECALL

FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL SWITCH WAS NOT DISCONNECTED

REPLACE SPEED CONTROL CABLE

SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SOEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

85408 PERFORM C-C RECALL

PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH, PER 98S15

RECALL PERFORM RECAL 98S15

RECALL CK AND REPL FLUID CC SWITCH AND CONECTOR PER RECALL. WF TEC300 ON DRIV

INSTALL SWITCH AND CONNECTOR

98S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

RECALL RECALL REPLACE SPEED CONTROL SWITCH

COMPLETE RECALL 98S15

REPLACED DEACTIVATION SWITCH PER RECALL 98S15

RECALL 98S15

INSTALLED SPEED CONTROL SWITCH AS PER RECALL 98S

1 COMPLETED RECALL 98S15 NOTE-SEE JOB#6 FOR RECALL RELATED REPAIRS...

68486 TESTED SPEED CONTROL ELEC. SPEED CONTROL INOP. PINPOINT TEST, OPN IN BRAKE PRESSURE SWITCH, REPLACED SWITCH, BLEED BRAKES. ROAD TE

RECALL 98S15 98S15

RECALL REPAIR PER RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 98S15 REPLACE C-C SW

- MODIFY PER RECALL 98S15

PERFORMED RECALL 98S15

COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

REPLACE SWITCH PER RECALL

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.

PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 98S15 INSPECT REPLACED SPEED CONTROL DEACTIVATED SWITCH AND CONN

COMPLETED RECALL 98S15B 1

RECALL 98S15 PERFORMED RECALL 98S15

98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL

COMPLETED RECALL

RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

10625 REPLACED SW- AND CONNECTOR FOR CRUISE DEACTIVAT PER RECALL 98S15.

SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVATION SWIT

PERFORM RECALL 98S15

PERFORMED RECALL

REPAIRED PER 98S15

CONTROL DEACTIVATION SWITCH RECALL

SAFETY RECALL 98S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH

98S15 RECALL PERFORMED

INSTALLED SPEED CONTROL DEACTIVATION SWITCH.

80731 REPLACED CRUISE CUT OFF SWITCH AS PER RECALL

RECALL 98S15 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL
RECALL REPAIR PER RECA

REPLACE CRUISE CONTROL SWITCH AND CONNECTOR
PERFORMED RECALL
RECALL 99S15B RECALL 99S15B C-C A99 CORR 42
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
COMPLETE RECALL 99S15
SPEED CONT REPL SWITCH
PERFORMED RECALL

REPLACE CONNECTOR AND SWITCH
99S28 WARR PERFORM RECALL 99S15 B REPLACE SWITCH AND CON- NECTOR
0 DEFECTIVE SWITCH.X REF RO 64448 LINE 51
RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH
REPLACE SWITCH AND HARD SHELL
99S15B PERFORMED RECAL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
PREFORM SPEED CONTROL DEACTIVATION RECALL

REPLACED CRUISE SWITCH PER RECALL
PERFORMED RECALL

87768 RECALL .5 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B
PERFORMED RECALL
RECALL 99S15 PERFORMED RECALL 99S15B
99S15 99S15 PERFORM RECALL REPLACED SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 1
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
94744 RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL INST.
RECALL SW REPL
PERFORM RECALL AS PER INSTRUCTIONS
RECALL COMPLETE
99S15 REPLACED SWITCH AND CONNECTOR
REPLACE SWITCH PER RECALL LETTER
RECALL 99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
B 99S15
PERFORM 99S15
1 PERFORMED RECALL
PERFORM RECALL 99S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
REPL DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH PER 99S15
 C RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTORS. CHECK NORMAL OPERATION.
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR.
 INSTALL SWITCH PER RECALL
 COMPLETE RECALL 99S15
 1 REPLACED SPEED CONTROL SWITCH AS PER 99S15
 REPLACED SPEED CONTROL SWITCH AND WIRE CONNECTIO
 21042 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B

REPAIR CRUISE CTL PER RECALL
 PERFORMED RECALL 99S15 PER LETTER OF INSTRUCTION
 REPL CRUISE CONTROL SWITCH
 RECALL SPEED CONTROL DEACTIVATIONREPLACE CRUISE SWITCH AND CONECTOR
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

COMPLETED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.
 PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS
 ADD ON AUTH SB 1 PERFORMED RECALL C
 RECALL 99S15
 RECALL 99S15
 PERFORMED RECALL 99S15
 PERFORM RECALL
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15 99S15 REPAIR AS PER RECALL
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 REPLACE CRUISE SWITCH

RECALL #99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 REPLACE DEACTIVATOR PER INSTRUCTIONS
 RECALL COMPLETED
 RECALL COMPLETE
 PERFORMED RECALL 99S15
 RECALL 99S15 PERFORM RECALL 99S15
 SUPPLEMENT #1 5-88 INSPECTION OPERATION ADDED REPLACE SOEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL RECALL
 PERFORMED RECALL
 PERFORM RECALL 99S15 INSTALL BRAKE KIT PER RECALL 99S15
 51000 PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 99S15,CRUISE SWITCH
 REPLACE SW AND CONNECTOR
 RECALL RECALL

2002-025 1.1822

RUN STAR TEST FOR CODES, PINPOINT TEST FOR RESERVOIR CODE BRAKE LEAK AT DEACTIVATION SWITCH-DEFECTIVE DEACTIVATION SWITCH
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORM RECALL

SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15
1 REPLACED SPEED CONTROL DEACTIVATION SWITCH 99S15B 0.5 ADMIN 0.1
PERFORM RECALL 99S15-REPLACE SPEED CONTROL SWIT
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

PERFORM RECALL 99S15

RECALL REPLACED SWITCH AS PER RECALL
99S15 REPLACED DEACTIVATION SWITCH
99S15 SWITCH AND CONNECTOR 99S15
REPL SWITCH PER RECALL
RECALL COMPLETED
99S15 RECALL COMPLETED
REPLACED BRAKE SWITCH PER RECALL
INSTALLED SWITCH RECALL COMPLETED

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S
1 CAMPAIGN COMPLETED.

40834 TRY TO REMOVE THE SW OUT IT WAS SEIZE IN THE MOUNTING. 2 HR M TIME TO REMOVE THE SW OUT. PERFORM THE RECALL.
PERFORMED RECALL

RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
REPLACED SPEED CONTROL ACTUATOR PER RECALL RETE STED OK. NO OTHER CONCERN AREAS EVIDENT AT THIS TIME
SWITCH 99S15
RECALL 99S15 99S15
COMPLETED RECALL 99S15 99S15B 1
76067 746 PERFORM RECALL 99S15 BLEAD REAR BRAKES ROAD TEST TO RECHECK OK
RECALL PERFORMED RECALL 99S15

FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH SWITCH WAS DEACTIVATED

96322 REPLACED SPEED CONTROL DEACTIVATION SWITC

PERFORM RECALL

RECALL REPAIR AS PER RECALL 99S15

1 PERFORM 99S15 RECALL

1 EPLACE BRAKE SWITCH AND CONNECTOR
REPLACED SWITCH AND CONNECTOR AS PER RECALL
REPLACED BRAKE PRESSURE-SPEED CONTROL DE-ACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15. THANK YOU. 1
COMPLETE RECALL
REPLACED SPEED CONTROL SWITCH

98114 INSTALL SWITCH AND HARDSHELL CONNECTOR
 REPLACE SWITCH PER RECALL CRUISE INOP PUT OLD SWITCH BACK IN CRUISE STILL INOP PUT NEW SWITCH BACK IN CUST. DECLINE ANY REPAIRS AT THIS TIME
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 045 REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR
 RECALL COMPLETED
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

98815 REPLACED DEACTIVATION SWITCH

58460 RECALL 98815. PERFORM RECALL 98815. REPLACE THE SWITCH AND THE CONNECTOR.
 PERFORMED RECALL 98815 CRUISE SWITCH
 C INSTALL SWITCH AS PER RECALL
 79 RECALL

PERFORMED RECALL 98815 REPLACED CRUISE SWITCH
 REPLACED THE SWITCH PER RECALL 98815
 FORD SAFETY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
 COMPLETED RECALL 98815
 98815 98815
 PERFORMED RECALL 98815
 PERFORMED RECALL
 RECALLED BY FORD MOTOR COMPANY COMPLETED RECALL PER LETTER REPLACED THE SWITCH.
 PERFORMED RECALL 98815 REPL DEACT SWITCH
 08726 PERFORMED 98815 RECALL
 118841 REPLACE SWITCH AND CONNECTOR PER 98815 8728
 RECALL COMPLETED RECAL
 PERFORM RECALL
 RECALL 98815 98815 COMPLETED RECALL
 AS PER RECALL 98815 RECALL TO INSTALL HARDSHELL CONNECTOR
 RECALL CK AND REPL FLUID CC SW PER RECALL AND RECK WF TEC800
 SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL 98816 SPEED CONT DEACT SWITCH
 REPAIR PER RECALL 1
 RECALL 98815 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH CONNECTOR
 COMPLETE RECALL 98815 REPLACE SPEED CONTROL DEACTIVATION SWITCH

53995 PERFORM RECALL REPLACE CRUISE SWITCH
 PERFORM 98815 R R SPEED CONTROL SWITCH AND CONNECTOR
 98816B J PLUS .1 ADMIN REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED SERVICE AS REQUESTED
 PERFORMED RECALL
 CORRECTED RECALL
 82409 REPLACED CRUISE CONTROL SWITCH AND CONECT
 120871 RECALL 98815 R&R BRAKE DEACTIVATION SWITCH AND HARNESS CONNECTOR AS PER RECALL 98815
 INSTALLED SPEED CONTROL DEACTIVATION KIT
 RECALL 98815 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL 98S15
1 PERFORM RECALL 98S15 INSTALL SWITCH AND CONNECTOR

06 REPLACED SWITCH
RECALL PERFORMED RECALL

98S15 REPL DEACTIVATION SWITCH
PERFORMED RECALL
PERFORMED RECALL 98S15
RECALL 98S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL
REPLACED DEACTIVATION SWITCH
PERFORMED RECALL 98S15

D
RECALL REPLACE DEAC SWITCH AND CONNECTOR
REPLACE SPEED CONTROL SWITCH AND WIRE CONNECTOR AS PER RECALL 1 98S15. 1
98S15 REPLACE PRESSURE SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL
PERFORMED RECALL 98S15
47780 98S15B 0.5 ADMIN 0.1
PERFORM RECALL 98S15
REPL SWITCH PER RECALL
A DONE
122202 1 PERFORMED RECALL 98S15
INSTALLED NEW SWITCH KIT

REPLACE SPEED CONTROL CABLE AS PER RECALL 98S15 2 OF 2 ROS
98S33 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
RECALL PERFORMED
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
RECALL 98S15 SPEED CONTROL DEACTIREPLACE SWITCH AND HARD SHELL CONNECTOR
RECALL 98S15

PERFORMED RECALL 98S15
COMPLETED RECALL -DID 98S15B
REPLACE CRUISE CONTROL DEACTIVATION SWITCH
178245 PERFORMED SPEED CONTROL RECALL 98S15
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15
INSTALL HARNESS & KIT PER RECALL
PERFORMED RECALL
98S35 RECALL LABOR OP. 98S15B 0.5 HRS.
98S35 REPLACE CRUISE SWITCH BRAKE AS PER RECALL

PERFORM RECALL 98S15 RECHECK OPERATION OK
98S37 PERFORMED RECALL 98S15
PERFORM RECALL
REPL SWITCH PER RECALL
RECALL REPLACED DEAC SWITCH AND CONNECTOR

8802-925 11/2/25

INSTALLED SPEED CONTROL DEACTIVATION KIT
DO RECALL 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH.
REPLACED SPEED CONTROL DEACTIVATION SWITCH
PERFORM 99S15
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15. REFER TO 108478-02 FOR RELATED DAMAGE.
99S15 RECALL NOTIFICATION 99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL
RECALL 99S15 COMPLETED
C RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH 48

RECALL COMPLETED
RECALL 99S15
45977 RECALL W RECALL 99S15 BRAKE REPAIR KIT INSTALLED
PERFORMED RECALL 99S15
DID RECALL-DID 99S15B.
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15
RECALL RECALL
REPL SWITCH PER RECALL
1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS

REPLACE SWITCH PER RECALL
PERFORMED RECALL
REMOVE & REPLACE SPEED CONTROL CABLE
99S15B.5 PLUS .1 ADMIN REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED SERVICE AS REQUESTED
147904 RECALL 99S15B.5 REPLACED DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACT SWITCH AND CONNECTOR
COMPLETED RECALL,REPLACED SWITCH
D
PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK
40112 INSTALL RECALL PPS15 SPD CONTROL DEACTIVATION
RECALL 99S15
RPLC SPEED CTRL DEACTIVATION SWITCH & CONN PER 99S15
PERFORM RECALL
RECALL 99S15
X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
INSPECTED DEACTIVATION SWITCH NEEDED RECALL-REPLACED WITH RECALL 99S15
COMPLETED RECALL
RECALL REPLACE DEAC SWITCH AND CONNECTOR

SPEED CONTROL SWITCH MOD 99S15 RECALL SPEED CONTROL SWITCH
1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.
1 PERFORMED 99S15 RECALL
75848 PERFORMED RECALL #99S15 REPLACED BRAKE SENSOR
SPEED CONTROL LEAKING PERFORMED 99S15 RECALL

RECALL 99S15 COMPLETED
 RECALL 99S15
 PERFORM RECALL 99S15 PER INSTRUCTIONS
 RECALL 99X15
 A DONE
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15.
 PERFORMED SAFETY RECALL 99S15
 PERFORMED RECALL 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTOR. CHECK NORMAL OPERATION.
 127801 PERFORM RECALL 99S15 SPEED CONTROL SWITCH FOUND TO BE FINE AT THIS TIME
 99S15. REPLACE CRUISE LOCK OUT SWITCH AND HARD SHELL.
 1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 REPL SWITCH PER RECALL
 PERFORM RECALL
 75371 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR HARD SHELL CODE 42 TX574
 REPLACED DEACTIVATION SWITCH
 INSTALL SWITCH PER RECALL
 REPAIR AS PER RECALL 99S15.
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15
 REPLACED DEACTIVATION SWITCH AND CONNECTOR.
 REPLACED DEACTIVATION SWITCH
 PERFORMED RECALL
 PERFORMED RECALL 99S15 O.C. 99S15B 0.5 ADMIN 0.1
 99S15 99S15 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED SPEED CONTROL
 REPLACED CRUISE DEACT SWITCH
 REPLACED DEACTIVATION SWITCH PER RECALL
 RECALL 99S15 CRUISE CONTROL DEACTIVATION PERFORM RECALL 99S15 INSTALL BRAKE SWITCH & HARD SHELL CONNECTOR
 60630 99S15B 0.5 ADMIN 0.1
 70264 RECALL REPLACE SWITCH AS PER RECALL 2886
 REPLACED SWITCH AND CONNECTOR
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15
 88888 RECALL 99S15B 0.5HRS INSTALL NEW SWITCH AND CONECTOR TK372
 141741 REPLACE CRUISE DEACTIVATION SWITCH AND RELATED CONNECTOR PER RECALL 99S15.
 REPL SWITCH PER RECALL
 REPL SWITCH PER RECALL 99S15
 RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT
 PERFORMED RECALL
 RECALL REPLACE SPEED CONT DEACT SWITCH
 REPLACE SPEED CONTROL CABLE
 99S15 99S15 RECALL
 RECALL REMOVED AND REWIRE CONNECTOR AND REPLACED SWITCH DONE 144, RECHECK OK.
 REPLACED SWITCH
 51030 99S15B .5 .5 RECALL
 RECALL PERFORM RECALL INSTALL DEACTIVATION SWIT

PERFORM SPEED CONTROL RECALL 99S15

PERFORMED RECALL

PERFORMED SAFETY RECALL 99S15

REPLACED SPEED CONTROL CABLE

RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACE CRUISE CABLE CONTROL SWITCH AND WIRE CONN, BLEED BRAKE, RT OK

1 REPAIR OR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER PER RECALL INSTRUCTIONS.

99S15

REPLACE CRUISE CONTROL SWITCH PER RECALL

REPLACED DEACTIVATION SWITCH

RECALL

REPLACE SPEED CONTROL DEACT SWITCH AND HARD-SHELL CONNECTOR

1 PERFORM RECALL

REPLACED DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH

82458 INSTALL RECALL

PERFORMED RECALL 99S15

PERFORM RECALL

1 REPLACED SWITCH AND CONNECTOR PER RECALL 99S1

PERFORM RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH

99S15

INSTALL SWITCH PER RECALL 99S15 A99

99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.

REPL SWITCH PER RECALL

112033 TECH 181 99S15-0.6 REPLACE SWITCH

RECALL 99S15-INSPECT AND REPLACE BRAKE SWITCH AND CONNECTOR TECH 916

RPL CRUISE DEACTIVATION SWITCH

PERFORM RECALL 99S15B

99S15 RECALL

C 99252 AA

81084 TECH NO. 6932 REPLACE DE-ACTIVATION SWITCH AND HARDSHELL CONNECTOR PER 99S15L

RECALL 99S15

RECALL 99S15

REPL SPEED CONTROL SWITCH

PERFORMED 99S15 RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

28036 RECALL DEACTIVATION SWITCH I WILL REPLACE SWITCH AND CONNECTOR

PERFORMED RECALL

89078 WARR DONE RECALL 99S15 REPLACE BRAKE KIT

PERFORMED RECALL

RECALL 99S15

99S15B COMPLETE RECALL 99S15

PERFORM RECALL

RECALL COMPLETED

99S15 RECALL

REPLACE SWITCH AND CONNECTOR PER RECALL
 PERFORM RECALL 99815
 REPLACED SWITCH
 99082 RECALL W/ REPLACE SWITCH GA
 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99815.
 71272 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH
 REPLACED DEACTIVATION SWITCH AND CONNECTOR.
 - MODIFY PER RECALL 99815
 RECALL RECALL
 PRODUCT MODIFICATION REPLACE SPD CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 1 INSTALL SWITCH AS PER RECALL

PERFORMED RECALL 99815 INSTALLED DEACTIVATION SWITCH PER RECALL 99815
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 RECALL REPLACE SPEED CONTROL DEACT SWITCH AND HARD SHELL CONNECTOR

SPEED CNTRL DEACTVTN SWITCH REPLCMITPERF SAFETY RECALL 99815
 PERFORM RECALL
 PERFORM RECALL
 1 REPLACE CRUISE CONTROL SWITCH PER RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL
 --- PERFORMED RECALL 99815
 62064 RECALL WARRANTY REPLACE SPEED CONTROL DEACTIVATION SWITCH
 78999 TECH NO. 5932 REPLACE DE-ACTIVATION SWITCH PER 99815
 INSTALLED DEACTIVATION KIT

INSTALL SPEED CONTROL SWITCH
 RECALL 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED CRUISE SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPLACE THE CONTROL
 REPLACED SWITCH AND CONNECTOR.
 PERFORM RECALL 99815
 PERFORMED RECALL 998215.
 INSPECT AND INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 99815 ALL OK
 PERFORMED RECALL 99815
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99815.
 X 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR
 99815 99815 PRESSURE SWITCH
 RECALL COMPLETE
 REPLACE SPEED CONTROL SWITCH
 REPLACED SPEED CONTROL SWITCH 7 CONNECTOR
 73304 RECALL REPLACED SWITCH
 RECALL COMPLETED

20482 RECALL REPLACED DEACTIVATOR SWITCH 15()

RECALL 99S15 RECALL

106633 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH

58573 PERFORMED RECALL 99S15-REPLACED SPEED CONTROL

INSTALL SWITCH 99S15B 0.0

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL NOTICE

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 99S15

RECALL RECALL

PERFORMED RECALL

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

1 CAMPAIGN COMPLETED

RECALL 99S15

1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-

PERFORMED RECALL PERFORMED RECALL

RECALL COMPLETED

REPLACE SWITCH

CAMPAIGN REPLACE SWITCH CONNECTOR PER RECALL

VEHICLE HAS AN OPEN RECALL PERFORM RECALL

107735 PERFORMED RECALL 99S15-REPLACED SPEED CONTROL

INSTALL SWITCH PER RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

PERFORM RECALL REPL DEACTIVATION SWITCH

RECALL REPLACE DEACTIVATION SWITCH

INSTALL CRUISE DEACTIVATION SWITCH 99S15

COMPLETED RECALL

VERIFY RECALL RREPLACE CRUISE SWITCH AS PER FMC CHECK OK

024 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND REWIRED HARNESS

99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTO

99S15 99S15

REPLACE SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH

1 INSTALL SWITCH AND CONNECTOR

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

SUPPLEMENT #1 8-98 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

99S15 COMPLETED

RECALL PERFORMED

99S15 99S15

R&R SPEED CONTROL SWITCH & HARD SHELL BLEED SYSTEM PER RECALL

PERFORMED RECALL 99815
 119823 RECALL W 99815 REPLACED NEEDED SWITCH AND CONNECTOR.
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.
 RECALL PERFORMED

RECALL R-R DEAC SW, INSTALLED NEW, AND CONN.
 REPL SWITCH PER RECALL 99815

INSTALL CRUISE CONTROL SWITCH

PERFORMED RECALL 99815
 RECALL COMPLETE
 TECH COMPLETED RECALL #99815 AS REQUIRED
 1 INSTALLED NEW CRUISE DEACT SWITCH AND BLEED BRAKES PER RECALL AND TEST DROVE
 1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 115579 PERFORMED RECALL 99815
 73806 PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 77354 | INSTALLED SWITCH AND CONNECTOR
 114448 PERFORM RECALL 99815 SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 TECH REPLACED SWITCH AS REQUIRED
 VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK
 1 INSTALLED CRUISE SWITCH AS PER RECALL 1
 REPLACED THE SWITCH PER RECALL 99815

REPLACED SWITCH
 RECALL COMPLETED
 REPLACE CRUISE SWITCH PER RECALL
 RECALL 99815 COMPLETED
 99815 RECALL 99816 RECALL
 FACTORY RECALL COMPLETED RECALL
 85789 PERFORMED RECALL 99815
 99815 99815
 PERFORM RECALL
 REPLACED DEACTIVATION SWITCH
 COMPLETE RECALL 99815
 REPLACED SWITCH AND CONNECTOR
 - MODIFY PER RECALL 99815
 REPLACE SPEED CONTROL SWITCH
 COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH
 PERFORMED RECALL
 81384 RECALL 99815B 0.5 ADMIN 0.1 REPLACE PLUG AND SWITCH
 REPLACED SPEED CONTROL SWITCH
 83222 99815

ENG-825 11831

A98 98S15
 INSTALLED SWITCH
 REPLACED DEACTIVATION SWITCH
 98S15 98S15

RECALL 98S15
 REPL SWITCH PER RECALL
 1 REPLACED SWITCH PER RECALL 98S15
 REPLACE DEACTIVATION SWITCH PER RECALL
 AS PER RECALL 98S15 RECALL TO INSTALL SPEED CONTROL CABLE
 91635 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 PERFORMED 98S15
 1 INSTALL PRESURE SWITCH KIT AS PER RECALL
 RECALL 98S15
 REPLACED DEACTIVATION SWITCH
 PERFORMED RECALL 98S145 - CHECK AND REPLACE CRUISE CONTROL CABLE AND RECHECK OK
 COMPLETED RECALL
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 SERVICED AS PER RECALL
 PERFORM RECALL 98S15
 PERFORM RECALL 98S15 PER FORD

98S15 ADM .1
 82878 RECALL 0.5 INSTALLED NEW BRAKE PRESSURE SWITCH AND CONNECTOR 98S15B
 REPLACED DEACTIVATION PER RECALL
 REPL SWITCH PER RECALL
 RECALL RECALL
 77020 RECALL 98S15 WRT PERFORMED RECALL 98S15 PLACED NEW DEACTIVATION SWITCH ON AND PASSED.
 COMPLETED OP 98S15B CAMPAIGN COMPLETED 98S15
 RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15
 98S15 SPEED CONTROL SWITCH RECALL 98S15
 63809 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR
 RECALL 98S15 98X15

PERFORM RECALL
 INSTALL DEACTIVATION SWITCH & HARD SHELL CONNECTOR PER 98S15
 98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.
 135458 98S15 WARR REPLACED SWITCH AND CONN
 58467 RECALL 98S15 INSTALL RECALL KIT- 98S15 CRUZ CONTROL SWITCH R REPL
 INSTALL PARTS PER RECALL
 MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.
 PERFORM RECALL 98S15
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.

0902-025 11832

RECALL
 COMPLETED RECALL 99815
 PERFORM RECALL 99815
 48108 99815 PERFORMED RECALL AS PER INSTRUCTIONS REPLACED DEACTIVATION SWITCH AND CONNECTOR SHELL
 PERFORM RECALL 99815 CRUISE SWITCH CONNECTOR
 REPLACE DEACTIVATION SWITCH
 84118 INSPECTED AND REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99815.
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 84105 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH PER RECALL X89 RECALL
 REPLACED SWITCH
 RECALL 99815 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO
 REPLACE CRUISE SWITCH
 81067 INSTALLED NEW SPEED DEACTIVATION SWITCH AS PER RECALL 99815.
 VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT
 1 PERFORMED 99815 RECALL
 REPLACE SWITCH AND CONNECTOR
 REPLACED SWITCH

PERFORM RECALL TECH NOTES REAR SHOCKS LEAKING AND REAR AXLE SHAFT SEEPAGE.
 RECALL R-R DEAC SW, R-R CONN, INSTALLED NEW, RECD OK.
 RECALL 99815 REPLACE C-C SW
 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTIONS
 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTO
 PERFORM RECALL

99816 RECALL PERFORM RECALL 99815
 PERFORM RECALL 99815
 73215 RECALL INSPECT SPEED CONTROL SYSTEM. REPLACED DEACTIVATION SWITCH AND REWIRED HARDSHELL.
 99815 RECALL 99815 RECALL COMPLETED
 INSTALL SWITCH AND CONNECTOR
 POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH REPLACED SWITCH AND THE CONNECTOR
 RECALL COMPLETE
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 53245 INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99815.
 SAFETY RECALL NOTICE PERFORMED AS OUTLINED IN THE FOMOCO INSTRUCTIONS
 109033 RECALL 0.5 REFORM RECALL 99815
 PERFORMED RECALL 99815

1 REPLACE CRUISE CONTROL SWITCH PER RECALL.
 COMPLETE RECALL

PERFORMED RECALL 99815 -- CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK
 RECALL PERFORMED RECALL
 53107 99815B .5" REPLACED DEACTIVATION SWITCH AND CONNECTOR.
 REPLACED SWITCH AND CONNECTOR

REPLACED CRUISE CONTROL BRAKE SWITCH
 AS PER RECALL 98S15 RECALL TO INSTALL SPEED CONTROL CABLE
 PERFORM RECALL REPLACE SWITCH
 98S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
 RECALL RECALL
 98S15 PERFORMED RECALL
 PERFORMED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 INSTALL DEACTIVATION SWITCH

PERFORM RECALL 98S15
 RECALL 98S15 COMPLETED
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
 98S15 REPLACED CONNECTOR AND SWITCH
 PERFORMED RECALL
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 98S15 98S15 PERFORM RECALL 98S15 REPLACE CRUISE CONTROL DEACTIVATION SW
 98S15 REPLACE DEACTIVATION SWITCH
 1 PERFORM RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME .5 PERFORM RECALL 98S15 AS PER INSTRUCTIONS
 REPLACED SWITCH AND CON
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO
 98S15 98S15
 70824 .3 + .1 ADMIN 98S15B. REPLACED DE-ACTIVATION SWITCH.
 RECALL 98S15 PERFORM RECALL 98S15
 PERFORMED RECALL

75247 PERFORM RECALL ABS LIGHT ON BEFORE RECALL
 RECALL COMPLETED
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 98S15
 PERFORM RECALL
 98S15 98S15 REPLACED SWITCH
 RECALL 98S15 - COMPLET

98S15 98S15
 COMPLETED FACTORY RECALL
 53384 REPLACED CRUISE SWITCH
 1 COMPLETED RECALL 98S15

5902-025 11034

PERFORMED RECALL

RECALL 99S15 REPLACED SWITCH
 RECALL CRUISE COMPLETED AS PER RECALL 99S15
 70074 PERFORMED RECALL

RECALL RECALL

33379 COMPLETED RECALL OPER#99S15B 0.5 HR
 REPLACED SWITCH PER RECALL 99S15 4.0L AUTO
 72567 PERFORMED RECALL 99S15 REPLACED DEATVA
 99S15 REPLACED SWITCH AND CONNECTOR
 INSTALLED CRUISE CONTROL SWITCH AND FLUID END AS PER RECALL MO-28533
 82160 COMPLETED RECALL OPER#99S15B 0.5 HR
 INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR. 99S15
 PER RECALL INSTALL SWITCH.

87307 RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH
 CRUISE DEACTIVATION SWITCH REPLACE AND REWIRE AS INSTRUCTED
 95440 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR SHELL. 99S15B 0.5 HR LABOR 0.1 ADMIN.
 36380 DID RECALL 99S15 TECH 3213
 REPLACE SPEED CONTROL PRESSURE SWITCH PER 99S15
 1 REPLACED DEACTIVATION SWITCH AS PER RECALL
 PERFORM RECALL 99S15.

99S15 99S15-INSTALL SWITCH AND COONECTOR
 REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL
 RECALL 99S15

PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
 COMPLETER RECALL
 INSTALL NEW VALVE AND CONNECTOR REPLACE WIRING HARNESS ALSO
 49007 99S15B 0.5 0.5 PERFROM 99S15
 110882 RECALL REPLACE SWITCH AND CONNECTOR AS PER RECALL
 PER RECALL REPLACE SPEED CONTROL REACTIVATION SWITCH AND CONNECTOR.

PERFORMED 99S15

PERFORMED RECALL 99S15
 1 REPLACED SPEED CONTROL SWITCH
 INSPECT FOR RECALL 99S15
 PERFORMED RECALL 99S15 PER INSTRUCTIONS
 21988 PERFORM 99S15 RECALL
 91168 REPLACE SW PER RECALL

REPLACE DEACTIVATION SWITCH

RECALL PERFORM RECALL 99S15
 COMPLETED FACTORY RECALL
 RECALL 99S15
 SPEED CNTRL DEACTYTN SWITCH RPLMNTPERF SAFETY RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER PROGRAM

99S15 REPLACE CRUISE BRAKE SWITCH
 SWITCH WOULD NOT DISCONNECT REPLACE SHUT OFF SWITCH
 DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW
 AE REPLACE SPEED CONTROL PRESSURE SWITCH PER 99S15 NOTE ABS LIGHT ON
 PERFORM RECALL
 PERFORM RECALL AS PER NOTICE
 1 DO RECALL 99S15
 COMPLETED RECALL
 REPLACED CRUISE SWITCH
 99S15 SPEED CONTROL SYS 99S15
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AND REWIRE HARDSHELL CONNECTOR
 99S15 RECALL 99S15 REPLACE SWITCH AND CONNECTOR AS PER RECALL
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL
 105079 RECALL #99S15 PERFORM RECALL #99S15 REPLACING CRUISE CONTROL BRAKE PRESSURE DEACTIVATION SWITCH % WP
 PERFORMED RECALL 99S15 B 1
 55860 99S15 RECALL REPLACE PRESSURE SWITCH AND CONNECTOR PER RECALL
 CORRECTED RECALL
 PERFORM RECALL PER 99S15 DONE

 99S15 99S15 RECALL
 7 INSTALLED CRUISE DEACTIVATION SWITCH PER RECALL 99S15
 SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99S15
 PERFORM RECALL 99S15
 RECALL 99S15 SPEED CONTROL DEACT SWITCH
 1 REPLACE SPEED CONTROL SWITCH
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. RECALL 99S15
 71303 PERFORMED RECALL
 99S15 COMPLETE
 99S15 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15
 REPLACE SPD CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL AS NEEDED ALL OK
 RECALL PERFORMED RECALL 99S15
 PERFORM RECALL
 PERFORM RECALL
 REPLACE SWITCH

 RECALL COMPLETED
 R R SPEED CONTROL SWITCH AND CONNET
 PERFORMED RECALL 99S15
 RECALL 99S15 INSTALL INERTIA SWITCH
 COMPLETED RECALL 99S15 B 1
 VEHICLE HAS AN OPEN RECALL PERFORM RECALL
 RECALL 99S15 INSTALL SWITCH
 PERFORMED RECALL

RECALL 99S15 COMPLETED
 INSTALL DEACTIVATION SWITCH
 99S15 RECALL 99S15 REPAIR AS PER RECALL
 PERFORMED RECALL 99S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH
 RECALL RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 RECALL RECALL ACCOMPLISHED
 RECALL 99S15 RECALL 99S15
 F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SPEED CONTROL DEACTIVATION SWITCH.
 INSTALL NEW DEACTIVATION SWITCH AND HARDSHELL CONNECTOR 99S15
 PERFORM RECALL
 INSTALL DEACTIVATION SWITCH
 PERFORMED AS PER FORD MOTOR CO.
 REPLACED DEACTIVATION SWITCH AND CONNECTOR

RECALL 99S15 REPLACED SWITCH
 74408 99S15 W REPLACED SWITCH
 RECALL WARR REPLACE SWITCH AND CONNECTOR
 1 CK REPLACED SWITCH AND HARNESS CONNECTOR
 99S15 RECALL

PERFORM RECALL 99S15
 167517 REPAIR PER 99S15B 0.5
 RECALL RECALL
 PERFORMED RECALL
 COMPLETED AS PER RECALL

RECALL 99S15 COMPLETED
 1 PERFORMED RECALL 99S15
 RECALL PERFORMED RECALL 99S15 INSTALLED NEW SWITCH AND CONNECTOR PER RECALL AND RETESTED OK
 PERFORM RECALL REPL DEACTIVATION SWITCH
 REPLATED DAMAGE TO CRUISE SWITCH RECALL-VEHICLE HARNESS CAUGHT FIRE DAMAGED 3 WIRING HARNESSES IN ENGINE COMPARTMENT-IN TIME TO REPLAI
 PERFORMED RECALL

1 PERFORMED RECALL
 RECALL 99S15
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH DUE TO RECALL
 REPLACED CRUISE SWITHC
 RECALL RECALL

PERFORM RECALL 99S15
 REPL SPEED CONTROL DEACTIVATION SWITCH
 PERFORMED RECALL
 99S15 PERFORM 99S15
 PERFORMED RECALL 99S15
 RECALL SPEED CONTROL DEACTIVATION SWITCH
 COMPLETED 99S15

REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 PERFORMED RECALL
 128047 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL
 S #BXNM99S15
 REPL CRUISE CONTROL SWITCH
 99S15 RECALL PERFORM RECALL
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH
 RECALL 99S15 REPLACED SWITCH
 1 PERFORMED RECALL 99S15
 PERFORM RECALL REPLACE SWITCH
 RECALL PERFORMED RECALL

DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH OK NOW
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 72839 RECALL 99S15B 0.5 + 0.1 REPLACE SPEED CONT. SWITCH & PLUG.
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH
 REPLACED SPEED CONTROL DEACTIVATION SWITCH
 99S15 RECALL ON 0A80B 99S15 RECALL REPLACED SWITCH & CONNECTOR
 PERFORM RECALL
 54711 RECALL 99S15 INSTALLED NEW CONNECTOR
 RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S15B .5) COMPLETED
 RECALL 99S15 COMPLETED RECALL 99S15
 PERFORM RECALL
 PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL 99S15
 PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH
 99S15 99S15 REPLACED CRUISE DEACTIVATION SWITCH
 99S15 RECALL PERFORMED

99S15 RECALL PERFORMED 99S15
 1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS
 52704 RECALL REPLACED DEACTIVATOR SWITCH AND CONNECTOR PER RECALL LETTER
 81400 RECALL 99S15 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR AS PER RECALL 99S15.

COMPLETED RECALL
 1 INSTALLED CONNECTOR AND CRUISE SWITCH
 PERFORMED RECALL
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR ON VEHICLE FOR RECALL 99S15
 REPL SPD CNTRL DEACTIVATION SW
 90009 RECALL 99S15B 0.5 TECH 151 PERFORM RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND HARDSHELL CONNECTOR-ROAD TEST TO VE

RECALL COMPLETED. THREAD STIPPED OUT ON PROPORTIONING VALVE
D

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH
INSTALL DEACTIVATION SWITCH AS PER RECALL

RNR SWITCH PERFORM RECALL 99S15

CHECKED OASIS. INSTALLED SPEED CONTROL DEACTIVATION SWITCH

X RECALL 99S15

REPLACED CRUISE SWITCH

VEHICLE NOT ELIGIBLE FOR CAMPAIGN AT THIS TIME

RECALL INSTALL DEACTIVATION SWITCH PER 99S15

COMPLETED RECALL AS REQUIRED

RECALL DONE

99S15 99S15 REPLACED SWITCH

INSTALL SWITCH AND CONNECTOR

REPLACE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15 2 OF 2 ROS

99S15 RECALL SPEED CONTROL DEACT SWITCH

99S158 .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S

RECALL 99S15 INSTALLED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL PER RECALL

RENEW SPEED DEACTIVATION SWITCH

REPLACED SWITCH

99S15 RECALL 99S158 0.5 0.5 REPLACE SWITCH AND CONNECTOR

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

15862 OK FOR RECALL 99S15. REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15

PERFORM RECALL 99S15 SPEED CONTROL AS PER MENU ALL CHECKS OK

99S15 99S15 RECALL

AE REPL BKSW & CONN.

RECALL REPLACE CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW

REPL SWITCH

RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL

REPLACED SPEED CONTROL PER RECALL

99S15 PERFORMED RECALL 99S15

PER RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH

25200 REPLACED SWITCH AND CONNECTOR

99791 REPLACE SWITCH AS PER RECALL

128354 REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR FOR RECALL

INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99A15A .20

INSTALLED SOP PERFORMED RECALL 99S15
 RECALL RECALL RECALL RECALL
 1 PERFORMED REPAIRS
 PERFORMED RECALL
 99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL
 PERFORM RECALL-INSTALL SWITCH
 PERFORM RECALL
 RECALL 99S15 M-O 62450 REPLACE DEACTIVATION SWITCH PER RECALL
 47371 RECALL 99S15B 0.5 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR
 88383 REPLACE CRUISE DEACT SWITCH RECALL 99S15
 132020 PERFORMED RECALL 0.5
 99S15
 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 99S15B .5 - ADMIN .1
 RECALL COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL
 REPLACED CRUISE CONTROL SWITCH
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE
 PERFORMED RECALL 99S15
 1 COMPLETED RECALL PER INSTRUCTIONS 1
 REPLACED BRAKE SWITCH, WIRE HARNESS BURNED, REPAIRED WIRE HARNESS, AND REPLACED CONN. RETEST OK
 PERFORMED RECALL 99S15 T125
 1 PERFORMED RECALL 99S15
 INSTALL SPEED CONTROL SWITCH
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5
 PERFORMED RECALL AS PER INSTRUCTIONS
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.
 1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH
 99S15 99S15 REPLACED DEACTIVATION SWITCH
 1 PERFORM RECALL 99S15
 PERFORM RECALL 99S15
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND PIGTAIL CONN. PER RECALL
 RECALL 99S15
 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 46115 99S15 PERFORM RECALL
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5

1 PERFORM RECALL 99S15
 RECALL 99S15 RECALL 99S15 REPLACE SWITCH AND PLUG
 PERFORM RECALL 99S15
 RECALL PERFORMED RECALL 99S15
 REPL SPEED CONTROL DEACTIVATION 99S15
 PERFORM RECALL
 RECALL PERFORM RECALL 99S15
 INSTALL SPEED CONTROL DEACTIVATION AS PER FMC TEST OK

67617 RECALL DID RECALL ON DEACTIVATION SWITCH REPLACED SWITCH
RECALL 98S15

98S15 98S15 INSPECT AND REPLACED SWITCH
98S29 RECALL 98S15 INSTALL CRUISE CONTROL SWITC
REPLACED DEACTIVATION SWITCH

ADD 98S15B 82 .1 ADMIN .5 LABOR 888 REPLACED SPEED CONTROL DEACTIVATION SWITCH
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 98S15

PERFORM RECALL 98S15 T125

98S15 98S15 RECALL
RECALL OK AND INSTALL CRUISE CONTROL HARNESS
REPLACED DEACTIVATION SWITCH AND CONNECTOR
PERFORM RECALL

COMPLETE INSTALLED SWITCH AS PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .8

RECALL REPLACED CRUISE CUT OFF SWITCH

CHECK AND INSTALLED CRUISE RECALL

MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

OPEN RECALL PERFORMED RECALL 98S15

RECALL PERFORMING

REPLACE SWITCH AND WIRE END

1 INSTALLED DEACTIVATION SWITCH PER RECALL

67688 DO RECALL 98S15

1 REPLACED SPEED CONTROL DEACTIVATION AND HARD SHELL CONNECTOR

INSTALLED DEACTIVATION SWITCH PER RECALL

REPLACED CRUISE SWITCH

SPEED CNTRL DEACTVATN SWITCH RPLCMTPERF SAFETY RECALL 98S15

FORD RECALL PERFORMED SPED DEACTIVAT SWITCH RECALL

INSTALLED DEACTIVATION SWITCH

RECALL 98S15

71798 98S15B 0.5 ADMIN 0.1

45028 PERF.RECALL REPLACED SWITCH TAPE AND INSP. CONNECTOR

RECALL 98S15

111522 .5 DID RECALL REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH, CONNECTOR

PERFORMED RECALL 98S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE SWITCH

80354 W PERFORM RECALL 98S15

98S15 98S15 PERFORM RECALL

COMPLETE RECALL

COMPLETED RECALL 98S15

RECALL COMPLETE

88558 RECALL DID RECALL ON DEACTVEATION SWITCH
88219 REPLACE DEACTIVATION SWITCH PER RECALL 88515.

PERFORMED RECALL
RECALL PERFORMED RECAL
1 PERFORM RECALL
120379 RECALL PERFORMED RECALL 88515
REPLACE CRUISE CONTROL CABLE SWITCH AND WIRE CONN,BLEED BRAKE AND RT PER RECALL

PERFORMED RECALL E
REPLACD DEACTIVATION SWITCH
INSTALL DEACTIVATION SWITCH AS PER RECALL 88515 2 OF 2 ROS
A98 88515
REPLACD SWITCH AND CONNECTOR PER RECALL

88515 RECALL 88515 REPAIRED AS PER RECALL
RECALL 88515 COMPLETED
PERFORM RECALL
PERFORMED RECALL 88515
88418 PERFORM RECALL - DEACTIVATION SWITCH
RECALL 88515
88515 REPLACE DEACTIVATION SWITCH AS PER RECALL
REPL SWITCH PER RECALL 88515
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 885

RECALL 88515 - B - RECALL
RECALL 88515B PERFORM RECALL 88515
PERFORMED 88515 REPLACED PRESSURE SWITCH AND CONNECTOR
PERFORM RECALL
INSPECTED & REPLACED THE HARDSHELL CONNECTOR
COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR
1 INSTALL SWITCH AND CONNECTOR....
REPAIR PER 88515B
PERFORMED RECALL 88515
1 PERFORMED RECALL
REPLACED CRUISE CONTROL DEACTIVATION SWITCH.
88540 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH RECALL 88515
PERFORMED RECALL
PERFORMED RECALL
REPLACE AS PER RECALL 88515
REPLACED THE SWITCH PER RECALL 88515
PERFORMED RECALL
INSTALL SWITCH AND CONNECTOR
PREFORM 88515 REPLACED SWITCH AND CONNECTOR
75321 REPLACE SPEED CONTROLL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL 99S15
REPLACE CRUISE DEACTIVATION SWITCH PER 99 S 15

REPLACE BRAKE KIT PER RECALL

RECALL 99S18
PERFORM RECALL

COMPLETE RECALL 99S15
REPLACED CRUISE DEACTIVATION SWITCH AS PER RECAL
113104 RECALL REPLACE DEACTIVATION SWITCH OER RECALL(WP) 23
REPLACED DEACTIVATION SWITCH AND BLEED BRAKES AS PERR RECALL
85210 R-R SWITCH CRUISE AND BLEED .
AS PER RECALL 99S15 RECALL TO REPLACED SPEED CONTROL CABLE
REPLACE SPEED CONTROL DEACTIVATION SWITCH
99S15 REPLACE SWITCH
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

99S15 RECALL PERFORMED 99S15
PERFORMED RECALL
72990 WFR30 REPLACE CRUISE CONTROL DEACTIVATION SWITCH
AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL DEACTIVATION SWITCH
RECALL 99S15 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
PERFORM RECALL 99S15.
REPLACE SWITCH AND HARNESS.
PREFORM 99 S 15 RECALL BY REPLACING SWITCH AND HARD SHELL CONECTER MO 84999
COMPLETE RECALL
PERFORMED RECALL
RECALL PERFORM RECALL 99S15
PERFORMED RECALL 99S15
1 PERFORM RECALL
SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99S15
PERFORM RECALL 99S15
RECALL REPLACED CRUISE CONTROL CABLE

PERFORMED RECALL 99S15
REPAIR AS PER RECALL 99S15.
RECALL 99S15 99S15

37318 99S15B 0.5 ADMIN 0.1
REPLACE SWITCH PER RECALL
74187 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH
PERFORM RECALL 99S15
108315 RECALL CC42 INSPECT AND REPLACE DEACTIVATION SWITCH AND CON NECTOR

99S15 RECALL 99S15 REPLACED SWITCH AND CONNECTOR
 PERFORMED RECALL 99S15
 COMPLETED RECALL
 RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15
 REPLACED CRUISE DEACTIVATION SWITCH PER 99S15
 REPLACED CONNECTOR AND SWITCH PER RECALL
 RECALL DID RECALL
 RECALL PERFORMED
 99S15 99S15
 PERFORM RECALL 99S15
 RECALL PERFORMED RECALL # 0836

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15
 PERFORMED RECALL
 SPEED CONTROL DEACTIVATION SWITCH COMPLETE RECALL 99S15
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS
 R&R CONNECTOR AND SWITCH PER RECALL
 RECALL 99S15
 PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

99S15 99S15
 1 INSPECTED PER RECALL CRUISE CONNECTOR WAS NOT DONE REPLACED CONNECTOR AN SWITCH PER RECALL
 REPLACED DEACTIVATION SWITCH
 REPLACED SPEED CONTROL SWITCH FOR RECALL
 APPLIED RECALL 99S15

22085 99S15B 0.5 HRS SPEED CONTROL RECALL
 PERFORM RECALL
 99S15 RECALL
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15
 COMPLETED RECALL
 1 COMPLETE CAMPAIGN
 PERFORM RECALL 99S15
 RECALL COMPLETED
 DONE WITH RECALL
 PERFORM RECALL
 PERFORM RECALL
 99S15 99S15 INSPECT AND REPLACE CABLE
 REPLACE BRAKE DEACTIVATION SWITCH RECALL 99S15
 REPAIR AS PER RECALL 99S15.

REPLACE SWITCH PER RECALL
 - REPLACED HARDSHELL CONNECTOR & DEACTIVATION SWITCH AS PER 99S15
 REPLACE SWITCH AND CONNECTOR
 1 PERFORMED RECALL
 PERFORMED RECALL 99S15B. PERMANENT REPAIR. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
 REPLACE SWITCH
 47716 W REPLACED HARDSHELL CONNECTOR, SWITCH, & LOCKING PIN AS PER RECALL SPECS GA
 RECALL PERFORMED CRUISE DEACTIVATION RECALL
 PERFORMED 99S15 RECALL
 RECALL 99S15 RECALL COMPLETE
 PERFORM RECALL
 99S15 CC DEACTIVATION SW RECALL 99S15 CC DEACTIVATION SW RECALL
 RECALL 99S15 COMPLETED
 PER RECALL PERF RECALL
 PERFORMED RECALL
 72500 RECALL 99S15 WPG PERFORMED RECALL 99S15
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL
 REPL SWITCH PER RECALL 99S15
 SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15
 88860 99S15B QLS HRS SPEED CONTROL RECALL
 INSTALLED SPEED CONTROL SWITCH AS PER RECALL 99S
 RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

 1 RECALL 99S15 SAFETY SWITCH
 PERFORM RECALL
 1 PERFORMED 99S15 RECALL
 REPLACED RECALLED SWITCH
 INSTALLED KIT
 PERFORMED RECALL
 99S15 RECALL
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.
 99S15 BRAKE KIT 99S15
 REPLACE SWITCH AS PER RECALL
 1 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL
 115244 RECALL 99S15 W PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPL
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15
 99S15B RECALL PERFORMED RECAL
 RECALL 99S15
 PERFORM RECALL
 PERFORM RECALL
 PERFORMED RECALL 99S15
 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH
 RECALL REPLACE CONNECTOR AND SWITCH
 PERFORM INSPECTION AND REPLACE CONNECTOR AND SWITCH ASSEMBLY

REPLACED CONN AND SWITCH PER RECALL
PERFORM RECALL

57141 PERFORM RECALL AS DIRECTED BY TECH INFO REPLACE REDUNDENT CIR BK OVERRIDE SWITCH AND CONECTOR.
98111 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG
98S15B RECALL SPEED CONTROL
REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 98S15
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 98S15
OPEN RECALL PERFORM RECALL
REPL SPEED CONTROL SWITCH 98S15

PERFORM RECALL
98S15 RECALL 98S15 REPAIRED AS PER RECALL

1 SPEED CONTROL DEACTIVATION SWITCH RECALL
RECALL 98S15 RECALL 98S15
RECALL COMPLETED
RECALL 98S15
63380 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS
COMPLETED 98S15 98S15
NA 98S15 REPLACE SWITCH AND CONNECTOR.
RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH REPLACEMENT
PERFORMED RECALL
RECALL COMPLETED
98144 RECALL DID RECALL 98S15

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S
SPEED CONTROL DEACTIVATION SWITCH NOT WORKING PROPERLY R AND R DEACTIVATION SWITCH
RECALL COMPLETED
RECALLED 98S15 PERFORMED
RECALL PERFORM RECALL
PERFORMED RECALL 98S15
RECALL PERFORM RECALL
RECALL CRUISE SWITCH RECALL
98S15 98S15 RECALL
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR
COMPLETED RECALL 98S15
REPLACED C CONTROL DEACTIVATION SWITCH PER 98S15 RECALL
98S15 RECALL PERFORM RECALL
REPLACED SWITCH AND CONNECTOR
FACTORY RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL
PERFORM SPEED CONTROL RECALL 98 S 15
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR
COMPLETED RECALL 98S15B