

**EA02-025**

**FORD 10/27/03**

**APPENDIX N**

**BOOKS 9 OF 61**

**PART 3 OF 4**

PERFORMED RECALL  
 PERFORMED RECALL  
 REPLACED SWT PER RECALL

RECALL COMPLETED  
 70501 PERFORM RECALL 99S15  
 COMPLETE RECALL 99S15 T  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL INSTRUCTIONS  
 RECALL 99S15 RECALL  
 SPEED CONTROL SWITCH PERFORM 99S15  
 93879 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S19  
 INSTALLED SPEED CONTROL DEACTIVATION AS PER RECALL 99S15 . TECH 43-2418 E  
 INSTALL SWITCH PREVIOUSLY DISCONNECTED ON RO 158832  
 TECH PERFORMED RECALL AS PER OUTLINED-REPLACING DEACTIVATION SWITCH AND REPLACED FAULTY SWITCH-DURING REPAIR FOUND DAMAGE PROPORTIO  
 REPLACED SWITCH PER RECALL  
 REPLACE CRUISE SWITCH  
 RECALL 99S15 RECALL PERFORME  
 PREFORM RECALL  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 1 REPLACED SPEED CONTROL SWITCH  
 RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO

PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH  
 SPEED CONTROL SWITCH 99S15 RECALL  
 118738 99S15B 0.5 HRS. SPEED CONTROL RECALL  
 REPLACE SPEED SWITCH AS PER RECALL  
 REMOVED SPEED DEACTIVATION SWITCH INSTALLED NEW SWITCH BLEED BRAKES TESTDROVE  
 PERFORMED 99S15 RECALL  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR  
 204702 DEACTIVATION SWITCH REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 PERFORMED RECALL 99S15  
 PERFORM RECALL  
 RECALL REPLACE SWITCH

99S15B 0.5

PERFORMED RECALL  
 1 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 99S15B .5 - ADMIN .1  
 75742 PERFORMED RECALL 99S15 AND ROADTESTED.  
 AS PER RECALL 99S15 RECALL TO INSTALL HARDSHELL CONNECTOR SWITCH  
 PERFORMED RECALL  
 RECALL PERFORM RECALL # 0838  
 106733 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
 RECALL 99S15

INSTALLED KIT 99S15 RECALL PREFORMED  
 COMPLETE RECALL  
 108144 REPLACED SWITCH  
 PERFORMED SPEED CONTROL RECALL 99S15  
 PERFORMED RECALL  
 INSP AND REPL SWTH AND CONN PER RECALL  
 PERFORM RECALL REPLACE SWITCH  
 PERFORM 99S15 RECALL, REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 99S15 99S15 COMPLETED

PERFORM RECALL  
 AS PER RECALL 99S15 RECALL TO INSTALL HARD SHELL CONNECTOR  
 1 INSTALL KIT  
 INSTALL BRAKE SWITCH PER RECALL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15  
 REPLACE SWITCH TO CORRECT  
 PERFORMED RECALL

99S15 CC DE ACTIVATION SW RECALL 99S15 CC DE ACTIVATION SW RECALL  
 99S15B RECALL 99S15B RECALL  
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
 RECALLED BY FORD MOTOR COMPANY 99S15 COMPLETED RECALL PER LETTER  
 PERFORMED DEACTIVATION SWITCH RECALL  
 PERFORM RECALL 99S15  
 REPLACED DEACTIVATION SWITCH  
 99S15 99S15 PERFORM RECALL INSTALLED NEW BRAKE SWITCH AND WIRE HARNESS  
 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15  
 INSTALL SPEED CONTROL KIT

COMPLETE RECALL 99S15 PER FORD SPECIFICATIONS

PERFORMED RECALL 99S15  
 R&R SPEED CONTROL DEACTIVATION SWITCH PER 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

99013 RECALL INSTALLED CRUISE SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
 80877 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 REPLACE SWITCH PER RECALL  
 RECALL 99S15 COMPLETED  
 PERFORMED OPEN RECALL 99S15

RECALL REPAIR CRUISE  
 INSTALL NEW DEACTIVATION SWITCH PER RECALL  
 AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS  
 RECALL 99S15 PERFORMED RECALL- RECALCED C-C DEACTIVATION SWITCH  
 REPL SWITCH PER RECALL 99S15  
 REPLACE SPEED SWITCH AND HARD SHELL COVER AS PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCH  
 CLOSED BY WPI  
 RECALL 99S15 RECALL 99S15  
 99S15 INSTALL RECALL PARTS AS PER INSTRUCTIONS.

RECALL REPLACE SWITCH AND CONNECTOR  
 PERFORM RECALL  
 COMPLETED RECALL 99S15  
 1 REPLACE DEACTIVATION SWITCH 99S15B  
 1 PERFORM SPEED CONTROL SWITCH RECALL 1839 J  
 CHECK OASIS TO SEE IF VEHICLE WAS COVERED, R AND R BRAKE PRESSURE SWITCH AND CONNECTOR. COMPLETED RECALL 99S15. TECH 627-3405  
 154889 RECALL WARR COMPLETED  
 99S15 INSPECT AND PERFORM RECALL 99S15

TECH REPLACED SWITCH AS REQUIRED  
 99S15 RECALL 99S15 RECALL, REPLACED SPEED CONTROL CANCEL SWITCH AND HARDSHELL  
 99S15 99S15 RECALL  
 RECALL 99S15 RPL SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR  
 102194 INSTALLED BRAKE KIT.  
 RECALL COMPLETED  
 COMPLETE RECALL REPAIRS  
 44684 PERFORM RECALL 99S15.  
 SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I  
 RECALL 99S15

APPLIED RECALL 99S15  
 148820 LABOR 99S15B .5\*\*\*ADMIN .1\*\*\*REPLACED SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 VERIFY R&R CONNECTOR PER RECALL  
 88182 WARR PERFORMED RECALL 99S15  
 COMPLETED SPEED CONTROL RECALL 99S15. THANK YOU FOR USING MONACO FORD.  
 99S15 RECALL  
 99S15 MO 93452 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 99S15 99S15

PERFORMED RECALL AS NEEDED 1  
 PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15

RECALL 99S15 99S15 RECALL PERFORMED

RECALL 98S15 REPLACED CRUISE DEACTIVATION SWITCH -WIRING CONNECTOR PER RECALL 98S15  
 REPLACED DEACTIVATION SWITCH  
 58852 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL  
 1 PERFORM RECALL 98S15 REPLACE DEACTIVATION SWITCH. THANKS JEFF S.  
 REPLACE SPEED CONTROL SWITCH  
 REPLACE DEACTIVATION SWITCH  
 RECALL REPLACE SWITCH  
 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED 98S15 RECALL  
 65738 RECALL 98S15 PERFORMED RECALL INSTALLED NEW SWITCH AND CONNECTOR. ROAD TESTED. CHECKED OPERATI OF SPEED CONTROL WORKED FINE. TEC  
 1058 REPLACE BRAKE SWITCH PER 98S15 RECALL TECH140  
 1 PERFORMED RECALL 98S15  
 RECALL 98S15 INSTALLED SWIT  
  
 INSTALL SWITCH PER RECALL  
  
 REPLACE SWITCH AND HARNESS PER RECALL  
 PERFORMED RECALL PERFORMED RECALL  
 PERFORMED RECALL 98S15  
 REPLACED DEACTIVATION SWITCH PER RECALL 98S15  
 PERFORM RECALL-REPLACE SWITCH AND CONNECTOR  
  
 98S15, REPLACED CRUISE CONTROL HARDSHELL CONN  
 RECALL REPLACE SWITCH AND CONNECTOR PER RECALL  
 PERFORMED RECALL  
 1 REPLACED CRUISE SWITCH PER RECALL  
 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 70298 RECALL WP40 PERFORMED 98S15 RECALL. REPLACED CRUISE CONTROL SWITCH.  
 PER NOTICE PERFORM RECALL  
 PERFORM RECALL 98S15  
 06150 PERFORMED RECALL 98S15  
 PERFORM RECALL  
 RECALL COMPLETED  
 75061 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND SHELL. 98S15B 0.5 HR LABOR 0.1 ADMIN.  
 PERFORM RECALL 98S15, INSTALL CRUISE DEACTIVATION SWITCH. THANK YOU. JEFF S  
 INSTALL SWITCH ASSY  
 REPLACE SWITCH  
  
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15  
 PERFORM RECALL  
 1 PERFORMED RECALL  
 REPLACED DEACTIVATION SWITCH  
 CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.  
 REPLACED DEACT CRUISE SWITCH

COMPLETE RECALL 99S15  
 PER RECALL COMPLETED RECALL  
 REPLACE SWITCH PER RECALL  
 83713 99S15 W REPLACED SWITCH  
 COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH T  
 PERFORMED RECALL 99S15: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR.  
 RECALL 99S15 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH

OPEN RECALL PERFORMED RECAL  
 INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
 99S15B COMPLETED RECALL  
 REPAIR AS PER RECALL  
 PERFORMED RECALL  
 720811 PERFORMED RECALL 99S15  
 RECALL INSTALL CUTOFF SWITCH AS DIRECTED

41738 PERFORMED RECALL 99S15.  
 PERFORMED RECALL  
 G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 1 PERFORM RECALL  
 PRFMD RECALL 99S15  
 99S15 REMOVE TAPE AND SECURE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL FOR INTERIM REPAIR  
 FACTORY RECALL COMPLETED RECALL  
 99S15  
 1 PERFORM SPEED CONTROL RECALL 1839 .5  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15. BLED BRAKE SYSTEM AND CHECKED OPERATION, EVERY  
 RECALL PERFORMED RECALL 99S15

PERFORMED RECALL 99S15  
 PERFORM RECALL  
 REPLACED SWITCH

87296 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL  
 99S15B COMPLETED  
 REPLACE AS PER RECALL 99S15  
 REPLACED CRUISE DEACT SWITCH  
 PERFORMED RECALL REPLACED THE SWITCH AND CONNEC TOR  
 RPL CRUISE SWITCH PER RECALL 99S15  
 INSTALLED KIT TO COMPLETE  
 PERFORM RECALL  
 AE REPLACE SWITCH AND CONNECTORE  
 99S15 RECALL  
 FORD SAFETY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTO  
 83101 RECALL 8A  
 REPLACED THE SWITCH PER SERVICE CAMPAIGN . 99S15 B .5 ADMIN .1

RECALL RECALL  
 08232 REPLACE SPEED CONTROL SWITCH AND CONNECTOR PER RECALL 99S15.  
 RECALL 99S15 - COMPLET  
 REPLACED DEACTIVATION SWITCH AS PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 RECALL REPLACED SWITCH AND CONNECTOR PER RECALL  
 INSPECTED CRUISE SWITCH AND INSTALLED NEW SWITCH AS PER RECALL AS NEEDED FOR REPAIRS  
 REPLACED SW & CONECTOR  
 REPLACED SWITCH AND CONNECTOR  
 PERFORMED 99S15 AS PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 90219 RECALL 99S15 REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR X 930 X  
 AS PER RECALL 99S15 RECALL TO INSTALL SWITCH KIT  
 114208 PERF RECALL-REPLACE CRUISE SWITCH  
 PERFORM RECALL 99S15.  
 RECALL 99S15 RECALL 99S15  
 RECALL COMPLETED  
 56854 99S15 WARRANTY INSTALL SWITCH AND WIRE PLUG.  
 RECALL DUE PERFORMED RECALL 99S15B  
 PERFORM RECALL  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL T  
 126702 RECALL 99S15 99S15B .5 REPLACED SWITCH AND CONNECTOR PER RECALL  
 FACTORY RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 99S15 99S15 RECALL

REPLACED DEACTIVATION SWITCH PER 99S15 RECALL  
 PERFORM RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 024 REPLACED CRUISE DEACTIVATION SWITCH  
 76757 99S15 WARRANTY RECALL INSTALL SWITCH AND PLUG  
 REPLACE DEACTIVATION SWITCH  
 67487 RECALL 99S15 INSTALL DEACTIVATOR SWITCH AS PER RECALL

99S15 99S15 RECALL  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PE RECALL 99S15  
 REPLACED CRUISE DEACTIVATION SWITCH PER 99S15  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 RECALL COMPLETE  
 RECALL 99S15 REPLACED CRUISE DE-ACTIVATION SWITCH AS PER RECALL 99S15  
 PERFORMED PROGRAM 99S15  
 RECALL 99S15 COMPLETED  
 TECH RECOMMENDS-TRANSMISSION SERVICE-122.00 PLUS TAX -TIRE ROTATION 15.50 PLUS TAX -FRONT END ALIGNMENT  
 PERFORM RECALL  
 1 PERFORM RECALL 1839 .50

82855 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15  
 110493 RECALL 98S15 REPLACE DEACTIVATION SWITCH PER RECALL  
 PERFORMED RECALL 98S15B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR.  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL  
 RECALL COMPLETE RECALL

CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL  
 PERFORMED RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR GOODWILL.....  
 1 CAMPAIGN COMPLETED.

REPLACED THE SWITCH PER RECALL 98S15  
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL  
 101084 CHECK AND INSTALL NEW CRUISE DEACTIVATION SWITCH PER RECALL 2558  
 98S15 RECALL INSTALL DEACTIVATION SWITCH  
 98S16 98S15-REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH  
 REPLACED SWITCH & CONNECTOR PER RECALL

98S16 98S16  
 1 PERFORMED RECALL 98S15  
 98363 DID RECALL 98S15 REPLACED SWITCH AND CONNECTOR SHELL

51063 PERFORM 98S15 RECALL PER INSTRUCTIONS  
 PERFORM 98S15 RECALL  
 31818 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B .5  
 PERFORM RECALL

REPLACE SWITCH  
 RPL CRUISE SW PER RECALL 98S15  
 X 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 RECALL PERFORM RECALL 98S15 CRUISE CONTROL

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS  
 1 PERFORM SPEED CONTROL RECALL 1830 .5  
 1 INSPECT AND PERFORM RECALL AND BLEED BRAKES .5 1838  
 85906 REMOVE AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15.  
 PERFORMED RECALL REPLACED SWITCH AND CONNECTOR  
 RECALL 98S15  
 115531 98S15B 0.5 HRS. SPEED CONTROL RECALL  
 PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTED  
 106837 RECALL REPLACED SWITCH  
 PERFORM RECALL 98S15

PERFORMED RECALL  
 PERFORMED RECALL 98S15  
 RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH  
 98S15 PERFORM 98S15  
 98S15 51117 MILEAGE REPLACE SPEED CONTROL PRESSURE SWITCH PER 98S15  
 1 PERFORM RECALL



1 PERFORMED RECALL  
 RAN DIAGNOSTIC TESTS. REPLACED DEFECTIVE SOLENOID FOR TORQUE CONVERTOR CONTROL. ROAD TESTED 98-08-05 CO-41 CP-7G138  
 INSTALLED RECALL 99S15 NOTE: RADIO DOES NOT WOR  
 95557 99S15B 0.5 ADMIN 0.1  
 PERFORMED RECALL 99S15  
 94888 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745  
 PERFORM RECALL 99S15  
 PERFORM RECALL  
 1 PERFORM CRUISE RECALL 1839 VEHICLE ALSO NEEDS TUNE, FUEL FILTER, PCV VALVE, INJECTOR CLEAN  
 00 99S15  
 52735 PERFORM RECALL, REPLACE DEACTIVATION SWITCH 99S15B .5  
 RECALL 99S15 RECALL COMPLETED  
 1 PERFORMED RECALL 99S15 DEACTIVATION SWITCH AND CONNECTOR 99S15B  
 REPLACE SPEED CONTROL CABLE PER RECALL 99S15  
 PER THE OASIS PERFORMED RECALL #99S14.  
 TECH COMPLETE RECALL AS REQUIRED  
 REPLACE SWITCH  
 99S15 99S15 RECALL  
 1 REPLACED SWITCH AND BLEED BRAKES AS PER RECAL  
 99303 1 PERFORMED RECALL 99S15  
 COMPLETED RECALL  
 REPLACED SC DEACTIVATION SWITCH 99S15  
 PERFORM RECALL  
 INSTALL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 RECALL DUE PERFORMED RECALL 99S15B  
 1 PERFORMED RECALL  
 99S15 RECALL 99S15 RPL SPEED CONTROL DEACTIVATION SWITCH & REWIRE CONNECTOR  
 99S15 99S15 RECALL  
 48001 SERVICE RECALL 99S15 REPLACE NEW BRAKE SWITCH  
 PERFORM RECALL.....  
 PERFORMED RECALL  
 99S15 99S15 RECALL  
  
 34211 INSTALL SWITCH PER RECALL .  
 99S15 99S15 RECALL  
 REPAIR AS PER RECALL  
 RECALL PERFORMED  
 REPLACED SWITCH & CONNECTOR PER 99S15  
 99S15  
 CAMPAIGN COMPLETED  
 REPLACED SWITCH AND CONNECTOR  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACE SWITCH  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL PER INSTRUCTION  
 PERFORMED RECALL 99S15

RECALL CRUISE CONTROL RECALL 98S15  
 REPLACED SPEED CONTROL SWITCH AND CONNECTOR  
 98S15  
 1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 98S15 PER RECALL INSTRUCTIONS  
 RECALL 98S15 RECALL PERFORME  
 PERFORM RECALL 98S15  
 PERFORM RECALL 98S15

85508 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 98S15  
 SUPPLEMENT #1 5-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 PERFORMED RECALL 98S15  
 98S15 RECALL 98S15 REPLACE SWITCH AND HARDSHELL CONNECTOR

D 98S15 WAS FOR 98S15E  
 88174 98S15 INSPECT AND INSTALL DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 PERFORM RECALL 98S15 INSTALL BRAKE KIT PER RECALL 98S15  
 RECALL COMPLETED 98S15  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL 98S15B \_ REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 98S15  
 98S15 BRAKE REPAIR  
 MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
 RECALL 98S15 SPEED CONT DEACT SWITCH  
 RECALL 98S15 REPLACE C-C SW  
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 98S15  
 PERFORMED RECALL 98S15  
 REPLACED DEACTIVATION SWITCH  
 SPEED CONTROL DEACTIVATION SWITCH REPLACE 98S15B PERFORMED RECALL 98S15B  
 28886 RECALL W/ REPLACE SWITCH GA  
 PERFORM 98S15 RECALL  
 PERFORM RECALL 98S15  
 COMPLETED RECALL 98S15  
 RECALL 98S15 PERFORMED RECALL 98S15-REPLACED CRUISE CONTROL SWITCH  
 1 REPLACE THE CRUISE CONTROL SWITCH AND PLUG 98S15  
 COMPLETE RECALL 98S15  
 OPEN RECALL PERFORMED 98S15  
 REPLACE SWITCH PER RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION  
 PERFORM RECALL  
 REPLACED SPEED CONTROL SWITCH PER RECALL  
 98S15 RECALL 98S15 REPAIRED AS PER RECALL

REPLACE SPEED CRTL CONNECTOR AND HARNESS

60029 0.5 REPLACED DEACTIVATION SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 99815 COMPLETED REPLACED SWITCH.  
 COMPLETED RECALL PER INSTRUCTIONS  
 128183 REPLACE SPEED CONTROL CABLE ROAD TEST YES OK AT THIS TIME. COMPLETED  
 RECALL 99815 PERFORMED RECALL-REPLACED C-C DEACTIVATION SWITCH  
 135914 TECH 079 PERFORMED RECALL 99815 ON CRUISE CONTROL

55782 REPLACED DEACTIVATION SWITCH 5314  
 INSTALL DEACTIVATION SWITCH

REPAIR REPLACE  
 100677 RECALL REPLACED DEACTIVATOR SWITCH AND CONNECTOR RECALL 99815

REPLACED SWITCH  
 INSPECT AND PERF RECALL ACCORDING TO INSTRUCTIONS 1  
 RECALL 99815 RECALL  
 REPLACE SWITCH PER RECALL  
 53189 998189 0.5 HRS. SPEED CONTROL RECALL  
 RECALL PERFORME DRECALL 99815  
 RECALL 99815 RECALL  
 1 99815B.5 ADMIN.1  
 1 INSTALLED RECALL SWITCH 1  
 99815 RECALL 99815 RECALL COMPLETE  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99815

99815 99815  
 99233 RR SWITCH  
 38207 99815 REPLACE DEACTIVATION SWITCH & CONNECTOR PER 99815 TECH 5323 TECH 532  
 106712 RECALL DO RECALL

REPLACED DEACTIVATION SWITCH  
 1 REPLACE BRAKE SWITCH AND CONNECTOR  
 SAFETY RECALL 99815 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 99815 99815 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 99815 99815 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SWITCH

PERFORMED CRUISE CONTROL RECALL 99815  
 COMPLETED AS PER RECALL

DN02-025 1.1000

bodyies\_OLD1

RPLC SPEED CONTROL DEACTIVATION SWITCH PER 99S15

REPLACE DEACTIVATION SWITCH AS PER RECALL  
PERFORM RECALL

1 PERFORM RECALL 99S15 E  
INSTALLED CRUISE RECALL 99S15.

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME  
REPLACE SPEED CONTROL DEACTIVATION SWITCH 1  
23901 INSTALL DEACTIVATION SWITCH PER RECALL  
REPLACED SWITCH  
104061 .5HRS PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL DEACT SWITCH.  
81955 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH  
1 PERFORM RECALL  
REPLACED SPEED CONTROL SWITCH  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR  
RECALL 99S15

COMPLETED AS PER RECALL

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5  
INSTALLED SWITCH

REPLACE SWITCH CONNECTOR ASSEMBLY

99S15 99S15

62297 PERFORMED RECALL # 99S15

REPLACED DEACTIVATION SWITCH

DIAGNOSE REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15,

99S15 SPEED CONTROL RECALL

PERFORM RECALL PER FORD

.5 LABOR AND .1 ADMIN PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS REPLACED DEACTIVATION SWITCH AND CONNECTOR

8PD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15

RECALL 99S15 COMPLETED

INSTALLED SWITCH ON CRUISE CONTROL AS PER RECALL 99S15.

103384 PERFORM RECALL 99S15 REPLACE CUT OFF SWITCH FOR CRUZ

99S15B RECALL 3 PERFORM RECALL

RECALL 99S15 PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS

RECALL SPEED CONTROL REPLACE SWITCH AND CONECTOR

99S15 RECALL 99S15 RECALL

99S15 REPLACED SWITCH & CONNECTOR PER RECALL

73858 WARR PAY TECH 4207 AS PER C. BEBER PERF 99S15  
 99S15 PERFORMED RECAL  
 REPLACE SWITCH AND CONNECTOR  
 RECALL 99S15 RECALL  
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 OPEN RECALL PERFORMED RECAL  
 RECALL REPLACESWITCHAND CONNECTOR  
 99337 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 PERFORMED RECALL  
 41898 REPLACED SPEED CONTROL DEACTIVATION SWITCH 99S15B 0.5 HRS. 0.1 ADMIN  
 REPLACE DEACTIVATION SWITCH TO CRUISE CONTROL 1  
 RECALL 99S15 RECALL-R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR

1 PERFORMED RECALL 99S15  
 PERFORMED RECALL 99S15  
 PERFORM RECALL 99S15 --REPLACE SPEED CONTROL SWITCH  
 PERFORMED RECALL

99S15 INSTALL CRUISE DEACTIVATION SWITCH PER RECALL  
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE,ALSO A FIRE COULD DEVOPE. REPLACE SPEED C  
 110847 REPLACED DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.  
 99788 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONECTOR  
 RECALL 99S15 REQUIRED REPL BRAKE DEACTIVATOR SWITCH PER RECALL 99S15.  
 CAMPAIGN COMPLETED

64438 RECALL99S15 99S15B 0.5 0.5 RECALL  
 RECALL INSTALL DEACTIVATION SWITCH AS PER RECAL  
 RECALL 99S15  
 PERFORM RECALL99S15

REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 REPLACE SWITCH PER RECALL  
 125990 CRUISE DEACTIVATION SWITCH RECAL 99S15 INSTAL CRUISE DEACTIVATION SWITCH FOR RECAL 23  
 100488 PERFORM 99S15 RECALL  
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 INSPECT AND REPLACE CRUISE CONTROL SWITCH  
 MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

00 99S15  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 AS PER RECALL 99S15 RECALL TO INSTALL HARSHHELL CONNECTOR KIT  
 COMPLETED AS PER RECALL  
 99S15 PERFORMED RECAL  
 RECALL 99S15 RECALL 99S15

## INSTALLED KIT PER FACTORY RECALL

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 COMPLETED RECALL PER INSTRUCTIONS  
 RECALL PERFORMED RECALL  
 RECALLED 99S15 PERFORMED  
 REPLACED SWITCH

99S15 99S15

PERFORM RECALL 99S15 BLEED BRAKE SYSTEM ROAD TEST OK AT THIS TIME...  
 D 99S15 WAS FOR 99S15E  
 177224 PERFORM RECALL AS PER INSTRUCTIONS

TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL  
 RECALL REPLACE SWITCH PER RECALL

RECALL 99S15 PERFORMED

108279 INSTALLED RECALL 99S15

27266 08 REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL.....

REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

99S15B 99S15B

COMPLETED AS PER RECALL

PERFORM RECALL

SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL

1 REPLACED SWITCH

COMPLETED RECALL PER INSTRUCTIONS

PERFORM RECALL AS REQUIRED

99S15

PERFORMED RECALL 99S15

REPAIR CRUISE CTL PER RECALL

RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL

COMPLETED RECALL 99S15

CRUISE SWITCH 99S15 REPLACE CRUISE SWITCH AND CONNECTOR

INSTALL CRUISE CONTROL CANCEL SWITCH

REPLACED SWITCH PER FACTORY RECALL

SPEED CONTROL SWITCH 99S15 RECALL

PERFORM RECALL 99S15 INSTALL KIT

RECALL COMPLETE

PERFORMED RECALL 1

99S15 SPEED CONTROL RECALL

## REPLACED SWITCH

84285 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

11350 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONDUCTOR TK372

PERFORMED RECALL

82 RECALL 98S15-R&amp;R SPEED CONTROL DEACTIVATION SWITCH

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTED

98S15 INSTALL SWITCH CONNECTOR

PERFORMED RECALL TECH 1737

PERFORM RECALL

82068 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH &amp; CONNECTOR PER RECALL

REPLACED DEACTIVATION SWITCH AND COVER

102899 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH

112885 PERFORM 98S15 SPEED CONTROL DEACT SWITCH

INSTALLED KIT 98S15 RECALL PERFORMED

RECALL SPEED CONTROL DEACTIVATION SWITCH

PERFORMED THE RECALL 98S15

REPLACED CRUISE CONTROL SWITCH PER RECALL

1 REPLACE CRUISE CONTROL SWITCH AS PER RECALL

PERFORMED THE RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

91705 RECALL 98S15

PERFORM 98S15 RECALL

0894-REPLACE HARDSHELL CONNECTOR AND SWITCH

01985 PERFORM RECALL

42754 98S15 R&amp;R CRUISE CONTROL SWITCH

REPLACE SWITCH AND CONNECTOR FOR RECALL RECALL

PERFORMED RECALL

TYPE 2 PROGRAM 98S15 PERFORM RECALL PER GUIDELI

RECALL 98S15 COMPLETED

REPLACED DEACTIVATION SWITCH

COMPLETED RECALL

SHORT MAY DISABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH &amp; PROTECT IT

PERFORM RECALL

PERFORMED RECALL 98S15 CRUISE SWITCH REPLACEMENT

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH &amp; HARD SHELL CONN

82052 98S15 RECALL R&amp;R SWITCH AND CONNECTOR PER RECALL

45342 42 WP40 COMPLETE RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTION

63332 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONDUCTOR TK372

64445 RECALL TECH 9177 PERFORM RECALL 98S15 INSTALL SWITCH AND CONNECTOR

84284 98S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745

CK AND REPAIR AS PER RECALL

PERFORMED RECALL 98S15, REPLACED THE SPEED CONTROL DEACTIVATION SWITCHES. NOTE: SPEED CONTROL DID NOT OPERATE PRIOR TO RECALL RECALL

INSTALL KIT

1 PERFORMED RECALL-REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
24998 INSTALLED NEW SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.  
RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS  
48851 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
3099 WLM 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
REPLACED CRUISE DEACTIVATION SWITCH PER RECALL  
99S15 COMPLETED  
REPLACED SWITCH PER RECALL  
99S15 SPEED CONTROL RECALL  
NA PERFORMED REPAIRS AS PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
PERFORM RECALL  
PERFORMED RECALL PERFORMED RECALL  
INSPECT OR REPLACE CABLE PERFORMED RECALL 99S09

22458 CC 42 PERFORM RECALL 99S15  
RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT  
REPLACE CRUISE CONTROL SWITCH AS PER RECALL  
PERFORMED RECALL 99S15  
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
99S15 99S15 RECALL  
PERFORMED RECALL  
99S15 REPL SPEED CONTROL DEACTIVATION SWITCH  
INSPECT AND REPLACE CRUISE CONTROL CONNECTOR  
PERFORM RECALL  
RECALL 99S15  
RECALL 99S15 PERFORM RECALL 99S15 PER LETTER  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
PERFORMED AS PER RECALL  
PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORM RECALL  
REPLACE SWITCH AND HARNESS PER RECALL  
PERFORMED CRUISE RECALL  
PERFORM RECALL 99S15  
FACTORY RECALL COMPLETED RECALL  
99S15 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL  
PERFORMED RECALL REPLACED SWITCH AND CONNECTOR CKS OK  
R REPLACE SWITCH PER RECALL INSTRUCTIONS

94998 79 PERFORM 99S15 R/R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST  
PERFORMED THE RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
99S06 CC-42 RECALL TECH 8045 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15



PERFORM RECALL  
 AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS  
 REPLACE SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 89824 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL # 98S15  
 REPLACE AS PER RECALL 98S15  
 PREFROEND RECALL

89821 RECALL#98S15 SPEED CONTROL DEACT SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL#98S15.  
 RECALL SPEED CONTROL DEACTIVATION SWITCH SELF APPROV FOR MISENTERED MILEAGE  
 PERFORM RECALL INSTALL SWITCH  
 COMPLETED RECALL  
 PERFORM RECALL -DONE  
 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 REPL SWITCH PER RECALL 98S15

COMPLETED RECALL  
 RECALL 98S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH  
 48573 PERFORMED RECALL 98S15  
 128360 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

REPLACED SWITCH AND CONNECTOR AS PER RECALL  
 PERFORMED RECALL REPLACED SWITCH AND CONNECTOR OKS OK  
 INSTALL UPDATED SPEED CONTROL DEACTIVATION SWIT CH.  
 31084 RECALL 98S15B 0.5, ADMIN 0.1 REPLACE DEACTIVATION SWITCH & CONNECTOR PER RECALL  
 1 REPLACED SPEED CONTROL SWITCH AND CONNECTOR  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 RECALL PERFORMED RECALL  
 REPLACED DISENGAGE SWITCH PER RECALL 98S15  
 AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS  
 75885 REPLACE DEACT SWITCH AND CONN PER RECALL 98S15  
 REPAIR SPEED CTL PER RECALL  
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 98S15 RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL

RECALL 98S15 REPLACE C-C SW  
 RECALL 98S15 CONNECTOR MELTED WIRES MELTED AND FUSE BLOWN REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15 ALSO REPLAC

CRUISE RECALL REPL SW.  
 RECALL 98S15  
 PERFORM RECALL 98S15  
 PERFORMED RECALL 98S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 COMPLETE RECALL 98S15

INSTALL DEACTIVATION SWITCH KIT

1 DO RECALL 99S15

COMPLETE RECALL

120138 RECALL PERFORM RECALL 99S15 REPLACE SWIT

COMPLETE RECALL

REPLACED SWITCH PER RECALL 99S15

84208 W.. REPLACE CRUISE SWITCH PER RECALL(CC82)

99S15 99S15 RECALL

99S15 REPAIR PER RECA

RECALL

99S15 RECALL PERFORMED

PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL,BLED BRAKES,CHECKS OK

48009 INSTALLED 99S15 SPEED CONTROL SWITCH

99S15 99S15

1 REPLACED DEACTIVATION SW AS PER RECALL 99-8-1

RECALL 99S15 RECALL 99S15

99S15 99S15

99S15 RECALL COMPLETE RECALL

INSTALL SWITCH KIT

COMPLETE RECALL 99S15

PERFORM RECALL 99S15

COMPLETE RECALL 99S15

PERFORM RECALL 99S15 REPLACE SWITCH

PERFORM RECALL 99S15

99S15-4404 REPLACED SPEED CONTROL DEACTIVATION SWITCH

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15

99S15B

RECALL

99S15 RECALL

RECALL 99S15

RECALL 99S15

PERFORM RECALL SPEED CTRL DEACT SWITCH

REPLACED CRUISE SWITCH AND CONNECTOR PER RECALL

99S15 REPLACED CRUISE DEACTIVATION REPLACED DEACTIVATION SWITCH FOR CRUISE CONTROL

132598 R-R SW PER RECALL

INSPECT AND REPALCE CRUISE SWITCH AND CONNECTOR

45716 W PERFORM RECALL

99990 RECALL INSTALL RECALL SWITCH AND CONTACTOR AS INSTRUTED

1 PERFORMED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (99S15B .5) COMPLETED

REPL SWITCH PER RECALL 99S15

PERFORM RECALL 99S15- REPLACE CRUISE CONTROL PARTS

ENR-025 11883

98S15 98S15 RECALL  
78135 REPLACE SWITCH AS PER RECALL  
RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.  
PERFORMED RECALL 98S15B.

COMPLETE RECALL 98S15  
5400 98S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
REPAIR AS PER RECALL 98S15.  
98S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT  
PERFORMED RECALL  
COMPLETED RECALL  
REPL SWITCH PER RECALL 98S15  
98S15 98S15

PERFORMED RECALL 98S15  
REPLACED SWITCH AS PER RECALL  
PERFORMED RECALL 98S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH  
007 COMPLETED RECALL 98S15  
PERFORMED RECALL  
78914 RECALL WP40 PERFORM RECALL REPLACE BRAKE PRESSURE SWITCH AND CONNECTOR  
PERFORMED OPEN RECALL  
90067 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL  
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITC  
98S15 98S15 RECALL  
PERFORMED 98S15 RECALL  
PERFORM SAFETY RECALL  
98S15 RECALL PERFORMED 98S15 RECALL  
UNKNOWN INSTALL CRUISE DEACTIVATION SWITCH PER 98S15  
30887 .3 + .1 ADMIN. 98S15B. REPLACED DE-ACTIVATION SWITCH.  
REPL KIT PER RECALL 98S15  
158391 REPLACED SPEED CONTROL SWITCH AS PER RECALL # 98S15  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
PERFORMED 98S15 RECALL  
PERFORM 98S15 RECALL  
PERFORMED RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
PERFORM RECALL  
PERFORMED RECALL

81575 REPLAGE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
98S15 98S15-REPLACED THE CRUISE CONTROL SWITCH  
RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
115517 98S15  
PERFORMED RECALL

AS PER RECALL 98S15 RECALL TO INSTALL SPEED CONTROL HARDSHELL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 128083 99S15B 0.5 0.5 PERFORM 99S15  
 RECALL DONE AS PER RECALL  
 23448 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL.  
 REPLACE SWITCH AND HARD SHELL  
 OPEN RECALL PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH  
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 99S15 99S15  
 COMPLETED RECALL 99S15  
 99S15 INSTALLED REPAIR KIT AS PER RECALL  
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH  
 180733 42 ROAD TEST TO VERIFY, EVAC & RECHARGE TO REMOVE EXCESS OIL REPLACE ORFICE & PRESS SWITCH & BLEND DOOR ACT & PET.OMETER  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 RECALL 99S15  
 181048 RECALL W INSPECT REPLACE DEACTIVATOR SWITCH AND CONNECTOR PER 99S15 811 1168  
 REPLACED CRUISE DEACTIVATION SWITCH  
  
 RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 88548 PERFORM RECALL 99S15  
 PERFORME 99S15  
 88532 WARRANTY, PERFORMED SPEED CONTROL SWITCH RECALL AS PER RECALL INSTR.  
 REPLACE SPEED CONTROL SWITCH  
 PERFORMED RECALL 99S15  
 99S15 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR  
 1 RECALL 99S15  
 118918 PERFORM 99S15 RECALL, REPLACE DEACTIVATION SWITC  
 38448 PERFORMED RECALL 99S15.  
 PERFORMED RECALL 99S15  
 REPLACE CRUISE DEACTIVATION SWITCH  
 RECALL 99S15 REPLACE DEACTIVATION SWITCH  
 PERFORM RECALL 99S15 - -REPLACE CRUISE CONTROL SWITCH  
 RECALL 99S15 RECALL  
 SPEED CONTROL SWITCH 99S15 RECALL  
  
 INSTALL HARDSHELL CONNECTOR  
 48308 99S15B .5 REPLACE SWITCH AND HARDSHELL  
 99S15 99S15  
 RECALL 99S15  
  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6  
 REPL SWITCH PER RECALL 99S15  
 REPL SWITCH PER RECALL 99S15  
 99S15B 0.5  
 COMPLETED RECALL 99S15  
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACED DEACTIVATION SWITCH PER 99S15 RECALL  
84984 DID RECALL # 99S15

X PERFORMED RECALL  
108221 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.  
1 REPLACE CRUISE CONTROL SWITCH AS NEEDED  
8 5 INSTALLED SWITCH AND WIRING 7548  
SWITCH AND WIRING CONNECTOR. 1  
1 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION  
201433 RECALL 99S15 RPL BRAKE PRESSURE SW AND CNCTR PER 99S15

REPLACE SWITCH PER RECALL  
REPLACE SPEED CONTROL SWITCH  
99S15 SPEED CONTROL RECALL  
RECALL 99S15 REPLACE C-C SW

99S15 RECALL 99S15 RECALL INSTALLED SPEED CONTROL CABLE PER RECALL  
99S28 WHILE REMOVING THE DEACTIVATOR SWITCH THE THREADS PULLED OUT OF THE METERING VALVE THE VEHICLE NEEDS A NEW VALVE INSTALLED NEW 8  
PERFORMED RECALL  
82255 RECALL W REPLACE SWITCH AND PLUG GA  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
REPLACED HARD SHELL AND SWITCH AS PER RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
94163 INSTALLED THE BRAKE INPUT SWITCH FOR THE SPEED CONTROL SYSTEM PER RECALL NOTICE  
REPLACED SC DEACTIVATION SWITCH 99S15  
REPLACED DEACTIVATION SWITCH AS PER RECALL

PERFORM RECALL 99S15  
REPL SWITCH PER RECALL 99S15  
PERFORM RECALL 99S15  
PERFORMED RECALL 99S15  
RECALL 99S15 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC  
RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC  
RECALL RECALL COMPLETE  
99S15 REPLACE DEACTIVATION SWITCH  
RECALL 99S15 PERFORM RECALL 99S15  
RECALL RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL PERFORMED RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

DEACTIVATION SWITCH 99S15  
RECALL INSTALL NEW DEACTIVATION SWITCH  
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
99S15 99S15 RECALL  
OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS

99815 COMPLETED 99815 COMPLETED  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815  
 REPLACED SPEED CONTROL  
 RECALL PERFORM RECALL RENEW SWITCH AND CONNECTOR  
 99815 PERFORM RECALL 99815  
 1 1 REPL DEACTIVATION SWITCH AND CONNECTOR  
 1 REPLACED DEACTIVATION SWITCH AS PER RECALL 99815  
 X 99815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 RECALL 99815  
 9 PERFORM RECALL 99815  
 14802 79 PERFORM 99815 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST  
 PERFORMED RECALL 99815  
 PERFORM RECALL  
 RECALL 99815 RECALL 99815 COMPLETED  
 99815 SPEED CONTROL RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99815B TIME 5 PERFORM RECALL 99815 AS PER INSTRUCTIONS  
 VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK  
 RECALL 99815 RECALL  
 REPL SWITCH AND CONNECTOR REPAIR AS PER RECALL 99815  
 REPLACED KIT PER RECALL  
 PERFORMED RECALL  
 99815 CC DE ACTVATIN SW RECALL 99816 CC DE ACTVATION SW RECALL  
 INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN  
 99815 REPLACE DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL  
 RECALL 99815B REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 99815B PERFORMED RECALL  
 PERFORM RECALL 99815  
 RECALL 99815 PERFORM RECALL 99815  
 RECALL C COMPLETED  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 REPLACE DEACTIVATION SWITCH PER RECALL 99815  
 PERFORMED RECALL 99815  
 PERFORM RECALL 99815  
 42246 W 752 PERFORMED RECALL 99815  
 PERFORM RECALL  
 INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99815E 0.3 HRS PERMANENT REPAIR REPLACED SP  
 REPLACE DEACTIVATION SWITCH FOR CRUISE CONTROL  
 REPLACE DEACTIVATION SWITCH MILEAGE WAS VERIFIED  
 REPLACED SPEED CONTROL SWITCH AND CONNECTOR  
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 REPLACE DEACTIVATION SWITCH  
 1 INSTALLED SWITCH AND CONNECTOR

5002-025 11067

REPL SWITCH PER RECALL 99S15  
107330 RECALL 99S15 PERFORM RECALL 99S15 AS PER TEST DRIVE 4 MILES O. K  
REPLACED CRUISE DEACTIVATION SWITCH  
99S15 99S15 COMPLETED

110064 RECALL WPG40 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15  
OPEN RECALL PERFORM RECALL  
CRUISE DEACTIVATION SWITCH, PERF RECALL AS PERSCRIBED ROAD TESTED OK

X RECALL

1 INSTALLED SWITCH AND WIRE CONECTOR  
PERFORMED AS PER RECALL  
REPLACED SWITCH AND CONNECTOR AS PER RECALL  
RECALL RECALL DONE  
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. INTERIM REPAIR-REMOVE, TAPE AND SECURE SI  
CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA  
99S15 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORM RECALL INSTALL SWITCH  
110064 RECALL 99S15B 0.5 0.5 RECALL  
REPLACED SWITCH  
PERFORM RECALL  
REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
99S15 COMPLETED 99S15 COMPLETED  
PERFORMED THE RECALL 99S15  
PERFORMED RECALL 99S15  
99S15 PERFORMED RECALL  
RECALL COMPLETED  
COMPLETED RECALL 99S15

161430 RECALL W PERFORMED RECALL 99S15 REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR  
PERFORM RECALL  
1 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
1 PERFORMED RECALL  
RECALL 99S15 RECALL, REPLACE SWITCH  
76201 99S15 WARR REPLACED SWITCH AND CONN  
PERFORMED RECALL  
PERFORMED RECALL  
SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACT. SWITCH AS DIRECTED  
PERFORMED 99S15 RECALL

J6 PERFORM RECALL REPL DEACTAVITON SWITCH AND CONNECTOR  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPLACED DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH  
 SERVICE REPLACED SWITCH AND BLEED BRAKES PER RECALL  
 DIFFERENCE OF ONE MILE FOR ROAD TESTING.  
 REPLACED DEACTIVATION SWITCH PER RECALL  
 RECALL 98S15 REPLACE C-C SW

PERFORMED THERECALL 98S15  
 PERFORM SPEED CONTROL RECALL  
 PERFORM RECALL 98S15  
 PER RECALL RPLC SPEED CONTROL DEACTIVATR SW PER RECALL & HARD SHELL  
 1 RECALL 98S15 COMPLETED  
 MILEAGE ENTERED IS CORRECT. ON 6/2 VEHICLE HAD 68883 MILES, THEN ON 7/28 IT HAD 71004. DONT UNDERSTAND PROBLEM ?  
 88203 98S15 RECALL ADD ON OKD BY R.A.B. INSPECT AND INSTALL DEACTIVION SWITCH AND HARD SHELL AS PER 98S15 INSTRUCTIONS  
 RECALL 98S15 PERFORMED RECALL 98S15  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 PERFORMED THE RECALL 98S15  
 CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION  
 PERFORM RECALL 98S15  
 42585 RECALL 98S15 W 98S15B 0.5 HRS ADMS 0.1 HRS REPLACE SPEED CONTROL DEACTIVATION SWITCH AND C ONNECTER PERRECALL 98S15-B  
 RECALL 98S15  
 OPEN RECALL PERFORMED RECALL 98S15  
 98S15 RECALL 98S15 RECALL  
 RECALL RECALL  
 INSTALLED NEW SPEED CONTROL SWITCH AS PER RECALL 98S15 ROAD TEST NORMAL. TECH 408-06846  
 RECALL INSTALL SPEED CONTROL DEACTIVATION SWITC  
 REPLACE DEACTIVATION SWITCH PER RECALL  
 119408 RECALL 98S15 INSTALL SPEED CONTROL SWITCH AND HARNESS  
 REPLACE DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH  
 98S15B 98S15B  
 98S15 CC DE ACTIVATION SW RECALL98S15 CC DE ACTIVATION SW RECALL  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
 REPLACE SPEED CONTROL SWITCH AS PER RECALL 98S15  
 RECALLED 98S15 PERFORMED  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 98S15 SERVICE WRITER FORGOT TO ADD MILEAGE FROM REPLACEMENT SPEEDOMETER  
 RECALL PERFORM RECALL  
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA  
 1 COMPLETED RECALL 98S15  
 93774 RECALL 98S15B-0.5 HRS PERFORMED RECALL 98-S-15 TK 8276  
 PERFORMED RECALL 98S15  
 PERFORMED RECALL 98S15  
 RECALL 98S15 - B -RECALL  
 PERFORM RECALL 98S15  
 RECALL 98S15 - B - RECALL  
 RECALL CRUISE CONTROL RECALL 98S15



98772 RECALL REPLACED SWITCH AND TEST DROVE WORKS NORMAL  
PERFORMED THE RECALL 98815  
PERFORMED RECALL  
REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 98815  
PREFORM SPEED CONTROL RECALL  
REMOVED & REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98615 PERFORMED RECALL 98815  
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98815  
REPLACED DEACTIVATION SWITCH PER RECALL  
RECALL 98815 98815  
DIAG REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 98815  
1 PERFORMED RECALL 98815  
PERFORM RECALL 98815 AS PER TECHNICAL INSTRUCTIO

PERFORM RECALL 98615  
RECALL 98815 REPLACE C-C SW  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR, ROAD TEST.E  
98815 CC DE ACTIVATION SW RECALL98815 CC DE ACTIVATION SW RECALL  
PER RECALL PERF RECALL  
98815 - SPEED CONTROL SWITCH 98615 - REPLACE SWITCH AND CONNECTOR

REPLACED CABLE  
RECALL 98815 RECALL COMPLETE  
RECALL 98815 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 98815  
INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
RECALL REPLACE CRUISE SWITCH CONNECTO.,  
98815 98815

98815 CC DE ACTIVATION SW RECALL98815 CC DE ACTIVATION SW RECALL  
RECALL 98815 RECALL  
REPL SWITCH PER RECALL 98815  
PERFORMED RECALL 98815,REPL DEACTIVATION SWITCH  
42000 PERFORM RECALL 98815 INSTALL SWITCH  
REPLACE SPEED CONTROL SWITCH PER RECALL  
PERFORMED RECALL  
MODIFIED PER RECALL  
82283 79 PERFORM 98815 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH  
INSTALL DEACTIVATION SWITCH  
COMPLETED RECALL  
PERFORMED RECALL 98815 F  
RECALL PERFORM RECALL, INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH  
1 PERFORMED RRECALL 98815

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98815  
REPLACE DEACTIVATION SWITCH AS PER 98815

1 COMPLETED RECALL 99S15  
 INSTALL DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS  
 COMPLETED AS PER RECALL  
 1 PERFORMED RECALL, REPLACED SPEED CONTROL DE-ACTIVATION SWITCH.  
 199506 RECALL 99S15 R&R CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15  
 81957 REPLACED DEACTIVATION SWITCH 9314  
 115- CRUISE SWITCH RECALL - 99S15 - REPLACE CRUISE BRAKE SWITCH AND CONN PER 99S15

COMPLETED RECALL INSTALL SW  
 PERFORMED RECALL 99S15  
 INSTALLED SWITCH PLUG PER RECALL 99S15  
 RECALL 99S15 REPLACE C-C SW  
 RECALL 99S15 RECALL 99S15  
 30413 INSTALLED RECALL KIT 99S15 OPERATION OK  
 99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT  
 REPLACED SPEED CONTROL SWITCH PER RECALL  
 RECALL COMPLETED

PERFORM RECALL  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 1 COMPLETED RECALL  
 FDF RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 RECAL PERFORMED SPEED CONTROL DEACTIVATION SWTIC  
 PERFORM RECALL 99S15  
 55385 RECALL WA PERFORM RECALL, REPLACE SWITCH  
 DOES NOT OPERATE PROPERLY ANTI-LOCK BRAKE SYSTEM - DIAGNOSIS  
 PERFORMED RECALL 99S15  
 REPL SWITCH PER RECALL 99S15  
 PERFORM RECALL 99S15  
 1 PERFORMED RECALL  
 PERFORMED THE RECALL 99S15

PERFORM RECALL 99S15  
 99S15 99S15 RECALL  
 REPLACE SWITCH FOR SPEED CONTROL PER RECALL 99S1  
 COMPLETE RECALL  
 PERFORM RECAL  
 REPLACED SPEED CONTROL SWITCH  
 SPEED CONTROL DEACTIVATION SWITCH REPLACED DEACT. SWITCH AS DIRECTED  
 RECALL PERFORMED RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 RECALL REPLACE SWITCH M  
 RECALL 99S15 99S15  
 REPLACED SWITCH AND CONNECTOR PER RECALL

RECALL COMPLETED  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTION  
 RECALL COMPLETE

REPLACED SC DEACTIVATION SWITCH 99S15  
 PERFORMED RECALL 99S15  
 99S15 REPLACE SWITCH  
 90834 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15B  
 RD TEST, RUN ELEC TRAN DIAG, NO CODES, R/R TRAN PAN, REPLACED EPC SOLENOID AND BRACKET, R/R V-B & O-H, FLUSHED SYSTEM, RD TEST OK  
 REPLACED DEACTIVATION SWITCH AND HARD SHELL  
 CRUISE SWITCH RECALL REMOVED AND REPLACED CRUISE SWITCH RECALL PART.  
 PERFORMED RECALL AS PER INSTRUCTIONS  
 RECALL 99S15 COMPLETED  
 PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH AS PER 99S15  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 PERFORM RECALL 99S15  
 99S15E PERFORMED RECALL - SPEED CONTROL SWITCH  
 OPEN RECALL PERFORM RECALL  
 99S15 99S15  
 PERFORMED 99S15 RECALL, REPLACED DEACTIVATOR SWITCH & CONNECTOR  
 REPLACED SWITCH AN CONECTOR  
 91683 CC 42 99S15B 0.5- ADMIN D.1 REPLACED SWITCH AND CONNECTOR.  
 SPEED CONTROL DEACTIVATION SWITCH REPLACED SWITCH  
 PERFORMED RECALL PER FACTORY  
 1 PERFORM RECALL  
 REPLACE CRUISE CONTROL DEACTIVE SWITCH  
 REPLACE DEACTIVATION SWITCH  
 RECALL 99S15 INSTALLED SWITCH  
 PERFORM RECALL 99S15  
 99S15 99S15-REPLACE CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR ASSY  
 PERFORM SAFETY RECALL  
 116819 REPLACE SWITCH AND CONNECTER  
 49988 INSPECTED AND INSTALLED DEACTIVATION SWITCH AND PARTS PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 - MODIFY PER RECALL 99S15  
 99S15 99S15 REPLACE THE CONN AND SWITCH  
 99S15, REPLACED HARD SHELL CONN PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 99S15 SPEED CONTROL RECALL  
 REPLACE SW. PER RECALL  
 RECALL 99S15 INSTALLED DEACTIVATION SWITCH PER RECALL  
 RECALL 99S15 REPLACED CABLE  
 RECALL RECALL  
 42260 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15  
 REPLACE DEACTIVATION SWITCH  
 78520 RECALL WARR TECH 465 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL, RECHECKED OK  
 1 CAMPAIGN COMPLETED.  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL 99S15 RECALL 99S15 REPLACE SWITCH AND PLUG

PERFORMED RECALL 99S15  
1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
COMPLETED RECALL 99S15B 1  
PERFORMED RECALL  
RECALL 99S15 REPLACE DEACTIVATOR SWITCH PER RECALL  
PERFORMED THE RECALL 99S15

PERFORMED RECALL AS PER FORD SPECIFICATIONS  
RECALL 99S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH IN A/W RECALL 99S1 5.  
PERFORMED RECALL 99S15 SPEED CONTROL  
CABLE PERFORM RECALL 99S15  
APPLIED RECALL 99S15  
1 PER RECALL INSTALL CRUISE CANCEL SWITCH AND CONNECTOR RETEST OK  
PERFORMED RECALL  
SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15  
RECALL PERFORMED RECALL  
99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S  
PERFORMED RECALL 99S15

.9 RECALL  
71545 WARR REPLACE SWITCH AS PER RECALL 99S15

99S15 RECALL 99S15 REPAIR AS PER RECALL  
49914 REPLACE SPEED CONTROL SWITCH  
RECALL 99S15 REPLACE C-C SW  
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I  
99S15 INSTALL SWITCH AND CONN  
1 COMPLETED RECALL 99S15  
RECALL 99S15 COMPLETED RECALL 99S15 (SPEED CONTROL SWITCH) HAS BEEN COMPLETED  
RECALL 99S15 REPLACED PLUG AND SENSOR AS PER RECALL 99S15

DO THE RECALL  
REPLACE SPEED CONTROL SWITCH PER RECALL  
OPEN RECALL PERFORM RECALL  
RECALL 99S15 REPLACED CRUISE CONTROL SWITCH  
RECALL PERFORMED RECALL  
RECALL 99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.  
COMPLETED RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
99S15 REPLACE SPEED CONTROL DEACTIVATION AND HARD-SHELL CONNECTOR  
REPLACED SPEED CONTROL SWITCH.  
PERFORM RECALL 99S15  
1 PERFORM RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
99S15-CRUISE RECALL 99S15-CRUISE RECALL

PERFORMED RECALL 99S15 CRUISE SWITCH  
99S15B .5 ADMIN .1 INSTALL CRUISE SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
99S16, REPLACED CRUISE DE-ACTIVATION SW  
INSTALL SWITCH PER RECALL

PERFORMED RECALL

104085 PERFORM RECALL 99S 15  
REPLACED SC DEACTIVATION SWITCH 99S15

REPLACE CRUISE CONTROL SWITCH  
111358 PERFORM RECALL 99S15 INSTALL SWITCH-CONN KIT  
RECALL 99S15; PERFORM RECALL 99S15;REPL BRK-PRESS. SWITCH;  
REPLACE SPEED CONTROL SWITCH  
COMPLETED RECALL  
INSTALL SWITCH 99S15  
PERFORMED RECALL 99S15

PERFORM RECALL PER FORD SPECS  
REPLACE SWITCH AND CONNECTOR PER RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
RECALL 99S15 REPLACED SWITCH  
RECALL 99S15 99S15 INSTALL CRUISE DEACTIVATION SWITCH PER RECALL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN  
99S15 R&R SPEED CONTROL DEACTIVATION SWITCH  
49998 COMPLETED 99S15 CRUISE SWITCH  
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
COMPLETED RECALL 99S15  
1 COMPLETE RECALL 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
RECALL 99S15 REPLACED SWITCH AND CONNECTOR FOR CRUISE CONTROL  
112953 REPLACE SWITCH AND CONNECTOR AS PER RECA  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
99S15 99S15 99S15E .3 PERFORMED 99S15 REPLACED DEACTIVATION SWITCH  
RECALL 99S15 RECALL COMPLETE

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
69677 RECALL WARR TECH 465 PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL , REPLACED CONNECTOR PER RECALL RECHECKED  
99S15 RECALL 99S15 RECALL, REPLACED DEACTIVATION SWITCH AND CONNECTOR  
SUPPLEMENT #1 3-89 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
REPLACE DEACTIVATION SWITCH PER 99S15  
REPLACE SWITCH PER 99S15, BLEED BRAKE.

5902-925 11574

R&R BRAKE SWITCH & HARD SHELL BLEED SYSTEM PER RECALL  
 71887 INSTALLED CRUISE SWITCH  
 R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98-8-16  
 1 EWPLACE CRUISE CONTROL SWITCH 1  
 38870 REPLACE SWITCH AND CONNECTOR PER RECALL  
 COMPLETED RECALL AS PER LETTER  
 120243 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR  
 PERFORM RECALL  
 PERFORMED RECALL 98S15  
 RECALL 98S15 REPLACE SWITCH AND CONNECTOR  
 REPL SWITCH PER RECALL 98S15  
 COMPLETED RECALL 98S15  
 INSTALLED CRUISE DEACTIVATION SWITCH

REPL SWITCH PER RECALL 98S15

SERVICED AS PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 PERFORMED RECALL  
 98S15 98S15 SPEED CONTROL SWITCH RECALL  
 RECALL 98S15 REPLACE SPEED CONTROL SWITCH  
 PERFORM RECALL AS PER NOTICE  
 F RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 A DONE  
 PERFORMED RECALL 98S15  
 RECALL COMPLETE

REPLACED THE SWITCH PER RECALL 98S15  
 RECALL COMPLETE  
 DEACTIVATION SWITCH 98S15  
 RECALL COMPLETE  
 COMPLETED RECALL AS PER LETTER  
 PERFORMED RECALL REPAIR  
 PERFORMED RECALL 98S15  
 REPLACED CRUISE KIT  
 98S15 PERFORM RECALL 98S15  
 PERFORMED RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 98S15B TIME & PERFORM RECALL 98S15 AS PER INSTRUCTIONS  
 SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD  
 OPEN RECALL PERFORM RECALL  
 98S15 98S15 RECALL  
 COMPLETED RECALL 98S15  
 WE PERFORMED RECALL 4237  
 INSTALL SWITCH/BLEED AS PER RECALL 98S15

RECALL 99S15 - B - RECALL  
 1 INSTALL CRUISE CONTROL KIT, RECALL 99S15  
 REPLACED SWITCH CONNECTOR  
 RECALL COMPLETED  
 PD RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 PERFORM RECALL 99S15  
 1 REPLACED SWITCH

124802 99S15 PERFORMED RECALL AS PER INSTRUCTIONS REPLACED SWITCH  
 REPLACED SWITCH AND CONNECTOR  
 PERFORM RECALL

REPLACE SWITCH AND HARNESS PER RECALL  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 11883 RECALL 99S15 INSTALL NEW CONNECTOR AND SWITCH

PERFORMED RECALL  
 RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL 99S15  
 114175 REPLACE SWITCH PER RECALL  
 RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK  
 RECALL 99S15  
 51707 RECALL 99S15 DONE  
 REPLACE SPEED CONTROL CABLE  
 REPLACE SWITCH

PERFORM RECALL AS PER NOTICE  
 PERFORMED RECALL 99S15  
 1 INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL 99S15-INSTALL SWITCH  
 11883 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 PERFORMED 99S15 RECALL REPLACED SWITCH  
 REPLACED SWITCH ASSEMBLY PER RECALL  
 REPLACE SWITCH  
 RECALL SPEED CONTROL DEACC SWITCH REPLACE CRUISE SWITCH  
 COMPLETED RECALL 99S15-INSTALLED DEACTIVATION SWITCH  
 INSTALL SWITCH PER RECALL

RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH INSTALL SWITCH AND CONNECTOR  
 SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD :  
 ONP RECALL 99S15  
 RECALL 99S15 INSTALL CRUISE DEACTIVATION SWITCH PER 99S15  
 PERFORM RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99815 CRUISE CTNROL SWITCH  
COMPLETED RECALL PER INSTRUCTIONS

RECALL 99815 RECALL 99815 REPL SWITCH AND CONNECTOR  
99815B REPLACE CRUISE DEACTIVATION SW  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99815.  
RECALL 99815 RECALL 99815  
48829 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL  
REPLACED SWITCH AND CONNECTOR  
DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
RECALL 99815 99815  
99815 RECALL 99815 REPLACED SWITCH AND CONNECTOR  
RECALL RECALL  
RECALL RECALL  
113567 RECALL WARR REPLACE SPEED CONTROL DEACTIVATOR SWITCH AND CO NNECTOR PER RECALL  
COMPLETE RECALL 99815  
99815E PERFORMED RECALL AS PER RECALL  
COMPLETED RECALL  
REPLACED LEAKING THERMASTAT AND GASKET COOLING F  
80P HERE REPLACE BRAKE SWITCH AND CONN PER RECA  
PERFORMED RECALL  
RECALL 99815 COMPLETED  
99815 99815  
OPEN RECALL PERFORM RECALL  
REPL SWITCH PER RECALL 99815  
RECALL 99815  
INSTALL SWITCH  
RECALL 99815 PERFORMED RECALL 99815

1 REPLACED CRUISE CONTROL SWITCH PER RECALL  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
PER RECALL REPL DEACTIVATOR SWITCH  
PERFORM RECALL INSTALL SWITCH  
110988 AS PER RECALL  
1 REPLACED CRUISE SWITCH AND CONNECTOR  
87964 REPLACE SWITCH AND WIRES PER RECALL AND BLEED BRAKES  
INSTALLED NEW SWITCH PER RECALL  
COMPLETE RECALL 99815  
REPLACE SWITCH PER RECALL  
SPD CTRL DEACTIVATION SW REPLCMINTPERFORMED RECALL 99815  
PERFORM RECALL  
RECALL PERFORM RECALL # 0038  
PERFORM RECALL  
PERFORMED RECALL 99815, REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
PERFORMED RECALL 99815-INSTALL SWITCH  
REPLACE PARTS PER RECALL



REPLACE SWITCH PER RECALL  
PERFORM RECALL 98S15 RECHECK OK 1  
COMPLETED RECALL PER NOTIFICATION.

REMOVE AND INSTALL RECALL 98S15 CRUISE CONTROL TECH23858  
88802 REPLACED SPEED CONTROL SWITCH, 8-2 8274  
REPLACED DEACTIVATION SWITCH. PER RECALL.  
98S15 98S15 PERFORM RECALL  
INSTALLED NEW DEACTIVATION SWITCH AND CONNECER  
PERFORMED RECALL HAD TO REPLACE PROPORTIONING VALVE REPLACED DUE TO BEING FROZEN IN SWITCH A TIME TO REPLACE VALVE  
PERFORM RECALL INSTALL SWITCH  
RECALL 98S15 RECALL 98S15  
REPLACE DEACTIVATION SWITCH 1  
REPLACE THE SPEED CONTROL SWITCH PER RECALL 98S1  
108801 REPLACED SPEED CONTROL SWITCH AS PER RECALL  
PERFORMED RECALL  
REPLACE SWITCH PER RECALL  
RECALL RECALL 98S15 REPLACE SPEED DEACTIVATION KIT  
PERFORMED RECALL 98S15-INSTALL SWITCH  
76747 RECALL 5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B  
REPLACE DEACTIVATION SWITCH AND CONNECTOR  
12 REPLACE CRUISE SWITCH PER RECALL  
73860 REPLACE DEACTIVATION SW AND CONNECTOR OK OF ALL OK  
RECALL 98S15 REPLACE C-C SW

VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK  
PERFORM RECALL  
COMPLETED RECALL INSTALLED DEACTIVATION SWITCH.

REPL SWITCH PER RECALL 98S15  
REPLACED CRUISE SWITCH  
SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 98S15  
PERFORMED RECALL 98S15  
REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
REPLACED CONTACT SWITCH AND SWITCH CONVERTER.  
DEACTIVATION SWITCH 98S15  
98S15 PERFORM 98S15  
98S15 98S15

PERFORM RECALL 98S15  
98S15 RECALL 98S15 REPAIR AS PER RECALL  
PERFORM CAMPAIGN 98S15, SPEED CONTROL DEACTIVE SWITCH REPLACED SPEED CONTROL SWITCH  
1 REPLACE SWITCH  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL-  
102228 REPLACED SWITCH

## RECALL COMPLETE

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 41480 PERFORMED RECALL 98S15 3728  
 84784 PERFORMED SPEED CONTROL SWITCH RECALL  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 98S15 RECALL 98S15 RECALL 98S15  
 RECALL  
 98S15 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL  
 PERFORMED CRUISE CONTROL SWITCH RECALL 98S15 .3, .1 ADMIN  
 91842 PERFORM 98S15 RECALL  
 PERFORM RECALL  
 PERFORM RECALL 98S15  
 REPL CRUISE CONTROL SW AND WIRE CONNECTOR AND BLEED BRAKE FLUID. ROAD TEST OK PER RECALL  
 PERFORMED RECALL  
 REPLACE DEACTIVATION SWITCH PER RECALL 98S15  
 1 PERFORMED RECALL 98S15  
 98S15 RECALL 98S15 REPLACE CONNECTOR AND SWITCH AS PER RECALL  
 RECALL REPLACED DEACTIVATION SWITCH PER RECALL  
 PERFORMED CRUISE CONTROL RECALL  
 REPLACE DEACTIVATION SWT. PER RECALL  
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15  
 98S15 RECALL  
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
 PERFORM RECALL INSTALL SWITCH  
 REPLACED DEACTIVATION SWITCH - PER RECALL  
 1 98S15B .5 ADMIN .1  
 RECALL 98S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 82933 PERFORM 98S15 RECALL REPLACE DEACTIVATION SWITCH  
 DO RECALL 98S15 PUT IN NEW SW AND COND

## VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT

PERFORM RECALL  
 RECALL COMPLETED  
 REPLACE CRUISE CONTROL SWITCHES PER RECALL 98S15  
 REPLACED DEACTIVATION SWITCH  
 1 TECH PERFORMED CRUISE DEACTIVATION SWITCH RECALL 98S15  
 1 REPLACED SPEED CONTROL SWITCH  
 34720 98S15 RECALL COMPLETED  
 PERFORM RECALL

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X3  
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE SPEED C  
 RECALL PERFORMED 1  
 REPLACE DEACTIVATION SWITCH AS PER RECALL

PERFORM 99S15 RECALL

99S15 RECALL 99S15 RR BRAKE SWITCH AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
COMPLETED REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

67191 99S15

NA

99S15 INSTALLED SWITCH

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X3

SAFETY RECALL 99S15 PERFORMED SAFETY RECALL 99S15 REPLACED CRUISE CONTROL

REPAIR PER RECALL

PERFORMED BY AND CLOSED BY ANOTHER DEALERSHIP BUT STILL OPEN WHEN WE HAD VEH

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B 1.5 REMOVED TAPED AND SECURED S1

REPLACE SWITCH PER RECALL

RECALL

SPEED CONTROL DEACTIVATION SWITCH

68251 RECALL 0.5 REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR 99S15B

99S15

REPLACE DEACTIVATION SWITCH

PERFORM RECALL

INSTALL SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

107063 RECALL 99S15B 0.5L PERFORMED RECALL REPLACED SWITCH AND CONNE CTOR

INSTALLED SWITCH PER RECALL

1 REPLACED DEACTIVATION SWITCH AND CONECTOR AS PER RECALL 99S15B

COMPLETE RECALL THIS IS NOT A REPEAT REPAIR WITH 036903 BECAUSE THAT REPAIR WAS FOR INSPECTION ONLY

RECALL PERFORMED

X

99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED SWITCH CAMPAIGN

99S15B

PERFORMED RECAL

RECALL

99S15 COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

99S15

99S15 RECALL

COMPLETE RECALL

93502 REPLACE SWITCH AS PER RECALL

120867 RECALL 99S15 PERFORM RECALL 99S15 REPLACE SWITCH AND HARDSHELL CONNECTOR

99S15

REPLACE DEACTIVATION SWITCH

OWNER NOTIFICATION

CRUISE CONTROL RECALL 99S15

RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT

TECH REPLACE SWITCH AS REQUIRED

99S78 RECALL 99S15

PERFORMED RECALL, SPEED CONTROL DEACTIVATION SWITCH

UNKNOWN RECALL COMPLETE

1 COMPLETED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

INSTALLED DEACTIVATION SWITCH AS PER RECALL

PERFORM SPEED CONTROL RECALL 99 8 15

RECALL, REPLACED DEACTIVATION SWITCH AND HARDSHELL PER RECALL.

109857 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS RECALL 99S15

RECALL INSTALLED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

SERVICED AS PE RECALL E

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

CK BRAKE SYSTEM BRAKE SWITCH IS LEAKING AT THREADS REPLACE SWITCH AND BLEED SYSTEM

RECALL 99S15B RECALL 99S15B

1 INSTALLED RECALL SWITCH

RECALL PERFORM RECALL PER PROGRAM 99S15, DEACTIVATION SWITCH

RECALL 99S15 PERFORMED RECALL AS PER FORD

COMPLETED 99S15

RECALL DID RECALL

RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH REPLACEMENT

99S15 REPLACE SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL

INSPECTED CRUISE CONTROL OPERATION AND REPLACED REAR BRAKE RELEASE KIT AS PER RECALL AS NEEDED FOR REPAIRS

1 PERFORMED RECALL

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

COMPLETE RECALL 99S15

NAC 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

99S15B RECALL 99S15B RECALL

REPLACE SPEED DEACTIVATION SWITCH

PERFORMED RECALL AS BY FACTORY PERFORMED RECALL

PERFORM RECALL 99S15

PERFORM RECALL 99S15

RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL AS PER 99S15

RECALL 99S15 COMPLETED

71275 REPLACED SPEED CONTROL DEACTIVATION AS TO RECALL 99S15

1 RECALL COMPLETE

RECALL COMPLETED.

REPLACE CRUISE CONTROL SWITCH AND CONN,SHELL,BLEED REAR BRAKES

COMPLETED 99S15

COMPLETED RECALL

RECALL COMPLETED

81788 SPEED CONTROL DEACT SWITCH RECALL WARR COMPLETED

PERFORMED RECALL

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH

1 REPLACE SWITCH PER RECALL

INSTALL DEACTIVATION SWITCH PER RECALL 99S15 99S15B .50

8982-028 11061

99S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR. POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH INSPECTED VEHICLE - HAS ONLY VACUUM OPERATED SYSTEM

REPLACED CRUISE DEACTIVATION SWITCH

PERFORM RECALL 99S15.

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

AS PER RECALL. REPLACED SPEED CONTROL SWITCH

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

99S15 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

INSTALL SWITCH AND HARD SHELL

RECALL 99S15

PERFORM RECALL

CHECKED OASIS INSTALLED HARDSHELL CONNECTOR AND SWITCH

99S15 RECALL SPEED CONTROL DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR

INSTALLED SWITCH AND CONNECTOR

POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH. PERFORMED RECALL REPLACE CRUISE CABLE

RECALL 99S15

PERFORMED RECALL 99S15 B

71704 RECALL PERFORM 99S15

PERFORMED SPEED CONTROL RECALL

1 REPLACED PART PER RECALL

PERFORM RECALL

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE

117578 INSPECTED AND REPLACED THE SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.

RECALL COMPLETE

1 PERFORMED SAFETY RECALL 99S15.

PERFORMED THE RECALL 99S15

PERFORMED 99S15 RECALL

125784 99S15 INSTALL CRUISE SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL 99S15

RECALL 99S15 RENEW CRUISE DEACT SWITCH

1 99S15 RECALL. INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

PERFORMED RECALL PER SPECS

COMPLETED RECALL

SPEED CONTROL SWITCH 99S15 RECALL

UNKNOWN RECALL COMPLETE

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

PERFORMED RECALL 99S15 SPEED CONTROL SWITCH  
 125045 99S15 W REPLACED DEACTIVATION SWITCH  
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 REPLACE CRUISE DEACTIVATION SWITCH AS PER RECALL  
 PERFORM RECALL 99S15  
 REPLACE DEACTIVATION SWITCH  
 INSTALLED DEACTIVATION SWITCH  
 R&R CRUISE SWITCH PER RECALL  
 REPLACE SPEED CONTROL SWITCH PER RECALL  
 99S15  
 00 99S15  
 21166 PERFORMED RECALL  
 REPLACE SWITCH  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 REPLACED SWITCH AND CONNECTOR  
 PERFORM RECALL...CAMPAIGN...  
 RECALL 99S15 RECALL REPLACE SWITCH  
 COMPLETE RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 RECALL INSTALLED BRAKE REPAIR KIT AS PER RECALL  
 99S15 RECALL 99S15 REPAIR AS PER RECALL  
 RECALL 99S15-DEACTIVE SWITCH 99S15  
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 COMPLETED RECALL PER INSTRUCTIONS  
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH 1  
  
 1 PERFORMED RECALL  
 REPAIRED AS PER RECALL  
 RECALL REPLACED SWITCH REPLACED SWITCH PER RECALL  
 99S15 COMPLETED RECALLS-CAMPAIGN 99S15  
 RECALL REPLACE SWITCH AND WIRE PLUG  
 COMPLETED RECALL  
 99S15 REPLACED SWITCH AND CONNECTOR  
 PERFORMED RECALL PERFORMED RECALL  
 R CRUISE CONTROL RECALL 99S15  
  
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE  
 FACTORY RECALL COMPLETED RECALL  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 64726 PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15-INSTALL SWITCH  
 REPLACED BRAKE PRESSURE SWITCH & CONNECTOR PER RECALL 99S15  
 RECALL PERFORM RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

## COMPLETE RECALL

RECALL ~~PERMANENT REPAIR~~

RECALL RECALL

RECALL 99815 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

CHECKED OASIS. REPLACED BRAKE PRESSURE SWITCH

PERFORMED RECALL 99815-INSTALL SWITCH &amp; PLUG CONNECTOR.

COMPLETE RECALL 99815

. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99815

REPLACE SPEED CONTROL SWITCH

PERFORM RECALL 99815

REPLACED SPEED CONTROL SWITCH

1 -REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL--

PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL 99815-REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL AS PER INSTRUCTIONS

COMPLETED . REPLACED SWITCH

76544 REPLACED SPEED CONTROL SWITCH, 8-2 8274

COMPLETED RECALL 99815B

REPLACE SWITCH AND CONNECTOR

58417 INSTALL DEACTIVATION SWITCH PER RECALL

42779 PERFORM RECALL 99815 INSTALLED BRAKE REPAIR KIT JH

132885 PERFORMED RECALL.

## PERFORM RECALL

DEACTIVATION SWITCH 99815

REPLACE CRUISE CABLE

PERFORM RECALL

PERFORMED SPEED CTL DEACTIVATION SWITCH RECALL

1 PERFORMED RECALL.

C RC 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT &amp; REWIRE

OTHER RECOMMEND SERVICES: SERP BELT, ENGINE COOLING SYSTEM HOSES, COOLANT FLUSH, ENGINE FLUSH, POWER STEERING FLUSH, BATTERY SERVICE, CO

COMPLETE RECALL 99815

47767 REPLACED DEACTIVATION SWITCH.

48081 RECALL 99815 REPLACED SPEED CONTROL DEACTIVATION SW PER RECALL 99815. BLEED BRAKES AND TESTED OPERATION. OK

72088 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED RECALL REPLACED THE SWITCH AND CONNECTOR BLEED THE SYSTEM

RECALL PERFORMED RECALL

REMOVE TAPE AND SECURE LABOR OF 99815E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99815B .5 REMOVED TAPED AND SECURED 91

108- SPD CONTROL SWITCH RECALL - 99815 - REPLACE SPEED CONTROL ACTIVATION SWITCH PER RECALL

PERFORMED RECALL

REPLACE CRUISE CONTROL SWITCH

RECALL PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

75895 98S15B 0.5 ADMIN 0.1  
 98S15E REMOVE,TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED  
 RECALL REPAIR SPEED CONTROL  
 98S15 PERFORMED RECALL 98S15  
 REPLACED CONTROL DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
 REMOVED AND REPLACED SPEED CONTROL SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15 ~ MILES OUT 88621  
 REPLACED BRAKE SWITCH PER RECALL  
 PERFORMED RECALL  
 PER RECALL REPL HEADLIGHT DEACTIVATOR SWITCH  
 RECALL 98S15 REPL SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 98S15 REPLACE C-C 8W  
 PERFORMED RECALL  
 WARRANTY MILES OUT 90,110 PERFORMED RECALL 98S15 DEACTIVATION SWITCHH.  
 REPLACE SPEED CONTROL SWITCH PER RECALL 98S15  
 CHECK AND REPAIR AS REQUIRED  
 REPL SWITCH PER RECALL 98S15  
 PERFORMED RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR BLEED THE SYSTEM  
 REPLACED SPEED DEACTIVATION SWITCH RECALL 98S15  
 58348 WARR PERFORM RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SC DEACTIVATION SWITCH 98S15  
 134488 RECALL 98S15 DID 98S15  
 INSTALLED SWITCH AND HARDSHELL PER RECALL 98S15  
 138827 RECALL 98S15B REPLACE SWITCH AND CONICTOR TK372  
 98S15E REMOVE,TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED  
 REPLACED SWITCH AS PER RECALL 98S15  
 RECALL REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
 REPL SWITCH PER RECALL 98S15  
 REPLACE DEACTIVATION SWITCH  
 RECALL RECALL  
 REPLACE SPEED CONTROL ADEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 RECALL SPEED CONTROL DEACT SWITCH-PERFORM RECALL 98S15 TECH 131 PERFORM WORK  
 RECALL PERFORMED RECALL 98S15  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 92114 RECALL REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL 98S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED RECALL 98S15  
 PROGRAM CODE 98S15.  
 PERFORMED RECALL



COMPLETED RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15  
1 CAMPAIGN COMPLETED.

REPLACED SPEED CONTROL SWITCH AS PER RECALL  
RECALL COMPLETE  
101-CRUISE CONTROL SWITCH RECALL-99S15 - CHECK AND REPLACE CC BRAKE SWITCH

PERFORMED RECALL 99S16 SPEED CONTROL DEACTIVATION SWITCH.  
99S15 SPEED CONTROL DEACTIVATION REPLACED SWITCH AND CONNECTOR PER RECALL 99S15

REPLACE SWITCH  
109S16 RECALL 99S16B 0.5 0.5 REPLACE DEACTIVATION SWITCH AND CONNECTOR  
R&R SWITCH AND CONNECTOR  
INSTALLED SWITCH KIT  
RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.  
RECALL 99S15 REPLACE SPEED CTRL. DEACTIVATION SWITCH & HARDSHELL CONNECTO  
99S15B .5 HRS ADMIN .1 HRS R&R SWITCH AND CONNECTOR

RECALL 99S15 RECALL 99S15  
REPL BRK PRESSURE SWITCH  
91990 RECALL REPLACE DEACTIVATION SWITCH PER RECALL(WP) 23  
99S15 99S15 REPLACE SWITCH

RECALL 99S15 RECALL 99S15  
PERFORMED RECALL  
REPLACE DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
RECALL 99S15  
RPERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15-INSTALL SWITCH  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.

1 INSTALL SWITCH AND CONNECTOR  
COMPLETE RECALL 99S15  
PERFORMED RECALL PERFORMED RECAL  
RECALL 99S15  
RECALL 99S15 PERFORM RECALL 99S15  
RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
1 REPLACED SPEED CONTROL PER RECALL  
RECALL COMPLETED  
PERFORM 99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 RECALL INSTALL SWITCH  
 PERFORM RECALL.....

REPLACED CRUISE DEACTIVATION SWITCH  
 REPL SWITCH PER RECALL 99S15  
 REPL HARDSHELL CONNECTOR PER RECALL  
 PERFORMED RECALL 99S15-INSTALL SWITCH  
 RECALL PERFORMED RECALL  
 PERFORM RE-CALL  
 RECALL COMPLETED  
 PERFORMED RECALL 99S15  
 COMPLETED RECALL  
 REPLACE BRAKE SWITCH AND HARD SHELL CONNECTOR  
 99S15 99S15 RECALL  
 PERFORMED RECALL 99S15-INSTALL SWITCH  
 RECALL RECALL  
 1 CK REPLACED SWITCH BLEED BRAKES  
 OPEN RECALL COMPLETE 99S15  
 PERFORMED CRUISE CONTROL RECALL 99S15  
 RECALL PERFORMED RECALL  
 99S15 REPLACED SWITCH AND CONNECTOR  
 RECALL 99S15  
 100043 REPAIR AS PER RECALL 99S15  
 PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15  
 PERFORM RECALL 99S15 INSTALL SWITCH PER RECALL 99S15  
 PERFORM RECALL 99S15  
 PERFORM RECALL 99S15 REPLACE BRAKE PRESSURE SWITCH PER RECALL 99S15  
 INSTALLED UPDATE SPEED CONTROL DEACTIVATION SWITCH ....TR5  
 128045 MOD. 99S15 COMPLETE  
 99S15 RECALL  
 MAY CAUSE A SHORT CHECK OUT AND DISCONNECTED THE WIRE CONNECTOR AT THE SPEED CONTROL DEACTIVATION SWITCH AND TAPE UP END.  
 COMPLETED RECALL 99S15 SPEED CONTROL  
 REPAIR AS PER RECALL 99S15  
 COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 1 REPLACED CABLE AND SWITCH ASSEMBLY.  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL 99S15. INSTALL SPEED CONTROL DEACTIVATION SWITCH, RE-CHECK-OK  
 COMPLETED 99S15 RECALL 1

PERFORM RECALL  
 REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER CAMPAIGN 99S15  
 RECALL 99S15 99S15 COMPLETED RECALL  
 99S15 SPEED CONTROL SWITCH 99S15  
 RECALL 99S15

PERFORMED RECALL 99S15  
 REPLACE CRUISE DEACTIVATION SWITCH AS PER 99S16 RECALL  
 92173 PERFORMED 99S15, REPLACED SWITCH & CONNECTOR  
 RECALL 99S15 RECALL COMPLETE  
 PERFORM RECALL  
 R AND R CRUISE CRT CONNECTOR AND SWITCH

RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONT. PER RECALL RECK OK  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 PERFORM RECALL RENEW SWITCH AND CONNECTOR  
 REPLACE CC SWITCH AND CONNECTOR  
 DIAG AND PERFORMED RECALL 99S15 INSTALL NEW DEACTIVATION SWITCH OK NOW

RECALL 99S15  
 RECALL COMPLETED 99S15 SPEED CONTROL DEACT SWITCH  
 RECALL PERFORM RECALL 99S15  
 INSP AND RR CONNECTOR AND SWITCH

99S15 REPL SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECT  
 RECALL - 99S15B  
 OPEN RECALL PERFORMED RECALL  
 REPLACE CRUISE CONTROL SWITCH AS PER RECALL 99S1  
 REPLACE DEACTIVATION SWITCH PER RECALL  
 37735 PERFORMED RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR, CPN, 99S15, 99S15B, 0.5, ADMIN, 0.1, CC RECAL  
 COMPLETED RECALL AS REQUIRED  
 SPD CNTRL DEACTIVATION SWITCH BAD REPLACED SPEED CONTROL DEACTIVATION SWITCH-HARDSHELL CONNECTOR  
 RECALL PERFORMED  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 71586 WF PERFORM RECALL AS INSTRUCTED  
 REPLACE SPEED CONTROL SWITCH  
 99S15 RECALL SPEED CONTROL PERFORMED RECALL OF SPEED CONTROL  
 RECALL COMPLETED  
 REPL SWITCH PER RECALL  
 99S15 PERFORM RECALL  
 RENEW DEACTIVATION SWITCH  
 99S15 RECALL COMPLETED  
 99S15 SPEED CONTROL RECALL  
 PERFORMED RECALL 99S15

RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTION  
 REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99S15 RECALL  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CHANGED HARD SHELL CONNECTOR  
 RECALL 99S15  
 1 PERFORMED RECALL 99S15.

PERFORMED RECALL  
72088 98S15B 0.5 HRS. SPEED CONTROL RECALL  
PERFORM RECALL 98S15- REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 98S15 RECALL  
98S15 RECALL 98S15 RECALL PERFORMED  
REPLACED DEACTIVATION SWITCH  
PERFORM RECALL  
CC RECALL PERFORM RECALL 98S15 REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
COMPLETE RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
98S15 COMPLETED  
RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
INSTALL CRUISE CABLE PER RECALL 98S15  
PERFORMED RECALL 98S15  
REPLACED SWITCH PER RECALL  
88693 RECALL 98S15 REPLACED SPEED CONTROL SWITCH AS PER RECALL 98S15  
98S15 CC DE ACTIVATION SW RECAL 98S15 CC DE ACTIVATION SW RECALL

REPLACED SWITCH CONNECTOR PER RECALL 98S15  
DIAG AND PERFORMED RECALL 98S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW  
REPLACE CONNECTOR AND SWITCH AS PER RECALL

43553 98S15 INSTALL BRAKE SW AND CONNECTOR  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.  
COMPLETED RECALL 98S15  
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
98508 RECALL 98S15 XX OPERATION 98S15B REPLACE SWITCH AND ELECTRICAL CONNECTOR XX BLEAD BRAKE  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
88694 REPLACED SPEED CONTROL SWITCH 98S15  
PERFORM RECALL 98S15  
98S15 RECALL 98S15 RECALL COMPLETE  
RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS  
25587 DO RECALL 98S15  
PER RECALL REPLACE SWITCH CONNECTORS  
RECALL 98S15  
PERFORM RECALL  
PERFORM RECALL

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLAC  
98S15 MD 82988 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
78278 INSTALL DEACTIVATION SWITCH PER 98S15 7821 MILES AT 78278

70788 REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

PERFORMED RECALL  
 REPLACED CONNECTOR AND SWITCH PER RECALL  
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED C  
 REPLACED SWITCH PER RECALL  
 PERFORM RECALL 99S15  
 RECALL 99S15  
 COMPLETED AS PER RECALL  
 REPL CRUISE DEACTIVATION SWITCH  
 PERFORM RECALL 99S15  
 PERFORM SAFETY RECALL  
 COMPLETED RECALL 99S15  
 99S15 RECALL 99S15 RECALL COMPLETE  
 RECALL COMPLETED  
 REPLACED SWITCH  
 REPLACED CC SWITCH AND CONNECTOR ASSEMBLY  
 10748S RECALL 99S15 WARR. PERFORMED DEACTIVATION SWITCH RECALL 99S15.  
 COMPLETED RECALL ON SPEED CONTROL SWITCH  
 99S15 99S15 REPLACE S-C DEACTIVATION SWITCH AND CONNECTOR  
 REPLACE CRUISE SWITCH AND HARNESS CONNECTOR AS PER 99S15 RECALL  
 1 REPLACE BRAKE SWITCH AND CONN PER RECALL  
  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 RECALL RECALL  
  
 99S15 RECALL 99S15 RECALL  
 1 99S15B .5 ADMIN .1  
 RECALL INSPECT SPEED CONTROL CABLE  
 1 INSTALLED DEACTIVATION SWITCH  
 93908 CK FOR RECALL 99S15. REPLACED CRUISE CONTROL SWITCH FOR RECALL 99S15  
 PERFORMED RECALL  
 PERFORM SPEED CONTROL DEACTIVATION PER RECALL  
 REPL SWITCH PER RECALL 99S15  
 PERFORMED RECALL RECALL COMPLETED  
 RECALL 99S15 REPLACED DEACTIVATION SWITCH PER RECALL  
 DID 99S15 RECALL  
 PERFORM RECALL  
 INSTALLED PINS IN NEW CONNECTER AND REMOVED OLD SWITCH AND REPLACED WITH NEW BLEED SYSTEM OF AIR TEST DROVE GOOD  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 PERFORMED RECALL  
 99S15 99S15  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
 PERFORM RECALL 99S15  
 CAUSE=RECALL CORRECTION=PERFORM RECALL  
 80007 PERFORM RECALL 99S15  
  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL ACTIVATION SWITCH  
100038 99S15 PERFORM RECALL, REPLACE SWITCH AND CONNECTOR.  
REPLACED SWITCH

REPLACE SWITCH PER RECALL 99S15  
SUPPLEMENT #1 5-99 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORM RECALL 99S15 REPLACE SWITCH.  
RECALL 99S15 RECALL COMPLETE  
INSTALL SPEED CONTROL DEACTIVATION SWITCH PWER RECALL  
99S15 RECALL 99S15 RECALL COMPLETE  
RECALL 99S15 REPLACED DEACTIVATION SWITCH  
RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
RECALL PERFORMED  
99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
90448 COMPLETED RECALL 99S15. 245  
REPL SWITCH PER RECALL 99S15  
PERFORMED RECALL  
INSTALLED SWITCH PER RECALL  
63029 INSPECT AND REPLACE DEACTIVATOR SWITCH AND CON-NECTOR.  
REPLACE SWITCH  
14547 RECALL W INSTALL CONECTOR GA  
RECALL 99S15  
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

RECALL COMPLETED  
PERFORM RECALL  
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE  
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

RECALL COMPLETED  
RECALL COMPLETE, REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL.  
99S15 RECALL PERFORM RECALL  
PERFORMED RECALL 99S15  
INSTALL SWITCH&CONNECTOR RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TI  
99S15 REPLACED SPEED CONTROL SWITCH RECALL PERFORMED  
1 1 PERFORMED RECALL 99S15  
INSPECT AND REPAIR C C CONNECTOR AND SWITCH  
REPLACE CONNECTOR AND SWITCH  
70082 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
PERFORM RECALL 99S15 RECHECK OK 1  
RECALL 99S15B PERFORM RECALL 99S15B  
COMPLETE RECALL REPAIRS

RECALL 99S15

1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
RECALL REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
88888 INSTALL SWITCH PER RECALL  
REPLACED SWITCH  
88S15 SPEED CONTROL RECALL  
REPLACED SPPED CONTROL DEACTIVATION SWITCH..

88S15 88S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
1 PERFORM RECALL  
REPLACE KIT PER RECALL  
PERFORMED RECALL

RECALL PERFORMED RECALL 88S15  
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.  
RECALL REPLACE SWITCH PER RECALL  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 88S15 RECALL  
RECALL 88S15

88888 DID RECALL 88S15B 0.5 HRS  
PERFORM RECALL 88S15  
1 REMOVE AND REPLACE CRUISE CONTROL SWITCH PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
PERFORMED RECALL 88S15  
REPLACE SWITCH

88061 PERFORMED RECALL 88S15 AND RR SWITCH  
88S15 88S15  
REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH  
1 RECALL 88S15  
1 PERFORM RECALL

78201 88S15B 0.5 HRS. SPEED CONTROL RECALL  
REPLACED DE-ACTIVATION SWITCH PER 88S15 RECALL  
REPLACE SWITCH AND CONNECTOR  
88S78 INSTALL RECALL SWITCH AND CONNECTOR  
182402 28 88S52 REPLACED SWITCH PER RECALL 88S1  
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 88S15B  
COMPLETED RECALL  
SPEED CONTROL DEACTIVATION SWITCH 88S15 REPAIR PER RECALL  
RECALL COMPLETED

88320 PERFORMED SPEED CONTROL RECALL AND CONNECTOR Y  
REPLACED SWITCH & CONNECTOR PER RECALL  
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD  
REPLACE CRUISE CONTROL CONNECTOR AND SWITCH  
RMAID R SPD CRTL CONN AND SWITCH  
88S15 RECALL COMPLETE  
88808 RECALL DO RECALL 88S15

REPLACE SWITCH PER RECALL  
 PERFORMED RECALL 99S15  
 RECALL INSTALL SWITCH  
 160421 RECALL INSTALL SWITCH AND HARDSHELL CONNECTOR PER RECALL  
 PERFORMED RECALL 99S15  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR RECALL 99S15 BOX B

PERFORMED RECALL 99S15

70149 R-T CK CRUISE OPERATION/PERF SPEED CONTROL TEST P-P TO RECALL NOT DONE HARNESS DISCONNECTED INST RECALL R-T OK  
 76090 REPLACED BRAKE SWITCH AND CONNECTOR PER RECALL

INSTALL SWITCH PER RECALL PER SPECS  
 RECALL REPLACE SWITCH AND CONNECTOR PER RECALL  
 RECALL RECALL  
 1 PREFORM THE 99S15 RECALL AND REPLACED THE SWITCH  
 REPLACE CRUISE DEACTIVATION SWITCH  
 RECALL COMPLETE  
 REPLDACE DEACTIVATION SWITCH  
 RECALL RECALL  
 76800 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15  
 RECALL 99S15 99S15  
 PERFORMED RECALL PER FACTORY SPEC  
 RECALL 99S15 - B - RECALL  
 REPLACE DEACTIVATION SWITCH PER RECALL 99S15 2 OF 2 ROS  
 INSTALL SWITCH AND HARD SHELL RD TEST  
 REPAIR AS PER 99S15 RECALL  
 PERFORMED RECALL  
 INSTALLED SWITCH PER RECALL

PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 90896 RECALL REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 98018 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 DIAG AND PERFORMED RECALL 99S15 INSTALLED A DEACTIVATION SWITCH OK NOW  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15  
 INSPECT AND REPLACE SWITCH  
 PERFORMED RECALL  
 1 COMPLETED RECALL 99S15  
 REPLACE SWITCH AND HARD SHELL  
 PERF RECALL 99S15  
 REPLACED THE SPEED CONTROL DE-ACTIVATION SWITCH & HARD SHELL CONNECTOR  
 98169 RECALL COMPLETE



CHECK AND REPLACE CONNECTOR PER RECALL

F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

COMPLETE RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

87836 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH

TYPE 2 PROGRAM 99S15 PERFORM RECALL PER GUIDEL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER SAFETY RECALL 99S16.

PERFORMED RECALL 99S15

RECALL REPLACE SPEED CONT DEACT SWITCH PER RECALL

A99 99S15

PERFORMED RECALL 99S15

PERFORM RECALL 99S15

38124 DO RECALL 99S15

PER RECALL REPLACED SWITCH.

RECALL 99S15 DONE- REPL CRUISE SW

PERFORMED 99S15B

REPL SWITCH PER RECALL

PER QASIS PERFORMED RECALL 99S15 B

REPLACED DEACTIVATION SWITCH AS PER RECALL 99S15

PERFORM RECALL 99S15B

INSTALL SWITCH

RECALL PERFORM RECALL

99453 RECALL 99S15 W PERFORMED RECALL 99S15; REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTING HARNESS, TEST DRO

REMOVE AND REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH AND HARD SHELL

PER RECALL PERF RECALL

PERFORMED RECALL

97998 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP

1 REPLACED SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

117915 PERFORM SPEED CONTROL DEACTIVATION SWITCH AND CONNECTER REPLACEMENT RECALL

REPLACE SWITCH PER RECALL

48224 W REPLACE SWITCH GA

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL RECALL

RECALL 99S15 REPLACED SPEED CONTROL SWITCH

99S15 CRUISE DEACTIVATION SWITCH 99S15

1 TECH 247 COMPLETE RECALL

PER FORD PERFORMED RECALL 99S15.

REPLACE DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15

RECALL                      REPLACE DEACT SWITCH  
REPLACE SPEED CONTROL CUT OFF SW FOR RECALL 99S15 BLEED BRAKES ROAD TEST OK..

PERFORMED RECALL 99S15

INSTALL NEW HARD SHELL AND SWITCH AS PER RECALL  
118231 99S15 WARR REPLACED SWITCH AND CONN

99S15                      99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
70889 RECALL IN 2071 CHANGED SPEED CONTROL DEACTIVATION SWITCH AND CONN.

RECALL 99S15                      99S15

VERIFY CONCERN, INSTALL NEW SWITCH

RECALL                      99S15 RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL

REPLACED THE SWITCH PER RECALL 99S15

91181 REPLACE DEACTIVATION SWITCH WITH IMPROVED TYPE

PERFORMED RECALL

PERFORMED RECALL

99S15 RECALL                      99S15 COMPLETED RECALL

PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

REPLACE CRUISE DEACTIVATION SWITCH

99S15                      99S15

1 REPLACE SWITCH

TEST CRUISE, PINPOINT. REPL DEACTIVATION SWITCH, OPEN.

90214 R99S15 0.5HR RECALL COMPLETE

024 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL                      99S15 - B - RECALL

1 PERFORMED 99S15 RECALL.

DIAG AND PERFORMED RECALL 99S15 REPLACED DEACTIVATION SWITCH OK NOW

COMPLETED 99S15 RECALL

REPLACED BRAKE DEACTIVATION SWITCH PER RECALL

RECALLED BY FORD                      PERFORMED RECAL

SWITCH                      99S15

PERFORM RECALL

PERFORM RECALL 99S15

REPLACED DE-ACTIVATION SWITCH PER 99S15 RECALL

70830 99S15 REPL SWITCH

PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

COMPLETED RECALL

78210 COMPLETE  
 REPLACE AS PER RECALL 99815  
 PERFORMED 99815 RECALL  
 1 INSTALLED SWITCH  
 VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815  
 TESTED AND FOUND FUSE BLOWN TO BRAKE SWITCH, FOUND SPEED DEACTIVATION SWITCH BLOWING THE FUSE, PERFORMED RECALL 99815  
 REPLACE DE-ACTIVATION SWITCH  
 F RC 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 REPLACED SWITCH & HARD SHELL PER 99815  
 PERFORMED RECALL 99815

PERFORM SAFETY RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 INSTALL SPEED CONTROL SWITCH  
 REPLACE DEACTIVATION SWITCH  
 INSTALL CABLE PER RECALL 99815  
 REPLACED DEACTIVATION SWITCH  
 PERFORM RECALL 99815  
 RECALL 99815

PERFORM RECALL 99815- REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 99815 RECALL 99815 COMPLETED RECALL  
 RECALL  
 REPLACED BRAKE SWITCH AND CONNECTOR PER 99815.  
 RECALL 99815  
 PERFORMED RECALL 99815  
 INSTALLED SWITCH PER RECALL  
 99815 99815  
 PERFORMED RECALL  
 COMPLETED RECALL 99815  
 99815-RECALL 99815-RECALL  
 99815 PERFORM RECALL 99815  
 1 REPLACED CRUISE CONTROL SWITCH PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED RECALL 99815. ALSO SEE JOB 1.  
 INSPECT AND REPLACE SPEED DEACTIVATION SWITCH AND PLUG. BLEED BRAKES.  
 RECALL COMPLETED  
 RECALL PERFORMED  
 48598 99815B 0.5 HRS. SPEED CONTROL RECALL  
 INSTALL SENDER & CONNECTOR.  
 INSTALLED SWITCH AND HARD SHELL  
 RECALL PERFORM RECALL

EMR-825 11000

98815 98815

98815 98815-REPLACE CRUISE CONTROL DEACTIVATION SWITCH &amp; CONNECTOR ASSY

PERFORM RECALL 98815

98834 PERFORM RECALL

RECALL COMPLETED

REPLACE DEACTIVATION SWITCH

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98815.

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98815.

PERF RECALL 98815

PERFORMED RECALL

SPEED CONTROL SWITCH REPL. SPEED CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

REPLACED SC DEACTIVATION SWITCH 98815

REPLACED CRUISE CONTROL CABLE

43397 RECALL, WARR PERFORM 98815, REPLACED DEACTIVATION SWITCH AND HARDSHELL. TEST DROVE ALL OK.

RECALL 98815

ASDPADSPADSPADSPAD

RECALL 98815 RECALL

PERFORMED SPEED CONTROL RECALL

INSTALL SWITCH AND HARD SHELL

PERFORMED RECALL

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98815 BOX B

ASA PER RECALL AS PER RECALL

RECALL 98815

RECALL 98815

COMPLETED

98815 REPL. DEACTIVATION SWITCH

98815 98815

X 98815 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

98815 RECALL 98815 RECALL

PERFORMED RECALL

X REPLACE SPEED CONTROL DEACTIVATION SWITCH &amp; HARD SHELL CONNECTOR

85858 98815B 0.5 ADMIN 0.1

PERFORMED RECALL

98815 98815 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.

REPLACE SWITCH PER RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. ROAD TEST.

23505 RECALL 98815 RECALL 98815

INSTALLED SPEED CONTROL TIE DOWN PER RECALL RET ESTED OK. NO OTHER CONCERN AREAS EVIDENT AT THIS TIME-

RECALL REPAIR PER RECA

REPLACE DEACTIVATION SWITCH AS PER RECALL

RECALL 98815 PERFORM RECALL 98815

COMPLETE RECALL  
PERFORMED RECALL AS BY FACTORY PERFORMED RECALL  
80111 PERFORM RECALL 99S15

PERFORMED 99S15 RECALL  
REPLACED SPEED CONTROL CABLE AS PER RECALL

X REPLACED CLIP & SWITCH, RETEST, SYSTEM OK PER RECALL  
PERFORMED 99S15 RECALL, REPLACED REDUNDANT DEACTIVATOR SWITCH  
RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
99S15 REPLACED CONNECTOR AND SWITCH  
REPLACE DEACTIVATION SWITCH AS PER RECALL  
108161 99S15B 0.6 HRS. SPEED CONTROL RECALL  
RECALL 99S15 REPLACE C-C SW  
1 PERFORM RECALL  
107571 RECALL REPLACE DEACTIVATION SWITCH & CONN 94  
46057 99S15 99S15 0.6 REPLACE SWITCH & CONNECTOR  
46033 REPLACE SPEED DEACTIVATION SWITCH AND CONNECTOR AS PER 99S15B .5 + .1 ADMIN  
REPLACED SPEED CONTROL SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS  
RECALL RECALL  
PERFORMED RECALL 99S15  
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
RECALL 99S15 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
38768 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745  
43477 COMPLETED 99S15  
82088 RECALL REPLACED SPEED CONTROL SWITCH FOR RECALL 99S15  
REPLACE CRUISE CONTROL CUT OFF SWITCH AS PER RECALL  
REPL SWITCH PER RECALL 99S15  
PERF. RECALL  
PERFORMED RECALL  
42 99S15  
PERFORMED RECALL 99S15  
COMPLETE RECALL 99S15  
REPLACE SWITCH AND CONNECTOR  
99S15-RECALL 99S15-RECALL  
66348 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745  
RECALL PERFORM RECALL  
RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
PERFORM RECALL AS PER INSTRUCTIONS  
REPLACE SWITCH AND CONNECTOR PER RECALL  
REPLACE SWITCH PER RECALL  
PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE  
RECALL COMPLETE

## RECALL COMPLETED

SPEED CONTROL DEACTIVATION SWITCH. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL.  
 REPLACED SWITCH AND CONNECTOR  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15  
 1 PERFORM RECALL 98S15 BRAKE SWITCH  
 1 PERFORMED CRUISE CONTROL RECALL  
 PERFORM BRAKE SWITCH RECALL WARR  
 PERFORMED 98S15 RECALL

## REPLACED DEACTIVATION SWITCH AND HARD SHELL

1 PERFORMED RECALL 98S15 REPLACED SPEED CONTROL SWITCH AND CONNECTOR  
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO

## COMPLETE RECALL

RECALL 98S15 PERFORM RECALL 98S15  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 RECALLED BY FORD PERFORMED RECAL  
 REPLACE SWITCH AS PER 98S15

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 98S15B .6  
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 98S15B FOR .5 AND .1 FOR ADMIN. TIME  
 RECALL R-R DEAC SW, INSTALLED NEW CONNECTOR. WHILE UNDER HOOD I RECOMMEND THAT THE BATTERY BE SERVICED  
 REPAIR PER RECALL 1

REPLACED DE-ACTIVATION SWITCH  
 REPLACE CABLE PERFORM RECALL

## PERFORMED RECALL 98S15

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

## PERFORMED RECALL 98S15

## PERFORM RECALL 1

REPLACED CRUISE CONTROL SWITCH PER RECALL 98S15

RECALL 98S15 CRUISE CONTROL SWITCH

1 PERFORM RECALL 98S15

RECALL PERFORMED RECAL

## RECALL COMPLETE

RECALL RECALL

82138 RECALL INSTALL DEACTIVATION SWITCH

AS PER RECALL 98S15 RECALL TO INSTALL HARDSHELL SWITCH CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH

48815 RECALL 98S15 RECALL 98S15 R-R DEACTIVATION SWITCH

RECALL 98S15 RECALL

98S15 98S15

RECALL - PERFORMED RECALL # 8178

## REPAIR AS PER RECALL

80374 INSTALL NEW DEACTIVATION SWITCH

1 PERFORMED RECALL

RECALL INSTALL CRUISE CONTROL DEACTIVATION SWIT

RECALL COMPLETED ALL OK  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 REPLACE AND INSPECT CRUISE CTRL CONNECTOR  
 R AND R SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETED RECALL 99S15  
 COMPLETED RECALL

. PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN BULLETIN, REPL DEACTIVATION SWITCH,PER 99S15  
 REPLACED DEACTIVATOR SWITCH  
 . REPLACED SWITCH AS PER RECALL 1  
 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH

100420 PERFORM RECALL 99S15 INSTALL SWITCH  
 PERFORM RECALL PER INST

18109 RECALL WF PERFORMED RECALL AS INSTRUCTED

43122 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER 99S15 RECALL I ALSO REPLACED CONNECTOR  
 RECALL #99S15; PERFORM RECALL #99S15;REPL BRK-PRESS. SWITCH;  
 REPLACE SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARD-SHELL CONNECTOR AS PER RECALL 99S15. 99S15B 0  
 PERFORMED RECALL PERFORMED RECAL

PERFORM RECALL

MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEACTIVATION SWITCH

PERFORMED 99S15B

99S15 INSTALL NEW SWITCH ASY.-NOTE-MASTER CLY WAS VERY LOW ON FLUID,HOIST VEHICLE AND CHECK ALL BRAKES AND FOUND ALL FOUR TO BE AT 5% OR  
 COMPLETE RECALL

1 INSTALLED SPEED CONTROL SWITCH

51438 99S15 PERFORM RECALL,REPLACE SWITCH AND CONNECTOR.

71049 DONE

RECALL COMPLETE

RECALL 99S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO

44816 RECALL #99S15 PERFORM RECALL #99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND ITS CONNECTOR \*5 WP

118890 99S15 PERFORMED 99S15 PER INSTRUCTIONS

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

COMPLETED CAMPAIGN COMPLETED OP 99S15B

INSPECT FOR RECALL 99S15

RECALL RECALL

PERFORM SAFETY RECALL

PERFORMED RECALL 99S15 REPLACED SPEED SWITCH AND TERMINAL BLEED BRAKES

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

PERFORM RECALL 99S15

64014 RECALL WF PERFORMED RECALL AS PER INSTRUCTIONS

40123 REPLACE CRUISE DEACTIVATE SWITCH AND CONNECTOR PER RECALL

99S15-1827 REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL PERFORMED RECAL

PERFORM 99S15

INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN  
 77878 RECALL 99S15 5 W PERFORM RECALL 99S15  
 REPL BRAKE PRESSURE SWITCH  
 RECALL COMPLETED  
 COMPLETE RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15

114528 REPLACED SPEED CONTROL SWITCH 99S15  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 188587 RECALL 99S15 PERFORM RECALL 99S15  
 REPLACE CRUISE SWITCH  
 44550 99S15 RECALL W RR DEACTIVATION SWITCH PER 99S15 RECALL  
 SWITCH 99S15  
 REPLACED DEACTIVATION SWITCH PER RECALL  
 PERFORM SUBFRAME SAFETY RECALL AS INSTRUCTED

99S15 99S15  
 REPLACE SWITCH AND HARNESS PER RECALL  
 PERFORM SAFETY RECALL  
 23108 99S15 C 0.5 HRS.  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 PERFORM RECALL  
 PERFORM RECALL  
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 A DONE  
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15  
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15  
 1 1 COMPLETED RECALL  
 50080 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15 JH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15  
 55385 99S15 5L RR CRUISE DEACTIVATION SWITCH  
 PERFORMED RECALL 99S15 B  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 PERFORMED RECALL 99S15  
 88358 RECALL RECALL COMPLETED  
 COMPLETED RECALL  
 REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR 99S15B-80  
 PERFORM SPEED CONTROL SWITCH RECALL  
 REPLACE SWITCH PER RECALL  
 PERFORMED RECALL  
 99S15 99S15  
 REPLACED THE SPEED CONTROL SWITCH PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 RR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15



PERFORM RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 REPLACE BRAKE KIT PER RECALL  
 X REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 98S15 REPLACE C-C SW

RECALL COMPLETED

PERFORM RECALL

REPLACED THE SPEED CONTROL SWITCH PER RECALL  
 120435 RECALL 98S15 WVR RECALL 98S15 SPEED CONTR  
 16385 RECALL REPLACE DEACTIVATION SW AND CONNECTOR  
 REPLACE SWITCH

REPLACED DEACTIVATION SWITCH AS PER RECALL  
 REPLACE DEACTIVATION SWITCH FOR SPEED CONTROL 3  
 PREFORM 98S15 AS INSTRUCTED

REPLACE SWITCH AS DIRECTED BY RECALL  
 PERFORMED RECALL 98S15, CRUISE CONTROL  
 RECALL REPLACE SWITCH PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATOR SWITCH  
 1 REPLACED SWITCH AND CONNECTOR  
 REPLACE SWITCH PER RECALL  
 REPL SWITCH PER RECALL 98S15

PERFORM RECALL

105283 INSTALLED RECALL

PERFORMED RECALL

INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 98 S 15 FOR CRUISE CONTROL

X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL

DO RECALL 98S15

INSTALLED DEACTIVATION SWITCH AS PER RECALL 98S15

REPLACED SWITCH AND CONNECTOR COMPLETED RECAL

INSPECTED SPEED CONTROL OPERATION AND INSTALLED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAIRS

RECALL REPLACED CRUISE DEACTIVATION SWITCH PER RECALL

REPLACED THE SWITCH PER RECALL 98S15

INSTALL SPEED SWITCH PER RECALL 98S15

PERFORM SAFETY RECALL 98S15

98S15 REPLACE DEACTIVATION SWITCH

98S15 COMPLETE

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE

REPLACED SWITCH

COMPLETED 99S15 RECALL  
REPLACE DEACTIVATION SWITCH AS PER RECALL  
REPLACE SWITCH PER RECALL

REPLACE CRUISE CNTRL SWITCH AND CONNECTOR ASSEMB

99S15 RECALL  
PERFORMED RECALL 99S15  
RECALL 99S15 99S15 REPLACE SPEED CONTROL SENSOR AND CONNECTOR  
COMPLETE RECALL 99S15  
COMPLETED FACTORY RECALL  
29291 99S15 DONE \*28  
122478 RECALL 99S15 W PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
75498 RECALL W/ PERFORM RECALL  
99S15 PERFORM RECALL 99S15  
54240 SWITCH RECALL REPLACE SWITCH AND CONNECTOR, RECALL JH  
REPLACE DEACTIVATION SWITCH PER RECALL  
REPLACED DEACTIVATION SWITCH AND CONNECTOR  
RECALL COMPLETE  
78510 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONNECTOR TK372  
COMPLETED RECALL 0

RECALL 99S15 99S15  
DO RECALL 99S15  
PER RECALL PERF RECALL  
COMPLETE RECALL 99S15  
PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS  
RECALL 99S15 99S15  
REPL SWITCH PER RECALL 99S15  
53591 RECALL PERFORM RECALL 99S15. REPLACE SWITCH AND HARD SHELL CONNECTOR  
PER FORD INSTALLED SWITCH

PERFORM RECALL 99S15 PERFORM RECALL 99S15  
REPL SWITCH PER RECALL 99S15  
46064 RECALL INSTALL DEACTIVATION SWITCH  
125797 RECALL REPLACE SWITCH AND CONNECTOR AS PER RECALL  
09844 RECALL 99S15 PERFORMED RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
149139 RECALL REPLACE CRUISE SWITCH AND CONNECTOR  
PERFORM RECALL 99S15  
RECALL 99S15 99S15 INSTALL CABLE PER RECALL  
RPL SPEED CONTROL 99S15 RECALL  
45768 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 9115  
REPLACED SPEED CONTROL DEACTIVATION BRACKET.  
RECALL COMPLETE

COMPLETE RECALL

RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
 PERFORM RECALL 99S15  
 PERFORMED RECALL 99S15  
 99S15 RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 116920 RECALL REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 PERFORM SPEED CONTROL RECALL  
 204567 99S15C 0.5 HRS.  
 RECALL RECALL

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 RECALL 99S15 PERFORMED RECALL  
 INSTALLED DEACTIVATION SWITCH PER RECALL

CHECK AND INSTALLED PARTS PER RECALL  
 RECALL COMPLETED  
 PERFORMED OPEN RECALL 99S15B  
 37759 RECALL 99S15  
 PERFORM RECALL 99S15  
 PERFORM RECALL 99S15  
 RECALL 99S15 INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL  
 X 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 REPLACED DE-ACTIVATION SWITCH

PERFORM RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 99S15B TIME .5 PERFORM RECALL 99S15 AS PER INSTRUCTIONS  
 PERFORMED RECALL  
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH & PLUG PER RECALL

VERIFY CRUISE CONTROL SWITCH  
 INSTALL SWITCH AND PLUG AS PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 RECALL PERFORM RECALL  
 PERFORM RECALL PER FORD NOTICE  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 99S15 99S15  
 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
 23390 REPLACED CRUISE DEACT. SWITCH & CONNECTOR PER RECALL 99S15  
 PERFORM RECALL  
 PERFORM RECALL  
 PERFORM RECALL  
 PERFORM RECALL  
 1 1 REPL SWITCH AND CONNECTOR  
 PERFORM RECALL

RECALL 99S15  
PERFORMED RECALL 99S15  
1 PERFORMED RECALL  
84381 PERFORM RECALL 99S15  
SWITCH 99S15

99S15 RECALL ON 04S83 99S15 RECALL REPLACED SWITCH & CONNECTOR  
99-6-15 99-6-15  
REPLACE BRAKE KIT PER RECALL  
99S15 RECALL  
PERFORMED RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND INSTALL HARD SHELL CONNECTOR, CPN, 99S15, 99S15B, 0.5, ADMIN, 0.1, CC RECAL  
REPL DEACTIVATION SWITCH PER RECALL  
99S15 SWITCH-CONNECTOR 99S15  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
PERFORMED RECALL PERFORMED RECAL  
PERFORM AS PER NOTIF  
REPL SWITCH PER RECALL 99S15  
8766 SPEED CONTROL RECALL  
RECALL 99S15 RECALL REPLACE SWITCH  
99S15 INSTALL BRAKE SWITCH AND CONNECTOR PER RECALL  
84: PERFORM 99S15 RECALL  
REPLACED THE SWITCH PER RECALL 99S15  
8077 RECALL W REPLACE SWITCH AND PLUG GA  
PERFORM RECALL 99S15  
PERFORM SPEED CONTROL RECALL  
COMPLETE RECALL 99S15  
RECALL 99S15 99S15  
INSPECT AND PERFORM RECALL

RECALL INSTALL DEACTIVATION SWITCH AS DIRECTED  
SPEED CONTROL SWITCH 99S15 RECALL  
OPEN RECALL PERFORMED RECAL  
RECALL COMPLETED  
PERFORM SPEED CONTROL DEACTIVATION RECALL  
1 PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
INSPECTED AND REPLACED BRAKE REPAIRS KIT AS NEEDED FOR RECALL REPAIRS  
COMPLETE RECALL 99S15  
MANUFACTURE REQUIREMENT INSPECTED & INSTALLED DEACTIVATION SWITCH  
1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
PERFORM RECALL F  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

8982-825 11709

04143 RECALL W PERFORMED RECALL 99S15  
 DID RECALL 99S15 ON SPEED CONTROL  
 99S15 RECALL COMPLETE  
 PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION  
 REPLACED SWITCH AND HARD SHELL CONNECTOR. SPEED CONTROL IS INOP.  
 99S16S 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH A  
 1 INSTALLED 8 CRUISE SWITCH AND HARD SHELL  
 RECALL 99S15B  
 1 COMPLETED RECALL 99S15  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8  
 COMPLETED RECALL  
 PERFORMED 99S15  
 PERFORM RECALL  
 106000 INSTALL NEW SWITCH AND CONNECTOR PER RECALL  
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 RECALL - PERFORMED RECALL # 0636  
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 154788 PERFORM MODIFICATIONS PER 99S15  
 CAMPAIGN 89-8-15 COMPLETED AS PER RECALL INSTRUCTION.  
 REPLACE CRUISE CONTROL BRAKE SWITCH PER RECALL  
 PERFORMED 99S15 RECALL 99S15  
 COMPLETE RECALL  
 PERFORM RECALL 99S15B  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 PERFORM RECALL  
 RECALL 99S15  
 RECALL 99S15 DEACTIVATION SWITCH FOR SPEED CONTROL REPLACED  
 REPLACE BRAKE PRESSURE SWITCH PER RECALL  
 80884 RECALL (#17)-REPLACE SWITCH AND HARD SHELL AS PER RECALL, BLEED BRAKES.  
 76277 78 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST  
 REPLACE SPEED CONTROL SWITCH PER RECALL  
 PERFORM RECALL 99S15  
 PERFORM RECALL  
 INCORRECT CONNECTOR SHELL AND WIRE TERMINALS WERE INSTALLED AT A PREVIOUS REPAIR. SOLDER IN CORRECT TERMINAL ENDS.  
 1 PERFORM RECALL 99S15  
 99S15 99S15  
 104000 RTECALL 99S15 COMPLETE RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 RECALL RECALL REPL CAR  
  
 99S15 REPLACED DEACTIVATOR SWITCH  
 1 RECALL COMPLETE  
 SERVICE INSTALL KIT PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH, ETC.  
 100681 COMPLETE RECALL 99S15 AS PER RECALL

RECALL 99S15  
88004 W REPLACE SWITCH RAT.  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

PERFORMED TSB 99S15  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
RECALL REPLACED DEACTIVATION SWITCH  
PERFORMED 99S15  
REPLACE DEACTIVATION SWITCH AS PER RECALL  
PERFORM RECALL REPLACE SWITCH  
1 REPLACED SWITCH

77039 99S15 W REPLACED SPEED CONTROL DEACTIVATION SWITCH 2745  
9854 99S15 RECALL W PERFORM RECALL 99S15  
RECALL 99S15 SPEED CONTROL REPLACE SWITCH AND CONTOR PER RECALL RECK OK  
PERFORM RECALL 99S15 PERFORMED RECAL  
38036 RECALL W PERFORM RECALL TECH # 008

RECALL COMPLETE,REPLACED THE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
REPLACE SPEED CONTROL DEAVTIVATION SWITCH  
RECALL 99S15  
OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

OPEN RECALL PERFORM RECALL  
RECALL 99S15 PERFORMED, REPLACED SPEED CONTROL ACTIVATION SWITCH 1  
PERFORMED RECALL 99S15 WHEN REMOVING DEACTIVATIN SWITCH THREADS OUT OF PROPORTIONING VALVE REPLACED HOOKED UP ABS ADAPTER  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
PERFORMED RECALL 99S15 INSTALLED CRUISE SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

127741 DID RECALL AND BLEED BRAKES—6 HRS  
RECALL 99S15 REPLACED DEACTIVATION SWITCH.  
PERFORM RECALL  
OPEN RECALL PERFORM RECALL  
73140 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
73140 42 WP40 COMPLETE RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
PERFORM RECALL 99S15  
RECALL 99S15 PERFORMED 1

INSTALL RECALL KIT.

RECALL 99S16B NEC TO PERFORM RECALL 99S16B  
MAY CAUSE A SHORT INSTALL THE SPEED CONTROL DEATVATION SWITCH  
29884 99S15 WARN PERFORM RECALL, TEST DRIVE TO OK OPERATION OF SPEED CONTROL, OK.

REPLACED CRUISE CONTROL SWITCH  
34925 RECALL W REPLACE SWITCH GA  
71769 PERFORMED RECALL 99S15-SPEED CONTROL SWITCH  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH ASSEMBLY  
FACTORY RECALL COMPLETED RECALL  
REPLACE DEACTIVATION SWITCH PER RECALL  
RECALL PERFORMED RECALL 99S15  
RECALL 99S15 PERFORMED RECALL 99S15 - REPLACED CRUISE CONTROL CUT OUT SWITCH  
PERFORMED RECALL 99S15-REPLACED SPEED CONTROL DEACTIVATION SWITCH  
96707 99S15B .5 HR REPLACE DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
RECALL DID RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST.  
DEFECTIVE REPLACED DEACTIVATION SWITCH AS PER RECALL  
1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
COMPLETE RECALL ON SPEED CONTROL SWITCH  
96707 99S15B 0.5- ADMIN 0.1 RECALL  
1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B .5  
FACTORY RECALL COMPLETED RECALL  
INSTALLED SWITCH PER RECALL  
NGS TESTED TESTED FUEL INJECTOR FOUND NOT CONTRIBUTING REPLACED INJECTOR AND RETESTED  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE REPLACED DEACTIVATION SWITCH  
REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
REPLACE CRUISE DE-ACTIVATION SWITCH AS PER RECALL  
COMPLETED RECALL 99S15  
RECALL 99S16 RECALL COMPLETED  
1 RECALL COMPLETE  
PERFORM RECALL  
PERFORMED RECALL 99S16-INSTALL SWITCH  
99S16 99S15  
. COMPLETED RECALL  
PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15  
108428 PERFORMED OPEN RECALL 99S15  
REPLACED CRUISE SWITCH  
PERFORM RECALL  
99412 INSTALL NEW SWITCH  
197499 99S16 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR  
INSTALLED KIT 99S16 RECALL PERFORMED  
RECALL 99S15  
COMPLETED RECALL 99S15  
75174 RECALL 99S15 5 W PERFORM RECALL 99S15

6062-925 11769

PERFORMED RECALL  
 REPLACED SPEED DEACTIVATION SWITCH  
 99S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.  
 REPLACE SWITCH

99S15 99S15 RECALL COMPLETED

1 PERFORMED RECALL

PERFORMED RECALL 99S15

PERFORM 99S15 RECALL

99489 WARRANTY RECALL 99S15 REPLACE SWITCH AND WIRE PLUG

CHECK AND REPAIR AS REQUIRED

PERFORM SAFETY RECALL 99S15

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15

REPLACED SWITCH PER RECALL 99S15

PERFORMED RECALL F

99S15 99S15 RECALL, REPLACE CRUISE CONTROL DEACTIVATION SWITCH

DO RECALL 99S15

REPLACED BRAKE PRESSURE SWITCH AND CONNECTOR AS PER RECALL

78288 99S15B .5.5 RECALL

RECALL 99S15 PERFORM RECALL 99S15

99S15 99S15

PERFORMED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SWITCH

INSTALL SPEED CONTROL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACE SPEED CONTROL PER RECALL

99S15 REPLACE DEACTIVATION SWITCH

79 REMOVE AND REPLACE BRAKE SWITCH AND CONNECTOR PER RECALL

93280 99S15 INSPECT AND REPLACE SWITCH

RECALLED BY FORD MOTOR CO REPAIR AS NEEDED

99S15 99S15

PERFORM RECALL 99S15

RECALL PERFORM RECALL

84014 PERFORM 99S15

REMOVED AND REPLACED SPEED CONTROL CABLE

REPLACED CRUISE DEACT SWITCH

REPLACED SWITCH AND CONNECTOR

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

WHEN DOING RECALL THREADS CAME OUT ORDERED DISTRIBUTION BLOCK R & R DISTRIBUTION BLOCK BLEED BRAKES TEST DROVE PERFORMED RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.



COMPLETE RECALL 99S15  
 RECALL 99S15 RECALL PERFORME  
 REPLACE VALVE  
 119083 RECALL CRUISE DEACTERAVATION SWITCH I DID REPLACE CONNECTOR AND SWITCH  
 1 REPLACED SPEED CONTROL SWITCH & CONNECTOR  
 PERFORMED RECALL 99S15B  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 COMPLETED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15  
 RECALL 99S15 RECALL COMPLETED  
 143812 PERFORMED RECALL 99S15  
 58214 RECALL PERFORM RECALL  
 REPLACED BRAKE DEAC SWITCH PER RECALL  
 57890 99S15 W PERFORMED SERVICE 99S15

99S15 .3 SECURED SWITCH 99S15B .5 REPLACED SWITCH & CONNECTOR PERFORMED DEACTIVATION OF SWITCH  
 85703 RECALL 99S15B 0.5 HRS. NEC TO PERFORM RECALL 99S15.  
 REPLACED THE SWITCH PER RECALL 99S15  
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15  
 INSTALL BRACKET  
 1 REPLACED SWITCH AND CONNECTOR  
 98216 INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL 99S15.  
 RECALL 99S15 RECALL  
 REPLACE SWITCH PER RECALL  
 RECALL PERFORM RECALL PER PROGRAM 99S15, DEACT SWITCH  
 REPLACED SWITCH TEST DRIVE WORKS FINE PER RECALL  
 RECALL 99S15 RECALL  
 REPLACED DEACTIVATION SWITCH  
 71137 RECALL 99S15 PERFORMED LABOR OPERATION 99S15B-0.5 HRS.  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 INSTALLED NEW SWITCH  
 PERFORMED RECALL 99S15  
 REPLACED SPEED CONTROL BRAKE SWITCH  
 RECALL PERFORM RECALL AS PER BOOK  
 RECALL 99S15 PERFORM RECALL 99S15

RECALL PERFORMED SPEED CONTROL DE-ACTIVATION SWIT  
 OPEN RECALL PERFORM RECALL  
 INSTALLED CRUISE DEACTIVATION SWITCH  
 77894 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15  
 COMPLETED RECALL  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .5

RECALL REPLACE DEACTIVATION SWITCH PER RECALL  
 77741 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATI SWITCH

30087 99S10B D.5 HRS. SPEED CONTROL RECAL  
REPLACE SPEED CONTROL SWITCH  
59354 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY AND HARNESS & CONNECTOR JH

99S15 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
RECALL COMPLETE  
PERFORM RECALL PER MANUFACTURER PERFORMED RECAL  
REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15  
RECALL COMPLETED  
INSTALL SWITCH BRKT  
RECALL COMPLETED REPLACED SW  
29334 RECALL 99S15 REPLACE DEACTIVATOR SWITCH AS PER RECALL  
PERFORM RECALL 99S15  
COMPLETED RECALL  
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL  
PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
INSTALL RECALL SWITCH  
99S15 99S15  
PERFORM RECALL 99S15  
A DONE

REPLACE SPEED CONTROL SWITCH  
RECALL COMPLETE  
99S15 99S15  
RECALL RECALL  
RECALL 99S15  
99398 INSTALL RECALL 99S15 WARRANTY INSTALL SWITCH AND WIREPLUG  
REPLACED DEACTIVATION SWITCH  
PERFORM RECALL  
3 COMPLETED RECALL

REPLACED C CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
RECALL PERFORMED SPEED CONTROL DEACTIVATION SWIT  
RECALL 99S15  
REPLACED SPEED CONTROL CABLE  
82507 PERFORM RECALL REPLACE DEACTIVATION SWITC  
PERFORMED THE RECALL 99S15  
PERFORMED RECALL 99S15  
164578 RECALL 99S15, R&R DEACTIVATION SWITCH AND CONNECTOR, RETURNED PARTS  
RECALL 99S15 RECALL DONE  
80084 RECALL 99S15 WPC RECALL 99S15  
R&R CRUISE CONTROL DEACTIVATION SWITCH AND HARNESSCONNECTOR PER RECALL 99S15

RECALL 99S15 RECALL  
 72708 RECALL INSPECT AND REPLACE SPEED SWITCH ASSY  
 REPLACED DEACTIVATION SWITCH.  
 1 COMPLETED RECALL AS NEEDED 1  
 99S15B REPLACED DEACTIVATION SWITCH  
 REPLACED CRUISE DEACT SWITCH

PERFORM RECALL 99S15 SPEED CONTROL CABLE  
 COMPLETE RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 11278 INSPECT VEHICLE FOR DEACTIVATION SWITCH. REMOVE AND REPLACE SWITCH AND CONNECTOR. AS PER RECALL 99S15.  
 103998 REPLACE SWITCH PER 99S15  
 99S15-9911 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH  
 CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA  
 99S15 RECALL R-R CRUISE SHUT-OFF SWITCH AS PER RECALL AND BLEED BRAKES  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 82138 PERFORMED RECALL

138548 REPLACED SW. AND CONECTOR.  
 OPEN RECALL COMPLETE RECALL  
 99S15B REPLACED SPEED CONTROL - CANCELLATION SWITCH & CONNECTOR SHELL AS  
 COMPLETE RECALL  
 PERFORM RECALL 99S15  
 62820 REPLACED SPEED CONTROL SWITCH, S-2 8274  
 PERFORM RECALL 99S15 - -INSTALL SPEED CONTROL SWITCH  
 PERF. RECALL.  
 99S15B RECALL 99S15B RECALL  
 REPLACE SWITCH  
 G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 REPL SWITCH PER RECALL 99S15  
 99S15 99S15

REPLACE CRUISE SWITCH AS PER 99S15 RECALL. 1

PERFORMED RECALL 99S15  
 99S15 RECALL 99S15 8310 REPLACE SWITCH & PLUG G  
 2 99S15B .5 ADMIN .1 INSTALLED NEW SWITCH PER RECALL  
 REPLACE SPEED CONTROL CABLE AS PER RECALL 99S15  
 INSTALL SWITCH ANF PLUG CONN  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 RECALL RECALL  
 RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL  
 INSTALL BRAKE SWITCH AND CONNECTOR  
 PERFORM RECALL 99S15

30102 REPLACED SPEED CONTROL SWITCH, 8-2 2874  
 99S158 .5 HR. REPLACE CRUISE CONTROL DEACTIVATION SWITCH.  
 REPLACE SWITCH PER RECALL  
 99S15 99S15  
 99S15 99S15  
 124056 RECALL 99S15 WR PERFORMED RECALL 99S15

PERFORM RECALL

— RECALL COMPLETED  
 REPLACED SPEED CONTROL SWITCH

COMPLETED RECALL 99S15  
 REPLACED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 99S15 RECALL  
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 88035 PERFORM RECALL 99S15  
 58177 LABOR OF 99S158 .5 HR  
 132409 RECALL 99S15 99S158 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15.  
 COMPLETED RECALL.  
 PERFORM RECALL AS PER INSTRUCTIONS  
 81634 99S158 0.5 ADMIN 0.1  
 99S15 99S15  
 INSTALLED CRUISE CONTROL CANCEL SWITCH PER RECALL 99S15  
 99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

1 PREFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH  
 PERFORMED RECALL REPLACED THE SWITCH AND CONNECT OR  
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
 PERFORMED RECALL 99S15 INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH  
 REPLACE BRAKE SWITCH AS PER RECALL  
 REPLACED SWITCH & CONNECTOR PER RECALL  
 COMPLETED RECALL 99S15 REPLACEMENT OF SPEED CONTROL SWITCH-DID 99S158.  
 RECALL 99S15 28980 MILES RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH  
 111670 99S158 0.5 HRS. SPEED CONTROL RECALL  
 RECALLED BY FORD PERFORMED RECALL  
 06501 99S15 W REPLACED SPD CTRL DEACTIVATE SW. 2746  
 REPLACED SWITCH AND CONNECTOR  
 TECH 160 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND WIRING CONNECTOR AS PER RECALL 99S1  
 PERFORM RECALL 99S15  
 06670 99S15 W REPLACED SWITCH  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 INSTALL DEACTIVATION SWITCH  
 PERFORM RECALL 1  
 PERFORMED RECALL 99S15 PERFORMED RECALL 99S158  
 PERFORM RECALL

END-025 11713

PERFORM RECALL 98S15 A88  
 REPL CONNECTOR 98S15  
 RECALL IS REQUIRED COMPLETE RECALL  
 REPLACED CRUISE SWITCH PER RECALL 98S15  
 PERFORMED 98S15 RECALL  
 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR BLEED BRAKES.  
 RECALL REPLACE DEAC SWITCH PER RECALL  
 DIAG AND PERFORMED RECALL 98S15 INSTALLED NEW DEACTIVATION SWITCH OK NOW  
 REPLACE BRAKE SWITCH AS PER RECALL  
 1 INSTALL UPDATED CRUISE RECALL SWITCH  
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 PER NOTIFICATION RECALL 98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 98S15 RECALL INSTRUCTIONS  
 78576 RECALL .5 PERFORMED REPAIR PER RECALL  
 PERFORM RECALL PER FORD NOTICE  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15B QJ5, ADMIN Q.1  
 44533 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH  
 PERFORM RECALL 98S15 REPLACE SWITCH  
 98S15 COMPLETED  
 PERFORM RECALL 98S15  
 REPLACED DEACTIVATION SWITCH.  
 43316 .5 INSTALLED NEW DEACTIVATION SWITCH  
 105525 RECALL 98S15 WTR RECALL 98S15  
 REPLACED SWITCH AND CONNECTOR  
 REPLACE CRUISE CONTROL SWITCH AND CONNECTORS AS PER RECALL  
 REPLACE BRAKE LIGHT SWITCH  
 PERFORMED RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15  
 SPEED CONT REPL CABLE  
 RECALL 98S15 RECALL 98S15  
 - MODIFY PER RECALL 98S15  
 98S15 98S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
  
 77517 REPLACE SPEED CONTROL SWITCH AND CONECTOR RECAL 98S15B  
 94587 RECALL REPLACE DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL SWITCH AS PER RECALL 98S15  
  
 PERFORM RECALL.....  
 182- SPD CONTROL SWITCH RECALL - 98S15-INSPECT & REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH  
 32008 98S15 W PERFORMED SERVICE 98S15  
 REPLACED SWITCH AND CONNECTOR  
 REPLACE SPEED SWITCH AS PER RECALL  
 REMOVED AND REPLACED SWITCH AND CONNECTOR AS PER RECALL  
 INSPECT FOR RECALL INSTALL SPEED CNTL DEACTIVATION SWITCH RECALL COMPLETE  
 PERFORM RECALL  
 REPLACE SWITCH

88815 RPL SPEED CONTROL DEACTIVATION SWITCH  
REPLACED DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL 88815

184974 PERFORM RECALL

REPL SPEED CONTROL DEACTIVATION SWITCH AND CONN

RECALL PERFORMED RECALL

REPLACE SWITCH RECALL 88815

DOES NOT OPERATE PROPERLY INSTALLED DEACTIVATION AS PER RECALL

PERFORM RECALL

REPLACED SPEED CONTROL SWITCH AS PER RECALL

REPLACED DISENGAGE SWITCH PER RECALL 88815.

INSTALL CRUISE CONTROL DEACTIVATION SWITCH

RECALL 88815 REPLACE C-C SW

48263 88815 COMPLETED RECALL

REPLACE SWITCH

PERFORMED RECALL REPLACED CRUISE SWITCH

REPL SWITCH PER RECALL 88815

REPLACED SPEED CONTROL DEACTIVATION SWITCH CONNECTOR AS PER RECALL 88815

PERFORM RECALL 88815

ROAD R CRUISE CNTRL SWITCH AND CONN

R&R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL

PERFORMED RECALL PERFORMED RECALL

REPLACE SPEED CONTROL SWITCH

82839 RECALL 88815 88815B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 88815.

87084 RECALL INSTALL DEACTIVATION SWITCH

REPLACE SPEED CONTROL SWITCH PER RECALL 88815

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 88815

PERFORM RECALL

88815 RECALL 88815 RECALL COMPLETE

REPLACED SPEED CONTROL SWITCH

PERFORM RECALL 88815

112882 SPEED CONTROL DEACT, S-W REPLACED PER RECALL

88282 88815 W REPLACED SPD CTRL DEACTVATE SW 2745

REPLACE SWITCH

RECALL 88815 RECALL

RECALL 88815 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT

104880 RECALL CRUISE DEACTIVATION SWITCH I DID REPLACE SWITCH AND CONNECTOR TEST DROVE VEHICLE OK DRIVERS SEAT ON VEHICLE IS BROKEN AND

134011 RECALL INSTALL SWITCH AND PLUG PER RECALL

124888 J5 INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 88815 5862

PERFORMED 88815 RECALL

RECALL PERFORMED RECALL

AS PER FORD MOTOR COMPANY SPECIFICATIONS COMPLETED RECALL PER FORD INSTRUCTIONS

REPLACE SPEED CONTROL DEACTIVATION SWITCH.

PERFORMED RECALL

1 REPLACE SWITCH AS PER RECALL

PERFORM RECALL 99S15

PERFORM RECALL 99S15

1 PERFORMED RECALL

REPLACED BRAKE SWITCH PER RECALL, BLEED REAR BRAK

REPL SPEED CONTROL SWITCH

128316 PERFORM 99S15 RECALL DONE

1 PERFORM RECALL AS OUTLINE

12 REPLACED CONNECTOR AND DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH AS PER 99S15

REPLACED SWITCH

COMPLETED RECALL 99S15 PER PROGRAM

PERFORMED RECALL AS PER 99S15

REPLACE SWITCH AND HARNESS PER RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL 82073 REPLACE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

1 COMPLETED RECALL

APPLIED RECALL 99S15

PERF. RECALL

CUSTOMER REQUESTS PERFORM RECALL PERFORMED RECA

REPLACED SPEED CONTROL DEACTIVATION SWITCH

78121 RECALL AND STRIPPED SWITCH BLOCK REPLACED DEACTIVATION SWITCH AND HARDSHELL DURING SWITCH REPLACEMENT THREADS CAME OUT OF SWI

PERFORM RECALL-INSTALL SHIELDS

99S15 RECALL SPEED CONTROL DEACT SWITCH PERFORMED 99S15 RECALL

128089 RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S15 COMPLETED RECAL

RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO

REPL SPD CNTRL DEACTIVATION SW

PERFORMED RECALL

1 INSTALLED SWITCH

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.8 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .6 REMOVED TAPED AND SECURED S

TECH 31 PERFORMED RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED A SAFETY RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AND BRAKE SYSTEM

REPLACED SWITCH AS PER RECALL 99S15

99S15 RECALL REPLACED SWITCH AND WIRE PLUG PER RECALL 99S15

99S15 99S15 REPLACED DEACTIVATION SWITCH

REPLACED SC DEACTIVATION SWITCH 99S15

PERFORM RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH

53818 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL.

PERFORM RECALL

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE SPEED CR  
. INSTALLED SWITCH AS PER RECALL 1

70300 W REPLACE SWITCH GA

RECALL 99S15 PERFORM RECALL 99S15

RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE. ALSO A FIRE COULD DEVOPE. REPLACE SPEED CR

RECALL 99S15 REPLACED DEACTIVATION SWITCH AS PER RECALL

TECH 33 PERFORMED RECALL 99S15 REPLACE SPEED CO NTROL CABLE

REPLACE SPEED CONTROL SWITCH ##X##

REPLACED SC DEACTIVATION SWITCH 99S15

RECALL 99S15

94775 PERFORMED RECALL 99S15 REPLACMENT OF SPEED CONTROL DEACTIVATION SWITCH AND SWITCH HARD SHIELD PLUG.

99S15 99S15

99S15 RECALL 99S15 RECALL, REPLACE BRAKE SWITCH AND REWIRE CONNECTOR

134906 RECALL INSPECT AND REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

31776 PERFORMED RECALL 99S15

PERFORMED RECALL

99S15 REPLACED SWITCH AND CONNECTOR

PERFORM RECALL 99S15 COMMENT GEAR SHIFT HARD TO MOVE BEFORE REPAIRS

OPEN CONTROL ASSEMBLY-AIR CONDITIONER - REPLACE

1 PERFORMED 99S15 RECALL

PERFORM SPEED CONTROL SW RECALL 99S15

REPLAED CRUISE CONTROL SWITCH FOR RECALL

SUPPLEMENT #1 5-08 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORMED 99S15B

RECALL 99S15 COMPLETED RECAL

REPLACE PRESSURE SWITCH PER RECALL

INSTALLED CRUISE RECALL 99S15.

INSTALLED SWITCH AND CONNECTOR

REPLACED SPEED DEACTIVATION SWITCH

RECALL COMPLETED

REPLACE CRUISE CONTROL DEACTIVATION SWITCH

RECALL 99S15 INSTALLED SWITCH PER RECALL

1 INSTALL KIT

REPLACE SWITCH AND HARNESS PER RECALL

99S15 99S15

REP SPEED CONTROL CABLE AS PER RECALL

REPAIR AS PER RECALL

99S15 RECALL 99S15 RECALL COMPLETE

97890 99S15 RECALL REPLACE SW AND SHELL



1 REPLACED DEACTIVATION SWITCH PER VEHICLE RECALL

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S15

REPLACE SPEED CONTROL SWITCH AND PLUG

UNKNOWN

INSTALL SWITCH AND CONNECTOR PER 98S15

RECALL

RECALL

REPLACED DEACTIVATION SWITCH PER RECALL 98S15.

PERFORM RECALL 98S15

REPLACE SPEED CONTROL SWITCH

RECALL - - PERFORMED RECALL # 00376

REPLACE SPEED CONTROL DEACTIVATION SWITCH

DIAGNOSE AND REPLACED CRUISE CONTROL SWITCHES

RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS

REPLACE DEACTIVATOR SWITCH PER RECALL

98S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

INSTALLED KIT

98S15 RECALL PERFORMED

98S15

98S15 COMPLETED

PERFORM SPEED CONTROL DEACTIVATION RECALL

1 INSTALL KIT

RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL SWITCH AND PLUG AS PER RECALL

RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR

REPLACE CRUISE CONTROL SWITCH

98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL

X

PERFORMED RECAL

PERFORMED 98S15 RECALL

PERFORMED RECALL 98S15 CHECK AND REPLACED CRUISE CONTROL CABLE

PERFORMED RECALL 98S15 PER INSTRUCTIONS

RECALL DH R R DEACTIVATION SWITCH PER 98S15

R AND R SPEED CRL CONNECTOR AND SWITCH ASSEMBLY

PERFORMED RECALL INSTALLED SOP PARTS

1 - COMPLETED RECALL 98S15 SPEED CONTROL

48807 98S15 RECALL W RR DEACTIVATION SWITCH PER 98S15 RECALL

INSTALL NEW SWITCH

REPLACED SWITCH AND CONNECTOR PER RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15

RECALL 98S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

98S15

PERFORMED 98S15 RECALL

REMOVED AND REPLACED CRUISE CONTROL DEACTIVATOR SWITCH AND CONNECTOR AS PER RECALL

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 98S15 ALL OK TO RELEASE

RECALL

98S15

REPLACE SWITCH

RECALL

RECALL

2002-025 11718

188482 RECALL 98S15 PERFORM RECALL 98S15

REPLACE SWITCH PER 98S15

98S15 98S15

PERFORMED RECALL AS PER INSTRUCTIONS

98S15 CC DE ACTIVATION SW RECALL 98S15 CC DE ACTIVATION SW RECALL

90281 PERFORM RECALL

PERFORM RECALL

REMOVE TAPE AND SECURE LABOR OP 98S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 98S15B .5 REMOVED TAPED AND SECURED 81  
PERFORMED RECALL

85188 RECALL 98S15 RECALL 98S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL

PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION

X

98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORMED RECALL 98S15 REPLACED CONTROL SWITCH AND CONNECTOR.

FACTORY RECALL COMPLETED

82448 CC RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH ROAD TEST ALL OK RECALL 98S15

INSTALL CRUISE SWITCH PER RECALL

RECALL

98S15 RECALL

R AND R CONNECTOR AND SWITCH AS PER RECALL

REMOVE TAPE AND SECURE LABOR OP 98S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 98S15B .5 REMOVED TAPED AND SECURED 81  
RECALL

REPLACED SPEED CONTROL SWITCH AS PER RECALL.

TYPE 2 PROGRAM 98S15 PERFORM RECALL PER GUIDELI

RECALL DH REPLACE DEACTIVATION SWITCH AND CONNECTOR

90181 98S15 RECALL 98S15 REPLACE DEACTIVATOR SWITCH

PERFORM RECALL PER TECHNICAL INSTRUCTIONS IN RECALL BULLETIN REPL DEACTIVATION SWITCH, PER 98S15

X

98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPL CRUISE CONTROL SWITCH

RECALL RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES PER RECALL

RECALL 98S15 INSTALLED MODIFICATION FOR CRUISE CONTROL

REPAIRED AS PER RECALL 98S15

PERFORMED RECALL

RECALL 98S15 PERFORM RECALL 98S15

RECALL 98S15 - B - RECALL

77472 RECALL 98S15 PERFORMED RECALL 98S15 AS PER FORD

PERFORMED RECALL 98S15

PERFORM RECALL

AS PER RECALL 98S15 RECALL TO REPLACE HARD-SHELL CONNECTOR

INSTALLED MASTER CYLINDER SWTH

REPLACE SPEED CONTROL SWITCH

REPLACE BRAKE PRESSURE SWITCH PER RECALL

REPLACE SPEED CONTROL SWITCH

EP02-025 11718

88720 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL  
 NA 88S15 REPLACED SWITCH  
 COMPLETE RECALL  
 29411 PERFORM RECALL 98S15  
 PER RECALL 88S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 98S15B .5 ADMIN .1 PERFORM RECALL 98S15, INSTALL SWITCH AND CONNECTOR END  
 98S15 RECALL  
 PERFORM RECALL 98S15  
 93243 PERFORMED RECALL 98S15  
 98218 WARR PER RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH  
 UNKNOWN RECALL COMPLETE  
 REPLACE SPEED CONTROL CABLE AS PER RECALL 98S15B  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM  
 1 PERFORMED RECALL  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 REPLACE BRAKE SWITCH AS PER RECALL  
 REMOVE TAPE AND SECURE LABOR OF 98S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 98S15B .5 REMOVED TAPED AND SECURED SF  
 REPL DEACTIVATION SWITCH 98S15  
 98S15  
 RECALL 98S15 INSTALLED SWITCH PER RECALL  
 PERFORMED RECALL  
 COMPLETE RECALL  
 01 RECALL 98S15  
 101785 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
 PERFORMED RECALL  
 1 COMPLETED RECALL 98S15  
 R&R SPEED CONTROL SWITCH AS PER 98S15  
 PERFORM RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 TEST GEM REPL CTM PER OASIS  
 CRUISE CONT 98S15 INST SWITCH  
 REPLACED DEACTIVATION SWITCH  
 98S15E PERFORMED RECALL-INSTALLED NEW CRUISE CONTROL DEACTIVATION SWITCH  
  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 98S15 INSTALL SWITCH  
 RECALL 98S15 98S15 REPLACE SPEED CONTROL SWITCH  
 OPEN RECALL PERFORMED RECALL  
 INSTALL DEACTIVATION SWITCH 1  
 98S15 98S15  
 RECALL 98S15 REPLACED SWITCH  
 REPLACE SWITCH  
 PERFORM RECALL AND REPAIR RELATED DAMAGE. OPERATION CODES: 9816A & 14526A THESE ARE THE RELATED DAMAGE.  
 COMPLETED 98S15 RECALL 98S15B .5 ADMIN .1

88720-825 11728

INSTALL AS PER RECALL 99S15  
 RECALL 99S15 RENEW CRUISE DEACT SWITCH AND CONN  
 R AND R CRUISE SWITCH AND CONNECTOR ASSEMBLY  
 PERFORMED RECALL  
 86725 SAFETY RECALL INSPECTED AND REPLACED BRAKE SWITCH DEACTIVATOR AND CONNECTOR  
 PERFORMED RECALL  
 16055 COMPLETED RECALL 99S16  
 DO THE RECALL  
 INSTALL NEW SWITCH PER RECALL  
 87378 RECALL 99S15 RECALL 99S15  
 INSTALLED SPEED CONTROL CABLE AS PER RECALL  
 COMPLETED RECALL 99S15, SPEED CONTROL SWITCH  
 PERFORMED RECALL 99S15  
 77060 PERFORMED RECALL 99S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
 CHECK AND REPLACE SWITCH PER REC ALL  
 RECALL COMPLETED  
 40012 99S16B 0.5 ADMIN D.1  
 PERFORMED RECALL 99S15  
 REPLACE AS PER RECALL 99S15  
 INSPECTED CRUISE CONTROL SWITCH OPERATION AND REPLACED BRAKE REPAIR KIT AS NEEDED FOR RECALL REPAI  
 PERFORM RECALL 99S15 SPEED CONTROL

PERFORMED RECALL  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 REPLACE CRUISE CONTROL DEACT SWITCH  
 71904 99S15B-.5.5 REPLACE SPEED CONTROL SWITCH AS PER RECALL 99S16  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 51156 PERFORMED RECALL 99S15.  
 RECALL 99S15 INSTALL SWITCH  
 CK OUT FOUND DEACTIVATION SWITCH FAULTY REMOVE AND REPLACE SWITCH  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD !  
 1 REPLACED CRUISE DEACTIIVE SWITCH PERFORMED RECALL 99S15B  
 99S15 99S15  
 PERFORMED RECALL  
 RECALL 99S15  
 PERFORM RECALL  
 PERFORMED RECALL  
 54552 RECALL 99S15 B .5  
 RECALL COMPLETED  
 PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION

RECALL 99S15  
 PERFORM RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH

COMPLETE RECALL 99S15  
R&R CRUISE DEACTIVATOR  
REPL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15  
OPEN RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
COMPLETE REPLACED SPEED CONTROL BRAKE DEACTIVATOR SWITCH & CONNECTOR AS PER RECALL  
75201 MALFUNCTIONING DEACTIVATION SW R&R SW AND HARD SHELLE CONNECTOR  
RECALL 99S15 COMPLETED  
REPLACED SPEED CONTROL SWITCH PER RECALL  
PERFORMED RECALL 99S15  
PERF RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL COMPLETED

99-S-15 99-S-15 COMPLET  
RECALL COMPLETED  
RECALL 99S15 PERFORMED 1  
RECALL 99S15 RECALL  
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL  
99S15 REPLACED SWITCH AND CONNECTOR  
REPAIR PER 99S15 RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

99S45 99S16B 0.5 ADMIN 0.1

RECALL REPLACE SWITCH PER RECALL  
77097 INSTALL KIT RETURN OLD PARTS TO NATE  
REPLACED LIGHT SWITCH ASSEMBLY AND CONNECTOR AS PER RECALL  
INSTALLED DEACTIVATION SWITCH  
78201 RECALL 99S15 REPLACE SW AND ROAD TEST  
PERFORMED RECALL  
RECALL RECALL  
INSPECTED, REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORMED SPEED CONTROL RECALL  
COMPLETE RECALL 99S15  
1 PERFORMED RECALL AS TO REMOVE AND REPLACE THE DEACTIVATOR SWITCH FOR THE CRUISE CONTROL AN BRAKE SYSTEM  
99449 PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL  
RECALL COMPLETED  
PERFORM RECALL 99S15  
PERFORMED RECALL 99S15-INSPECTED AND REPLACED CRUISE DEACTIVATION SWITCH  
RECALL 99S15 PERFORMED RECALL 99S15  
1 INSTALLED SPEED CONTROL SWITCH

98S15 RECALL 98S15 COMPLETE  
PERFORMED 98S15 RECALL

RECALL 98S15 REPLACE C-C SW  
REPLACE SWITCH AND CONN PER PROGRAM  
RECALLED BY FORD PERFORMED RECALL 98S15  
98S15 REPLACE SWITCH  
PERFORM RECALL 98S15 CRUISE SWITCH REPLACEMENT.  
COMPLETED RECALL 98S15, SPEED CONTROL SWITCH

PERFORMED CRUISE CONTROL RECALL  
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
REPLACED SWITCH AND CONNECTOR PER RECALL 98S15  
RECALL SPEED DEACT SWITCH MODIFICATION  
INSTALL SPEED CONTROL DEACTIVATION SWITCH 1  
REPLACED SENDER & CONNECTOR PER RECALL 98S15  
98S15 PERFORM RECALL  
REPLACE SPEED CONTROL SWITCH PER RECALL 98S15  
RECALL 98S15 PERFORMED RECALL 98S15  
PERFORM RECALL 98S15

RECALL 98S15 AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
1 PERFORMED RECALL 98S15

RECALL 98S16 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH  
RECOMMENDED REPAIR REPLACE SWITCH AND CONNECTOR  
RECALL 98S16  
98S15 98S15  
RECALL 98S15 PERFORMED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL

REPLACE SWITCH AND HARD SHELL  
REPLACED SPEED CONTROL SWITCH AS PER RECALL  
COMPLETE RECALL

98S15 98S15 PERFORM RECALL  
ORECALL RECALL  
RECALL 98S15 PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH  
SPEED CTRL DEACTIVATION SWITCH 98S15 REPAIR PER RECALL  
REPLACED THE SPEED CONTROL SWITCH PER RECALL  
SWITCH 98S15 DEACTIVATION SWITCH

CHECKED AND VERIFIED CONCERN, RAN CIRCUIT TESTING, FOUND OPEN CIRCUIT AT SWITCH. REMOVED AND REPLACED SWITCH  
 COMPLETE. REPLACED CRUISE DEACTIVATOR SWITCH & CONNECTOR  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

DO RECALL 99S15

PERFORMED RECALL 99S15

RECALL

REMOVE AND REPLACE CRUISE DEACTIVATION SWITCH AND REPLACE CONNECTOR END PER RECALL 99S15.

COMPLETED RECALL

PERFORMED RECALL

RECALL 99S15, REPLACE DISINGAGEMENT SWITCH

88764 RECALL. REPLACE SWITCH AND CONNECTOR PER RECALL

89669 RECALL W/ REPLACE SWITCH GA

PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 INSTALLED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

1. REPLACE CRUISE CONTROL SWITCH.

RECALL RECALL

COMPLETED RECALL

OPEN RECALL PERFORMED RECALL

PERFORM RECALL 99S15

REPLACED DEACTIVATION SWITCH

DO 99S15B

REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

99S29 RECALL 99S15 INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL INSTRUCTIONS

. REMOVE TAPE AND SECURE DEACTIVATION SWITCH 99S15E.3

RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH

? PERF RECALL 99S15 CRUISE CONTROL SWITCH REPL.

RECALL 99S15 PERFORMED RECALL 99S15

RECALL COMPLETED

PERFORMED RECALL

RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL 99S15 REPLACED CRUISE CONTROL SWITCH

INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

COMPLETE RECALL

DO 99S15B

PER DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL 99S15

RECALL COMPLETED

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S16.

1. CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACE CONNECTOR AND SWITCH PER RECALL

94717 INSTALL REVISED PRESSURE SWITCH (SPEED CONTROL DEACTIVATION SW.) KIT.

REPLACED PER RECALL

99S15 RECALL

REFORMED RECALL 99S15  
 99S15 RECALL            REPLACE SWITCH AS PER RECALL  
 INSTALL CRUISE CONTROL SWITCH PER RECALL  
 PERFORM 99S15 RECALL REPLACE DEACTIVATION SWITCH  
 RECALL            RECALL  
 RECALL 85204 REPLACE SWITCH AND CONNECTOR  
 22839 W REPLACE SWITCH QA  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.  
 70189 W REPLACE SWITCH ME  
 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND WIRE CONNECTOR.  
 1 COMPLETED RECALL 99S15 SPEED CONTROL RECALL  
 INSTALLED DEACTIVATION SWITCH PER INSTRUCTIONS ON RECALL 99S15  
 046 DIAGNOSSED AND REPLACED CRUISE DEACTIVATION SWITCH  
 RECALL            99S15 INSTALLED SWITCH  
 INSTALL NEW SWITCH  
 REPLACED SPEED CONTROL CABLE PER RECALL 99S15  
 1 PERFORM RECALL  
 INSTALLED SWITCH PER RECALL  
 SPEED CONTROL PERFORMED RECALL 99S15 R AND R DEACTIVATION SWITCH AND CONNE AND BLEED ALL FOUR BRAKES  
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 RECALL            99S15  
 PERFORMED RECALL 99S15  
 FACTORY RECALL COMPLETED RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR COMPLETE RECALL 99S15  
 RECALL            99S15 - B - RECALL  
 RECALL 99S15 PERFORMED RECALL 99S15  
 PERFORMED SAFETY RECALL 99S15  
 REPLACE COMPLETED  
  
 1 ACCESS INSPECT & REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 99S15  
 PERFORMED RECALL  
 PERFORMED RECALL  
 1 PERFORMED RECALL  
 REPLACED DISENGAGE SWITCH PER RECALL 99S15.  
 E            RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 REPLACED SWITCH AS PER RECALL  
 DIAG AND PERFORMED RECALL 99S15 INSTALLED DEACTIVATION SWITCH OK NOW DISABLED ON RO 28729 THIS ON RO 28729 VOIDED BECAUSE OF DATE  
 REPLACE SWITCH AND HARDSHELL PER RECALL  
 99S15            99S15  
 RECALL -- PERFORMED RECALL # 0838  
 108728 RECALL WR RECALL 99S15  
 X            99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 RECALL 99S15 COMPLETED  
 PERFORMED RECALL  
 PERFORM RECALL 99S15B REPLACE THE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15            RECALL 99S15



RECALL 98S15 RECALL COMPLETED 98S15 RECALL COMPLETED  
 1 PERFORMED RECALL 98S15 - INSTALLED SWITCH  
 RECALL 98S15 INSTALLED SWITCH  
 TECH INSTALLED NEW CRUISE SWITCH PER FORD RECALL  
 TECH INSTALLED NEW CRUISE CONTROL SWITCH PER FORD RECALL  
 PERFORM RECALL

INSTALLED SWITC

UNKNOWN RECALL COMPLETE

PERFORMED SAFETY RECALL 98S15

96735 RECALL REPLACE DEACTIVATION SWITCH PER RECALL

REPLACE SWITCH AND CONNECTOR PER RECALL

102079 REPL SW.

PERFORMED RECALL

75988 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOAD TEST JH

127101 RECALL 98S15 WARR REPLACED DEACTIVATION SWITCH

60030 RECALL 98S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL

COMPLETED RECALL

RECALL 98S16

98S15 REPLACE SPEED CONTROL SWITCH

30380 RECALL W REPLACE SWITCH GA

PERFORM RECALL 98S15

REPLACE DEACTIVATION SWITCH 1

47280 REPLACE BRAKE SWITCH AND CONNECTOR

INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL

RECALL

DID RECALL

PERFORM RECALL 98S15- REPLACE CRUISE CONTROL SWITCH

PERFORMED RECALL

70660 98S15B 0.5 ADMIN 0.1

89888 RECALL W 98S15 REPLACED DEACTIVATION SWIT

COMPLETE INSTALLED SWITCH AS PER RECALL

INSTALL SWITCH AND HARD SHELL

21448 98S15 W REPLACED-CONTROL-DEACTIVATION-SWITCH-98S52

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15

1 ACCESS 8 REPL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL 98S15

88018 PERFORMED RECALL 98S15

REPLD CRUISE DEACTIVATION SWITCH 98S15

INSTALLED DEACTIVATION SWITCH AS PER RECALL

98S15 SPEED CONTROL DEACTIVATION 98S15 SPEED CONTROL DEACTIVATION

PERFORM RECALL

RECALL DID RECALL

REPLACE SWITCH AS PER 98S15

98S15B 98S15B

REPLACE SWITCH AS PER RECALL

75909 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
1 OK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG  
RPL SPEED CONTROL DEACTIVATION SWITCH AND CONNECT  
83000 RECALL RECALL 99S15  
99S15 99S15 PERFORMED RECALL  
PERFORMED RECALL

PERFORM RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
RECALL 99S15 COMPLETED  
OH INSTALL DEACTIVATION SWITCH PER RECALL 99S15  
REPAIRED AS PER RECALL  
INSTALL SWITCH PER INSTRUCTIONS ON RECALL 99S15

PERFORM RECALL  
OTHER 00S15 PERFORM RECALL  
REPLACE DEACTIVATION SWITCH-WARRANTY-RECALL-BILL  
110287 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
REPLACED THE SPEED CONTROL SWITCH PER RECALL  
PERFORM RECALL 99S15  
PERFORM RECALL 99S15 REPLACE SWITCH  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPL SWITCH PER RECALL  
PERFORMED RECALL 99S15  
RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH CONNECTOR  
99S15 R&R DEACTIVATION SWITCH  
99S15 99S15 RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I  
PERFORMED RECALL  
175000 RECALL #99S15 PERFORM RECALL #99S15 REPLACING CRUISE CONTROL DEACTIVATION SWITCH \*S WP  
1 DO 99S15 RECALL  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR  
PERFORMED RECALL

REPLACE CRUISE CONTROL DEACTIVATION SWITCH.  
RECALL 99S15 PERFORMED RECALL 99S15  
PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
REPLACE DEACTIVATION SWITCH PER RECALL 99S15  
80262 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
RECALL 99S15  
PERFORMED RECALL AS NEEDED ALL OK

106883 RECALL 99615 REPLACE CRUISE CONTROL SWITCH AND PLUG  
78882 INSTALLED NEW DEAC SW AND HARDSHELL CONN AS PER RECALL  
PERFORMED RECALL

RECALL RECALL  
INSTALLED NEW ACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL 99615  
94788 99615 COMPLETED DEACTIVATION SWITCH RECALL  
108258 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH  
REPL SWITCH  
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99615  
- MODIFY PER RECALL 99615  
PER NOTIFICATION 99615 INSTALLED BRAKE REPAIR KIT PER RECALL INSTRUCTIONS  
VERIFY VEHICLE FOR RECALL, INSTALL RECALL KIT  
REPLACED DEACTIVATION SWITCH

COMPLETED RECALL

OTHER 99615 PERFORM RECALL  
REMOVE & REPLACE CRUISE DEACTIVATION SWITCH  
REPLACED SWITCH AND CONNECTOR  
INSTALL DEACTIVATION SWITCH AND CONNECTOR  
120216 99615 WARR REPLACED SWITCH  
REPLACE CRUISE SWITCH AND CONNECTOR AS PER 99615 RECALL

COMPLETED RECALL  
REPLACED DEACTIVATION SWITCH  
RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
48819 RECALL W REPL CRUISE SWITCH PER RECALL 99615

99615 99615  
RECALL 99615  
PERFORM RECALL  
120777 INSTALLED DEACTIVATION SW AS PER RECALL 99615  
RECALL 99615 COMPLETED  
RECALL DONE  
RECALL 99615 REPLACED SWITCH  
RENEW SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL AS REQUESTED  
INSTALLED DEACTIVATION SWITCH AS PER RECALL

94548 COMPLETE RECALL 99615  
99665 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99615  
1. PERFORMED RECALL 99615 REPLACED DEACTIVATION SWITCH CRUISE CONTROL AND CONNECTOR

51320 PERFORM RECALL SPEED CONTROL SWITCH  
SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I

INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR AS PER RECALL INSTRUCTIONS

98S15 98S15

INSTALL SPEED CONTROL

REPL DEACTIVATION SWITCH

120830 RECALL REPLACED CRUISE SWITCH 98S15B—.5 HR.

98S15 98S15

105888 OPEN RECALL 98S15 REPLACE SWITCH DONE

RECALL 98S15 COMPLETED

RECALL 98X15

RECALL 98S15 INSTALL RECALL KIT

PERFORMED RECALL

REPLACE BRAKE PRESSURE SWITCH PER RECALL

REPLACED SWITCH AND BLED.

REPLACED DEACTIVATION SWITCH

PERFORMED RECALL 98S15

71847 RECALLED REPLACED SWITCH AND WIRE PER RECALL

RECALL PERFORM RECALL 98S15

PERFORM RECALL 98S15

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 98S15

RECALL 98S15 REPLACE DEACTIVATION SW

REPLACED BRAKE DEACTIVATION SWITCH PER RECALL

98S15 RECALL SPEED CONTROL DEACT SWITCH

RECALLED BY FORD PERFORMED RECAL

72388 98S15 W REPLACED SPEED CONTROL SW 2748

REPLACE SPEED CONTROL CABLE PER RECALL 98S15

REPLACED SPEED CONTROL SWITCH PER RECALL

REPLACED DEACTIVATION SWITCH

88830 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL

RECALL ADD ON

RECALL RECALL

RECALL PERFORM RECALL PER PROGRAM 98S15, DEAC SWITCH

1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5

98S30 RECALL WT DONE

PER FACTORY RECOMMENDATIONS INSPECTED AND FOUND VEHICLE HAS VACUUM OPERATED SPEED CONTROL SYSTEM

98S15 RECALL 98S15 RECALL COMPLETE

98S15 98S15

98S15 RECALL

RECALL 98S15 - COMPLET

1 COMPLETED RECALL 98S15

INSTALL NEW SWITCH AND WIRE CONNECTOR

PERFORM SAFETY RECALL

98S15B RECALL

98S15 RECALL 98S15 RECALL COMPLETE

PERFORMED RECALL 98S15  
 AS PER RECALL 98S15 RECALL TO SECURE DEACTIVATION SWITCH  
 PERFORMED RECALL 98S15-INSTALL SWITCH  
 FORD RECALL PERFORMED SPEED CONTROL DEACTIVATION SWITCH RECALL  
 E RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 BOX 8 REPLACED SPECIAL ORDERED X CABLE FOR RECALL AND BLEED SYSTEM LN 51 CUT CABLE  
 COMPLETED RECALL  
 RECALL 98S15 COMPLETED  
 REPLACED SWITC AND CONNECTOR PER RECALL  
 REPAIR AS PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 RNR ACTIVATION SWITCH PERFORM RECALL 98S15  
 RNR SWITCH PERFORM RECALL 98S15  
 RECALL 98S15  
 PERFORMED RECALL # 98S15  
 REPLACE SWITCH PER RECALL LETTER  
 REPLACED DEACTIVATION SWITCH  
 98S15 98S15  
 DID RECALL 98S15  
 REPLACED DEACTIVATION SWITCH  
 PERFORM RECALL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
 113444 RECALL INSTALLED RECALL ON BRAKE SWITCH  
 RECALL IS REQUIRED COMPLETE RECALL  
 COMPLETED RECALL  
 RECALL 98S15 INSTALLED SWITCH  
 PERFORMED RECALL E  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR (98S15B .5) COMPLETED  
  
 PERFORMED RECALL 98S15  
 RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
 55003 RECALL INSTALLED SPEED CONTROL RECALL  
 UNKNOWN INSTALL SWITCH AND CONNECTOR PER 98S15  
 REPLACE SWITCH AND CONNECTOR PER RECALL  
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 PERFORM RECALL REPLACE DEACTIVATION SWITCH  
 PERFORM RECALL  
 DID RECALL 98S15  
 REPLACED SPEED CONTROL SWITCH PER RECALL  
 REPLACED DISENGAGE SWITCH PER RECALL 98S15  
 RECALL INSTALL NEW CRUISE CONTROL DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15.  
 RECALL CRUISE CONTROL RECALL 98S15  
 98S15 98S15  
 SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S  
 PERFORMED RECALL 98S15 - REPLACED CRUISE CONTROL DEACTIVATION SWITCH

90S15                      90S15  
 INSTALL SW AND CONN  
 RNR DEACTIVATION SWITCH      PERFORM RECALL 90S15  
 RECALL COMPLETED  
 RNR DEACTIVATION SWITCH      PERFORM RECALL 90S15  
 REPL SWITCH PER RECALL 90S15  
 1 PERFORMED RECALL 1  
 REPLACED DEACTIVATION SWITCH  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 OPEN RECALL PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL  
 PERFORMED RECALL                      90S15  
 77282 W RNR SPEED DEACTIVATION SWITCH AND CONNECTOR  
 PERFORME 90S15  
 PERFORM RECALL.....  
 90S15 90S15 W REPLACE SPEED CTRL DEACTIVATE SW 2745  
 117478 INSTALLED NEW ACTIVATION SWITCH AND CONNECTOR  
 RECALL 90S15                      90S15  
 90018 PERFORM RECALL 90S15  
 90S15 RECALL                      90S15 RECALL,REPLACED DEACTIVATION SPEED CONTROL SWITCH AND CONNE  
 REPLACE SPEED CONTROL SWITCH  
 COMPLETED RECALL  
 90S15                      90S15 REPLACE CRUISE SWITCH PER RECALL  
 CHECK AND PERFORMED RECALL 90S15  
 RECALL                      90S15  
 RECALL 90S15                      RECALL 90S15  
 PERFORMED RECALL  
  
 INSTALLED CRUISE SWITCH AS TO RECALL  
 PERFORMED RECALL 90S15 INSTALL CRUISE DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH  
 PERFORM CRUISE SWITCH RECALL PER INSTRUCTIONS  
 PERFORM RECALL 90S15  
  
 REPLACE SWITCH & CONN  
 RECALL COMPLETED  
 REPLACE SWITCH PER RECALL  
  
 RECALL                      REPLACE DEACT SWITCH  
 90S15 RECALL                      90S15 RECALL  
 108 REPLACED SWITCH  
  
 DEACTIVATION SWITCH OUT OF RANGE  
 90S15 W 90S15 REPLACE SWITCH AND CONNECTOR PER RECALL GA

PERFORM RECALL 99S15 CRUISE DEACTIVATION SWITCH  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
99S15 REPLACED SAFETY SWITCH AND REPLACED WIRES  
OPEN RECALL PERFORM RECALL

47320 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

RECALL 99S15  
60780 99S15B 0.5 0.5 PERFORM 99S15  
PERFORMED RECALL  
SPEED CONTROL SWITCH 99S15 REPLACE SWITCH  
RECALL 99S15 RECALL 99S15  
PERFORMED RECALL REPLACED THE SWITCH AND CONNED TOR  
X PERFORMED RECAL  
37490 R099S15 PERFORM R099S15  
87000 RECALL INSTALL DEACTIVATE SWITCH AND HARDSHELL CONNECTOR RETURN ORIGINAL PART IN TO PARTS DEPT  
RECALL PERFORM RECALL PER PROGRAM 99S15, DEAC SWITCH

RECALL 99S15 RECALL  
CRUISE RECALL COMPLETED AS PER RECALL 99S15  
CRUISE SWITCH 99S15 INSTALL CRUISE SWITCH AND CONNECTOR  
PERFORMED RECALL 99S15-INSTALL SWITCH  
99S15 REPLACED SWITCH & CONNECTOR PER RECALL  
APPLIED RECALL 99S15  
PERFORMED RECALL 99S15  
INSTALLED DEACTIVATION SWITCH PER RECALL  
PERFORM RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15  
PERFORM SPEED CONTROL RECALL  
REPAIR AS PER RECALL  
1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 99S15B X5

78352 RECALL 99S15 PERFORM RECALL 99S15  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
UNKNOWN INSTALL SWITCH AND CONNECTOR PER 99S15  
PERFORMED RECALL REPLACE SENSOR AS PER RECALL 9 9S15  
PERFORMED RECALL 99S15  
RECALL RECALL  
111216 DEACTIVATION RECALL WT DONE  
COMPLETED CAMPAIGN COMPLETED OP 99S15B  
REPLACED DACTIVATION SWITCH PER SAFETY RECALL 99S15.  
REPL SWITCH PER RECALL 99S15  
ONP 99S15 ONP 99S15 SPEED CONTROL DEACTIVATION SWITCH  
REPLACED PARTS PER RECALL

X COMPLETED  
 99815 99815  
 99815 RECALL  
 REPL SWITCH PER RECALL 99815  
 RECALL PERFORMED 1  
 99815B REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 100448 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815B  
 REPL SWITCH PER RECALL 99815  
 1 RECALL COMPLETE  
 INSTALL NEW SPEED DEACTIVATION SWITCH REPLACE W WIRE AND BLEED BRAKES AS PER RECALL 99815  
 COMPLETED AS PER RECALL  
 RECALL COMPLETED  
 118108 RECALL 99815 W PERFORM RECALL 99815 REPLACE THE CONECTOR  
 RECALLED BY FORD MOTOR CO. REPAIR AS NEEDED  
 PERFORMED RECALL 99815 FOR CRUISE SWITCH  
 REPLACE SWITCH  
 118178 DO RECALL 99815  
 INSTALL SWITCH AND NEW HARD SHELL CONNECTOR AS OUTLINED IN RECALL  
 99815 RECALL  
 REPLACED SPEED CONTROL SWITCH  
 INSTALLED NEW SWITCH PER RECALL  
 RECALL 99815 COMPLETED  
 RECALL 99815  
 RECALL COMPLETED  
 NOTE: EST \$ 610 SEAT TRACK ASSY  
 SWITCH 99815  
  
 PERFORMED RECALL IN ACCORDANCE WITH NOTIFICATION  
 08500 REPLACE SWITCH AND CONNECTOR PER RECALL  
 RECALL 99815 99815  
 PERFORMED RECALL 99815  
 82552 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR. SWITCH WAS SEIZED IN LINE BLOCK.  
 1 PERFORMED RECALL 99815 INSTALL BRAKES SW. CONNECTOR 99815B  
 1 PERFORMED RECALL 99815  
 PERFORMED RECALL 99815  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99815  
 RECALL 99815 RECALL  
 03487 INSTALLED CONNECTOR AND SWITCH  
 99815 99815  
 REPL SWITCH PER RECALL 99815  
 RECALL 99815 PERFORM RECALL 99815  
 PERFORM 99815 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL  
 RPLC SPEED CTRL DEACTIVATION SWITCH PER 99815  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99815  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99815



RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 PERFORM RECALL 99S15  
 SPD CTRL DEACTIVATION SW REPLCMNT/PERFORMED RECALL 99S15  
 REPLACE SPEED CONTROL ACTIVATION SWITCH AS PER RECALL 99S15  
 PERFORMED RECALL  
 COMPLETED RECALL

64382 99S15 W REPLACED SPEED CONTROL 2745  
 INSTALLED SPEED DEACTIVATION SWITCH AS PER RECALL  
 PERFORM PER RECALL 99S15  
 PREFORM 99S15 AS INSTRUCTED  
 REPLACED DEACTIVATER SWITCH-WARRANTY-RECALL-BILL NOTE-CHECK ENGINE LIGHT IS ON  
 PERFORMED RECALL 99S15  
 REPLACE BRAKE SWITCH AND CONECTOR  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 PERFORM RECALL 99S15  
 REPLACE SWITCH PER RECALL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 INSTALL SPEED ACTIVATION SWITCH

RECALL 99S15 RECALL COMPLETE  
 REPLACE PRESSURE SWITCH AND CONNECTOR  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL  
 RECALL REPLACED THE DEACTIVATION SWITCH AND CONNECTOR, RETEST OK AT THIS TIME  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 PERFORM RECALL  
 REPL SWITCH PER RECALL 99S15  
 PERFORMED RECALL REPLACED THE SWITCH AND CONNEC OR  
 RECALL 99S15 PERFORMED RECALL 99S15  
 INSTALL SWITCH AND CONN  
 99S15 REPLAE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 1 REPLACED SWITCH AS PER 99S15 1  
 RECALL 99S15 INSTALL SWITCH  
 99S00 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLED NEW UPDATED SPEED CONTROL DISABLE SWITCH AND CONNECTOR TO VEHICLE TYPE  
 X INSTALLED CRUISE DEACTIVATION SWITCH

99S34 REPLACE SWITCH AND CONNECTOR PER RECALL  
 COMPLETE RECALL

REPLACED SPEED CONTROL SWITCH.  
 RECALL 99S15 REPLACED CRUISE CONTROL DEACTIVATION SW  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 99S15

AS PER RECALL 00S16 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL  
 RECALL 00S16 RECALL 00S15B  
 PERFORM RECALL 00S16

- MODIFY PER RECALL 00S16  
 1 PERFORM RECALL  
 PERFORM 00S16 RECALL AS INSTRUCTED  
 A DONE  
 PERFORM RECALL  
 PERFORM RECALL  
 A DONE  
 RECALLED BY FORD PERFORMED BY FO  
 57855 78 PERFORM 00S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH

COMPLETED RECALL  
 1 PERFORMED RECALL  
 RECALL 00S16 RECALL 00S16  
 COMPLETED AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 00S15  
 RECALL 00S15 COMPLETED  
 UNKNOWN INSTALL CRUISE DEACTIVATION SWITCH AND CONNECTOR PER 00S15  
 REPLACE CRUISE CONTROL SWITCH  
 00228 RECALL WARRANTY PERFORMED RECALL 00S15

APPLIED RECALL 00S16  
 PERFORM RECALL

REPAIR AS PER RECALL 00S15.

RECALL 00S15 REPLACED SWITCH  
 REPLACE BRAKE PRESSURE SWITCH PER RECALL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 00S15  
 RNR DEACTIVATION SWITCH PERFORM RECALL  
 TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 00S15  
 INSPECT & REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
 RECALL 00S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONN  
 PERFORMED RECALL 00S15 - CHECK AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 RNR DEACTIVATION SWITCH PERFORM RECALL 00S15  
 REPLACED DEACTIVATION SWITCH

REPLACED CONTROL DEACTIVATION SWITCH  
 RECALL 00S15  
 REPLACED DISENGAGE SWITCH PER RECALL 00S15  
 00S16 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 SAFETY RECALL 00S15 - REPAIR PER RECALL

RECALL 99S15      PERFORM RECALL 99S15

99S15 RECALL  
99S15      SPEED CONTROL DEACTIVATION SWITCH  
REPLACE CRUISE CONTROL SWITCH  
COMPLETED RECALL RECALL 99S15

56838 REPLACED DEACTIVATION SWITCH,CONNECTOR PER RECALL  
REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
PERFORMED RECALL 99S15, INSTALLED NEW SPEED CONTROL DEAC. SWITCH AND CONECTOR.  
COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
REPLACED SPEED CONTROL CABLE AS PER RECALL  
96461 RECAL REPLACE BRAKE SWITCH AND HARDSHELL CONNECTOR 5383,2843

109824 99S15 RECALL 99S15 REPLACE DEACTVATOR SWITCH  
101474 INSTALLED RECALL 99S15, BRAKE PRESSURE SWITCH  
PREFORM 99S15 AS INSTRUCTED  
ONP 99S15      ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHEL  
82581 COMPLETED RECALL NUM 99S15  
PERFORM RECALL  
97859 RECALLED REPLACED SWITCH AND WIRE CONNECTOR PER RECALL  
PERFORM RECALL 99S15  
REPAIR PER RECALL  
RECALL      99S15 REPLACED SWITCH.

REPLACED THE SWITCH PER RECALL 99S15  
PERFORME 99S15  
REPLACED SWITCH AS PER RECALL 99S15

REPLACE DEACTIVATION SWITCH RECALL 99S15.  
00778 REPLACE SWITCH AND CONNECTOR PER RECALL  
99S15 RECALL      99S15 REPAIR AS PER RECALL  
RECALL 99S15      99S15

RECALL COMPLETED  
REPAIR AS PER 99S15

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE,TAPE AND  
TECH INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS INSTRUCTED IN RECALL 99S15

PERFORME 99S15  
RNR CRUISE SWITCH      PERFORM RECALL 99S15  
RECALLED BY FORD      PERFORMED RECAL  
99S15B      PERFORMED RECAL  
UNKNOWN      INSTALL CRUISE SWITCH AND CONNECTOR PER 99S15  
99S15B      REPLACED  
99S15,RR CONNECTOR AND DEACTIVATION SWITCH

REPLACED SWITCH  
 CUSTOMER PAID REPAIRS 1  
 PERFORM RECALL PER MANUFACTURER PERFORMED RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH  
 RECALL 99S15 COMPLETED  
 REPL DEACTIVATION SWITCH PER RECALL  
 99S15 R&R DEACTIVATION SWITCH  
 PERFORMED RECALL 99S15  
 INSTALLED NEW SWITCH PER RECALL  
 58214 RECALL INSTAL SWITCH AND CONNECTOR AS PER RECALL 99S15  
 REPLACE SPEED CTRL DECT SWITCH AND SHELL CONNECTOR  
 RECALL 99S15  
 PERFORMED RECALL # 99S15  
 RECALL 99S15  
 PERFORM RECALL 99S15

1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS PERFORM RECALL 99S15-B  
 DH REPLACE SWITCH AND CONNECTOR PER RECALL  
 RECALL 99S15  
 COMPLETED AS PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL SWITCH BLEED BRAKES  
 RECALL COMPLETED COMPLETED RECALL 99S15B FOR .5 AND .1 FOR ADMIN. TIME  
 REPLACE CRUISE CONTROL CABLE  
 REPLACED KIT PER RECALL T  
 99S15 RECALL PERFORMED

REPLACE SWITCH AND CONNECTOR PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 76109 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH  
 1 PERFORM RECALL  
 1 PERFORM RECALL 99S16 BRAKE SWITCH

99S15 99S15  
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL 99S15  
 RECALL 99S15 99S15  
 REPLACE SPEED CONTROL SWITCH  
 COMPLETED AS PER RECALL  
 COMPLETED RECALL 99S15 DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH  
 RNR DEACTIVATION SWITCH PERFORM RECALL  
 1 COMPLETED RECALL 99S15 SPEED CONTROL  
 REPL SWITCH PER RECALL 99S15  
 REMOVE TAPE AND SECURE LABOR OF 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15B .5 REMOVED TAPED AND SECURED 81

RECALL                      REPLACE DEAC SWITCH PER RECALL  
57592 RECALL INSTALLED NEW BRAKE SWITCH AND CONNECTOR TEST DROVE, CRUISE WORKS OK  
REPLACE SPEED CONTROL CABLE AS PER RECALL  
RECALL 99815. REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99815.

COMPLETED RECALL  
REPLACED DEACTIVATION SWITCH

REPLACED SPEED CONTROL SWITCH AS PER RECALL  
PERFORM RECALL  
RECALL 99815 - SPEED CONTROL DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

23712 REPLACE SPEED CONTROL DEACTIVATION SWITCH TEST DRIVE OK  
99815 RECALL                      99815 RECALL PERFORMED  
RECALL                      INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
INSTALLED SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99815  
RECALL 99815 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL  
RECALL 99815  
1 REPLACE SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATION.  
REPLACE SWITCH AND CONNECTOR  
PERFORM 99815  
PERFORMED RECALL 99815  
99815                      99815 PERFORM RECALL  
RECALL                      REPLACE DEACT SWITCH PER RECALL  
99834 99815 COMPLETED DEACTIVATION SWITCH RECAL  
PERFORM 99815

REPLACE CONNECTOR AND SWITCH  
RNR DEACTIVATION SWITCH                      PERFORM RECALL 99815

REPAIR AS PER RECALL  
COMPLETED RECALL  
RECALL                      RECALL  
78573 RECALL REPLACED SPEED CONTROL DE-ACTIVATION SWITCH AND TEST DROVE WORKS NORMAL  
REPLACE SWITCH AND CONNECTOR  
REPLACE BRAKE PRESSURE SWITCH PER RECALL.  
82373 RECALL INSPECT AND PERFORM RECALL  
RECALL                      REPLACE DEACT SWITCH PER RECALL  
RECALL 99815                      COMPLETED

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLAC  
99815 RECALL                      SPEED CONTROL SWITCH  
99815  
1 PERFORMED SWITCH AND CONNECTOR RECALL  
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99815.  
REPAIR AS PER RECALL 99815.

PERFORMED RECALL 98S15  
 REPAIR AS PER RECALL  
 INSTALL SWITCH AND CONNECTOR  
 53769 RECALL 98S15 W/REPLACED DEACTIVATION SWIT  
 RECALL 98S15 REPLACED CRUISE DEACTIVATION SWITCH  
 RECALL 98S15 RECALL 98S15  
 REPLACED SPEED CONTROL CABLE PER RECALL  
 PERFORM RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
 PERFORMED RECALL 98S15 BRAKE RELEASE  
 55854 RECALL WPB30 PERFORM 98S15 CRUISE SWITCH REPLACEMENT  
 REPLACED SWITCH PER RECALL  
 PERFORM RECALL 98S15  
 98S15B RECALL REPLACED DEACTIVAT.98S15B RECALL REPLACED DEACTIVATION SWITCH  
 REPLACE SWITCH AND CONNECTOR PER RECALL 98S15 1  
 PERFORM RECALL 98 S 15 . INSTALL CRUISE DEACTIVATION SWITCH  
 VEHICLE HAS AN OPEN RECALL PERFORM RECALL

SPEED CONTROL DEACTIVATOR TECH REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 REPLACED BRAKE DEACTIVATION SWITCH  
 98S15 REPLACED SWITCH  
 INSTALLED SWITCH PER RECALL  
 REPLACED SWITCH PER RECAL  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 REPLACED C CONTROL DEACTIVATION SWITCH PER 98S15 RECALL  
 PERFORMED RECALL  
 PERFORM RECALL INSTALL SPEED CONTROL DEACTIVAT ION SWITCH  
 INSTALL SWITCH AND CONNECTOR PER RECALL

PERFORMED 98S15B

98S15 RECALL  
 101112 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15  
 REPLACE SPEED CONTROL CANCEL SWITCH PER RECALL  
 COMPLETE RECALL #98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

INSTALL SPEED CONTROL SWITCH  
 1 (PERMANENT REPAIR) REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR 98S15B X5  
 007 COMPLETED RECALL 98S15  
 PERFORM RECALL  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 98S15B .B  
 67279 PERFORMED RECALL,INSTALLED PRESSURE SWITCH  
 44782 WARR REPLACED A98S15 SPEED CONTROL SWITCH  
 COMPLETE RECALL #98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.

REPLACED SWITCH FOR RECALL

PERFORMED RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

1 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH

REPLACE DEACTIVATION SWITCH PER RECALL

PERF RECALL 99S15

70890 WARR INSTALL CRUISE DEACTIVATION SWITCH

PERFORM RECALL

94090 REPLACE SPEED CONTROL SWITCH PER RECALL

RECALL 99S15 PERFORMED RECALL 99S15

09250 COMPLETED SPEED CONTROL DISABLE SWITCH. INSTALL DNEW UPDATED SPEED CONTROL DISABLE SWITCH

107489 RECALL 99S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL

RECALL PERFORM RECALL

REPLACE SPEED CONTROL SWITCH PER RECALL. WAITN

AS PER RECALL 99S15 RECALL TO REPLACE SPEED CONTROL CABLE

COMPLETED OPEN RECALL 99S15

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6

OPEN RECALL COMPLETED

99S15 RECALL PERFORMED

RECALLED 99S15 PERFORMED

99S15 99S15 PERFORM RECALL

RECALL 99S15

PERFORMED RECALL

COMPLETED RECALL. REPLACED BRAKE SWITCH PER CAMPAIGN

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR...PERMANENT REPAIR.

78107 99S15 RECALL W PERFORMED 99S15 RECALL. INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH.

OPEN RECALL COMPLETE RECALL

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15

99S15 99S15

RECALL 99S15 SPEED CONTROL DEACTIREPLACE DEACTIVATION SWITCH AND CONNECTOR, RECALL PERFORMED.

1 PERFORMED RECALL

REPLACED DEACTIVATION SWITCH PER RECALL 99S15

DEACTIVATION SWITCH AND CONNECTOR. REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

INSTALLED SWITCH & CONNECTOR

PERFORM RECALL ON SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

PERFORMED CRUISE CONTROL SWITCH RECALL 99S15

204240 RECALL PERFORMED RECALL 99S15 - REPLACED DEACTIVATOR SWITCH AND CONNECTOR

RECALL RECALL

RECALL 99S15 PERFORMED RECALL 99S15

PERFORM RECALL

143484 RECALL WARR RECALL 99S15 REPLACE CONTROL DEACTIVATION - SWITCH  
 NAC PERFORMED RECALL  
 976231 REPLACED THE CRUISE DEACTIVATION SWITCH AND PLUG PER RECALL 99S15  
 RECALL COMPLETED  
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
 PERF RECALL 99S15  
 REPLACE SWITCH  
 RECALL COMPLETED  
 0 99S15 PROGRAM  
 RECALL 99S15 99S15 PERFORMED RECALL  
 PERFORM RECALL 99S15B  
 67475 RECALL W/ REPLACE SWITCH AND PLUG GA  
 RECALL RECALL  
 RECALL 99S15 COMPLETED  
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 1 JOB COMPLETED  
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL  
 PERF RECALL 99S15  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 OPEN RECALL PERFORM 99S15 RECALL  
 PERFORMED RECALL  
 78855 INSTALLED BRAKE SWITCH RECALL  
 RECALL 99S15B  
 SPEED CONTROL STICKING PERFORMED 99S15 RECALL  
  
 INSTALLED SWITCH PER RECALL  
 1 PERFORMED RECALL 99S15, INSTALLED CRUISE CONTROL SWITCH AS PER RECALL  
 RPL CRUISE DEACTIVATION SWITCH  
 99S15 99S15  
 99S15 SWITCH CONNECTOR 99S15  
 1 PERFORMED RECALL  
 REPLACED SWITCH PER RECALL  
 PERFORMED RECALL  
 RECALL 99S15 COMPLETED  
 PERFORMED RECALL  
 20395 PERFORMED RECALL 99S15 3  
 INSTALL BRAKE REPAIR CONN KIT  
 PERF RECALL  
 PERFORMED RECALL 99S15  
 1 COMPLETED RECALL 99S15  
 REPLACE DEACTIVATION SWITCH AS PER RECALL

RECALL DONE  
 PERFORM DEACTIVATION SWT.  
 REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15



INSTALLED DEACTIVATION SWITCH AS PER RECALL  
 99S15                      99S15 RFORMED  
 X                      RECALL  
 1 REPL DEACTIVATION SWITCH. 1  
 41335 DIO RECALL 99S15 TECH 3213  
 99S15 RECALL                      99S15 RECALL COMPLETE  
 REPLACE CRUISE SWITCH  
 24487 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH  
 RECALL                      99S15 COMPLETED  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 113082 99S15 99S15 .5 COMPLETED RECALL AS PER 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH K  
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE  
 PERFORMED RECALL  
 PERFORM RECALL 99S15 DEACTIVATION SWITCH RECHECK OPERATION SYSTEM OK 99S15B .5 ADMIN .1  
 FACTORY RECALL COMPLETED RECALL  
 INSTALLED KIT                      99S15 RECALL PERFORMED  
 87940 INSTALL SWITCH AND CONNECTOR  
 REPLACE SWITCH AS PER RECALL  
 RECALL                      99S15 REPLACE SWITCH AND CONNECTOR  
 PER NOTIFICATION 99S15 REPLACE SWITCH AND HARNESS CONNECTOR PER RECALL INSTRUCTIONS  
 77779 REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 21528 RECALL REPLACE CRUISE CONTROL SWITCH  
 RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 99S15                      99S15  
 99S15 99S15 PERF 99S15 .5+ .1-6  
 DIAGNOSIS AND INSPECT FOR CAMPAIGN INSTALLED SWITCH PERFORM CAMPAIGN AS PER NOTICE  
 99S15                      99S15  
 PERFORM RECALL  
 RECALL 99S15 CRUISE CONTROL REPLACE SWITCH AND CONNECTOR PER RECALL  
 63705 99S15B 0.5- ADMIN 0.1 RECALL  
 COMPLETED CAMPAIGN REPLACED SWITCH  
  
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
 99S15                      99S15  
 X                      REPLACE CRUISE CONTROL DEACTIVATION SWITCH  
 RECALL                      99S15 INSTALLED SWITCH PER RECALL  
 99S15 RECALL 99S15 WARR REPLACED DEACTIVATOR SWITCH AND CONNECTOR PER RECALL 99S15  
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
  
 PERFORMED RECALL PER SPECS  
 FACTORY RECALL COMPLETED RECALL  
  
 VEHICLE HAS AN OPEN RECALL                      PERFORM RECALL  
 PERFORMED RECALL                      RENEW SWITCH AND HARDSHELL CONNECTOR

74012 RECALL REPLACE DEACTIVATION SWITCH  
 CRUISE RECALL 99S15 INSTALL CRUISE SWITCH AND CONNECTOR  
 1 INSTALL SPEED CONTROL MODIFICATION AS PER RECALL  
 1 INSTALL SPEED CONTROL MODIFICATIONS  
 REPLACE DEACTIVATION SWITCH  
 RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH INSPECTED SWITCH. REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 PERFORMED RECALL PERFORMED RECALL

REPLACED SPEED CONTROL SWITCH & CONNECTOR  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
 POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 53038 99S15 REPAIR ACCORDING TO 99S15  
 PERFORM 99S15 RECALL CRUISE CONTROL

CAMPAIGN 99-8-15 COMPLETED AS PER RECALL INSTRUCTION.  
 COMPLETE RECALL  
 COMPLETED OPEN RECALL 99S15  
 REPLACE SWITCH  
 1 RECALL 99S15 PERFORMED  
 PERFORM RECALL

RECALL COMPLETED. REPLACED CONNECTOR AND SWITCH. ROAD TEST.  
 99S15 RECALL  
 PERFORMED OPEN RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL RECALL  
 REPLACE SWITCH AND HARD SHELL  
 REPAIR AS PER RECALL 99S15.  
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 REPAIR AS PER RECALL 99S15.

42 99S15  
 1 REPLACE DEACTIVATION SWITCH AND CONNECTOR  
 99S15 99S15  
 99S15 99S15  
 RECALL PERFORMED RECALL 99S15.  
 134420 RECALL 99S15, REPLACE SWITCH AND CONNECTOR  
 INSTALL DEACTIVATION SWITCH  
 99S15E PERFORMED RECALL INSTALLED NEW CRUISE  
 81201 REPLACED SWITCH 0.5  
 SPEED CONTROL SWITCH 99S15 RECALL  
 RECALL DONE  
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED CRUISE DEACTIVATION SWITCH  
 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 COMPLETED RECALL 98S15  
 87545 RECALL 98S15B D.S REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RNR SWITCH PERFORM RECALL 98S15  
 1 PERFORMED RECALL  
 PERFORMED RECALL 98S15  
 40044 COMPLETED 98S15 REPL SWITCH  
 REPLACED SWITCH AND CONN  
 REPLACED DEACTIVATION SWITCH AND HARD SHELL  
 R-R SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 98S15 RECALL REPLACE SWITCH  
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
 REPLACE CRUISE DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL  
 RECALL DONE  
 RECALL PERFORMED RECAL

REPLACE SWITCH AND HARD SHELL  
 SWITCH MAY DEVELOP A RESISTIVE SHORT CIRCUIT. REPLACED CONNECTOR AND SWITCH  
 98S15 REPL DEACTIVATION SWITCH  
 COMPLETED RECALL

10489 RECALL 98S15 WR PERFORM RECALL 98S15

PERFORMED RECALL PERFORMED RECAL  
 RECALL 98S15 REPLACE DEACTIVATOR SWITCH  
 98S15B PERFORMED RECALL - REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL 98S15  
 PERFORMED  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
 RECALL RECALL  
 90001 79 PERFORM 98S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH  
 78700 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 98S15  
 RPL CRUISE DEACTIVATION SWITCH  
 PERFORM RECALL 98S15B

87348 PERFORM RECALL 98S15  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 8 8856998S15  
 REPAIR AS PER RECALL

8802-828 11744

PERFORM RECALL  
PERFORMED RECALL AS PER INSTRUCTIONS  
PERFORMED RECALL CODE 42

REPLACE CRUISE DEACTIVATION SWITCH PER RECALL  
PERFORMED RECALL 99S15 INSTALLED CRUISE CONTROL SWITCH AND CONNECTOR  
111000 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR AS PER 99S15  
99S15 SPEED CONTROL DEACTIVATION REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
REPLACED SC DEACTIVATION SWITCH 99S15  
REPLACED SWITCH AND PLUG

REPLACED SPEED CONTROL DEACTIVATION SWITCH  
99S15 PERFORM RECALL 99S15  
PERFORMED RECALL 99S15 - REPLACED PART

PERFORM RECALL

RECALL RECALL  
RECALL COMPLETED -DID 99S15B.  
PERFORM RECALL 99S15

RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG PER RECALL

99S21 PERFORMED RECALL REPLACED SWITCH AND CONN  
PERFORMED RECALL REPLACED SPEED CONTROL SWITCH

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

99S15 SPEED CONTROL SWITCH 99S15 REPLACED SPEED CONTROL SWITCH  
INSTALL DEACTIVATION SWITCH  
PERFORM RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
REPLACED DEACTIVATION SWITCH 99S15 REPAIRED PER RECALL

99S15 99S15

PERFORMED RECALL

PERFORMED RECALL 99S15

RECALL COMPLETE

PERFORMED 99S15 DEACTIVATED CRUISE CONTROL

PERFORM DIAGNOSIS, ROAD TEST, SWITCH DEFECTIVE? REPLACE SWITCH

48247 REPLACED DEACTIVATION SWITCH AND CONNECTOR, PER RECALL

PERFORM RECALL 99S15

RECALL 99S15 COMPLETED

RECALL 99S15 COMPLETED

99S15 RECALL 99S15 RECALL COMPLETE

SOME SPEED CONTROL DEACTIVATION SWITCHES ON THE AFFECTED VEHICLES MAY DEVELOP A RESISTIVE SHORT COMPLETED RECALL AS OUTLINED BY FORD I

106446 PERFORMED RECALL

RECALL COMPLETED

125851 PERFORM RECALL PER RECALL 99S15 INSTALL CRUISE DEACTIVATOR SWITCH AND CONNECTOR  
94842 REPL CRUISE BRAKE SWITCH

BRG-828 11745

REPLACE SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 130871 INSTALLED SWITCH AND HARDSHELL PER BULLITIN.  
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

PERFORM RECALL  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR - 98S168 .5  
 REPLACE CRUISE DEACTIVATION SWITCH  
 RECALL COMPLETE  
 72000 I PERFORMED RECALL 98S15  
 PERF RECALL 98S15  
 27768 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR SHELL 0.5 HR LABOR 0.1 ADMI  
 1 PERFORMED RECALL 98S15  
 REPLACED SC DEACTIVATION SWITCH 98S15  
 COMPLETED RECALL 98S15  
 RECALL 98S15 COMPLETED  
 REPLACED SC DEACTIVATION SWITCH 98S15

RECALL 98S15 98S15 PERFORMED-REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNEC  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15  
 REPLACE CRUISE DEACTIVATION SWITCH..RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15  
 98S15 REPLACE CRUISE DEACTIVATION SWITCH  
 98S15 RECALL 98S15 RECALL COMPLETED  
 REPLACE SPEED CONTROL SWITCH  
 78141 RECALL 98S15, SPEED CONTROL SWITCH  
 RECALL 98S15 RECALL INSTALL CONNECTOR & SWITCH  
 RECALL COMPLETED  
 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS OUTLINED IN REC ASLL 98S15 ALL OK TO RELEASE  
 OPEN RECALL PERFORMED RECALL  
 PERFORMED RECALL 98S15-INSTALL SWITCH  
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE  
 RECALL COMPLETED 98S15 RECALL  
 98S15 98S15  
 104879 PERFROM RECALL 98S15 OP 98S15B  
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 98S15  
 REPLACED THE SWITCH PER RECALL 98S15  
 PERFORM RECALL 98S15  
 RECALL 98S15 COMPLETED  
 REPLACED SPEED CONTROL SWITCH  
 024 REPLACE CRUISE DEACTIVATOR SWITCH  
 PERFORMED RECALL 98S15  
 SAFETY RECALL 98S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 1 INSTALLED SPEED CONTROL SWITCH & CONNECTOR

DO RECALL 98S15

DID CRUISE RECALL

99S15 99S15  
99S15 99S15

REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 1

FACTORY RECALL COMPLETED RECALL

70859 RECALL 99S15 PERFORMED RECALL 99S15

88908 RECALL 99S15 PERFORMED RECALL 99S15

REPLACED SWITCH AND CONNECTOR

INSTALLED SWITCH

71164 RECALL 99S15 WR PERFORM RECALL 99S14 SPEED CONTROL INSTALL NEW ONE AND REPAIR WIRE FOUND THAT ABS LIGHT ON AND BRAKE LIGHT ON  
PERFORMED RECALL

INSTALLED DEACTIVATION SWITCH AS PER RECALL, REPAIRED WIRE HARNESS TO SWITCH, HAD AFTERMARKET CONNECTOR, INSTALLED

72977 CAMPAIGN 99S15 SPEED CONTROL DEACTIVATION SWITCH 99S15E .3HRS .3HRS REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15

SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S

RECALL 99S15 COMPLETED

82598 RECALL PERFORM RECALL 99S15 REPLACE THE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR

RECALL 99S15

PERF RECALL 99S15

PERFORM RECALL

REPL DEACTIVATION SWITCH PER RECALL

POSSIBLE ELECTRICAL FAILURE IN DEACTIVATION SWITCH PERFORMED RECALL 99S15 FOR SPEED CONTROL DE-ACTIVATION

99S15 99S15-INSTALL SWITCH AND CONNECTOR

PERFORMED RECALL 99S15

RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH

-- REPLACED SWITCH

99S15 RECALL

DO RECALL 99S15 CK ONLY IS OK

99S15 RECALL 99S15 RECALL COMPLETE

89710 RECALL R-R CRUISE SWITCH AND BLEED BRAKES AS PER RECAL

99S15 DO RECALL

1 INSTALLED BRAKE DEACTIVATION SWITCH AS PER RECALL 99S15

PERFORMED RECALL

1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

REPLACED SWITCH AND CONNECTOR PER RECALL 99S15

RECALL 99S15 RECALL 99S15

RECALL 99S15 PERFORMED RECALL 99S15B

REPLACE SWITCH AND CONNECTOR

INSTALL CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15 RECALL 99S15,REPLACE DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 RECALL REPLACED BRAKE SWITCH  
 RECALL 99S15 COMPLETE  
 76881 PERFORMED RECALL ADDED BRAKE FLUID AND PR STR FLUID WASHED ENGINE  
 PERFORMED RECALL 99S15  
 COMPLETE RECALL  
 PERFORMED 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 125829 PERFORM RECALL 99S15 C-C SWITCH  
 INSTALL SWITCH PER RECALL  
 197985 PERFORMED RECALL AS PER LETTER. INSTALLED SWITCH AND CONNECTOR 99S15B 0.5 HR LABOR  
 DID RECALL 99S15. SPEED CONTROL DEACTIVATION SWITCH

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 PERFORMED RECALL  
 REPLACED SWITCH AND CONNECTOR  
 R AND R SWITCH PER RECALL  
 RECALL 99S15 INSTALLED SWITCH  
 REPAIRED AS PER PROGRAM  
 RAR SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER 99S15  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR PER RECALL

114406 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECAL

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 COMPLETED RECALL 99S15  
 PERFORMED SAFETY RECALL 99S15  
 PERFORM 99S15 RECALL CRUISE SWITCHES  
 RECALL PERFORM RECALL  
 X COMPLETED COMPLETED  
 OPEN RECALL PERFORM RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B  
 REPLACED CRUISE CONTROL SWITCH  
 REPLACED BRAKE SWITCH FOR SPEED CONTROL AS PER RECALL  
 REPL SWITCH PER RECALL

COMPLETE RECALL 99S15  
 REPLACED CONTROL SWITCH  
 116988 RECALL 99S15 W PERFORMED RECALL INSTALLED UPDTE SWITCH AND TE ST OK SEE OTHER LINE FOR REPAIRS NEEDED TO TEST SYSTEM FOUND TERN  
 PERFORM RECALL PER MANUFACTURER RECALL PERFORME  
 PERFORM RECALL  
 99S15 99S15 RECALL  
 PERFORMED RECALL

2082-825 11749

COMPLETE RECALL 99S15.  
PERFORMED RECALL

RECALL PERFORM RECALL  
99-S-15 99-S-15 COMPLET  
OK REPL SWITCH  
PERFORM RECALL INSTALL SWITCH  
NBS TO REPLACE DEACTIVATION SWITCH  
REPLACED SC DEACTIVATION SWITCH 99S15  
INERTIA SWITCH/PER RECALL 99S15  
PER RECALL 99S16  
99S15 REPL DEACTIVATION SWITCH  
1 COMPLETE RECALL  
99S15 99S15  
REPLACED SWITCH PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
PERFORM RECALL

INSTALLED DEACTIVATION SWITCH  
RECALL PERFORMED RECALL 99S15B SPEED CONTROL DEACTIVATION  
PER THE QASIS PERFORM RECALL 99S15.

RECALL COMPLETED ALL OK

REPLACE SPEED CONTROL DEACTIVATION SWITCH  
RECALL 99S15  
COMPLETED 99S15  
RECALL 99S15 PERFORM RECALL 99S15  
REPLACED DEACTIVATION SWITCH  
99S15 RECALL 99S15 RECALL COMPLETE  
105533 REPLACED SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR..  
RECALL 87031 REPLACE SWITCH AND CONNECTOR

OPEN RECALL COMPLETE RECALL 99S15  
PERFORMED 99S15  
99S15 99S15 RECALL DO  
RECALL 99S15  
RECALL COMPLETE  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
REPL SWITCH PER RECALL 99S15  
129852 99S15 INSTALLED CONNECTOR AND CRUISE SWITCH AS OUTLINED IN 99S15  
108250 REMOVED OLD SPEED SWITCH AND REPLACED IT WITH THE NEW SPEED DEACTIVATION SWITCH  
REPLACED CRUISE SHUT OFF SWITCH

ENG-025 11749



50142 RECALL REPL- SPEED CONTROL DEACT SWITCH & A PLUG 90S15B 0.5  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 52574 RECALL 90S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 90S15  
 REPLACE DEACTIVATION SWITCH, RECALL  
 REPL CRUISE SWITCH 90S15  
 90S15 RECALL 90S15 REPAIRED AS PER RECALL  
 50578 REPLACED SWITCH  
 90S15 90S15  
 PERFORM RECALL  
 REPLACED SWITCH AND CONNECTOR  
 PERFORMED RECALL PERFORMED RECALL  
 1 INSTALL DEACTIVATION SWITCH 1  
 90S15 90S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL REPLACE CRUISE SWITCH  
 PERFORM RECALL  
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE  
 90S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 90S15  
 PERFORM RECALL REPL DEACTIVATION SWITCH  
 REPLACED C CONTROL DEACTIVATION SWITCH PER 90S15 RECALL  
 COMPLETED 90S15 RECALL  
  
 PERFORM RECALL 90S15 RECALL 90S15 SPEED CONTROL DEACTIVATION SWITCH  
 REPLACE AS PER RECALL 90S15  
 PERFORM RECALL INSTALL SWITCH  
 90S15 RECALL 90S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 1 COMPLETED RECALL 90S15  
 REPL SWITCH PER RECALL  
 90S15 RECALL  
 REPLACED CRUISE SWITCH  
  
 1 INSTALL SPEED CONTROL DEACTIVATION SWITCH 1  
 90S15 RECALL  
 RECALL PERFORMED RECALL  
 54005 INSTALLED A NEW SWITCH PER RECALL NOTICE  
 JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR  
 SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 90S15  
 PERFORM RECALL 90S15  
 23060 90S15 REPLACE SWITCH AND CONNECTOR PER RECALL GA  
 INSTALL NEW CRUISE CONTROL BRAKE SWITCH PER RECALL 90S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 90S15  
  
 PERFORM RECALL  
 REPLACE SWITCH AND HARD SHELL  
  
 74019 PERFORM RECALL, REPLACE SWITCH 90S15B .5

REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 ONP 99S15 ONP 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHEL  
 1 PERFORMED RECALL 99S15 1  
 REPLACE SPEED CONTROL PER RECALL

RECALL REPLACESWITCHAND CONNECTOR  
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 FACTORY RECALL COMPLETED RECALL  
 99S15 99S15B  
 RECALL COMPLETED

OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE  
 99S15 99S15B  
 INSTALLED CRUISE KIT PER RECALL  
 PERFORM RECALL 99S15  
 99S15 RECALL 99S15 REPAIRED A PER RECALL

INSTALLED NEW DEACTIVATION  
 44331 PERFORMED SPEED CONTROL DEACTIVATION SW. RECALL  
 RECALL COMPLETE  
 INSTALL DEACTIVATION SWITCH.  
 PERFORM RECALL REPLACE SWITCH AND CONNECTOR 99S15 BLEED AND ROAD TEST VERIFY REPAIRS  
 X PERFORMED RECAL  
 80228 RECALL WARR REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PE R RECALL 99S15  
 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNETOR END  
 REPL SWITCH PER RECALL 99S15  
 RECALL 99S15 PERFORM RECALL 99S15  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 PERFORM RECALL 99S15 PERFORM RECALL 99S15  
 COMPLETE RECALL 99S15  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
 D RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 20428 REPLACE SWITCH AND CONNECTOR PER 99S15 87  
 99S15 RECALL PERFORMED  
 99S15 RECALL 99S15 RECALL COMPLETE  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 INSTALL CRUISE DEACTIVATIONL SWITCH  
 RECALL PERFORMED RECALL 99S15.  
 1 PERFORMED RECALL  
 91405 INSTALLED A NEW 8 SPEED CONTROL PRESSURE SWITCH PER RECALL NOTICE  
 RECALL 99S15  
 RECALL 99S15 RECALL  
 RECALL RECALL  
 DID RECALL 99S15

EM62-629 11791

REPLACE DEACTIVATION SWITCH  
 36802 REPLACED THE DEACTIVATION SWITCH ALONG WITH THE PROPORTIONING VALVE BECAUSE THE VALVE WAS DAMAGED WHEN THE SWITCH WAS REMOVED  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15  
 INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN  
 RECALL 99S15 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETED  
 1 RECALL COMPLETE  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 APPLIED RECALL 99S15  
 RECALL 99S15 REPLACE CRUISE SWITCH  
 W/ DISCONNECTED SPEED CONTROL AND ORDERED NEW DEACTIVATION SWITCH.  
 COMPLETED RECALL 99S15, SPEED CONTROL DEACTIVATION  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ASSY AS PER 99S15 RECALL  
 RECALL 99S15  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 REPL SWITCH PER RECALL 99S15  
 RECALL COMPLETE  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 REPL SWITCH & CONNECTOR PER RECALL 99S15  
 70882 PERFORMED RECALL 99S15  
 REPLACED DEACTIVATION SWITCH  
 RECALL #99S15 RECALL #99S15  
 PER RECALL 99S15 OASIS DOWN INSTALL NEW DEACTIVATION SWITCH PER RECALL 99S15  
 99S15 REPLACE CRUISE CONTROL BRAKE SWITCH  
 FACTORY RECALL COMPLETED RECALL  
 PERFORM RECALL ON SPEED CONTROL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 PERFORM RECALL SENT BY WPI  
 PERFORM RECALL 99S15  
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 110152 DID RECALL 99S15 REPLACED CONNECTOR AND SWITCH  
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR .... 99S15B .5 + .1  
 PERFORM RECALL  
 PERFORMED RECALL  
 REPAIR AS PER RECALL  
 A89 99S15 62 99S15B - 610 - LABOR & ADMIN .1 REPLACED SPEED CONTROL DEACTIVATION SWITCH, AND HARD SHELL CONNECTOR  
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 DEACT SWITCH #99S15  
 PERFORM RECALL 99S15  
 PERFORM RECALL 99S15  
 99S15 99S15  
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 50117 99S15 W/ INSPECTED AND REPLACED SPEED CONTROL RECALL PER 99S15. 6115

REPLACE SWITCH & CONNECTOR  
 RECALL 99S15 RECALL- REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 99S15B REPLACE SWITCH RECALL  
 INSPECTED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 99S15 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED RECALL  
 PERFORMED RECALL  
 RECALL 99S15 - B - RECALL  
 PERFORMED RECALL  
 99S37 RECALL 99S15 RECALL 99S15 JH

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS  
 91901 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG  
 99S15 R&R DEACTIVATION SWITCH  
 COMPLETED 99S15 RECALL  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR.  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 COMPLETE RECALL 99S15  
 PERFORM RECALL 99S15

99S15 RECALL 99S15 RECALL COMPLETE  
 1 PERMANENT FIX - REPLACE DEACTIVATION SWITCH AND CONNECTOR. 99S15B 0.5 HRS  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL REPAIR AS PER RECALL 99S15 SPEED DEACTIVATION SWITCH REPLACEMENT  
 99S15 RECALL 99S15 RECALL COMPLETED  
 REPAIR PER FOMOCO  
 OPEN RECALL PERFORM SERVICE REPAIR PER RECALL MESSAGE

99S15 99S15 PERFORM RECALL  
 99S15B RECALL 99S15B REPLACED CRUISE ACTIVATION SWITCH  
 58138 REPLACED SWITCH  
 PERFORMED RECALL 99S15 - CHECK AND REPLACED CRUISE CONTROL CABLE AND RECHECK OK  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER 99S15 RECALL  
 RECALL COMPLETE  
 99S15  
 99S15B RECALL 99S15B RECALL REPLACED CRUISE DEACTIVATION SWITCH  
 30277 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH JH  
 REPLACED DEACTIVATION SWITCH  
 FACTORY RECALL COMPLETED RECALL  
 RECALL PERFORM RECALL  
 PERFORM 99S15  
 RECALL COMPLETE  
 FACTORY RECALL COMPLETED RECALL  
 COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH E  
 COMPLETED FACTORY RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 99S15 CAMPAIGN  
1 REPLACE CRUISE SWITCH AND BLEED BRAKES  
INSTALL DEACTIVATION SWITCH  
PERFORM RECALL  
PERFORMED RECALL

30761 PERFORMED RECALL 99S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND CONECTOR BLEED BRAKES AND TEST DROVE ALL OK  
PERFORM RECALL

PERFORMED RECALL 99S15

AS PER RECALL # 99S15

OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15

99S15 99S15

1 INSPECTED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

COMPLETE RECALL 99S15

PERFORMED RECALL

PERFORM SPEED CONTROL SAFETY RECALL AS INSTRUCTE

RECALL REPLACED DEACTIVATION SWITCH PER RECALL

99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH A

110000 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

PERFORM RECALL AS PER LETTER

REPLACE DEACTIVATION SWITCH PER RECALL

RECALL 99S15 MIL 21821 DID RECALL 99S15 REPLACE SWITCH & CONECTOR

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

REPL SPEED CONTROL SWITCH 99S15 RECALL

PERFORM RECALL 99S15

50739 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15

REPLACE CRUISE SWITCH PER RECALL

INSTALLED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15

REPL SWITCH PER RECALL

PERFORMED RECALL 99S15

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED S

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

AE PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR

RECALL REPAIR

99790 RECALL 99S15 INSTALL NEW SWITCH AND CONNECTOR

PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

72365 RECALL 99S15B 0.50 INSTALL NEW BRAKE DEACTIVATION SWITCH

99S15 99S15 PERFORM RECALL

1 PERFORMED 99S15 RECALL

RECALL COMPLETE

COMPLETED RECALL 99S15

PERFORMED RECALL 99S15

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.  
REPLACED PARTS PER RECALL  
REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR

PERFORM RECALL 98S15 RECHECK OK 1  
PERFORM RECALL 98S15  
PERFORMED RECALL AS PER INSTRUCTIONS  
RECALL INSPECT AND REPLACE SWITCH PER RECALL  
PERFORMED RECALL PER BULLETIN  
INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL  
INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15  
98S80 INSTALLED RECALL  
COMPLETE 98S15  
REPLACED DEACTIVATION SWITCH  
98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 98S19  
PERFORMED RECALL  
INSTALL KIT FOR DEACTIVATION SWITCH  
REPLACED CRUISE SWITCH  
98S15 RECALL  
RENEW DEACTIVATION SWITCH  
PERFORM SPEED CONTROL MODIFICATION PER RECALL  
PERFORMED RECALL 98S15

98S15B RECALL COMPLETE  
RECALL COMPLETE  
RECALL 98S15 98S15  
REPLACED CRUISE CONTROL BRAKE SWITCH AND CONNECTOR PER RECALL  
98S15 RMR SWITCH  
COMPLETED RECALL

PERFORM RECALL 98S15  
REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 98S15  
REPLACED CRUISE DEACTIVATION SWITCH PER RECALL  
98S15 98S15 REPLACED SWITCH AND CONNECTOR  
C INSTALL SWITCH AS PER RECALL  
PERFORMED RECALL  
31823 PERFORMED RECALL 98S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE ALL O  
REPL CRUISE CONTROL SWITCH ASY  
PERFORMED RECALL AS BY FACTORY PERFORMED RECALL  
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 98S15.  
DIAG AND PERFORMED RECALL 98S15 INSTALLED DEACTIVATION SWITCH ALL OK WITH CRUISE NOW  
PERFORM RECALL 98S15  
44456 PERFORMED RECALL 98S15 REMOVED AND REPLACED CRUISE DEACTIVATION SWITCH AND TEST DROVE OK  
SWITCH AND CONNECTOR INSTALLED

COMPLETED

SPEED CNTRL DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15  
 REPLACE DEACTIVATION SWITCH 1  
 71705 99S15 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND PLUG IN CONNECTOR  
 RECALL 99S15  
 REPLACED DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 RECALL SPEED CONTROL DEACTIVATION SWITCH  
 109952 RECALL 99S15 INSPECTED AND INSTALLED CRUISE DEACTIVATION SW. SEE LINE D..  
 99S15B .5 HRS ADMIN .1 HRS COMPLETED RECALL 99S  
 REPLACE SPEED CONTROL PER RECALL  
 RECALL COMPLETED  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL CABLE PER RECALL

RECALL 99S15  
 1 PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL SWITCH  
 PERFORMED RECALL  
 99S15 99S15 REPLACE CRUISE SWITCH PER RECALL 99S15

PERFORM RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR PER RECALL 99S15  
 INSTALL SWITCH PER RECALL  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 PERFORM RECALL AS PER FACTORY REQUIREMENTS  
 99S15 RECALL PERFORMED  
 99S15 99S15  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 93210 REPLACED CRUISE CONTROL SWITCH 99S15

RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 37306 RECALL REPLACED DEACTIVATION SWITCH 150  
 REPLACED DEACTIVATION SWITCH

87721 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15  
 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH PERMANENT REPAIR  
 RECALL 99S15 RECALL COMPLETE  
 REPLACE DEACTIVATION SWITCH, RECALL  
 99S15 99S15  
 99S01 PERFORMED RECALL 99S15  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 AS PER RECALL 99S15 RECALL TO REPLACED DEACTIVATION SWITCH

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 REPL DEACTIVATION SWITCH PER RECALL

PERFORM RECALL 98S15

1 TECH REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL 98S15 T  
PERFORM SAFETY RECALL 98S15

94521 REPLACED SPEED CONTROL DEACTIVATOR SWITCH AND HARDSHELL AND BLEED BRAKES AS PER RECALL  
INSPECTED ALREADY DISCONNECTED REPLACED SWITCH PER RECALL

1 REPLACE CRUISE CONTROL SWITCH AS NEEDED  
PERFORMED RECALL 98S15

35202 PERFORMED 98S15 RECALL

PERFORMED SPEED CONTROL RECALL TECH 9208

PERFORM RECALL 98S15B PERFORM RECALL 98S15B

RPLC CRUISE DEACTIVATION SWITCH PER 98S15

REPL SPEED CONTROL SWITCHES

REPLACE AS PER RECALL 98S15

81280 RECALL TECH 9177 PERFORM RECALL 98S15 INSTALL SWITCH AND CONNECTOR

REPLACE AS PER RECALL REMOVE AND REPLACE AS PER RECALL (98S15B)

43157 PERFORM RECALL AS PER RECALL

REPLACE DEACTIVATION SWITCH 98S15 RECALL PER FORD INSTRUCTIONS

REPLACED DEACTIVATION SWITCH

98S15 RPL SPEED CONTROL DEACTIVATION SWITCH

1 REPLACE CRUISE CONTROL DEACTIVATION SWITCH PER RECALL

COMPLETED 98S15

RPL CRUISE DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

98S15 REPL DEACTIVATION SWITCH 98S15 COMPLETED - REPLACED DEACTIVATION SWITCH

PERFORM RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

COMPLETED RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

RECALL 98S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORMED RECALL 98S15 AND CHECKS OK

REPLACED CRUISE SWITCH

55555 98S15B 0.5 ADMIN 0.1

INSTALLED DEACTIVATION SWITCH

PERF RECALL

REPLACED SWITCH PER RECALL

REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR 98S15B .5

- MODIFY PER RECALL 98S15

RECALL COMPLETE

TECH CHECK AND REPLACED AS REQUIRED

REPLACED CRUISE BRAKE KIT F

OPEN CAMPAIGN 98S15 REMOVE AND REPLACE SPEED CONTROL SWITCH AS PER CAMPAIGN, PERFORM LABOR OPERATION 98S15B

INSTALL SPEED CONTROL PART PER RECALL

98S15 PERFORMED RECAL



99801 RECALL 99815E 0.3L PERFORMED RECALL  
RECALL COMPLETED

99815 REPLACE SWITCH AND CONNECTOR PER RECALL  
COMPLETED RECALL 99815

110449 RECALL REPLACE DEACTIVATION SWITCH PER RECALL 99815

95721 PERFORMED CRUISE RECALL WHEN REPLACING SWITCH THREADS PULLED OUT OF BLOCK ORDERED PRESSURE BLOCK REMOVED FUSE BLOCK ,P8 BOTTLE  
1 PERFORM RECALL  
REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL

RECALL RECALL

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99815 RECALL INSTRUCTIONS

99815B INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

PERFORMED RECALL 99815-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH

COMPLETED RECALL

RECALL COMPLETED 99815 RECALL

PERFORMED RECALL 99815

FACTORY RECALL COMPLETED RECALL

REPLACE CRUISE SWITCH PER RECALL

PERFORMED RECALL 99815

REPLACED PER RECALL

PERFORMED INSPECTION AND REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815

PERFORM RECALL

REPLACE SWITCH PER RECALL

??

99142 RECALL 0.5 INSTALLED BRAKE PRESSURE SWITCH AND HARDSHELL CONNECTOR 99815B

99224 RECALL .5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815B

THE CAR NEEDS A NEW FAN BELT AT \$83.00. CUST AWARE THE COOLANT BOTTLE IS EMPTY. BATTERY NEEDS SERVICE.

99815 99815

CERTAIN 1982 AND 83 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CAR WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION

INSPECTED AND REPLACED CRUISE SWITCH PER RECALL NOTICE

102059 RECALL 99815 W RECALL 99815 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR TOP OFF BRAKE FLUID AND BLEED BRAKES

REPLACE SPEED CONTROL SWITCH PER RECALL

PERFORMED RECALL 99815: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR.

80000 RECALL WPG40 INSTALLED NEW SWITCH & WIRE CONNECTOR PER RECALL 99815 FINISHED

REPLACED SWITCH AND PLUG AS PER RECALL 99815

INSTALLED CRUISE CONTROL KIT AS PER RECALL

RNR DEACTIVATION SWITCH PERFORM RECALL 99815

91766 RECALL 99815 REPLACE CRUISE CONTROL SWITCH AND PLUG

F RC 99815 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

PERFORM RECALL

PERFORMED RECALL 99815-INSTALL SWITCH

55249 REPLACED SWITCH AND CONECTOR  
PERFORM RECALL 99S15      PERFORM RECALL

77544 DO RECALL 99S15  
PERFORM RECALL 99S15 REPLACE CRUISE DEACTIVATION SWITCH  
SPEED CONTROL DEACTIVATION SWITCH REPLACE 99S15B PERFORMED RECALL 99S15B  
REPLACED DEACTIVATION SWITCH AS PER RECALL  
157323 RECALL REPLACED SWITCH AND CONNECTOR RECALL 99S15B  
1 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH 99S15B  
1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S  
REPL SWITCH PER RECALL 99S15  
PERFORM RECALL  
PERFORM RECALL  
RECALL 99S15 PERFORM RECALL 99S15  
CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.  
SPEED CNTRL DEACTVTN SWITCH RPLCMTPRF SAFETY RECALL 99S15  
99S89 PERFORMED RECALL 99S15  
COMPLETED OPEN RECALL 99S15  
INSTALLED CRUISE SWITCH  
33852 RECALL R+R DEACTIVATION SW AND REWIRED HARD SHELL CONN  
90427 MAINT DID RECALL REPLACED SWITCH AND WIRES TECH 10

159059 99S15 SPEED CONTROL DEACTIVATION SWITCH PERFORM INSPECTION AND REPLACE SWITCH AND CONECTOR AS PER RECALL  
RECALL      PERFORM RECALL 99S15

PERFORM RECALL  
FACTORY RECALL COMPLETED RECALL  
99S15 SP-SWITCH INST  
REPLACED THE SPEED CONTROL SWITCH PER RECALL  
PERFORMED SPEED CONTROL RECALL  
90158 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONECTOR TK372  
PERFORM RECALL

A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE TAPE AND  
RECALL REPAIRED AS PER RECALL

99S15      99S15  
99S15 RECALL NOTIFICATION      99S15 RPL DEACTIVATION SWITCH AND HARDSHELL CONN PER RECALL  
REPLACE BRAKES PRESSURE SWITCH PER RECALL 99S15  
RECALL 99S15      PERFORM RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
RECALL TECH 876 WAYNE WP REPLACED CRUISE CUT OFF SWITCH AS PER RECALL CAR ON DRIVE  
NAC      99S15

RECALL 99S15      INSTALL KIT PER 99S15  
SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
REPLACE SPEED CONTROL DEACTIVATION SW RECALL 99S  
RECALL PERFORMED  
INSTALL SWITCH.  
PERFORMED RECALL

5982-623 11795

INSTALL SWITCH AS PER RECALL

1 REPAE SWITCH & CONNECTOR BLEED BRAKES

RECALL 98S15 98S15B .5 ADMIN .1 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL.

RECALL 98S15

RECALL 98S15

98734 RECALL REPLACE DEACTIVATION SWITCH AND CONNECTOR

X 98S15

RECALL 98S15 REPLACE SWITCH & CONNECTOR

08820 08S15B .5 INSTALL SWITCH PER RECALL

80897 PERFORMED RECALL 98S15

115632 RECALL 0.5 98S15B INSTALLED RECALL

80883 RECALL REPLACED SPEED CONTROL DEATVATER SWITCH AND CONNECTOR CODE 42 TK574 SUGGESTED EGR TUBE,INJECTOR SERV,CLEAN IAB VALVE,DE  
98S15 SPEED CONTROL RECALL

REPLACED SPEED DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15B

114104 RECALL REPLACED SWITCH AS PER RECALL

REPLACED SPEED CONTROL CABLE AS PER RECALL

RECALL 98S15 COMPLETED

1 08 REPLACED SWITCH

CHECK AND REPLACE CRUISE CONTROL SWITCH PER RECALL

98S15 RECALL 98S15 RECALL

50216 PERFORM RECALL 98S15B, REPLACE SPEED CONTROL SWITCH

98S24 RECALL REPLACE DEACTIVATION SW AND CONNECTOR

PERFORMED RECALL 98S15

RECALL 98S15 SWITCH

40430 RECALL 98S15 COMPLETED

RECALL 98S15 98S15

RECALL 98S15 COMPLETED

RECALL PERFORMED

RECALLED 98S15 PERFORMED

CHECK AND REPAIR AS REQUIRED

INSPECTED SYSTEM, REPAIRED IF NECESSARY PER RECA

80152 REPL CRUISE DEACTIVATION SWITCH PER RECAL

PERFORMED RECALL 98S15 1

. PERFORM RECALL 98S15

PERFORMED RECALL 98S15

RECALL 98S15 INSTALLED SWITCH

INSTALL NEW BRAKE SWITCH CONNECTOR PER RECALL OK OP OK

100806 98S15 WARR REPLACED SWITCH AND CONN

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15

SPEED CONTROL SWITCH 98S15 RECALL

80680 RECALL 98S15B 0.5 HRS. NEC TO PERFORM RECALL 98S15

RECALL REPLACE SWITCH AND HARD SHELL CONNECTOR

COMPLETED RECALL

INSPECTED AND REPLACED DEACTIVATION SWITCH AS PER RECALL  
 97000 COMPLETED SPEED CONTROL DISABLE SWITCH RECALL INSTALLED NEW SPEED DISABLE SWITCH TO VEHICLE  
 REPLACE SPEED SWITCH AS PER RECALL  
 RECALL 99S15  
 PERFORM RECALL INSTALL SWITCH  
 99S15B 0.5  
 COMPLETE RECALL 99S15  
 102093 REPLACED SWITCH AND CONNECTOR PER RECALL  
 RECALL PERFORMED RECALL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15.  
 SERVICE DIAG AND REPLACED SERVO ACCUMULATOR  
 PERFORMED RECALL 99S15. REPLACED CRUISE DE-ACTIVATION SWITCH. 99S15B .5  
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH  
 101431 RECALL DEACTIVATION SWITCH INSTALLED  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR AND BLEED BRAKES 3 COMPLETED  
 124205 RECALL 99S15 COMPLETED  
 PERFORMED 99S15 RECALL  
 1 PERFORM SERVICE  
 PERFORMED RECALL AS NEEDED REPLACED SWITCH  
 PERFORM RECALL SPEED CONTROL SWITCH  
 PERFORM RECALL 99S15  
 RECALL 99S15 RECALL 99S15  
 99S15 99S15 RECALL  
 RECALL 99S15  
 47146 RECALL W 7208 REPLACED SPEED CONTROL DEACTIVATE PER RECALL 99S15  
 RECALL 99S15 DONE  
 99S15 SPEED CONTROL RECALL  
 99S15 - PERFORMED RECALL REPLACED SWITCH & CONNECTOR & RD. TEST.  
 50077 99S15 PERFORM RECALL, FALLS INTO AFFECTED DATE, REPLACE SWITCH AND CONNECTOR, BLEED SYSTEM.  
 INSTALL SENDER & CONNECTOR PER RECALL 99S15  
 RECALL 99S15 RECALL  
 REMOVE AND REPLACE SPEED CONTROL SWITCH  
 RECALL REPAIR AS PER RECALL 99S15 CRUISE CONTROL CABLE REPLACEMENT  
 X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 REPAIRED PER RECALL  
 00 99S15  
 99S15B 0.5 ADMIN 0.1 - REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR REPLACED SPEED CONTROL DEACTIVATION SWITCH A  
 REPAIRED AS PER RECALL SPEED CONTROL  
 RECALL PERFORMED CAMPAIGN 99 S 15 CRUISE DEACTIVATION SWITCH  
 PROGRAM CODE 99S15.  
 COMPLETED RECALL 99S15.  
 RECALL 99S15 COMPLETED RECALL 99S15  
 74946 RECALL 99S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL

REPLACE DEACTIVATION SWITCH  
 RECALL COMPLETED  
 REPLACED SWITCH & CONNECTOR  
 RECALL RECALL  
 117039 REPLACED SWITCH & CONNECTOR PER RECALL  
 X 00S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 00S15B .8  
 00S15 REPLACED SWITCH PER RECALL  
 REPLACE DEACTIVATION SWITCH PER RECALL

PERFORM RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR OPERATION 00S15B TIME .5 PERFORM RECALL 00S15 AS PER INSTRUCTIONS  
 01100 RECALL 00S15 COMPLETED SPEED CONTROL DEACTIVATION SWITCH RECALL  
 PERFORMED RECALL  
 RECALL 00S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 VERIFY R&R CABLE PER RECALL  
 RECALL COMPLETED

REPLACE CRUISE SWITCH PER RECALL 00S15  
 RECALL 00S15 E REPLACED SWITCH AND CONNECTOR AS PER RECALL 00S15  
 TECH 241 PERFORMED 00S15 RECALL  
 102000 PERFORM 00S15 RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
 1 REPLACE CRUISE CONTROL SWITCH  
 REPLACE SWITCH PER RECALL  
 DIAGNOSIS AND INSPECT FOR CAMPAIGN PERFORM CAMPAIGN AS PER NOTICE INSTALLED SWITCH  
 REPL SWITCH PER RECALL 00S15  
 - MODIFY PER RECALL 00S15  
 COMPLETE RECALL AS DIRECTED

00S15 REPL SWITCH  
 REPLACED BRAKE DEACTIVATION SWITCH  
 RECALL 00S15 COMPLETED RECALL 00S15

RECALL REPAIR AS PER RECALL 00S15  
 CFN,00S15B,0.5,ADMIN,0.1,CC RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL  
 4370-PROGRAM CODE 00S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH WITH UPDATED PART - PER INSTRUCTIONS  
 RECALL 00S14 RECALL  
 PERFORMED RECALL 00S15  
 REPLACED SWITCH ASSEMBLY PER RECALL

COMPLETED RECALL  
 RECALL 00S15  
 RECALLED 00S15 PERFORMED  
 INSPECT AND SECURE SWITCH PER RECALL

CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION  
 128271 RECALL 98S15E, MX, 14200A 1.5L PERFORMED RECALL WIRING REPAIR DO TO NEW CONNECTOR PUT ON AND SWITCH REPLACED BEFORE. HAD TO INSTALL  
 PERFORM RECALL 98S15  
 D 98S15 PROGRAM  
 RECALLED BY FORD PERFORMED RECAL  
 PERFORMED RECALL

PERFORMED RECALL 98S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 116257 RECALL REPLACED C C DEACTIVATOR SWITCH AND CONECTOR.X99 RECALL  
 TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH 1  
 INSPECT,REPLACE CONNECTOR PER 98S15  
 1 TECH REPLACED DEACTIVATION SWITCH AS PER RECALL 98S15  
 98S15 RECALL PERFORMED  
 RECALL 98S15 PERFORM RECALL 98S15  
 RECALL 98S15  
 PERFORMED RECALL  
 100222 INSTALLED THE NEW SWITCH AND CONNECTOR PER RECALL  
 1 REPLACED DEACTIVATOR SWITCH AND CONNECTOR  
 RECALL 98S15 RECALL  
 94839 PERFORMED CRUISE SWITCH RECALL  
 98S15 SPEED CONTROL RECALL  
 98S15 98S15  
 INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL  
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 PERFORMED RECALL 98S15 SPEED CONTROL PER FACTORY  
 RECALL 98S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 98S15  
 RECALL 98S15 REPL SWITCH PER RECALL

1 INSTALL KIT  
 98S15 COMPLETED SECURED SWITCH  
 98S15  
 COMPLETED RECALL PER INSTRUCTIONS  
 98720 RECALL 98S15 98S15B 0.5 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15.  
 98S15 REPLACE SWITCH  
 98S15 98S15 RECALL DO

RESISTIVE SHORT. PERFORM RECALL-ONP PER FOMOCO INSTRUCTIONS.  
 RECALL COMPLETED  
 RECALL REPAIR  
 98S15 RECALL  
 PERFORM RECALL  
 1 1 COMPLETED RECALL  
 RECALL COMPLETED  
 RECALL 98S15 COMPLETED RECALL 98S15  
 REPLACED BRAKE DEACTIVATION SWITCH AND CONNECTOR  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR

RECALL 99S15 DONE  
 RECALL 99S15 REMOVED AND REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY AS PER RECALL 99S15  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO  
 FACTORY RECALL COMPLETED RECALL  
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS REPLACED DEACTIVATOR SWITCH  
 4788S INSTALLED KIT  
 COMPLETED RECALL  
 INSTALLED SWITCH PER RECALL  
 REPLACE DEACTIVATION SWITCH  
 DID RECALL 99S15  
 127532 RECALL REPLACED CRUISE DEACTIVATION SWITCH AND BLEED REAR BRAKES AS PER RECALL  
 REPLACED DEACTIVATION SWITCH AS PER RECALL

1 PERFORMED RECALL 99S15  
 1 INSTALL DEACTIVATION SWITCH PER RECALL

COMPLETED RECALL  
 AS PER RECALL, REPLACED CRUISE DEACTIVATION SWITCH  
 RECALL 99S15 PERFORMED 99S15  
 PERFORM RECALL 99S15

99S15 RECALL  
 135842 REPLACED SPEED DEACTIVATION SW- AND CONNECTOR PER RECALL 99S15.  
 REPLCED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
 C 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 PERFORM RECALL  
 RECALL 99S15 COMPLETED REPLACE SENSOR AND HARD SHELL CONNECTOR WIRE WAS MANGLED  
 833D2 99S15 W PERFORMED SERVICE 99S15  
 RECALL PERFORMED RECALL  
 1 PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR

99S15B 0.5  
 RECALL 99S15 COMPLETED  
 RECALL 99S15  
 COMPLETED 99S15 RECALL

RECALL 99S15 PERFORM RECALL 99S15  
 REPLACED SENDER & CONNECTOR PER RECALL 99S15  
 REPLACE CRUISE CONTROL  
 PERFORMED RECALL  
 SERVICE PUBLICATION 99S15 REPLACED SWITCH  
 REPLACE DEACTIVATION SWITCH PER RECALL  
 99S15 99S15  
 PERFORMED RECALL PER FACTORY  
 99S15 99S15 REPLACE SWITCH

88465 REPLACED CRUISE DEACTIVATION SW AND CONNECTOR PER RECALL 88S15.  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 . INSTALL SWITCH AS PER RECALL  
 88S15 RECALL 88S15 RECALL COMPLETE  
 PERFORMED RECALL 88S15-INSPECTED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL SPEED CONTROL DEACTIVATIONREPLACE SWITCH  
 88284 RECALL#88S15 SPEED CONTROL DEACTIVATION SWITCH. INSTALLED DEACTIVATION SWITCH AND CONNECTOR PER RECALL#88S15.  
 CAMPAIGN REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL INSTRUCTIONS.  
 RECALL 88S15 INSTALLED SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 1 1 REPL SWITCH AND CONNECTOR  
 X 88S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 88S15.  
 78249 REPLACE SPEED CONTROL DEACTIVATE SWITCH AND CONNECTOR PER RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 REMOVED AND REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 OPEN RECALL PERFORMED RECALL  
 REPLACED SWITCH AND CONNECTOR  
 REPLACED THE CRUISE DEACTIVATION SWITCH COMPLETED RECALL  
 REPLACE SWITCH AS PER RECALL  
 CHECK AND REPAIR AS REQUIRED  
 PERFORM RECALL  
  
 RECALL 88S15 PREFORMED RECALL 88S15  
 PERFORMED RECALL  
 REPLACED SWITCH AND CONENCTOR  
 RECALL RECALL  
 RECALL 88S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH, RETESTED OK.  
 COMPLETED RECALL 88S15, REMOVED DEACTIVATION SWITCH AND OLD CONNECTOR, REPLACED BOTH PARTS AND ALL TESTED FINE.  
 REPLACED SWITCH AND CONNECTOR PER RECALL 88S15  
 RECALL 88S15 RECALL 88S15  
 RECALL 88S15  
  
 RECALL 88S15 RECALL 88S15  
  
 RECALL 88S15 COMPLETED  
 4228 RECALL 88S15 REPLACED VACUM SWITCH FOR CRUISE CONTROL  
 REPLACE BRAKE PRESSURE SWITCH PER RECALL.  
 REPLACE SPEED CONTROL SWITCH  
  
 RECALL PERFORM RECALL  
 RECALL 88S15  
 RECALL 88S15 NOTICE RECALL 88S15 PERFORMED  
 INSTALLED KIT 88S15 RECALL PERFORMED  
  
 39008 88S15 WPC REPLACE DEACTIVATION SWITCH AND CONNECTOR.

ES02-023 11703



RECALL 99S15  
 1 1 REPL SWITCH  
 53588 RECALL 99S15 PERFORMED RECALL 99S15 CRUISE CONTROL  
 RECOMMENDATIONS AIR & FUEL FILTERS...\$ 70.00...TRANSMISSION SERVICE...\$ 170.00...SERPENTINE BELT...\$ 95.00...COOLANT SERVICE...\$ 85.00+TAX  
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 RECALL PERFORM RECALL 99S15  
 RECALL REPAIR AS PER RECALL 99S15 REPLACE DEACTIVATION SWITCH  
 93311 REPLACED DEACTIVATOR SWITCH.  
 PERFORMED RECALL  
 PERFORMED RECALL 99S15  
 RECALL REPAIR PER FORD  
 PERFORMED RECALL 99S15  
 REPLACED SWITCH AND CONNECTOR

1 PERFORMED RECALL 99S15  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 A SHORT IN THE SPEED CONTROL SWITH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE, REMOVE, TAPE AND  
 REPLACED THE SPEED CONTROL SWITCH PER RECALL  
 71058 RECALL .5 REPLACE SWITCH AND HARSHHELL CONNECTOR PER RECALL.

99S15 SPEED CONTROL RECALL  
 RECALL 99S15 NOTICE RECALL 99S15 PERFORMED  
 RECALL COMPLETED  
 RECALL 99S15 COMPLETED RECALL 99S15  
 INSPECTED INSTALLED KIT TO COMPLETE  
 RECALL COMPLETED.  
 83775 W 99S15 REPLACE SPEED CONTROL DEACTIVATE SWITCH PER RECALL 99S15B .5  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 1 PERFORMED RECALL  
 RECALL 99S15 COMPLETED RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH  
 X PERFORM RECALL- SPEED CONTROL SWITCH  
 PERFORM RECALL 99S15 R&R SWITCH PER RECALL 99S15  
 99894 REPLACED SWITCH & CONNECTOR PER RECALL  
 R&R SPEED CONTROL SWITCH. TEST DROVE TO VERIFY & REPAIR

RECALL PERFORMED RECALL 99S15  
 PERFORMED RECALL 99S15  
 COMPLETED CAMPAIGN COMPLETED OF 99S15B  
 1 COMPLETED RECALL 99S15

RECALL 99S15  
 REPLACE DEACTIVATION SWITCH, RECALL  
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

2002-025 11785

RECALL 99S15 REPLACED SWITCH  
 SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15  
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 1 PERFORMED LATEST REPAIR PROCESS PERTAINING TO 99S15 PER RECALL INSTRUCTIONS  
 REPLACE SWITCH AND HARD SHELL

PERFORMED RECALL  
 99S15 RECALL 99S15 RECALL  
 PERFORM RECALL 99S15 PER INSTRUCTIONS  
 REPLACE CRUISE CONTROL SWITCH  
 RECALL 99S15 COMPLETED RECALL 99S15  
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 REPLACED SWITCH AND CONNECTOR PER RECALL  
 RECALL 99S15 NOTICE RECALL 99S15 PERFORMED  
 59712 99S15 99S15B .5 .5 99S15B REPLACE SPEED CONTROL SWITCH, CONNECTOR  
 PERFORMED RECALL  
 99S15 RECALL .5 REPLACES SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
 99S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH PER RECALL  
 PERFORMED RECALL 99S15  
 PERFORM RECALL PER FACTORY, INSTALL UPDATED CRUISE CONTROL DEACTIVATION SWITCH, RE-CK OK  
 99S15B .5 PERFORM RECALL  
 99S15 0.5 OPERATION 99S15B REPLACED SPEED CONTROL DEACTIVATION SWITCH TEST DROVE AND CHECKED SPEED CONTROL OPERATION OK

RECALL 99S15  
 99S15 SPEED CONTROL RECALL  
 PREFROMD RECALL  
 99S15 RECALL REPLACE CRUISE DEACTIVATION SWITCH  
 REPL SWITCH PER RECALL 99S15  
 114813 RECALL 0.5 RECALL  
 1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED  
 NAC 99S15  
 RECALL 99S15. PERFORMED RECALL 99S15.

REPLACE SWITCH PER RECALL

99S15 REPLACED DEACTIVATION SWITCH AS PER RECALL  
 RECALL PERFORMED RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 INSTALLED SWITCH PER RECALL  
 REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED SI  
 CHECK AND REPAIR AS REQUIRED  
 REPLACE SWITCH AND HARD SHELL  
 99S15 RECALL .5 .10ADMD 99S15-B UPDATED DEACTIVATION SWITCH N CONNECTOR  
 CRUISE CONTROL 99S15 PERFORM RECALL  
 99S15 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

RECALL 99S15 PERFORMED RECALL  
 99S15B 0.6  
 INSTALLED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL  
 FACTORY RECALL COMPLETED RECALL  
 REPLACE BRAKE DEACTIVATION SWITCH AND CONNECTOR  
 PERFORMED RECALL

186877 RECALL WARR. RECALL 99S15 PERFORMED.  
 PERFORMED RECALL  
 RECALL 99S15  
 RECALL COMPLETED.  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 99S15 99S15 SPEED CONTROL

REPLACE DEACTIVATION SWITCH  
 116980 W REPLACE SPEED CONTROL SWITCH AND CONNECTOR 99S15B RECALL  
 99S15 99S15  
 152322 RECALL 99S15 PERFORM RECALL 99S15, REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR 5 WP  
 99S15B 99S15B  
 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNECTOR AS PER THE TECHNICAL INSTRUCTIONS  
 SPEED CONTROL DEACTIVATION SWITCHES MAY DEVELOP RESISTIVE SHORT IN ELECTRICAL CIRCUIT THAT MAY CAUSE UNDERHOOD FIRE. REPLACED SWITCH  
 PERFORM RECALL  
 REPLACE KIT PER RECALL  
 RECALL 99S15  
 COMPLETED RECALL 99S15  
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 99S15  
 116276 PERFORMED RECALL AND DURING DEACTIVATION SWITCH REPLACEMENT BRAKE VALVE BLOCK WAS DAMAGED REPLACED SWITCH AND CONNECTOR AN  
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
 REMOVED AND REPLACED SWITCH PERFORMED RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL JS 1  
 99S15 COMPLETED  
 RECALL COMPLETED.  
 99S15 99S15

REPLACE KIT PER RECALL  
 REPLACE CRUISE SWITC PER RECALL 99S15  
 PERFORM RECALL 99S15  
 F PERFORM SAFETY RECALL  
 PERFORM RECALL INSTALL SWITCH  
 99S15 99S15  
 78044 RECALL 99S15 WARR. INSTALL CRUISE DEACTIVATION SWITCH  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 106606 RECALL 99S15B 0.6 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL  
 EEC TEST PASS NG3 PID MONITOR AND RECORD. CHECK QASIS FOR TSB-SSM LONG FUEL TRIM GO NEGATIVE AT HIGHWAY SPEEDS REPLACE MAP SENSOR RESE

1 REMOVE, TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH -- 99S15E.3  
 RECALL TECH 897 MILES OUT 25090 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 RECALL                      REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 1 08 REPLACED SWITCH  
 INSTALLED DEACTIVATION SWITCH  
 99S15 RECALL                      99S15 COMPLETED RECALL  
 REPLACE SWITCH AND CONNECTOR  
 PERFORMED RECALL 99S15    INSTALLED SWITCH AND CONNECTOR PER RECALL 99S15  
 COMPLETED RECALL 99S15-INSTALLED SPEED CONTROL DEACTIVATION SWITCH.  
 99S15B 0.6  
 REPLACED SWITCH AND CONNECTOR  
 PERFORM RECALL PER MANUFACTURER DID RECALL  
 PERFORM 99S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 99S15                      99S15 REPLACED SWITCH  
 AS PER RECALL                      99S15 RECALL TO INSTALL DEACTIVATION SWITCH  
 RECALL 99S15    REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 PERFORM RECALL 99S15  
 97917 RECALL REPLACE DEACTIVATION SWITCH  
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
 RECALL                      99S15  
 120434 RECALL 99S15 REPLACE SPEED CONTROL SWITCH PER RECALL  
 99S15 RECALL                      99S15 REPAIRED AS PER RECALL  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 99S15                      REPLACE DEACTIVATION SWITCH  
 RECALL COMPLETED  
 REPLACED CRUISE CONTROL CABLE PER RECALL 99S15  
 PER RECALL INSTRUCTIONS: REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS  
 SPEED CNTRL. DEACTVTN SWITCH RPLCMTPERF SAFETY RECALL 99S15  
 PERF RECALL 99S15  
 PERFORM RECALL 99S15  
 INSTALLED DEACTIVATION SWITCH RECALL 99S15  
 RECALL 99S15                      PERFORMED RECALL- REPLACED C-C DEACTIVATION SWITCH  
  
 59090 DID RECALL 99S15B 0.6 HRS  
 99S15 RECALL                      INSTALL DEACTIVATION SWITCH  
 G                      RC 99S15    INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
 99S15 RECALL                      99S15 RECALL COMPLETE  
  
 INSTALL KIT PER RECALL 99S15  
 PERFORMED RECALL  
 INSTALL DEACTIVATION SWITCH  
 AS PER RECALL                      99S15 RECALL TO INSTALL SPEED CONTROL SWITCH  
 RECALL                      COMPLETED 99-S-  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 X                      PERFORMED RECAL  
 PERFORMED RECALL 99S15

99S15B-0.5 ADMIN-0.1 CHANGED SPEED CONTROL DEACTIVATION SWITCH AS OUTLINED IN RECALL 99S15  
 PERFORM RECALL 99S15 TEST DRIVE TO CHECK OK 1  
 INSTALLED DISENGAGE SWITCH PER RECALL 99S15.  
 REPLACED CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL  
 120942 RECALL WP40 PERFORMED RECALL, REPLACE BRAKE PRESSURE SWITCH  
 1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 REPLACE SWITCH AND CONNECTOR PER RECALL  
 PERFORMED RECALL 99S15  
 REPLACED DEACTIVATION SWITCH AND BLEED BRAKES PER RECALL  
 PERFORM RECALL  
 1 INSTALL SWITCH AS PER RECALL  
 RECALL PERFORMED RECALL  
 REPL SPD CNTRL DEACTIVATION SW  
 PERFORMED RECALL  
 PERFORM RECALL 99S15. REPLACE CRUISE DEACTIVATION SWITCH  
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 OPEN RECALL PERFORMED RECALL  
 PERFORM 99S15 RECALL  
 99S15 RECALL ON OASIS 99S15 RECALL REPLACED SWITCH & CONNECTOR  
 1 PERFORM RECALL  
 99S15 RECALL INSTALL SWITCH AS PER RECALL  
 REPLACED SPEED CONTROL SWITCH AND CONECTOR  
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1  
 AS PER RECALL 99S15 RECALL ON SPEED CONTROL SWITCH  
 REPLACE SWITCH RECALL 99S15  
 RECALL 99S15 - B - RECALL  
 CUSTOMER REQUESTS PERFORM RECALL, PERFORMED RECALL  
 RECALL RECALL  
 FACTORY RECALL COMPLETED FACTORY RECALL  
 COMPLETE RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH.  
 PERFORM RECALL  
 99S15 REPLACED SWITCH AND CONNECTOR PER RECALL  
 99S15 RECALL 99S15 RECALL  
 REPLACE SWITCH AS PER RECALL  
 PERFORM RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR  
  
 40579 99S15 B .5 .5 RECALL  
 REPLACED SPEED CONTROL DEACT SWITCH AND HARD SHELL CONN AS PER RECALL 99S15  
 CHECK AND REPAIR AS REQUIRED  
 REPLACED SWITCH AS PER RECALL  
 COMPLETE 99S15  
 TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH  
 99S15E .3 SECURED SWITCH 99S15B .5 REPLACED SWITCH AND CONNECTOR PERFORMED DEACTIVATION OF SWITCH  
  
 1 REPLACED SPEED CONTROL SWITCH & CONNECTOR

COMP.RECALL 99S15

CORRE.INSTALL DEACTIVATION SW.

APRX TIME.0.5

PERFORM RECALL  
RECALL COMPLETED

RECALL REPLACE SWITCH AND CONNECTOR

PERFORM RECALL

COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ... 99S15B .5 + .1

RECALL 99S15

INSTALLED DEACTIVATION SWITCH.

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

. INSTALLED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

REMOVE TAPE AND SECURE LABOR OP 99S15E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OP 99S15B .5 REMOVED TAPED AND SECURED \$1

1 COMPLETED RECALL 99S15, REPLACED SPEED CONTROL DEACTIVATION SWITCH

PERFORMED RECALL

MODIFY SPEED CONTROL DEACTIVATION SWITCH PER CAMPAIGN

116632 RECALL WARR, 99S15 DONE

PERFORMED RECALL

99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED C

REPLACE SWITCH PER RECALL

PERFORM RECALL 99S15

108109 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH NOTE PRIOR TO REPAIRS AIR BAG LIGHT FLASHING NO HORN ANTI LOCK LAMP ON CUSTOMER

PERFORM RECALL AND REPLACE THE SWITCH

1 99S15B .5 ADMIN .1

REPLACE SWITCH AND CONNECTOR

99S15 99S15 RECALL

COMPLETE RECALL 99S15

99S15 99S15 REPLACED SWITCH AND CONNECTOR

PER RECALL INSTRUCTIONS REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS

RECALL PROFORMED RECALL PER LETTER

REPLACE DEACTIVATION SWITCH PER RECALL

99S15 99S15

RECALL COMPLETE

78702 RECALL 99S19 WARR REPLACED SPEED CONTROL DEACTIVATION SWITCH RD TEST AFTER

REPLACED SWITCH AND PLUG IN PER RECALL

OPEN RECALL PERFORMED RECAL

1 PERFORMED RECALL

REPLACE AS PER RECALL 99S15

INSTALL DEACTIVATION SWITCH PER 99S15

PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15B PERFORMED RECALL

0902-923 11771

RECALL===== RECALL=====  
 04756 PERFORMED RECALL 99S15. REPLACEMENT OF SPEED CONTROL DEACT. SWITCH AND HARDSHELL CONN.  
 PERFORMED REC ALL  
 REPLACE SPEED CONTROL SWITCH

INSTALLED DEACTIVATION SWITCH  
 79 REPLACE BRAKE SWITCH AND CONECTOR PER RECALL  
 RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL  
 SPEED CONTROL SWITCH 99S15 RECALL  
 99S15 99S15 PERFORM RECALL  
 PERFORMED RECALL

PERFORMED RECALL

PERFORMED RECALL INSTALLED SWITCH  
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACE SWITCH  
 82782 W REPLACE SWITCH AND CONNECTOR PER RECALL 99S15 GA  
 PERFORMED RECALL 99S15. 99S15B .5HRS LABOR  
 04705 RECALL TECH 9177 PERFORM RECALL 99S15 INSTALL SWITCH AND CONNECTOR  
 RC RC  
 REPAIR PER 99S15 RECALL  
 SWITCH 99S15  
 RECALL 99S15 PERFORM RECALL 99S15  
 OTHER REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER FORD RECALL  
 AS PER RECALL 99S15 RECALL TO REPLACE SPEED CONTROL SWITCH  
 REPLACED DEACTIVATION SWITCH

07183 PERFORM 99S15 RECALL , REPLACED DEACTIVATION SWITCH

PERFORMED RECALL

78069 REPLACED SPEED CONTROL RECALL SWITCH 99S15.  
 1 PERFORM RECALL  
 PREFORM RECALL  
 PERFORMED RECALL  
 PERFORM RECALL 99S15 RECHECK OK 99S15B .5 ADMIN .1  
 121442 TECH 113 99S15B 0.5 REPLACE SWITCH AND CONNECTOR PER FORD  
 REPLACED SWITCH AND HARNESS  
 82345 PERF. RECALL 99S15 W PERF. RECALL 99S15. REPLACE SWITCH. BLEED SYSTEM ROAD TEST PASSED  
 PERFORMED RECALL 99S15-INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 31362 99S15 W REPLACED SPEED CONTROL SWITCH AND CONECTOR  
 1 99S15B .5 ADMIN .1  
 REPLACED DISENGAGE SWITCH PER RECALL 99S15.  
 99S15E REMOVE TAPE AND SECURE THE SPEED CONTROL DEACTIVATION SWITCH .3 PLUS .1 ADMIN COMPLETED SERVICE AS REQUESTED  
 PERFORM RECALL

0002-025 11772

RECALL PERFORMED RECALL  
REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL AND PICK TAIL CONN

RECALL COMPLETED  
REPLACED SPEED CONTROL SWITCH AND CONECTOR

RECALL 99S15 RECALL 99S15  
TECHNICIAN COMPLETED RECALL 99S15 - SPEED CONTROL DEACTIVATION SWITCH  
PERFORM RECALL  
99S15 RECALL PERFORMED

RWECALL RECALL 99S15 SPEED CONTROL COMPLETED  
REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 99S15.  
RECALL 99S15 RECALL  
PERFORMED RECALL

REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH & PLUG IN PERFORMED RECALL 99S15

PERFORMED RECALL 99S15

PERFORM RECALL 99S15  
REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER RECALL  
REPLACE DEACTIVATION SWITCH  
PER NOTIFICATION 99S15 INSTALLED BRAKE REPAIR KIT AS PER RECALL INSTRUCTIONS  
PERFORMED RECALL  
37711 REPLACE SWITCH AS PER RECALL

INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN  
REPLACED PARTS PER RECALL

80061 TECH 1964 REMOVED AND REPLACED DEACTIVATION SWITCH AS PER RECALL  
PERFORMED RECALL DEACTIVATION SWITCH AND CONNECT  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CO NNECTOR  
PERFORM RECALL 99S15

PERFORM RECALL  
PERFORMED RECALL

RECALL INSTALL SPEED CONTROL DEACTIVATION SWITCH 99S15B .5 - ADMIN .1  
INSPECT AND PERFORM RECALL AS STATED AND OUTLINED IN RECALL BULLETIN  
1 PERFORMED RECALL 99S15

94768 RECALL 99S15 WRT PERFORMED RECALL 99S15  
113331 TECH 101=RECALL=99S15B=0.5 REPLACE PRESURE SWITCH & CONECTOR.  
REPLACED RECALLED BRAKE SWITCH

X REPLACE SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL AND REPLACE THE SWITCH  
INSTALLED CRUISE SWITCH AND CONNECTOR PER RECALL  
RECALL DONE

- 99S15 RECALL COMPLETED  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
99S15 99S15



RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
 PERFORM RECALL 99S15B INSTALL SWITCH  
 RECALL 99S15B  
 A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLEING THE CRUISE ALSO A FIRE COULD DEVOPE. REMOVE TAPE AND  
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
 99S15 99S15  
 REPLACE CONNECTOR SHELL AND SWITCH AS PER RECALL 99S15, KS  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETE  
 RECALL COMPLETE  
 INSTALLED SWITCH PER RECALL  
 PERFORMED RECALL 99S15. 99S15B .5HRS LABOR  
 CRUISE RECALL 99S15 INSTALL SWITCH AND CONNECTOR

REPL BRK PRESS SWITCH  
 PERFORM RECALL 99S15B  
 SPEED CONTROL SWITCH 99S15 RECALL  
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME  
 PERFORM RECALL 99S15B REPLACE SWITCH  
 RECALL 99S15B REPLACE SWITCH & HARDSHELL CONNECTOR & BLEED BRAKES  
 RECALL 99S15B DEACTIVATION SWITCH AND CONNECTOR  
 99S15 99S15B REPLACED CRUISE SWITCH  
 123121 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL, BLEED SYSTEM AS PER RECALL  
 REPLACE SPEED CONTROL REPAIR KIT AS PER RECALL  
 RECALL 99S15B DONE  
 1 PERFORMED RECALL AS PER OASIS  
 COMPLETE RECALL  
 X 99S15B REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR  
 102585 REPLACED CRUISE CONNECTOR AND SWITCH AS PER RECALL  
 99S15  
 PERFORMED RECALL  
 INSTALLED SWITCH PER RECALL  
 99S15 RECALL 99S15B COMPLETED RECALL  
 INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 RECALL R-R DEAC SW, INSTALLED NEW CONN, RECD O  
 1 4301 INSPECT AND NECESSARY TO INSTALL CRUISE CONTROL CABLE AS PE RRECALL  
 INSTALL NEW SWITCH  
 COMPLETE RECALL

78203 99S15 99S15 .5 REPLACE SPEED CONTROL SWITCH & CONNECTOR, BLEED BRAKES  
 RECALL 99S15B REPLACED SPEED CONTROL DEACTIVATION SWITCH.  
 1 PERFORM CRUISE RECALL  
 RECALL NEEDED REPLACE CRUISE SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD-SHELL CONNE CTOR AS PER THE TECHNICAL INSTRUCTION  
 PERFORM RECALL 99S15  
 REPL SWITCH PER RECALL 99S15

99S16 99S15  
 99S15 PERFORM RECALL 99S15  
 99S16 99S16  
 RECALL 99S15 PERFORM RECALL 99S16  
 PERFORMED RECALL  
 RECALL PERFORMED RECALL  
 PERFORMED RECALL ACCORDING TO INSTRUCTIONS  
 RECALL 99S15  
 RECALL 99S15 COMPLETED RECALL 99S15  
 RECALL DID RECALL  
 99S16 99S15  
 PERFORM RECALL PER MANUFACTURER PERFORMED RECALL  
 COMPLETE RECALL 99S15  
 70595 RECALL REPL- SPEED CONTROL DEACTIVATION SWITCH & PLUG - 99S15B 0.5  
 RECALL 99S15 SPEED CONTROL SWITCH REPLACE SWITCH AND HARDSHELL CONNECTOR.  
 PERFORMED RECALL  
 RECALL 99S15B NEC TO PERFORM RECALL 99S15B  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 RECALL COMPLETE  
 RPL SPEED CONTROL SWITCH PER 99S15  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
 PERFORMED RECALL  
 RECALL 99S15  
 INSTALL CRUISE CONTROL DEACTIVATION SWITCH AS PER RECALL  
 REPLACED SWITCH AND PLUG.  
 SPEED CTRL DEACTIVATION SW RECALL 99S15 REPAIR PER RECALL  
 99S15 99S15  
 PERFORMED RECALL 99S15  
 RECALL PERFORM RECALL AS REQUIRED  
 INSPECT AND REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 1 99S15B.5 ADMIN .1  
 45057 RECALL W REPLACE DEACTIVATION SWITCH AS PER RECALL 99S15  
 REPLACE SPEED CONTROL SWITCH PER RECALL 99S15  
 PERFORMED RECALL  
 REPLACED DEACTIVATION SWITCH  
 REPLACED SWITCH AND CONNECTOR  
 DID RECALL AS PRE INSTRUCTED  
 RECALL R-R DEAC SW, INSTALLED NEW, CONN. RECD OK  
 PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 PERFORMED RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PER RECALL 99S15 -RECALLED  
 REPL HARD SHELL CONNECTOR PER 99S15  
 RECALL RECALL  
 RECALL COMPLETE

REPLACE SWITCH AND HARD SHELL  
 INSTALL CRUISE SWITCH AND CONNECTOR  
 124381 DUE RECALL 98S15  
 98S15 98S15  
 REPLACE DEACTIVATION SWITCH AS PER 98S15  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 98S15.  
 PERFORMED RECALL  
 RECALL 98S15  
 PERFORM RECALL REPLACE SWITCH  
 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARDSHELL CONNECTOR  
 INSTALL SWITCH  
 PERFORM RECALL  
 REPLACE DEACTIVATION SWITCH AS PER RECALL  
 PERFORM RECALL  
 REPLACE SPEED CONTROL SWITCH PER RECALL  
  
 RECALL R-R DEAC SW, INSTALLED NEW CONN, RECD O  
 108711 PERFORMED RECALL \*\*\*\*\*NOTE: BRAKES PULBATE\*\*\*\*\*  
 PERFORMED RECALL 98S15.  
 INSTALL CRUISE SWITCH AND CONNECTOR  
 PERFORM RECALL 98S15  
 98S15 RECALL 98S15B REPLACE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR FOR RECALL 98S15B  
  
 RECALL SPEED CONTROL SWITCH PERFORM RECALL 98S15, REPLACE SPEED CONTROL SWITCH  
 107503 RECALL 98S15B.5 PERFORM RECALL INSTALL CONN. AND SWITCH DISPATCH ERROR ON TIME RAN  
 X 98S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 REPLACE SWITCH AND CONNECTOR  
 98S15 98S15  
 RECALL COMPLETE  
 REPLACED DEACTIVATION SWITCH  
 113201 PERFORMED RECALL  
 - PERFORMED RECALL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
 SWITCH REPL SPEED CONTROL DEACTIVATION SWITCH  
 OPEN RECALL. PERFORMED 98S15 RECALL.  
 PERFORMED RECALL  
 98S15 98S15 REPLACED CRUISE SWITCH  
 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 PERFORME 98S15  
 INSTALL NEW SWITCH AND CONNECTOR 98S15  
 RECALL INSTALLED SWITCH  
 COMPLETED RECALL 98S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR .... 98S15B .5 + .1  
 1 -COMPLETED SPEED CONTROL RECALL  
 0 98S15 PROGRAM  
 PERFORM RECALL 98S15

REMOVE & REPLACE CRUISE DEACTIVATION SWITCH  
 72867 DID RECALL REPLACED SWITCH  
 RECALL 99S15  
 1 COMPLETED RECALL 99S15  
 — RECALL COMPLETED  
 COMPLETED RECALL 99S15  
 RECALL 99S15B PERFORM RECALL 99S15B  
 INSPECT AND REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 1 REPLACED DEACTIVATOR SWITCH AND PLUG PER RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONECTOR. 5  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 DEACTIVATION SWITCH 99S15  
 IPR AND EBP OUT OF SPEC FOLLOWED PERFORMANCE SHEET 1-14 REPLACED IPR AND TEST DROVE CODE 470 PID DIAG EBP 38 PSI OUT OF RANGE REPLACED E  
 FACTORY RECALL COMPLETED RECALL  
 REPLACED SPEED CONTROL BRAKE KIT  
 99S15 99S15 REPLACED SWITCH  
 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELLCONNECTOR  
 99S15 RECALL COMPLETED  
 PERFORM RECALL INSTALL NEW SWITCH AND BLEED REAR BRAKES  
 99S15 99S15  
 INSTALL SWITCH  
 PERFORM RECALL  
 99S15 SPEED CONTROL CABLE REPLACED SPEED CONTROL CABLE PER RECALL 99S15  
 AS PER RECALL 99S15 RECALL TO INSTALL CRUISE CONTROL SWITCH  
  
 REPLACE CRUISE CONTROL SWITCH WIRE CONN, BLEED BRAKE PER RECALL, RT OK  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 PERFORM 99S15  
 PERFORMED RECALL  
 REMOVE & REPLACE SPEED CONTROL DEACTIVATION SWIT  
 REPLACE SPEED CONTROL SWITCH PER RECALL  
 PERFORMED RECALL  
 REPLACE CRUISE CANCEL SWITCH  
 RECALL R-R DEAC SW, INSTALLED NEW CONNECTED, RECD OK  
 REPLACE DEACTIVATION SWITCH  
 210116 PERFORM RECALL  
 RECALL 99S15 RECALL, REPLACE SWITCH  
 RECALL 99S15 RECALL 99S15  
 DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 REPLACED SWITCH  
 INSTALLED DEACTIVATION SWITCH PER RECALL RT OK  
 RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL  
  
 PERFORMED RECALL

RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN TIME  
PERFORMED RECALL PERFORMED RECALL

PERFORM RECALL

PERFORMED RECALL 99S15B 1 PERFORMED RECALL

RECALL COMPLETED

COMPLETED RECALL PER INSTRUCTIONS. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.

REPLACED DEACTIVATION SWITCH

REPLACE DEACTIVATE SWITCH AND CONNECTOR SHELL PER 99S15B

NOTE-FRONT BRAKES ARE 1-32 CUST.DECLINED-BELT IS DRY ROT DECLINED-BATTERY HAS CORROSION DECLINED CLEANING-  
G RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACE SWITCH AND CONNECTOR

99S03 TECH 113 99S15B 0.5 PERFORM RECALL PER FORD REPLACE SWITCH AND CONNECTOR

SERVICED A SPER RECALL

PERFORMED 99S15 RECALL

1 PERFORM RECALL

99S01 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR PER RECALL, BLEED BRAKES

RECALL RECALL

RPLC CRUISE DEACTIVATION SWITCH PER 99S15

SPEED CONTROL SWITCH 99S15 RECALL

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER CAMPAIGN 99S15

OPEN RECALL PERFORMED RECALL

RECALL 99S15B COMPLETED RECALL 99S15B COMPLETED

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH

INSTALL SWITCH

PERFORM COMPLETE RECALL 99S15 PER INST

COMPLETED RECALL AS PER INSTRUCTIONS

99S15 RECALL 99S15 COMPLETED RECALL

150678 99S15 REPAIR SPEED CONTROL

99S49 RECALL INSTAL BK SWITCH AS PER RECALL 99S15 XXX ROAD TESTED TO MAKE SURE CRUISE CONTROL WORKS PROPERLY

99S15 99S15

PERFORMED RECALL 99S15

REPLACED SWITCH

PERFORM 99S15

REPL CRUISE CONTROL SWITCH AND METERING BLOCK - BLEED BRKS

99S15 99S15

REPLACE CRUISE CONTROL BRAKE CANCEL SWITCH

REPLACE SPEED SWITCH AS PER RECALL

RECALL R-R DEAC SW, INSTALLED NEW, RECKD OK

99S15 REPLACE DEACTIVATION SWITCH

RECALL PERFORMED RECALL 99S15

99S2-028 11778

103012 99S15B 0.5 0.5 PERFORM CAMPAIGN 99S15  
 REPLACE SW AND PLUG  
 99S15 COMPLETED  
 REPL CRUISE SWITCH 99S15  
 PERFORM RECALL  
 RECALL 99S15 99S15 REPLACE SPEED CONTROL SWITCH  
 CAMPAIGN COMPLETED

RPL SPEED CONTROL DEACTIVATION SWITCH PER 99S15  
 REPLACED SWITCH AND CONNECTOR  
 PER NOTIFICATION RECALL 99S15 REMOVE TAPE AND SECURE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 INSTRUCTIONS

NA 99S15 RPELACED DEACTIVATION SWITCH  
 REPLACED DSPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETE  
 117000 RECALL WPE30 PERFORMED RECALL 99S15 REPLACED SPEED SWITCH  
 61509 T 0.4, PERFORMED THE RECALL  
 RECALL REPLACED SWITCH  
 PERFORMED RECALL  
 105300 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 47832 PERFORMED RECALL  
 PERFORM RECALL 99S15 PER TECHNICAL INSTRUCTIONS  
 840484 PERFORM RECALL INSTALLED SWITCH AND CONNECTOR  
 PERFORMED RECALL AS OUTLINED  
 COMPLETED RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR .... 99S15B .5 + .1  
 PERFORM RECALL  
 REPLACED CRUISE DEACTIVATE SWITCH AND HARDSHELL CONNECTOR PER RECALL  
 1 1 REPL CONNECTOR  
 OWNER NOTIFICATION CRUISE CONTROL RECALL 99S15  
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL

REPLACED DEACTIVATION SWITCH & CONNECTOR  
 1 CK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH & PLUG  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 REPAIR AS PER 99S15  
 PER RECALL PERF RECALL  
 REPL BRK PRSS SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 REPLACE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL  
 RECALL 99S15 INSTALLED SPEED CONTROL SWITCH  
 1 PERFORMED RECALL 99S15  
 1 REPL CRUISE DEACT SWITCH  
 99S15 RECALL 99S15 RECALL  
 REPLACED DEACTIVATION SWITCH AND CONNECTOR  
 1 REPLACED SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY AND CONNECTOR. CHECK NORMAL OPERATION

REPLACED DEACTVATER SWITCH AND CONNECTOR  
 PERFORMED RECALL 99S15 SPEED CONTROL DEACTIVATION SWITCH T117  
 1 PERFORM RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER REALL 99S15  
 49008 PERFORMED RECALL, REPLACED SWITCH & CONNECTOR  
 PERFORMED RECALL, INSTALLED NEW SWITCH  
 REPLACED SWITCH AND CONNECTOR  
 99S15 RECALL 99S15 RECALL COMPLETE  
 74747 PERFORM RECALL, REPLA SWITCH 99S15B .5  
 102112 PERFORM 99S15 RECALL PER INSTRUCTIONS  
 RECALL RECALL  
 SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PERFORM RECALL RECALL  
 99063 WPB40 WPB40 REMOVE AND INSTALL SPEED DEACTIVATION SWITCH AND HARNESS, POST TEST, POST ROAD TEST.  
 RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
 90282 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
 97467 RECALL PERFORMED

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

PERFORM RECALL  
 43272 INSPECT FOR DEACTIVATION SWITCH. REMOVE AND REPLACE THE SWITCH AND CONNECTOR AS PER RECALL 99S15  
 PERFORMED RECALL  
 REPLACE SPEED CONTROL DEACTIVATOR. PER RECALL  
 RECALL 99S15 PERFORMED RECALL 99S15  
 RECALL 99S15  
 COMPLETED RECALL 99S14  
 REPLACED SPEED CONTROL CABLE  
 REPLACED DEACTIVATION SWITCH & CONNECTOR  
 REPLACED DEACTIVATION SWITCH  
 RECALL PERFORMED  
 REPLACED SC DEACTIVATION SWITCH 99S15  
 PERFORMED RECALL AS PER INSTRUCTIONS  
 PERFORMED RECALL INTERIM AND PART REPLACEMENT REPAIR RO 43767A WAS CODED INCORRECTLY ON THE LABOR OPERATION ALSO 43767A WAS CHARGE  
 REPLACED DEACTIVATION SWITCH PER RECALL 99S15  
 REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.  
 RECALL COMPLETED  
 REMOVED AND REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 90202 PERFORMED SPEED CONTROL RECALL  
 PERFORM RECALL 99S15  
 PERFORM 99S15 RECALL  
 ===== PERFORM RECALL 99S15- REPLACE CRUISE CONTROL SWITCH  
 RECALL DONE  
 17442 RECALL WP40 PERFORMED RECALL, REPLACED CRUISE CONTROL DEACTIVATION SWITCH.  
 RECALL PERFORMED RECALL  
 31243 99S15 W REFORMED 99S15 SPEED CONTROL SWITCH JH

31067 RECALL 99S15 RECALL 99S15 DEACTIVATION SWITCH  
99S15, SWITCH AND CONNECTOR  
PERFORM RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER REC 99S15

137382 RECALL RAR DEACT. SWITCH & CONNECTOR PER RECALL  
07291 INSPECT AND REPLACE DEACTIVATION SWITCH PER 99S15 RECALL  
99S15 99S15-REPAIR CRUISE CONTROL  
CHECKED OASIS. INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
REPLACED SPEED CONTROL SWITCH  
SPD CTRL DEACTIVATION SW REPLCMT PERFORMED RECALL 99S15  
PERFORM RECALL

99S15 99S15  
99S28 RECALL 99S15B 0.5HRS REPLACE SWITCH AND CONICTOR TK372  
REPLACE CRUISE SWITCH AND CONNECTOR  
RECALL PERFORM RECALL PER FORD  
SPEED CONTROL DEACTIVATION SWITCH PERFORMED RECALL 99S15

1 PERFORMED RECALL 99S15  
REPLACE CRUISE SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH  
DIAG PERFORMED RECALL 99S15  
REPLACE SPEED CONTROL SWITCH  
INSPECT AND REPLACE PRESSURE SWITCH AND CONNECTOR AS PER RECALL

99S15 99S15 REPLACED CONNECTOR AND SWITCH  
1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .8  
RECALL 99S15 COMPLETED  
PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS  
PERFORMED RECALL 99S15, INSTALLED NEW DEACTIVATION SWITCH  
RECALL 99S15B COMPLETED RECALL 99S15B COMPLETED

F RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE  
99S70 99S15 RECALL, R & R SPEED CONTROL BRAKE DIAC. SWITCH AS PER RECALL

146167 PERFORMED RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15, ROAD TEST AND VERIFIED REPAIR  
RECALL DONE

107612 PERFORM RECALL 99S15 REPLACE BRAKE SWICTH JUNT  
RECALL REPAIR AS PER RECALL 99S15 DEACTIVATION SWITCH REPLACEMENT  
68842 RECALL 99S15 REPLACED SPEED CONTROL SWITCH ROAD TEST OK  
MISC VEHICLE DAMAGE; L-F POWER WINDOW CONTROLS LOOSE BEZEL; AIR BAG LIGHT ON; FOG HORN ON  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR  
99S15 99S15

RECALL COMPLETED  
78146 REPLACED SWITCH PER RECALL TECH 508  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
COMPLETE RECALL  
REPL SWITCH PER RECALL  
120489 REPLACE SWITCH PER 99S15 8728



SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15  
 74505 RECALL REPLACED C C DEACTIVATOR SWITCH  
 RECALL REPLACE M SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 90609 RECALL DID RECALL REPLACED SWITCH AND WIRES TECH 10  
 RECALL RECALL  
 SAFETY RECALL 99S15-REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15 RECALL  
 REPLACE DEACTIVATION SWITCH SPEED CONTROL  
 REPLACE DEACTIVATION SWITCH AND HARDSHELL CON NECTOR PER RECALL  
 CAMPAIGN COMPLETED  
 48682 W F INSTALLED DEACTIVATION SWITCH AS PER RECALL  
 48623 REPLACE SWITCH PER RECALL  
 REPLACED DEACTIVATION SWITCH  
 RECALL PERFORM RECALL 99S15  
 PERFORM UPDATE  
 77215 RECALL 99S15 RECALL 99S15 DEACTIVATION SWITCH  
 FACTORY RECALL COMPLETED RECALL  
 RECALL 99S15 PERFORM RECALL 99S15

RECALL  
 138253 PERFORMED RECALL  
 PERFORMED RECALL 99S15  
 PERFORMED RECALL

===== PERFORM RECALL 99S15- REPLACE SPEED CONTROL SWITCH

NA 99S15 REPLACED SWITCH  
 1 REPLACE SPEED CONTROL DEACTIVATION AND CONNECTOR 99S15B .6

REPLACE CRUISE DEACTIVATION SWITCH  
 PERFORMED RECALL  
 PERFORM RECALL  
 83705 REPLACED C-C DE-ACTIVATION BUTTON M1 0.5 CC 42 PARTS FAILURE THIS RO LINE A  
 JS PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 RECALL COMPLETED  
 X REPLACED CRUISE DEACTIVATION SWITCH  
 PERFORMED RECALL  
 REPL CRUISE CONTROL SWITCHES  
 1 PERFORM RECALL AS PER INSTRUCTIONS  
 RECALL 99S15 PERFORMED RECALL 99S15  
 SPEED CONT REPL SWITCH  
 00 99S15B  
 RECALL REPLACE SWITCH  
 PERFORMED RECALL 99S15  
 PERFORME 99S15  
 COMPLETED RECALL 99S15B 1  
 DID RECALL 99S15

120002 PERFORMED RECALL, REPLACED SWITCH

00815 90815

REPLACE SWITCH

RECALL 90815 90815 REPLACE SPEED CABLE

REPLACE DEACTIVATION SWITCH AS PER RECALL

90815 90815 PERFORM RECALL

PERFORMED RECALL 90815

REMOVE TAPE AND SECURE LABOR OF 90815E 0.3 HR REPLACE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 90815B .5 REMOVED TAPED AND SECURED \$1

80302 RECALL INSPECT AND REPLACE SPEED CONTROL SWITCH

COMPLETE RECALL

PERFORMED RECALL 90815-INSTALL SWITCH

DEACTIVATION SWITCH AND CONNECTOR REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

REPLACED SWITCH AND CONNECTOR

INSTALL NEW SWITCH

REPLACE DEACTIVATION SWITCH AS PER 90815

50813 PERFORM RECALL 90815

42058 R&R SWITCH

COMPLETED RECALL

REPLACE BRAKE SWITCH

PERFORMED RECALL 90815

90815 SPEED CONTROL DEACTIVATION REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 90815

90815 90815

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

115146 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 90815

REPLACED BRAKE DEACTIVATION SWITCH

43137 PERFORM RECALL FOR CRUISE DEACTIVATION REPLACED SWITCH AND CONNECTOR

REPLACED SWITCH PER RECALL 90815

PERFORMED RECALL 90815

44881 PERFORM RECALL 90815 REPLACED DEACTIVATION BRAKE SWITCH

INSTALL PER RECALL

PER RECALL REMOVED OLD SWITCH AND INSTALL NEW SWITCH AND CON N PER RECALL

PERFORMED RECALL 90815

1 REPLACED SPEED CONTROL DEACTIVATION SWITCH ASSEMBLY. CHECK NORMAL OPERATIONS.

PERFORMED RECALL

PERFORM RECALL 90815 R&R CRUISE CONTROL DEACTIVATION SWITCH & CONNECTOR

PERFORMED RECALL 90815-INSTALL SWITCH

REPLACE CRUISE DEACTIVATION SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

SPD CTRL DEACTIVATION SW REPLACED PERFORMED RECALL 90815

RECALL SW REPL

99S15 99S15 RECALL  
REPLACE SWITCH PER RECALL

PER RECALL 99S15  
REPLACED SWT PER RECALL  
RECALL 99S15B PERFORM RECALL 99S15B  
RECALL 99S15 99S15  
SAFETY RECALL 99S15 -REPLACE SPEED CONTROL DEACTIVATION SWITCH

47172 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST  
74399 CC 42 99S15B 0.5- ADMIN 0.1 REPLACED SWITCH AND CONNECTOR  
1 PERFORM RECALL 99S15  
REPLACE DEACTIVATIO SWITCH PER RECALL  
99S15 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONN  
00 99S15B  
REPLACED SWITCH AND CONNECTOR  
PERFORMED RECALL AS PER INSTRUCTIONS  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
PERFORM RECALL ON SPEED SWITCH  
1 INSTALLED SWITCH AS PER RECALL  
99S15 RECALL  
1 INSTALL DEACT SWITCH AS PER RECALL  
1 REPLACE THE CRUISE DEACT SWITCH PER RECALL  
SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15  
PERFORM RECALL 99S15  
REPLACED CONNECTOR AND SWITCH AS PER RECALL  
REPLACED SWITCH PER RECALL  
RECALL 99S15  
TECH 141 PERFORM RECALL 99S15  
MODIFY AS PER INSTRUCTIONS  
99S15 RECALL .5 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15B  
1 PERFORMED RECALL 99S15 REPLACED CRUISE CONTROL SWITCH AND CONNECTOR

THE SHORT MAY DISABLE THE SPEED CONTROL SYSTEM OR CAUSE A FUSE TO OPEN. AFTER INSPECTION, IF THE VEHICLE IS INVOLVED THE DEALER WILL REPLAC  
RECALL 99S15 RECALL 99S15  
REPLACED CRUISE CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
99S15 SP SW REPLACE  
RECALL PERFORMED  
RECALL COMPLETED  
PERFORMED RECALL 99S15  
REPLACED SWITCH AND CONNECTOR  
REPLACED SC DEACTIVATION SWITCH 99S15  
99S15, CRUISE SWITCH  
REPLACE CRUISE SWITCH PER RECALL

RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15E  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

RECALL 99S15

RECALL CRUISE CONTROL RECALL 99S15

101899 99S15 RECALL

70849 99S15B 0.5 ADMIN 0.1

PERFORM RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL

REPLACED SPEED CONTROL SWITCH AND CONNECTOR

99S15 99S15 REPLACED CONNECTOR AND SWITCH

PERFORMED RECALL 99S15

PERFORMED 99S15 RECALL

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 99S15.

COMPLETE RECALL 99S15

RECALL COMPLETE

PERFORMED RECALL

REPLACE SWITCH

PERFORM 99S15 RECALL

X

PERFORMED RECAL

REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15

128402 INSTALLED RECALL

74329 RECALL 0.5 99S15B INSTALLED RECALL SWITCH

RECALL

99S15 RECALL COMPLETE

47812 99S15 RECALL 99S15 REPLACE DEACTIVATOR SWITCH

REPLACE SWITCH AND HARD SHELL

PERFORM RECALL

99S15

RECALL

147485 PERFORM 99S15

-

99S15 RECALL COMPLETED

RECALL COMPLETED.

. REPLACED CRUISE DEACTIVATION SWITCH AS PER RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

1 REPLACE DEACTIVATION SWITC

89711 REPLACE THE DEACTIVATION SWITCH

REPAIR AS PER RECALL

RECALL 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTO

RECALL

SW REPL

REPLACED DEACTIVATION SWITCH AND CONNECTOR

65382 PERFORM 99S15 SPEED CONTROL SWITCH ROAD TEST OK

RECALL COMPLETED.

PERFORM 99S15 REPLACE CRUISE DUMP SWITCH BLEED BRAKES

RECALL 99S15 INSTALLED MODIFICATION FOR CRUISE CONTROL

PERFORM RECALL

COMPL: RECALL 99S15, SPEED CONTROL SWITCH, REPLACED DEACTIVATION SWITCH & CONNECTOR. APPROX TIME: 0.5 HRS

RECALL PERFORMED RECALL 99815  
 COMPLETED RECALL 99815  
 REPL SPD CNTRL DEACTIVATION SW  
 REPLACED FAULTY C-CONTROL DEACTIVATION SWITCH, PER 99815B.  
 99815 RECALL ON 04818 99815 RECALL REPLACED SWITCH & CONNECTOR  
 99815 RECALL  
 PERFORM RECALL 99815 REPLACE SPEED CONTROL SWIT  
 PERFORM RECALL 99815  
 RECALL 99815 PERFORMED RECALL 99815  
 REQUEST RECALL 99815 SPEED CONTROL DEACTIVATION SWITCH INSTALLED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 UNKNOWN INSTALL CRUISE SWITCH AND CONNECTOR PER 99815  
 COMPLETED RECALL 99815  
 99815 RECALL  
 REPLACE AS PER RECALL 99815  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99815  
 SHORT MAY DIASABLE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNECTOR FROM CRUISE DEACTIVATION SWITCH & PROTE CT EI  
 75087 PERFORMED REC ALL 99815  
 RECALL 99815 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 182122 RECALL 0.5 99815B INSTALLED RECALL SWITC  
 RECALL 99815 PERFORM RECALL 99815  
 INSTALL SPEED CONTROL CONNECTOR  
 99815 99815 .5 .5 99815  
 83150 RECALL 0.5 INSTALLED RECALL SWITCH  
 PERFORMED RECALL  
 REPLACED DEACTIVATION SWITCH AD HARD SHELL CO NNECTOR AS PER RECALL 99815  
 99815 RECALL PERFORMED  
 83450 REPLACED SPEED CONTROL DEACTIVATION S-W PER R RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETED  
  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99815  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 82 INSTALL RECALL SWITCH  
 RECALL PERFORMED RECALL  
 PERFORMED RECALL AS NEEDED ALL AOK  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99815  
 99815 99815  
 REPLACE SWITCH AND CONNECTOR  
 REPLACE SWITCH AND HARD SHELL  
 REPLACE KIT PER RECALL  
 RECALL PERFORMED  
 INSTALLED SWITCH PER RECALL  
 RECALL 99815 COMPLETED  
 REPLACE DEACTIVATION SWITCH  
 41952 99815 W REPLACE SPEED CONT. SWITCH  
 85142 RECALL 99815 RECALL 99815

188501 PERFORM RECALL 98S15 SPEED CONTROL DEACTIVATION & REPLACE WITH NEW KIT

1 RECALL COMPLETE

98208 REPLACE DEACTIVATION SWITCH PER 98S15 RECALL

PERFORMED RECALL 98S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

1 PERFORMED RECALL 98S15

108118 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15 DONE 7218

CHECK AND REPAIR AS REQUIRED

RECALL

RECALL

ONP

PERFORMED RECALL

INSTALLED DEACTIVATION SWITCH AS PER RECALL 98S1

RECALL SWITCH

REPLACE DEACTIVATION SWITCH & CONN.

98S15 RECALL

98S15 RECALL

INSTALL CRUISE DISABLE SWITCH AND CONNECTOR PER RECALL

148342 RECALL 98S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RPL SPEED CONTROL SWITCH PER 98S15

REPLACE DEACTIVATION SWITCH—WARRANTY—RECALL—BILL

F

RC 98S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

80553 W REPLACED SPEED CONTROL SWITCH PER RECALL 98S15.

98S15

98S15

TEST & REPLACE DEACTIVATION SWITCH

INSTALLED SPEED CONTROL DEACTIVATION SWITCH AND HEAT SHIELD CONNECTOR PER RECALL

PERFORM RECALL

REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15

PUT NEW DEACT SWITCH FOR SPEED CONTROL AND NEW WIRE CONNECT AND BLEED BRAKES

1 COMPLETED RECALL PER FORD INSTRUCTIONS. REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH. THANK YOU, KENN

SPEED CNTRL DEACTVTH SWITCH RPLC&PERF SAFETY RECALL 98S15

1 DEACTIVATION SWITCH RECALL

RECALL 98S15

REPL SWITCH

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

REPLACED SC DEACTIVATION SWITCH 98S15

RECALL 98S15

98S15 RECALL ON OASIS

98S15 RECALL REPLACED SWITCH & CONNECTOR

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AS NOTED IN RECALL 98S15 ALL OK TO RELEASE

1 PERFORMED RECALL 98S15

RPLC CRUISE CTRL DEACTIVATION SWITCH & CONNECTION PER 98S15

AS PER RECALL

98S15 RECALL TO INSTALL DEACTIVATION SWITCH FOR SPEED CONTROL

111647 RECALL#98S15 SPEED CONTROL DEACTIVATION SWITCH. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL#98S15.  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.  
 RECALL 98S15  
 REPLACED BRAKE DEACTIVATION SWITCH  
 83842 0.5 HRS REPLACED DEACTIVATION SWITCH PER RECALL 98S15.  
 104587 RECALL INSTALL NEW SWITCH AND PLUG  
 RECALL RECALL  
 PERFORMED RECALL 98S15  
 RECALL 98S15 RECALL PERFORME  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 REPLACED SWITCH PER 98S15  
 70708 RECALL WPG40 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 30611 REPLACE SPEED CONTROL SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 98S15  
 RECALL COMPLETED  
 COMPLETED - RENEW SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

PERFORMED 98S15 RECALL  
 1 PUT KIT IN 77 STEVE  
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
 1 REPLACE SPEED CONTROL SWITCH 1  
 SPEED CONTROL SWITCH 98S15 RECALL

PERFORMED RECALL  
 REPLACED SC DEACTIVATION SWITCH 98S15  
 PERFORMED RECALL 98S15  
 98S15 RECALL ACT SWITCH  
 PERFORM RECALL  
 101419 98S15 RECALL WF INSTALL SPEED CONTROL SWITCH

RECALL 98S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL  
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
 PERFORMED FACTORY RECALL 98S15  
 RECALL 98S15 RECALL 98S15  
 106714 RECALL 98S15B 0.5HRS REPLACE SWITCH AND CONECTOR TK372  
 RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

1 PERFORM RECALL REPLACE DEACT SWITCH  
 REPL CRUISE CONTROL SWITCH  
 RECALL 98S15  
 RNR DEACTIVATION SWITCH PERFORM RECALL 98S15  
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 1 PERFORMED RECALL 98S15  
 RECALL 98S15

RECALL COMPLETE

RECALL 99S15 REPLACED SWITCH

PERFORMED 99S15 RECALL

1 REPLACE CRUISE DEACTIVATION SWITCH & CONNECTOR PER RECALL

PERFORM RECALL 99S15 99S15

RECALL 99S15 PERFORM RECALL PER PROGRAM 99S15, SPEED DEAC SWITCH

DEACTIVATION SWITCH 99S15

PERFORMED RECALL 99S15 SPEED CONTROL

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL

RECALL 99S15

- MODIFY PER RECALL 99S15

1 REPLACED SWITCH AND CONNECTOR

RECALL COMPLETED 99S15 PERFORMED

RECALL 99S15 REPLACED DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15.

REPLACED SPEED CONTROL DEACTIVATION SWITCH

41782 RECALL 99S15 PERFORMED RECALL 99S15

SPEED CONTROL SWITCH 99S15 RECALL

36745 RECALL WARR PERF. RECALL 99S15

OPEN RECALL PERFORM RECALL

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

RECALL COMPLETE

AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH

PERFORMED RECALL AS PER INSTRUCTIONS

PERFORM RECALL 99S15

RECALL COMPLETE

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

X 99S15 DONE REPLACE SPEED CONTROL SWITCH AND CONNECTOR

71828 RECALL CRUZ CONTROL DEACTIVATION SW AND CONNECTOR WARR REPLACED DEACTIVATION SW AND HARD SHELL CONNECTO ASSY PER RECALL 99S15

91271 99S15 0.5HR RECALL COMPLETE

PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

RECALL INSTALLED DEACTIVATION SWITCH

RECALL 99S15 REPLACED SWITCH

INSTALLED KIT TO COMPLETE

RECALL 99S15 99S15

PERFORM RECALL 99S15

RECALL 99S15B ... REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 99S15

APPLIED RECALL 99S15

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

INSTALL CRUISE SWITCH

99S15 RECALL PERFORMED

REPLACED SWITCH AND HARD SHELL CONNECTOR

PERFORM RECALL 99S15

56628 REPLACE BRAKE SWITCH AS PER RECALL 99S15B 0.5 HR

RECALL 99S15, REPAIRED IN AW RECALL 99S15.

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED



INSTALL CRUISE CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

87129 INSTLL SWITCH AND CONNECTOR

RECALL 99S15 REMOVED AND REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

REPLACE DEACTIVATION SWITCH

PERFORM RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL

50S17 RECALL 99S15B 0.5 REPLACE DEACTIVATION SWITCH & HARDSHELL CONN

99S15 RECALL PERFORMED 99S15

107805 REPLACED DEACTIVATION SWITCH AND CONNNECTOR PER RECALL \*\*\*WIPER DID NOT WORK PRIOR TO REPAIR. WIPER MOTOR IS MISSING\*\*\*

PERFORMED RECALL 99S15

99S15 INSTAL SWITCH AND CONNECTOR PER RECALL

1 COMPLETED RECALL 99S15

PERFORM RECALL 99S15

RECALL COMPLETE

PERFORMED RECALL

118500 99S15B .5HRL PERFORM RECALL

118884 INSTALLED DEACTIVATION SWITCH AND WIRE PLUG

38128 99S15 REPLACED THE BRAKE LINE SWITCH

1 CHECK AND REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

99S15 REPLACE SWITCH AND CONNECTOR PER RECALL

REPLACE SWITCH

PERFORM RECALL 99S15 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL COMPLETE

39103 RECALL 99S15B 0.5L PERFORMED RECALL

88288 RECALL 99S15 WR REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR AS PER RECALL.

1 -COMPLETED RECALL 99S15

TECH 812 PERFORMED RECALL SPEED CONTROL DEACTIVATION SWITCH

PERFORM RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR

REPLACED SPD CONTROL DEACTIVATION SWITCH

PERFORM RECALL

RECALL COMPLETED

99991 RECALL RECALL 99S15 - REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR

1 PERFORM RECALL

PERFORMED RECALL 99S15,REPLACE SPEED DEACTIVATION SWITCH

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

93134 INSTALLED SW. AND HARD SHELL CONNECTION

RECALL 99S15

99S15B 0.5

WORKING ON 74027 FROM 10-12-88 HEATER. PERFORM 98S15 SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR REPLACEMENT RECALL.  
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS INSTALLED DEACTIVATION SWITCH  
 PERFORMED RECALL REPLACED SWITCH AND CHECKS OK  
 98S15B RECALL  
 COMPLETE RECALL 98S15  
 RECALL 98S15B ... REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER 98S15  
 SPEED CONTROL DEACTIVATION MOD. 98S15 RECALL REPLACE SPEED DEACTIVATION SWITCH AND CONNECTOR  
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
 1 PERFORM RECALL

RECALL COMPLETED  
 SWITCH MAY DEVELOP A RESISTIVE SHORT IN THE ELECTRICAL CKT THAT MAY RESULT IN AN UNDERHOOD FIRE. REPLACE SPEED CONTROL DEACTIVATION SWIT  
 PERFORM RECALL INSTALL SWITCH  
 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 INSPECT AND PERF RECALL ACCORDING TO INSTRUCTIONS —THANK YOU-DARREN GREEN TEAM— 1  
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
 OPEN RECALL PERFORMED RECAL  
 PERFORM RECALL  
 REPLACED SC DEACTIVATION SWITCH 98S15  
 82781 R98S15 0.5HR RECALL COMPLETE  
 RECALL 98S15 REPLACE C-C SW  
 38487 98S15 W REPLACE SWITCH 98S15 RECALL GA  
 . INSTALL SWITCH AS PER RECALL  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 1 PERFORM RECALL 98S15  
 83540 RECALL WTY PREFORM RECALL

INSTALL CRUISE CONTROL SWITCH AS PER RECALL  
 PREFORM RECALL PER TECH INSTRUCTIONS  
 500086 WARR PERFORM RECALL 98S15  
 1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY. CHECK NORMAL OPERATION.  
 INSTALL UPATED SWITCH  
 . REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETED  
 REPLACED SPEEDS CRUS CONTROL SWITCH FOR RECALL  
 144156 INSTALL RECALL PARTS  
 PERFORMED RECALL 98S15 INSPECTED-REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTO

98S15 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL 98S15. ALSO NOTE THAT DUE TO MILEAGE RECOMMEND TRANS SERVICE, COOLANT SERVICE, INJE  
 1 REPLACE DEACTIVATION SWITCH AS PER RECALL 98S  
 1 PERFORM RECALL REPLACE DEACTIVATION SWITCH

RECALL 98S15 R AND R SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 73083 RECALL COMPLETE  
 REMOVE AND REPLACE DEACTIVATION SWITCH AS PER RECALL 98S15

PERFORM RECALL  
 99S15-SWITCH RECALL 99S15-SWITCH RECALL  
 99S15 99S15  
 RECALL 99S15 RECALL 99S15

94348 RECALL REPLACED CRUISE SW  
 PERFORMED OPEN RECALL

38562 RECALL WP30 PERFORMED 99S15 RECALL INSPECTION ONLY.  
 REPLACED SWITCH  
 PERFORM RECALL 99S15 SPEED CONTROL  
 REPLACED SWITCH AND CONNECTOR  
 98779 99S15 PERFORMED RECALL  
 RECALL 99S15  
 1 PERFORM RECALL

RECALL RECALL  
 1 PERFORMED RECALL 99S15  
 REPLACED CRUISE DEACTIVATION SWITCH  
 99S15 99S15  
 PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR.  
 74490 PERFORMED RECALL 99S15 REPLACED HARD-SHELL CONNECTOR  
 PERFORMED THER ECALL 99S15  
 PERFORMED RECALL  
 COMPLETED RECALL 99S15  
 RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED SWITCH & CONNECTOR PER RECALL  
 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 RECALL 99S15 REPLACE SWITCH AND CONNECTOR  
 COMPLETE RECALL 99S15  
 1 PERFORMED RECALL  
 RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15  
 OPEN RECALL PERFORMED RECALL  
 88229 REPLACE 8SPEED CONTROL SWITCH + CONNECTOR  
 INSTALLED DEACTIVATION SWITCH PER RECALL  
 1 PERFORM RECALL 99S15  
 8SPEED CONTROL SWITCH  
 REPLACE CRUISE DEACTIVATION SWITCH PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.  
 REPLACE DEACTIVATION SWITCH  
 REPLACE BRAKE PRESSURE SWITCH PER RECALL.

RECALL 99S15 COMPLETED  
 REPLACE SWITCH AND CONNECTOR PER RECALL

REPLACED WIRING HARNESS FROM COMPUTER & INJECTOR

1 PERFORMED RECALL 99S15

024 REPLACED CRUISE DEACTIVATION SWITCH

PERFORM RECALL

PERFORMED RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

R AND R DEACT SWITCH AND CONNECTOR

189446 99S15 RECALL W/ INSTALL SPEED CONTROL DEACTIVATION SWITCH

99S15

SPEED CONTROL DEACTIVATION SWITCH. REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR. PER RECALL 99S15.

REPLACED THE SWITCH PER RECALL 99S15

REPLACED SPEED CONTROL SWITCH.

RECALL 99S15 REPLACE C-C SW

RECALL SW CRUISE SW REPL

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

PERFORMED 99S15 RECALL

02: PERFORMED 99S15 RECALL, REPLACE CRUISE SWITCHES

58876 RECALL 99S15 DONE SPEED CONTROL DEACT SWITCH

COMPLETED RECALL

REPLACED SPEED CONTROL CABLE PER RECALL

FACTORY RECALL. COMPLETED RECALL

PERFORM RECALL

99S14 REPLACED SPEED CONTROL SENSOR AS PER RECALL 99S15

REPLACE CRUISE DEACTG SWITCH

88080 W REPLACE SWITCH GA

PERFORMED RECALL. REPLACE HARD SHELL CONNECTOR

REPLACE CRUISE DEACT SWITCH

OPEN RECALL. PERFORMED 99S15 RECALL

PERFORM RECALL ON SPEED CONTROL SWITCH

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL COMPLETE

78843 SAFETY RECALL 99S15 W COMPLETED SAFETY RECALL

PERF RECALL 99S15

RECALL COMPLETE

PERFORMED RECALL 99S15-INSTALLED DEACTIVATION S WITCH.

D RC 99S15 INSTALL CRUISE CONTROL DEACTIVATION SWITCH KIT & REWIRE

REPLACE SWITCH PER RECALL

FACTORY RECALL. COMPLETED RECALL

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL

INSTALL CRUISE CONTROL SWITCH PER RECALL

SPD CTRL DEACTIVATION SW REPLCMT/PERFORMED RECALL 99S15

PERFORM RECALL 9222

8902-025 11703

RECALL 99S15 COMPLETED  
 88380 R99S15 0.06HR RECALL COMPLETE  
 1 INSTALL SWITCH FOR RECALL  
 RECALL COMPLETED PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN. TIME  
 COMPLETE RECALL 99S15  
 REPLACE DEACTIVATION SWITCH  
 AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH  
 PERFORM 99S15  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 99S15 RECALL PERFORM RECALL 99S15 SPEED CONTROL SWITCH REPLACEMENT  
 PERFORM RECALL 99S15  
  
 1 INSTALLED NEW CRUISE SWITCH PER RECALL 99S15.  
 RECALL COMPLETE  
 PERFORM RECALL  
 1 PERFORM RECALL  
 INSTALL DEACTIVATION SWITCH PER RECALL  
 133224 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH  
 REPLACED DEACTIVATION SWITCH AND HARD SHELL  
 136017 SPEED CONTROL DEACTIVATION SWITCH RECAL 99S15 RENEW SPEED CONTROL DEACTIVATION SWITCH & CONN 23  
 INSTALL SPEED CONTROL DEACTIVATOR SWITCH PER RECALL WAITING  
 COMPLETED RECALL 99S15  
 RECALL 99S15 99S15 RECALL PERFORMED  
 RECALL 99S15 PERFORM RECALL 99S15  
 78090 REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S-15  
 119024 RECALL 99S15B .5, ADMIN .1 REPLACED DEACTIVATION SWITCH PER RECALL  
 AS PER RECALL 99S15 RECALL TO REPLACE DEACTIVATION SWITCH  
 AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL DEACTIVATION SWITCH  
  
 REPLACED CRUISE DEACTIVATION SWITCH AS PER RECAL  
 PERFORM RECALL.....  
 DID RECALL 99S15  
 PERFORMED RECALL 1  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
 RECALL REPLACED DEACTIVATION SWITCH AS PER RECALL  
 RECALL 99S15 - B - RECALL  
  
 RECALL COMPLETED  
 COMPLETED RECALL  
 99S15 99S15  
 SWITCHES ARE SHORTED REPLACE THE SWITCH  
 99S15 RECALL 99S15 RECALL COMPLETE  
 PERFORMED RECALL 99S15B REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

90505 99S15 RECALL WF INSTALL SPEED CONTROL SWITCH  
REPLACED SWITCH PER RECALL 99S15

99S15 RECALL  
RECALL COMPLETE

1 PERFORMED 99S15 RECALL

1 PERFORMED RECALL 1

99S15 RECALL PERFORM RECALL 99S15 SPEED CONTROL SWITCH REPLACEMENT

77022 TIME TO REPLACE SPEED CONTROL SWITCH AND CONNECT OR PER RECALL 99S15

99S15 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR

RECALL 99S15 REMOVED AND REPLACED THE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15, TEST DROVE VEHICLE AND THE

78090 99S15 .5 REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL REPLACE SWITCH & HARD SHELL CONNECTOR & BLEED BRAKES

RECALL 99S15- REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.

RNR DEACTIVATION SWITCH PERFORM RECALL 99S15

RECALL LETTER PERFORM RECALL AS PER FACTORY INSTRUCTION

PERFORM RECALL

INSTALLED SPEED CONTROL DEACTIVATION SWITCH KIT

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

RECALL COMPLETE

RECALL COMPLETED

INSTALL NEW DEACTIVATION SWITCH AND HARNESS PER RECALL

RECALL 99S15 REPLACED DEACTIVATION SWITCH FOR SPEED CONTROL

1 REPLACED CRUISE SWITCH AND CONNECTOR

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

INSTALL SWITCH KIT PER RECALL

0 99S15

RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

CONNECTOR 99S15

SPD CTRL DEACTIVATION SW REPLCMNT PERFORMED RECALL 99S15

1 PERFORMED RECALL

REPLACED CRUISE CONTROL DEACTIVATION SWITCH

PERFORMED RECALL 99S15

- PERFORMED RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH

145325 RECALL WPG40 RECALL COMPLETED, REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR

RECALL 99S15 COMPLETED

TECH INSTALLED CRUISE DEACTIVATION SWITCH PER FORD RECALL

REPLACE CRUISE CONTROL SWITCH

1 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR. CHECK NORMAL OPERATION.

COMPLETE RECALL 99S15

RECALL

REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL

REPLACED DEACTIVATION SWITCH AS PER 99S15

DID RECALL  
PERFORMED RECALL  
REPLACE SWITCH PER RECALL  
REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL LABOR 99S15B 0.5, ADMIN 0.1  
REPL CRUISE CONTROL SWITCH 99S15  
1 INSTALL DEACTIVATION SWITCH  
PERFORMED RECALL 99S15

43940 99S15B .5 & RECALL  
99S15 REPLACED SWITCH  
RECALL COMPLETE  
20: PERFORMED 99S15 RECALL, REPLACE SPEED CONTROL SWITCH  
RECALL 99S15B RECALL 99S15B  
PERFORM RECALL 99S15  
VERIFY FUEL ODOR OK FOR LEAKS RI UPPER PLENUM,EGR VALVE,RI FUEL RAIL,INJ ASSY,RR INJECTOR O RING SEALS,PLENUM AND EGR GSKTS.CHECK FOR LEAK

62765 RECALL 99S15 BASIC 99S52 INSTALLED SWITCH AS PER RECALL 99S15  
125728 RECALL #99S15 0.3 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
99S15  
1 REPLACE HARD SHELL CONNECTOR FOR CRUISE  
70470 RECALL 99S15 DEACTON SWITCH INSTALL SWITCH AND CONNECTOR PER RECALL TECH 4132  
99S15 REPLACE SWITCH AND CONNECTOR PER RECALL  
PERFORM SPEED CONTROL DEACT SW RECALL  
99S15B CHECK-REPLACE SPEED CONTROL DEACTIVATION SWITCH-CONNECTOR RECALL 99S09 COMPLETED

REPLACE SWITCH PER RECALL  
REPAIRED PER RECALL  
PERFORM RECALL  
REPLACE SWITCH  
70788 W REPLACE SWITCH AND CONNECTOR PER RECALL GA  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

PERFORMED RECALL 99S15  
PERFORMED RECALL  
RECALL 99S15  
REPLACE DEACTIVATION SWITCH PER 99S15  
94428 RECALL 99S15 PERFORMED RECALL 99S15  
PERFORM RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO

INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
INTERM REPAIR REMOVED TAPE SECURE THE SPEED CONTROL DEACTIVATION SWITCH LABOR OF 99S15E 0.3 HRS PERMANENT REPAIR REPLACED SP  
71394 RECALL WTY INSTALL SWITCH AND WIRE END PEWR RECALL

88027 PERFORMED RECALL 99S15 INSTALLED SWITCH

R&R DEACTIVATION SWITCH

134112 INSTALL NEW SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

COMPLETE RECALL 99S15

1 INSTALL SWITCH 1 99S15B 0.6

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 99S15

RECALL COMPLETED PERFORM CAMPAIGN PER FORD'S SPECIFICATIONS AND INSTRUCTIONS 99S15B FOR .5 AND .1 FOR ADMIN TIME  
PERF. RECALL

PER THE OASIS PERFORM RECALL #99S15.

RECALL 99S15

REPLACE SWITCH AND CONNECTOR PER RECALL

RECALL NOTICE RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

PERFORM RECALL 99S15

139285 99S15B 0.5 ADMIN 0.1

30188 99S15 .5 REPLACE SWITCH PER RECALL (((ADVISE CUST MASTER CYLINDER IS LEAKING ))) )))) NEEDS BOOSTER AND MASTER))))))

REPLACED DEACTIVATION SWITCH

REPLACED SWITCH AND CONNECTOR PER RECALL 99S15.

RECALL RECALL

RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

99S15 RECALL 99S15 REPAIR AS PER RECALL

99S15 RECALL PERFORMED

1 PERFORMED RECALL 99S15

RECALL 99S15 REPLACED SWITCH AND CONNECTOR AS PER RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH

RECALL 99S15 99S15 INSTALLED SPEED CONTROL SWITCH

PERFORM RECALL REPAIR SWITCH AND HARD SHELL CONNECTOR

99S15 RECALL

CAMPAIGN COMPLETED

1 REPLACE DEACTIVATION SWITCH AS PER RECALL 99S

OPEN RECALL PERFORMED RECALL

PERFORMED CRUISE CONTROL CABLE 99S15

FACTORY RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

REPLACE SWITCH PER RECALL

REPLACE SPEED CTRL DEACTIVATION SWITCH AND HARD SHELL PER RECALL

RECALL 99S15

114208 INSTALLED SWITCH PER RECALL

INSTALLED CONNECTOR AND DEACTIVATION SWITCH

RECALL 99S15 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND PLUG

63739 RECALL 99S15 REPLACE CRUISE CONTROL SWITCH AND PLUG

REPLACED CRUISE CONTROL DEACTIVATION SWITCH AND HARNESS

PERFORMED RECALL 99S15. REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR.



REPLACED DEACTIVATION SWITCH  
39858 INSTALL CRUISE CONTROL DEACTIVATION SWITCH RECALL 99S15  
99S15 REPLACED SWITCH PER RECALL  
REPLACED CRUISE CONTROL SWITCH

REPLACED SPEED CONTROL SWITCH PER RECALL  
REPLACED DEACTIVATION SWITCH PER RECALL  
COMPLETED RECALL  
INSPECT SPEED CONTROL SYSTEM AND COMPLETE LABOR OPERATION ACCORDINGLY COMPLETED SPEED CONTROL DEACTIVATION CAMPAIGN  
REPLACED CRUISE SWITCH AND CONNECTOR  
AS PER RECALL 99S15 RECALL TO INSTALL SPEED CONTROL SWITCH

REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

99S15 REPLACE DEACTIVATION SWITCH 99S15

1 PERFORMED RECALL

PERFORM RECALL

RECALL

99S15 RECALL

RECALL COMPLETED

104921 99S15 WARRANTY INSTALLED SPEED CONTROL DEACTIVATION SWITCH.

164105 99S15B .SHRL PERFORM RECALL

99S15 OPEN

PERFORM RECALL

198881 PERFORMED DEACT SW RECALL

REPLACE CRUISE SWT. AND CONNECTOR

PERFORM RECALL 99S15 REPLACE SPEED CONTROL SWITCH AND CONNECTOR

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

PER NOTIFICATION RECALL 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER 99S15 RECALL INSTRUCTIONS

PER RECALL

PERF RECALL

RECALL 99S15 COMPLETED

RECALL 99S15 REPLACED THE SPEED CONTROL DEACTIVATION SWITCH

CERTAIN 1992 AND 93 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR SPEED CONTROL ACTIVATION

RECALL

RECALL

123988 99S15 WARR REPLACED SWITCH AND CONN

RECALL 99S15 PERFORMED RECALL 99S15

72845 INSTALLED SPEED CONTROL DEACTIVATION SWIT

99S15B 0.5, TOTAL HRS 0.5, PERFORMED RECALL 99S15, REPLACED DEACTIVATION SWITCH AND CONNECTOR ASSEMBLY.

REPLACE SPEED CONTROL SWITCH AND HARD SHELL CONNECTOR

REPLACED SWITCH AND CONNECTOR.

REPLACED SPEED CONTROL SWTY

99S15

PERFORMED RECAL

PERFORM RECALL INSTALL SWITCH

1 RECALL COMPLETE

COMPLETE RECALL 99S15  
PERFORMED RECALL  
RECALL 99S15

PERFORMED RECALL  
RECALL 99S15 REQUIRED, INS AND REPL BRAKE DEACTIVATOR SWITCH PER RECALL 99S15.

PERFORMED RECALL  
RECALL 99S15 SPEED CONT RECALL  
99S15 REPLACE SWITCH AND CONNECTOR  
99S15 REPLACED SPEED CONTROL CABLE AS PER RECALL  
PERFORM RECALL 99S15  
REPL CRUISE DEACTIVATION SWITCH  
78375 RECALL W INSTALL KIT GA  
83075 R R DEACTIVATOR SWITCH PER RECALL  
RECALL 99S15 PERFORM RECALL 99S15  
81733 R&R CRUISE SWITCH RECALL 99S15  
18951 PERFORM RECALL 99S15  
PERFORMED RECALL 99S15  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL 99S15 INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
REPLACE BRAKE SWITCH PER RECALL  
RECALL 99S15 PERFORMED RECALL REPLACED SPEED CONTROL DEACTIVATION SWITC  
42251 INSTALL REVISED S.C. DEACTIVATION SWITCH.  
PERFORMED RECALL

1 REPLACED SWITCH AND CONN  
REPLACED SPEED DEACTIVATION SWITCH PER RECALL 99S15  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL. ALSO SEE RECALL RELATED DAMAGE IN REPAIR 0  
RPLC SPEED CTRL DEACTIVATION SWITCH PER 99S15  
REPLACED DEACTIVATION SWITCH  
PERFORMED RECALL 99S15  
RECALL PERFORMED RECALL 99S15  
RECALL 99S15  
110888 RECALL 99S15 WARRANTY REPLACE SPEED CONTROL SENSOR AND CONECTOR DO TO RECALL 99S15 3720  
X INSTALLED SWITCH  
INSTALL KIT PER RECALL

X 99S15 RECALL PERFORMED  
RECALL 99S15

1 PERFORM CAMPAIGN PER FORDS SPECIFICATIONS AND INSTRUCTIONS 99S15B .5  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15  
88147 REPLACE SPEED CONTROL DEACTIVATION SWITCH WHILE REPLACING SWITCH THREADS STRIPPED IN PROPORTIONING BLOCK ORDER PROPORTIONING B  
REPLACE DEACTIVATION SWITCH

RECALL PERFORM RECALL  
 1 REPLACED SPEED CONTROL SWITCH 1  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
 99S15 RECALL 99S15 RECALL  
 22290 REPLACED SPEED CONTROL DEACTIVATION SWITCH RECALL 99S15  
 REPL BK SW AND CONNECTOR  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
 99S15 99S15  
 99S15 REPLACED SWITCH  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 PERFORMED RECALL 99S15  
 RECALL REPLACE CRUISE CONTROL CABLE DEACT SWITCH REPLACE CONNECTOR  
 PERFORM RECALL 99S15

91928 RECALL REPLACE SWITCH AND WIRE CONNECTOR.  
 REPALCE DEACTIVATION SWITCH  
 100- SPD CONTROL SWITCH RECALL - 99S15 -REPLACED SWITCH PER RECALL  
 99S15 RECALL  
 PERFORMED RECALL 99S15  
 45124 RECALL PERFORM RECALL 99S15 PER BULLETIN

REPLACE SPEED DEACTIVATION SWITCH RECALL COMPLE  
 92510 99S15  
 REPLACE SWITCH PER RECALL  
 1 PERFORM RECALL 99S15  
 RECALL CRUISE CONTROL RECALL 99S15  
 RECALL 99S15 COMPLETED RECALL 99S15  
 PERFORM RECALL  
 153988 RECALL WES PERFORMED RECALL 99S15  
 RECALL 99S15 PERFORM RECALL 99S15  
 COMPLETE RECALL 99S15  
 PERFORMED RECALL  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH PER RECALL  
 INSTALLED KIT TO COMPLETE

PERFORM RECALL 99S15 99S15  
 99S15 RECALL  
 PERFORM RECALL 99S15  
 RECALL 99S15 RECALL; REPLACED DEACTIVATION SWITCH  
 113299 RECALL PERFORM RECALL 99S15-SPD.CONTORL SWITCH REPLACEMENT-INSTALL NEW SWITCH ASS.  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 99S15 RECALL 99S15 COMPLETED  
 99S15 REPLACED CRUISE CONTROL DEACTIVATION SWITCH  
 99S15 99S15 RECALL  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 BOX B  
 45578 RECALL 99S15 REPLACE SWITCH PER RECALL 99S15

PERFORMED RECALL 98S15 SPEED CONTROL DEACTIVATION SWITCH.  
1 RECALL COMPLETE  
1 08 REPLACED SWITCH

PERFORM RECALL 98S15  
VERIFY RECALL REPLACE CRUISE SWITCH AS PER FMC CHECK OK

RECALL 98S15 PERFORM RECALL REPL DEACTIVATION SWITCH AND CONNECTOR  
PERFORMED SPEED CONTROL RECALL 98S15  
R&R BRAKE SWITCH PER RECALL  
1 INSTALL SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & HARD SHELL CONNECTOR  
PER FORD MOTOR CO. 98S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR  
132848 W PERFORM RECALL 98S15 REPLACE DEACTIVATION SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
98S15 98S15  
20244 INSTALLED 98S15 SPEED CONTROL SWITCH

RECALL PERFORM RECALL 98S15, REPLACE SPEED CONTROL SWITCH  
PERFORMED RECALL  
PERFORMED RECALL  
REPLACED SWITCH AND CONNECTOR  
COMPLETED RECALL  
SUPPLEMENT #1 5-00 INSPECTION OPERATION ADDED REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR  
REPLACED SWITCH

98S15 RECALL PERFORM RECALL  
RECALL 98S15 REPLACE C-C SW  
REPLACE DEACTIVATION SWITCH AND CONNECTOR PER RECALL INST

14726 RECALL 98S15 COMPLETED  
REPLACE CONNECTOR AS PER 98S15 RECALL  
REPLACE BRAKE ON-OFF SWITCH AND BLEED BRAKES  
98S15 COMPLETE F

RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH & CONNECTOR  
RECALL 98S15 INSTALL SWITCH PER RECALL

1 COMPLETED RECALL

98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
98S15 RECALL 98S15 RECALL PERFORMED  
REPLACE DEACTIVATION SWITCH PER RECALL  
98S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL  
98S15 REPLACED SWITCH AND CONNECTOR

98S15B REPLACED CRUISE CONTROL DEACTIVATION

PERFORMED RECALL 98S15  
 RECALL REPLACE CRUISE SWITCH  
 RECALL 98S15  
 PERFORM RECALL 98S15

REPAIR AS PER RECALL  
 1 PERFORM RECALL-REPLACE SWITCH AND CONNECTOR  
 REPLACED THE SWITCH PER RECALL 98S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AS PER RECALL 98S15  
 TECH INSTALLED NEW CRUISE DE ACTIVATION SWITCH PER FORD RECALL  
 49068 PERFORMED RECALL AS PER INSTRUCTIONS  
 RECALL 98S15 PERFORM RECALL  
 RECALL 98S15 REPLACE SPEED CTRL DEACTIVATION SWITCH & HARDSHELL CONNECTO  
 REPLACE BRAKE PRESSURE SWITCH AND CONNECTOR  
 UNKNOWN INSTALL CRUISE CONTROL SWITCH AND CONNECTOR PER 98S15  
 105- SPEED CONTROL SWITCH RECALL-98S15 - INSTALL DEACTIVATION SWITCH PER RECALL  
 145760 RECALL 98S15B 0.5 0.5 REPLACE CRUISE DEACTIVATION SWITCH AND HARD SHELL CONNECTOR PER RECALL 98S15  
 REPLACE SWITCH AND CONNECTOR  
 REPLACED SWITCH PER RECALL  
 INSPECT AND OR PERFORM RECALL, INSPECTED AND OR PERFORMED RECALL AS PER RECALL INSTRUCTIONS.  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 RECALL REPLACED DEACTIVATION SWITCH PER RECALL  
 REPLACE SWITCH PER 98S15.  
 98S15 RECALL 98S15 RECALL COMPLETE  
 36638 RECALL REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 98S15 INSTALLED 98S15 SPEED CONTROL SWITCH  
 REPL CRUISE SWITCH 98S15  
 RECALL SPEED CONTROL REPLACE DEACTIVATION SWITCH

0578 98S15 RECALL REPLACE SPEED CONTROL DEACTIVATION SWITCH PER 98S15 RECALL JH  
 1 PERFORM RECALL  
 PERFORM RECALL 98S15  
 1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
 RECALL 98S15B 98S15B REPLACE SWITCH AND HARD SHELL CONNECTOR PLUG

REPLACED DEACTIVATION SWITCH PER SAFETY RECALL 98S15.  
 98S15 REPLACED OLD SWITCH WITH NEW SWITCH  
 1 PERFORMED RECALL 98S15

REPLACED SWITCH PER RECALL  
 COMPLETE 98S15 RECALL  
 36063 RECALL REPLACE CRUISE CONTROL SWITCH AND CONNECTOR  
 REPLACE DEACTIVATION SWITCH  
 PERFORMED 98S15 RECALL REPLACED SWITCH AS PER R ECALL  
 RECALL RENEW SPEED CONTROL DE-ACTIVATION SWITC

COMPLETED RECALL 99S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15  
 RECALL 99S15 PERF. RECALL  
 REPLACED PARTS PER RECALL  
 SPEED CONTROL DEACTIVATION SWITCHPERFORMED RECALL 99S15

REPLACE CRUISE DEACTIVATION CONNECTOR AND SWITCH PER RECALL 99S15  
 COMPLETED RECALL

OPEN RECALL PERFORM RECALL  
 REPLACED SWITCH & CONNECTOR PER RECALL  
 RECALL 99S15 RECALL

99S15 RECALL PERFORMED 99S15 RECALL, INSTALLED PART 99S32, REPLACED SPEED CONTROL DEACT SWITCH AND PERFORMED WIRING CONNECTOR REPAIR.  
 RPL CRUISE SWITCH PER RECALL 99S15

73200 REPLACE SPEED CONTROL SWITCH AND CONNECTOR PER RECALL 99S15.

102874 REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND HARDSHELL CONNECTOR PER RECALL #99S15.

RECALL 99S15

RECALL 99S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

COMPLETED RECALL

PERFORM 99S15 INSTALL KIT FOR CRUISE  
 REPLACE DEACTIVATION SWITCH & CONNECTOR

TECH COMPLETED RECALL AS REQUIRED

PERFORMED RECALL 99S15

RECALL 99S15 INSTALL KIT PER 99S15

37201 REPLACED SWITCH PER RECALL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL

RECALL REPLACE SWITCH

PERFORMED RECALL SPEED CONTROL SWITCH

PERFORMED RECALL 99S15

99S15 99S15 INSTALL K

PERFORM RECALL 99S15 REPLACE CRUISE CONTROL SENS

INSTALLED SWITCH PER RECALL

48585 RECALL 99S15 REPAIR AS PER RECALL

PERFORMED 99S15

1 PERFORMED RECALL

99S15 PERFORM RECALL 99S15

83712 W REPLACE SWITCH AND CONNECTOR GA

PERFORM RECALL 99S15 PER TECHNICAL INSTRUCTIONS  
 INSTALL NEW CRUISE SHUT OFF SWITCH & CONNECTOR 99S15

REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR SERVICE REQUESTED COMPLETED  
 RECALL RECALLED CRUISE DEACTIVATION SWITCH PER RECALL  
 NA 99S15 REPLACED SWITCH

A SHORT IN THE SPEED CONTROL SWITCH COULD DEVELOPE WHICH MAY OPEN A FUSE DISABLING THE CRUISE ALSO A FIRE COULD DEVOPE. REPLACE SPEED C  
 SPD CTRL DEACTIVATOR SW REPLACMETPERFORMED RECALL 99S15  
 RECALLED BY FORD PERFORMED RECALL 99S15  
 99S15 99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 00 99S15B  
 OPEN RECALL 99S15 RECALL

1 COMPLETED REQUESTED RECALL AS PER FORD INSTRUCTIONS  
 83312 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR BODY. RECALL 99S15.  
 REPLACE SWITCH  
 REPLACED DEACTIVATION SWITCH  
 REPLACED BRAKE SWITCH.  
 RECALL 99S15  
 SHORT MAY DISABILE SPEED CONTROL OR CAUSE BRAKE LIGHT FUSE TO OPEN DISCONNECT CONNCTOR FROM CRUISE DEACTIVATION SWITCH & PROTECT ET  
 PERFORM RECALL 99S15

PERFORMED RECALL 99S15  
 X 99S15 - REPLACED CRUISE CONTROL SOLENOID PER RECALL  
 RECALL COMPLETED  
 PERFORMED RECALL  
 RECALL 99S15 REPLACE C-C SW  
 PERFORMED RECALL  
 PERFORMED RECALL 99S15 - CHECK AND REPLACE DEACTIVATION SWITCH AND RECHECK OK  
 1 COMPLETED RECALL  
 1 PERFORM DEACTIVATION SWITCH RECALL  
 REPLACED THE DEACTIVATION SWITCH AS PER RECALL 99S15 SPECS.  
 REPLACED SPEED CONTROL SWITCH AS PER RECALL  
 1 PERFORMED RECALL 99S15  
 COMPLETED RECALL  
 99S15 99S15 PERFORM RECALL  
 RECALL 99S15  
 RECALL 99S15  
 REPLACE CRUISE DEACTIVATION SWITCH AND CONNECTOR PER RECALL 99S15

1 PERFORM RECALL-REPLACE SWITCH AND CONNECTOR  
 99S15 RECALL 99S15 RECALL  
 35787 RECALL W REPLACE SWITCH AND PLUG GA  
 99S15 RECALL PERFORMED 99S15 RECALL, R AND REPLACED DEACT. SWITCH, INSTALL BRAKE REPAIR KIT 99S15, BLEED BRAKE SYS. VERIFY.  
 DDIME = DEALER SELF APPROVAL

REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL.

99S13 99S15 W 99S15

99S15 REPLACE CRUISE CONTROL SWITCH PER RECALL  
 RECALL RECALL

REPLACE SWITCH AND PLUG

REPL SW AND CONNECTOR PER RECALL.

RECALL 99S15 REPLACED HEADLIGHT SWITCH AND CONNECTOR  
 DEACTIVATED SWITCH

PER RECALL 99S15

PERFORMED RECALL

PERFORMED RECALL

INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL

PERFORM RECALL 99S15 T119

RECALL 99S16 PERF. RECALL

RECALL COMPLETE

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 99S15

RECALL 99S15 DONE

1 RECALL COMPLETED, NO FURTHER CUSTOMER ACTION REQUIRED

M1 TIME TO TEST SPEED CONTROL, UNLISTED IN SLTS. REPLACED CRUISE CONTROL SWITCH, INOP.

COMPLETED RECALL REPLACED CRUISE DEACTIVATION SWITCH

1 PERFORMED RECALL 99S15

REPLACED CRUISE CONTROL CUTOFF SWITCH PER THE RECALL

PERFORM RECALL 99S15

PERFORMED 99S15

99S15 RECALL

61578 R R SPEED SWITCH AND CONNECTOR BLEED REAR BRAKES AND TEST DROVE

RECALL 99S15. PERFORMED RECALL 99S15

REPLACED SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15

RECALL REPLACE SPEED CONTROL SWITCH.

RECALL 99S16 99S15B RPL SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CON.

99S15 REPLACED DEACTIVATION SWITCH

99S15 RECALL 99S15 RECALL PERFORMED

COMPLETE RECALL 99S15

99S15 99S15 REPLACED DEACTIVATION SWITCH

131908 REPLACED DEACTIVATION SW. & CONN PER 99S15 99S15B

130730 RECALL 99S15 RECALL

102668 RECALL 99S15 REPLACE DEACTIVATION SWITCH AND CONNECTOR FOR RECALL 99S15

REPLACED CRUISE CONTROL SWITCH PER RECALL 99S15

REPLACE SWITCH

COMPLETE RECALL 99S15

1 REPLACE SWITCH& CONNECTOR

REPLACE CRUISE CONTROL CABLE

99S15 REPLACED SPEED CONTROL DEACTIVATION SWITCH

99S15 99S15B .5 REPLACE SWITCH AND CONECTOR PRT RECALL



105512 REPLACE DEACTIVATION SWITCH AND CONNECTOR  
COMPLETED RECALL  
REPLACE SWITCH AND CONNECTOR PER RECALL  
PERFORMED RECALL AS NEEDED ALL OK  
PER RECALL  
REPLACED SPEED CONTROL SWITCH AND CONNECTOR PER FORD RECALL NOTE  
REPLACE CRUISE DEACTIVATION CONNECTOR AND SWITCH PER RECALL 99S15  
RECALL R-R DEAC SW, AND CONNECTOR, RECD OK.  
99S15 99S15 PERFORM RECALL

PERFORMED RECALL 99S15  
RECALL W TECH 405 M 105397 PERFORM RECALL  
99S15 PERFORM RECALL 99S15  
RECALL 99S15 99S15 COMPLETED RECALL  
211410 RECALL 99S15B, 14200A 0.8L PERFORMED RECALL ALOS HAD TO REPAIR THE WIRING TO CONNECTOR. OLD CONNECTOR MISSING HAD TO SPLICE NEW COI  
151302 99S15 RECALL W PERFORMED 99S15 RECALL. INSTALLED NEW SPEED CONTROL DEACTIVATION SWITCH  
RECALL PERFORM RECALL  
REPLACED CRUISE SWITCH AS PER RECALL 99S15  
RECALL 99S15 99S15 COMPLETED RECALL  
99S15 RECALL 99S15 RECALL RE-WIRE DEACTIVATION SWITCH  
74584 PERFORM RECALL 99S15, REPLACE SPEED CONTROL SWITCH AND BLEED BRAKES.

RECALL 99S15 99S15 RECALL PERFORMED  
REPLACED CRUISE DEACTIVATION SWITCH PER RECALL 99S15  
99S15 99S15  
INSTALLED CRUISE DEACTIVATION SWITCH PER RECALL

163439 3 REPLACE CRUISE SWITCH  
RECALL 99S15 PERFORMED RECALL 99S15B  
COMPLETE RECALL  
118118 DID RECALL 99S15 SPEED CONTROL NOTE ABS LIGHT ON, ROTORS HAS VIBS, DENT LEFT UPPER FENDER.  
135592 REPLACE SWITCH AND CONNECTOR AS PER RECALL  
SPEED CONTROL SWITCH 99S15 RECALL  
AS PER RECALL 99S15 RECALL TO INSTALL DEACTIVATION SWITCH  
REPLACE SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS DIRECTED BY 99S15 SAFETY RECALL  
RECALL 99S15  
PERFORMED RECALL 99S15-INSTALL SWITCH  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD SHELL CONNECTOR AS PER RECALL  
INSTALLED DEACTIVATION SWITCH PER RECALL 99S15  
R-R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR  
REPLACE SPEED CONTROL DEACTIVATION SWITCH  
REPLACED DEACTIVATOR SWITCH  
PERFORMED RECALL  
99S15 RECALL  
78421 RECALL 99S15 REPLACE DEACTIVATOR SWITCH AS PER RECALL  
RECALL 99S15 REPLACE C-C SW  
PERFORMED RECALL 99S15

12282 PERFORM RECALL, REPLACE SWITCH 98S158 .5  
 REPLACE CONNECTOR PER RECALL 98S15.  
 98S15 98S15 RECALL, REPLACE SWITCH  
 REPLACED DEACTIVATION SWITCH  
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 98S15 RECALL 98S15 REPAIR AS PER RECALL  
 INSTALLED SPEED CONTROL DEACTIVATION SWITCH KIT PER RECALL  
 PERFORMED RECALL 98S15  
 PERFORMED RECALL 98S15  
 REPLACED CRUISE CONTROL SWITCH 98S15  
 PERFORM RECALL 98S15 98S15  
 24804 PERFORM DEACTIVATION SWITCH AND CONNECTOR SHELL REPLACEMENT RECALL  
 SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 PERFORMED RECALL AS PER INSTRUCTIONS  
 PERFORMED MODIFICATION  
 98S151 REPLACE DEACTIVATE SWITCH  
 98719 PERFORMED RECALL 98S15 TEST DROVE OK

PERFORM RECALL  
 RECALL 98S15 RECALL 98S15

SPD CTRL DEACTIVATION SW REPLCMNTPERFORMED RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 98S15

RECALL COMPLETED 98S15 RECALL  
 REPLACED SWITCH PER RECALL 98S15  
 REPLACE SPEED CONTROL DEACTIVATION SWITCH  
 RECALL 98S15 RECALL  
 73868 REMOVED AND INSTALLED NEW BRAKE DEACTIVATION SWITCH AND WIRE CONNECTOR SLEEVE PER RECAL 98S15 AND THEN ROAD TESTED, SPEED CONTR  
 RECALL RECALL  
 RECALL 98S15  
 REPLACE CRUISE CONTROL SWITCH ASY  
 CERTAIN 1982 AND 83 CROWN VICTORIA, GRAND MARQ, AND LINCOLN TOWN CARS WITH SPEED CONTROL AS PER RECALL-REPAIR 8 SPEED CONTROL ACTIVATION  
 INSTALL KIT PER RECALL  
 SERVICE INSTALLED SPEED CONTROL SWITCH PER RECA  
 69475 98S158 0.5 HRS. SPEED CONTROL SWITCH RECA  
 98S15  
 RECALL 98S15 RECALL 98S15  
 RECALL 98S15 COMPLETE RECALL 98S15

98S24 RECALL 98S15 INSTALL NEW SWITCH AND SHELL CONNECTOR  
 INSTALL SPEED CONTROL SWITCH PER RECALL 98S15  
 1 PERFORMED RECALL 98S15 SPEED CONTROL CABLE REPLACE SWITCH AND CONNECTOR  
 REPLACED DEACTIVATION SW PER RECALL  
 PERFORM RECALL

OPEN RECALL PERFORM 99S15 RECALL  
RNR DEACTIVATION SWITCH PERFORM RECALL 99S15  
COMPL: RECALL 99S15, CAUSE: SPEED CONTROL DEACTIVATION SWITCH. CORRE: PERFORM RECALL  
PERFORMED RECALL  
INSPECT AND REPLACE CRUISE CONTROL DEACTIVATION SWITCH AND CONNECTOR PER RECALL  
RECALL 99 S 15

99S15 RECALL PERFORMED 99S15  
99S15E RECALL 99S15E PERFORME  
RECALL 99S15 99S15 RECALL PERFORM MODIFICATIONS  
PERFORM RECALL  
121140 INSTALL 99S15 SPEED CONTROL DEACTIVATION

INSPECT AND REPLACE SWITCH AND CONNECTOR PER RECALL  
PERFORMED RECALL 99S15 AS REQUESTED.  
14787 RECALL 99S15 RECALL 99S15  
RECALL 99S15 COMPLETED  
REPLACED SWITCH FOR CRUISE CONTROL AND HARDSHELL CONNECTOR AS INSTRUCTED BY PROGRAM 99S15  
99S15 99S15  
21478 REPLACED SWITCH PER RECALL TECH 508  
97306 99S15 B 0.5 REPL CRUISE DEAC SW  
RECALL 99S15 REPLACE SPEED CONTROL DEACTIVATION SW & HARD SHELL CONNECTO  
REPLACED SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR.  
RECALL SPEED CONT SWITCH PERFORM RECALL 99S15  
REPLACED THE CRUISE DEACTIVATION SWITCH  
INSTALL DEACTIVATION SWITCH 99S15 RECALL PER FORD INSTRUCTIONS  
1 COMPLETED RECALL  
1 COMPLETED  
PERFORM RECALL  
33447 RECALL W INSTALL SWITCH AND CONNECTOR 99S15 GA  
99S15 99S15 RECALL PERFORMED  
40849 RECALL DID RECALL REPLACED SWITCH AND WIRES TECH 10  
9 PERFORM RECALL 99S15  
99902 RECALL 99S15 PERFORMED RECALL 99S15 REPLACED CRUISE DEACTIVATION SWITCH

INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RE  
PERFORMED RECALL  
PERFORMED RECALL  
REPLACED SWITCH PER BULLETIN

RECALL 99S15  
- MODIFY PER RECALL 99S15  
PERFORM RECALL

COMPLETED RECALL 99S15

2562-925 11000

RECALL CRUISE CONTROL RECALL 99S15  
 REPL SPD CNTRL DEACTIVATION SW  
 ASD 99S2 R2 737 99S15B .8 ADMIN .1 REPLACED SPEED CONTROL DEACTIVATION SWITCH AND HARD-SHELL CONNECTOR  
 1 1 PERFORM DEACTIVATION SWITCH RECALL  
 RECALL LETTER PERFORMED RECALL AS PER FACTORY INSTRUCTIONS  
 99S15 RECALL PERFORMED 99S15  
 WE PERFORMED RECALL 4237  
 99S15 99S15 REMOVE TAPE SECURE THE SPEED CONTROL SWITCH.  
 REPAIR AS PER RECALL  
 DID RECALL ON SWITCH BLEED BRAKES CHECKED OK...  
 COMPLETED RECALL  
 99S15 99S15  
 RPLC CRUISE DEACTIVATION SWITCH & PLUG PER 99S15, BLEED BRAKES  
 CONTROL DEACTIVATION SWITCH RECALL  
 PERFORMED RECALL AS PER 99S15  
 PERFORM RECALL  
 PERFORMED RECALL 99S15-INSTALL SWITCH  
 COMPLETE PERFORMED RECALL, R&R DEACTIVATION SWITCH  
 PERFORMED RECALL  
  
 99S15 REPLACED SWITCH AND CONNECTOR  
 COMPLETE RECALL 99S15  
 99S15 99S15  
 REPLACE CONN AND SWITCH PER RECALL INSTRUCTIONS  
 1 PERFORMED RECALL 99S15 REPLACE SPED CONTROL DEACTIVATION SW  
 72878 REPLACE SWITCH AS PER 99S15 RECALL  
 REPLACE SPEED CONTROL SWITCH AND CONNECTOR  
 RECALL 99S15  
 1 TECH REPLACED CRUISE DEACTIVATION SWITCH AND CONNECTOR AS PER RECALL 99S15  
 136435 RECALL DONE RECALL TECH 538  
 99S15 99S15  
 52028 79 PERFORM 99S15 R R SPEED CONTROL DEACTIVATION SWITCH AND CONNECTOR ROAD TEST JH  
  
 REPLACED CRUISE DEACTIVATION SWITCH  
 REPLACE CRUISE DEACTIVATION SWITCH  
 REPLACED SPEED CONTROL DEACTIVATION SWITCH  
 99S15 99S15  
 43883 RECALL W 0.5 HR8 0.1 ADMS INSTALL SPEED CONTROL DEACTIVATION SWITCH PER RECALL 99S15 OPER 99S15-B  
 99S15 99S15  
 INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 REPLACED DEACTIVATION SWITCH AS PER RECALL INSTRUCTIONS  
 REPAIR AS PER RECALL  
 RECALL REPLACE SWITCH AND HARDSHELL CONNECTOR  
 RECALL 99S15 RECALL 99S15 REPLACE SWITCH  
 78445 RECALL WARRANTY INSTALL SPEED CONTROL DEACTIVATION SWITCH  
 RECALL COMPLETED

EMD-625 11604